

Passwd 1 HPA
2 PBE

Alfaskop System 41

Terminal Console Functions and Customizing Instructions IBM 3270 Emulation

FE424-811C
1982.04.15

DATASAB

Preface

This manual presents a general description of the Alfaskop System 41 terminal console functions available to the user and explains how these functions are used. The customizing procedure is also described.

Specifications in this publication are subject to change or supplementation without notice.

Your Datasaab representative will be pleased to provide you with further information about the Alfaskop System 41.

Contents

| | |
|-------------------------------------|----|
| General | 1 |
| Terminal Console Functions | 2 |
| Customizing | 3 |
| Console Mode Logon and Logoff | 4 |
| First Menu | 5 |
| System Functions | 6 |
| Passwords | 6 |
| Generation of Passwords | 7 |
| System Addresses | 8 |
| CU/DV Addresses | 9 |
| Logical Addresses | 10 |
| Autologon | 11 |
| Printer Authorization | 11 |
| Assign Keyboard | 13 |
| Read/Change | 14 |
| Copy Volume | 14 |
| Read/Change Volume | 16 |
| Display Unit Definitions | 17 |
| Printer Definitions | 18 |
| Communication Processor Definitions | 18 |
| Display Volume | 18 |
| System Diskette Backup | 20 |

Appendices

1. Customizing Data for System Diskette 4016-001, M202-XX
 System Diskette 4016-002, M202-XX _____ E90001031E
2. Customizing Data for System Diskette 4016-031, M201-XX
 System Diskette 4016-071, M201-XX _____ E90002020E
3. Customizing Data for System Diskette 4016-021, M201-XX
 System Diskette 4016-022, M201-XX _____ E90001033E
4. Customizing Data for
 System Diskette 4016-104, M202-XX _____ E90002403E



General

The software used in Alfaskop System 41 consists of a number of main modules, the operating system, the emulation software and the terminal-console-functions software. The operating system is always resident in the display unit when the terminal system is in operation. The mode in which the system is operating determines which other software is called in (see below).

The display unit can operate in any of the following modes

- *Ready mode*. Only the operating system is loaded into the display unit.
- *Emulation mode*. The operating system and the emulation software are loaded into the display unit.
- *Console mode*. The operating system and the terminal-console-functions software are loaded into the display unit.

The software used in Alfaskop System 41 is stored on a diskette called the system diskette. System diskettes are produced at Datasaab. The system diskette includes all software intended for the user. However, Datasaab cannot, alone, supply all information needed to have the system function as desired by the user. Supplementary information must thus be entered into the terminal system in cooperation with the user. This is called customizing the diskette, and it includes the following

- Assignment of addresses to the display units, printer units, flexible disk units and communication processors.
- Definition of software that is to be loaded when power is turned on
- Definition of emulation-dependent parameters
- Generation of passwords.

Customizing is carried out using a display unit in the console mode. A display unit in the console mode is also used to control a number of other terminal system functions.

Terminal Console Functions

When the Alfaskop System 41 is in the console mode, the terminal system can be controlled using selected displays which, in turn, make it easy to select different functional branches. This type of control embraces customizing, password generation, autologon definition, dumping and disquette copy operations.

Fig. 1 presents the terminal console functions intended for the users, except for the terminal console functions used in connection with Alfaform. These functions are either presented on the screen as menus from which subfunctions can be selected or presented as forms into which the operator has to enter the requested data.

Descriptions of all terminal console functions intended for an Alfaskop System 41 user are presented below, except for those used in connection with Alfaform. Some terminal console functions and associated menus may be excluded or changed in certain configurations such as single-display-unit configurations.




Fig. 1. Diagram of terminal console functions.

To be able to use the terminal console functions, the operator must use a password. This password consists of three characters which can be determined by the user. The system diskette is delivered with a standard password to be used the first time the terminal console mode is selected.

Customizing

Before the customizing procedure can take place the user must define a number of parameters. Information presented in the Appendices entitled Customizing Data can be used as an aid in defining these parameters.

It is recommended that the user appoint a person, who can take responsibility for the Customizing Data forms and other documents needed for maintenance of Alfaskop System 41.

Normally the diskette is customized at the installation site. However, customizing can also be performed anywhere that complete customizing data, the necessary hardware and the system diskette are available.

Follow the instructions below in sequence when customizing system diskettes.

During customizing, data is entered on the system diskette but not loaded into the units. To reload, turn the power off and on or depress the reset button.

Console Mode Logon and Logoff

When power to a display unit is turned on, the following text is presented on the message line

LOAD

After part of the operating system has been loaded, *OS* will replace the word LOAD. When the entire operating system has been loaded, the following LOGON menu will appear.

If autologon of the emulation is defined, the emulation software must be logged off as follows:

- Depress the ROLL ML key.
- Depress the CU TO ML key.
- Write LOGOFF on the *OS* message line.
- Depress the ENTER key.

***** L O G O N *****

| | | |
|---------------|----|---|
| LOGON NAME: | >■ | < |
| LOAD MAP NO.: | > | < |
| PASSWORD 1: | > | < |
| PASSWORD 2: | > | < |
| CONTROL INFO: | > | < |
| | > | < |

OS

The operator has to enter CONSOLE as the logon name and the security code 3 delivered together with the system diskette (can be changed by the user) as password 1 and then depress the ENTER key. When the logon operation is completed, the logon menu will disappear and be replaced by the first console mode menu. Neither load map nor password 2 is used by the user.

The console mode can be logged off by depressing the PF12 key when the first console mode menu is displayed.

First Menu

```

*****
* *****
* * ALFASKOP SYSTEM 41 * *
* * CONSOLE MODE * *
* * *****
* *****

SYSTEM FUNCTION PF1

LOGOFF PF12 ASSIGN LOG. PRINTER >08< DU 00 M203-00

```

Not all console mode functions are available for Alfaskop System 41 users (some are reserved for service personnel etc.). Some menus therefore seem to be unnecessary since they provide only a single alternative. Console mode functions not intended for users are not displayed on the screen.

If printouts of console mode menus are wanted, the logical address of the printer shall be entered into the field following the text ASSIGN LOG PRINTER. The PF1 key shall then be depressed to assign the printer and obtain the next menu. The straight line at the bottom of the screen and the message line are not printed. Most of the illustrations in this manual are made from printouts.

System Functions

| | |
|-----------------------------------|-----|
| ***** C O N S O L E M O D E ***** | |
| S Y S T E M F U N C T I O N | |
| GENERATE PASSWORD | PF1 |
| AUTOLOGON DEFINITION | PF2 |
| SYSTEM ADDRESSES | PF3 |
| PRINTER AUTH. MATRIX | PF4 |
| ASSIGN KEYBOARD | PF5 |
| READ / CHANGE | PF6 |
| DISPLAY VOLUME | PF7 |
| RETURN | |
| PF12 | |

Select desired function by depressing the PF key that appears after the function name.

Passwords

Passwords are used in the logon menu to make certain that the terminal user is authorized to do the logon.

Two different passwords can be used. Password 1 is intended for Alfaskop System 41 users. Password 2 is intended exclusively for Datasaab personnel.

Password 1 is associated with three different security codes: 1, 2 and 3. The terminal-console-functions software is assigned security code 3. The password 1 defined for security code 3 must thus be entered into the logon menu when the display unit is to be put into the console mode. The emulation software is not assigned any security code and no password is needed to put the display unit into the emulation mode.

Password 2 cannot be used alone. It must be used together with password 1. This permits the Alfaskop System 41 user to control usage of terminal console functions by Datasaab personnel while the Alfaskop System 41 is being serviced.

Generation of Passwords

```
*****  C O N S O L E  M O D E  *****  
G E N E R A T E  P A S S W O R D  
  
SECURITY  
CODE      PASSWORD  
  1        > <  
  2        > <  
  3        > <  
  
EXECUTE RETURN  
ENTER   PF12
```

If a new password 1 is to be generated, enter the new password in the input field opposite security code 3. Depress the ENTER key. The new password is now generated and entered into the system, and must be used for the next logon. PF12 must be depressed to obtain the system function menu again.

System Addresses

The peripheral units in Alfaskop System 41 (display units, printer units and flexible disk units) are all assigned logical addresses. These logical addresses are used only within Alfaskop System 41.

However, only logical address 00 is used for single-display-unit configurations.

All display units and printer units are assigned device (DV) addresses. Communication processors and display units used in configurations having only a single display unit are assigned CU polling addresses. The DV and CU addresses are used by the IBM computer system to address the terminals.

```
*****  C O N S O L E  M O D E  *****  
          S Y S T E M  A D D R E S S E S  
  
          3270 CU-/DV.- ADDR          PF1  
          S41 LOGICAL ADDRESSES      PF3  
  
RETURN  
PF12
```

CU/DV Addresses

The CU/DV addresses must be selected from the set of addresses specified by IBM. Addresses that can be used are found in Reference Manual – IBM 3270 Emulation FE 411-810.

```

*****  C O N S O L E  M O D E  *****
          3 2 7 0  C U / D V  A D D R E S S E S
          C U - A D D R   >40<
          I N S E R T  D V - A D D R E S S E S  I N T O  T H E  L O G . A D D R .  T A B L E
LOG.ADDR.  0      1      2      3      4      5      6      7      8      9      10
DU >40< >C1< >C2< >C3< >C4< >C5< >C6< >C7< > < > < > <
PU > < > < > < > < > < > < > < > < > < > < > < > < > < > <
LOG.ADDR. 11     12     13     14     15     16     17     18     19     20     21
DU > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > <
PU > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > <
LOG.ADDR. 22     23     24     25     26     27     28     29     30     31
DU > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > <
PU > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > < > <

EXECUTE      RETURN
ENTER        PF12

```

The following data shall be filled into the above form

CU ADDR >xx< Enter the communication processor (CU) polling address at xx.

DU >xx< Enter the DV address beneath the logical address.
PU >xx<

When all addresses that are to be used have been filled in, depress the ENTER key to enter them onto the system diskette.

Logical Addresses

Logical addresses permit the user to assign each display unit (DU), printer unit (PU), and flexible disk unit (FD) an identifying number that can be used internally within the Alfaskop System 41. The logical addresses are also used in the software to establish the internal polling list used in the communication processor.

It is advisable to assign each display unit and printer unit the same logical address number as the corresponding IBM control unit port number. This allows IBM generated printer authorization matrices to be used without any changes.

```

*****  C O N S O L E   M O D E   *****
          L O G I C A L   A D D R E S S E S
          I N S E R T   P O R T   N O .   I N T O   T H E   L O G . A D D R .   T A B L E

LOG.ADDR. 0      1      2      3      4      5      6      7      8      9      10
DU >00< >01< >02< >03< >04< >05< >06< >07< > < > < > <
PU > < > < > < > < > < > < > < > < > < > < > < > <
FD >00< > < > < > < > < > < > < > < > >07< > < > < > <

LOG.ADDR. 11     12     13     14     15     16     17     18     19     20     21
DU > < > < > < > < > < > < > < > < > < > < > < > < > <
PU > < > < > < > < > < > < > < > < > < > < > < > < > < > <
FD > < > < > < > < > < > >15< > < > < > < > < > < > < > < > <

LOG.ADDR. 22     23     24     25     26     27     28     29     30     31
DU > < > < > < > < > < > < > < > < > < > < > < > < > <
PU > < > < > < > < > < > < > < > < > < > < > < > < > < > <
FD > < > >23< > < > < > < > < > < > < > < > < > < > < > >31<

EXECUTE      RETURN
ENTER        PF12

```

The Alfaskop port No. should be inserted under the assigned logical address. (No Logical Addresses form is used in single-display-unit configurations).

When the ENTER key is depressed the selected addresses are entered onto the system diskette.

Note that a special care must be given to the definition of FD address. There must be an FD assigned on an existing port. The FDs must also be assigned with the same port No. as logical No. If an incorrect FD address definition is made, it can happen that only part of the software can be loaded into the other Alfaskop units. No communication processor polling will be performed for port numbers (two-wire connection numbers) that are not entered into the Logical Addresses form.

In the example above, the printer having logical address 08 must be connected to the display unit (having logical address 00) which is connected to port 00.

Autologon

Autologon is used when a terminal user wants to have the emulation software loaded automatically into the display unit when power is turned on.

Autologon can only be used for software modules that have not been assigned security codes.

```

*****  C O N S O L E  M O D E  *****
          A U T O L O G O N  D E F I N I T I O N

DU LOGON NAME  LOADMAP      DU LOGON NAME  LOADMAP
0 >EM3274 < >001<      1 >EM3274 < >001<
2 >EM3274 < >001<      3 >EM3274 < >001<
4 >EM3274 < >001<      5 >EM3274 < >001<
6 >EM3274 < >001<      7 >EM3274 < >001<
8 >          < > <      9 >          < > <
10 >         < > <     11 >         < > <
12 >         < > <     13 >         < > <
14 >         < > <     15 >         < > <
16 >         < > <     17 >         < > <
18 >         < > <     19 >         < > <
20 >         < > <     21 >         < > <
22 >         < > <     23 >         < > <
24 >         < > <     25 >         < > <
26 >         < > <     27 >         < > <
28 >         < > <     29 >         < > <
30 >         < > <     31 >         < > <

READY
EXECUTE RETURN
ENTER   PF12

```

Each item of system software is given a logon name and sometimes a load map number. To specify autologon, the logon name and load map number shall be entered into the input field that corresponds to the logical address of the display unit. Only those logical addresses that are assigned using the logical addresses form will be shown in the autologon definition form. When the ENTER key is depressed, the autologon definition is entered into the system.

Logon names and load map numbers for displays that are to be provided with the autologon function appears in the customizing data in the Appendices.

Printer Authorization

The Printer Authorization Matrix (PAM) defines the printer mode and the printer class for the printers in a cluster. It also specifies which display units have access to the printers.

Further information about PAM is presented in the Reference Manual for the IBM 3270 Emulation (FE 411-810).

In Alfaskop System 41, each display unit can access several printers for local printout. Each such printer must be specified using the form shown below. Any previously entered definitions appear in the form.

Assign Keyboard

Three main keyboard versions are used for the IBM 3270 Emulation: the Typewriter Keyboard, the Typewriter Alternate and the Data Entry Keyboard.

Each keyboard version is associated with a keyboard table (KBTAB) within the software. Information about which keyboard version is to be used must be entered into the software. This is accomplished using the Assign Keyboard form.

```

***** C O N S O L E   M O D E *****
          A S S I G N   K E Y B O A R D

PORT NO.  0  1  2  3  4  5  6  7  8  9  10 11 12 13 14 15
KBTAB NO. >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0<

PORT NO.  16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31
KBTAB NO. >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0< >0<

          *

EXECUTE RETURN
ENTER   PF12

```

PORT NO. x x represents the Alfaskop port number, i.e. the number of the two-wire connection to which the display unit is connected.

KBTAB NO. >x< x represents the number of the keyboard version that is to be used.

The keyboard version number is determined when the system diskette is adapted to the desired national version by Datasaab.

The following keyboard version numbers are normally used

| <i>Version</i> | <i>KBTAB No.</i> |
|----------------------|------------------|
| Typewriter Alternate | 0 |
| Data Entry | 1 |
| Typewriter | 2 |
| Monocase Alternate | 3 |
| Monocase | 4 |

If the above keyboard version numbers are not used, information so stating is included with the system diskette.

When all definitions have been made, depress the ENTER key.

Read/Change

```
*****  C O N S O L E  M O D E  *****  
          R E A D  /  C H A N G E  
  
          C O P Y  V O L U M E                P F 1  
          R E A D  C H A N G E  V O L U M E   P F 2  
  
RETURN  
P F 1 2
```

Copy Volume

The flexible disk unit must be equipped with two drives if diskettes are to be copied.

Two diskettes cannot have the same volume number within a system. If the diskette on which the copy is to be recorded has the same volume number as the master diskette, the former volume number must be changed. The Display/Change Volume Label function is used for this operation. See section on Display Volume.

Note, however, that the diskette copy is automatically given the same volume number as the master diskette during the copy operation. If a different volume number is wanted on the diskette copy, the new volume number must be specified after the copy operation.

Volume numbering is explained in the section on Display Volume.

```

*****  C O N S O L E  M O D E  *****
          C O P Y  V O L U M E

ALL NUMBERS MUST BE HEXADECIMAL

COPY FROM DRIVE 1 START AT BLOCK >0001<
TO DRIVE 2 START AT BLOCK      >0001<
NUMBER OF BLOCKS                >07D2<
SELECT COPY AND CHECK           >y<
SELECT CHECK                     > <

BLOCKSIZE=00128  DECIMAL

EXECUTE  BREAK  RETURN
ENTER   PF1    PF12

```

- Fill the requested data into the Copy Volume form.

| | | |
|-------------------------------------|--------|---|
| COPY FROM DRIVE 1 START AT BLOCK | >0001< | 0001 specifies the first block stored on the master diskette. |
| TO DRIVE 2 START AT BLOCK | >0001< | 0001 specifies the first block location on the diskette copy. |
| NUMBER OF BLOCKS | >07D2< | 07D2 specifies the number of blocks to be copied. (If the master diskette is full, it contains 07D2 blocks.) |
| SELECT COPY AND CHECK | >x< | Fill in any character if a copy operation and subsequent verifi- cation of the diskette copy are wanted. |
| SELECT CHECK | >x< | Fill in any character if only a verification is wanted. |

- Insert a formatted initiated diskette (can be obtained from Datasaab) into the right-hand drive.
- Insert the master diskette into the left-hand drive.
- Depress the ENTER key to start copying and/or verification.
- The copy and verification operations take about 30 minutes.

Read/Change Volume

The Read/Change Volume form is used to read or change data that is stored on the diskette. The user only has access to the emulation-dependent parameters which are explained below and presented in the customizing data in the Appendices.

```

*****  C O N S O L E  M O D E  *****
          R E A D / C H A N G E  V O L U M E
VOL NAME> <VERSION > <LIBRARY > <FILE /MEMBER > <TYPE> <
LOGADDR> <DRIVE> <REC> <

EXECUTE          RETURN
ENTER           PF 12
  
```

To define the emulation parameters, proceed as follows for each set of parameters.

- Fill in the following fields in the Read/Change Volume form:

| | |
|--------------------------------|--|
| LIBRARY FILE/MEMBER TYPE | } According to the illustrations in the customizing data |
| LOGADDR | |
| DRIVE | |
| REC | Enter 1 if left drive is used, 2 if right drive is used. |
| | As shown in the illustration in the customizing data: |

Do not pay any attention to the other fields.

- Depress the ENTER key. Data according to the selected illustration in the customizing data will now appear on the screen.
- Enter the table position of the parameter to be changed into AT> <. In the example below (printer unit definitions), the printer connected to port 4 has table position 0023 (i e on the line that is numbered 002 and in the column that is headed 3).

- Enter the new value followed by a period after PUT>. If you wish to change a number of positions you can enter a string of new values followed by a period.
- Depress the ENTER key.
- Check the table on the screen to see that the new values have been entered properly.

```

***** CONSOLE MODE *****
READ / CHANGE VOLUME
PU on port No. VOL NAME>SYSTM ID<VERSION >02<LIBRARY >SYSLIB <FILE /MEMBER >BH000400<TYPE>F<
LOGADDR>SS<DRIVE>1<REC>0001<AT > <PUT> <
0 1 2 3 4 5 6 7 8 9 A B C D E F
00 000 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 01
02 001 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 03
04 002 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 05
06 003 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 07
08 004 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 09
10 005 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 11
12 006 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 13
14 007 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 15
16 008 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 17
18 009 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 19
20 00A 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 21
22 00B 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 23
24 00C 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 25
26 00D 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 27
28 00E 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 29
30 00F 01 12 00 46 00 00 00 01 12 CO 46 00 00 00 .....F.....F..... 31
NUMB:01600100 BLOCS:00328 RECS:00328 FILES:00001 SEQ:0 LOADP:A000 SIZE:00001
EXECUTE PAGE FORWARD PAGE BACKWARD CLOSE FOR DISMOUNT RETURN REC NO=0001
ENTER PF1 PF2 PF3 PF12
    
```

Display Unit Definitions

It is possible to define ten sets of parameters used within a cluster. These sets of parameters are recorded in members EADEMPA1, EADEMPA2 and so on up to EADEMPAA of library EMLIB1. (The member name may be slightly different. See customizing data in the Appendices).

Each member (EADEMPA) is associated with an emulation logon name and load map No.

| | Logon name | Load map No. |
|-------------------------|------------|--------------|
| EADEMPA1 corresponds to | EM3274 | 001 |
| EADEMPA2 corresponds to | EM3274 | 002 |
| . | . | . |
| . | . | . |
| EADEMPAA corresponds to | EM3274 | 010 |

When the emulation mode is logged on, the operator thus determines (by means of the load map No.) which set of emulation definitions should be used for the display unit.

Note that two parameters (3 and 4) determine the way in which the display unit in question edits local printouts on the connected printer. The editing of local printouts is always carried out in the display unit to which the printer is connected.

Printer Definitions

The only printer parameter defined by the user is the maximum number of characters on a printout line. If it is not defined by the user, a default value of 132 characters is used.

Communication Processor Definitions

Some parameters can be defined for the communication processor by means of the read/change volume function.

For the most part, these affect the modem interface or functions common to a complete cluster. See customizing data in the Appendices.

Display Volume

```

*****  C O N S O L E  M O D E  *****
          D I S P L A Y  V O L U M E

VOLUME NUMBER   >      <
OR
VOLUME NAME     >      <  VERSION  > <
OR
LOGICAL FD      >00<      DRIVE   >1<

          DISPLAY /CHANGE VOLUME LABEL      PF1

RETURN
PF12

```

- Fill the requested data into the form.
- Depress the PF1 key.
A new form is displayed.

The volume label is a collection of data fields on the first track of the diskette. The volume label contains information about the contents of the diskette. The only item of information presented in this form that can be changed by the user is the volume number. Most of the items presented contain status information that is of interest only to Datasaab personnel, and they are not explained in this document. Those that are of interest to users are explained below.

```

*****  C O N S O L E  M O D E  *****
D I S P L A Y  / C H A N G E  V O L U M E  L A B E L

TYPE      S
VOLNO     0160020A          NEW VOLNO 016002> <
NAME      SYSTM ID         NEW NAME  >      <
VERS      08
REVDT     M202-01
USER      2.18  810804
FLAG      00
STAT      0000
VPTR      0002
VSIZE     0020
FDBOT     80T002
NAT              NEW NAT  >
RPQ              NEW RPQ  >      <->  <      <

PRODNAME  IBM 3274/78 BSC,CLUSTER,GTLE 24 LINES

EXECUTE   RETURN
ENTER     PF12

```

| <i>Item of information</i> | <i>Explanation</i> |
|----------------------------|---|
| TYPE | S = System diskette. D = Data diskette. E = Empty diskette. |
| VOLNO | The volume number identifies the diskette. The volume number is created by adding two digits at the end of the product number after removing the first digit from the product number. Example 4015-001 Product number 015001xx Volume number |
| NAME | Volume name. |
| VERS | Volume version. |
| NAT | National version of keyboard, printer and line codes. |
| RPQ | Identification number of RPQ, if any is used. |


| <i>Input field name</i> | <i>Explanation</i> |
|--------------------------|--|
| NEW VOLNO YYYYYY >xx< | The last two digits in the volume number can be changed. Enter the new digits at xx and depress the ENTER key. The volume number is now changed. |

System Diskette Backup

When customizing is completed, don't forget to customize the backup diskette. Perform the same customizing procedure as for the first diskette, or use the Copy Volume function. Don't forget to reload the customizing station if it is to be used as a normal terminal. This operation is initiated by turning off and on the power or depressing the reset button on each unit.

CCITT Recommendations Series V

- V10 Electrical characteristics for unbalanced double-current interchange circuits for general use with integrated circuit equipment in the field of data communications.
- V11 Electrical characteristics for balanced double-current interchange circuits for general use with integrated circuit equipment in the field of data communications.
- V23 600/1200-baud modem standardized for use in the general switched telephone network.
- V24 List of definitions for interchange circuits between data-terminal equipment and data circuit-terminating equipment.
DTE DCE = Modem
- V25 Automatic calling and/or answering equipment on the general switched telephone network, including disabling of echo-suppressors on manually established calls.
- V26 2400 bits per second modem standardized for use on 4-wire leased telephone-type circuits.
- V27 4800 bits per second modems with manual equalizer standardized for use on leased telephone-type circuits.
- V28 Electrical characteristics for unbalanced double-current interchange circuits.
- V29 9600 bits per second modem standardized for use on leased telephone-circuits.



Series X

X21 General purpose interface between data terminal equipment (DTE) and data circuit-terminating equipment (DCE) for synchronous operation on public data networks. (DATE)

X24 List of definitions for interchange circuits between data terminal equipment (DTE) and data circuit-terminating equipment (DCE) on public data networks.

X26 Electrical characteristics for unbalanced double-current interchange circuits for general use with integrated circuit equipment in the field of data communications.

X27 Electrical characteristics for balanced double-current interchange circuits for general use with integrated circuit equipment in the field of data communications.

ORGANIZATIONS & STD'S

UN

ITU INTERNATIONAL TELECOMMUNICATION UNION

CCIR (RADIO) CCITT COMITÉ CONSULTATIF INTERNATIONAL
TELEGRAPHIQUE ET TELEPHONIQUE

ECMA EUROPEAN COMPUTER MANUFACTURERS ASSOCIAT.

ISO INTERNATIONAL ORGANIZ. FOR STANDARDIZA-
TION

ANSI *USA* AMERICAN NATIONAL STD. INSTITUTE
(UNIT. STAT. AMER. STD INST.)

EIA *USA* ELECTRONIC INDUSTRIES ASSOCIATION


)

)

)


)

)




Asynchronous transmission, asynchronous character structure

t →



Synchronous transmission, asynchronous character structure



Synchronous transmission, synchronous character structure

Fig. 4 Överföringsätt

| EIA-CCITT MODEM-TERMINAL INTERFACE | | | | |
|------------------------------------|--------|----------------------|----------------------------|------------------------|
| PIN | NAME | ↑ TO DTE ↓ TO DCE | FUNCTION | CIRCUIT CCITT (EIA) |
| 1 | FG | --- | FRAME GROUND | 101 (AA) |
| 2 | TD | --- | TRANSMITTED DATA | 103 (BA) |
| 3 | RD | --- | RECEIVED DATA | 104 (BB) |
| 4 | RTS | --- | REQUEST TO SEND | 105 (CA) |
| 5 | CTS | --- | CLEAR TO SEND | 106 (CB) |
| 6 | DSR | --- | DATA SET READY | 107 (CC) |
| 7 | SG | --- | SIGNAL GROUND | 102 (AB) |
| 8 | DCD | --- | DATA CARRIER DETECT | 109 (CF) |
| 9 | | --- | POSITIVE DC TEST VOLTAGE | |
| 10 | | --- | NEGATIVE DC TEST VOLTAGE | |
| 11 | DM | --- | EQUALIZER MODE | BELL 208A |
| 12 | (S)DCD | --- | SEC. DATA CARRIER DETECT | 122 (SCF) |
| 13 | (S)CTS | --- | SEC. CLEAR TO SEND | 121 (SCB) |
| 14 | (S)TD | --- | SEC. TRANSMITTED DATA | 118 (SBA) |
| 15 | NS | --- | NEW SYNC | BELL 208A |
| 16 | (S)RD | --- | SEC. RECEIVED DATA | 119 (SBB) |
| 17 | DCT | --- | DIVIDED CLOCK, TRANSMITTER | BELL 208A |
| 18 | RC | --- | RECEIVER CLOCK | 115 (DD) |
| 19 | (S)RTS | --- | SEC. REQUEST TO SEND | 120 (SCA) |
| 20 | DTR | --- | DATA TERMINAL READY | 108.2 (CD) |
| 21 | SO | --- | SIGNAL QUALITY DETECT | 110 (CG) |
| 22 | RI | --- | RING INDICATOR | 125 (CE) |
| 23 | | --- | DATA RATE SELECTOR | 111 (CH) |
| 24 | (TC) | --- | EXT. TRANSMITTER CLOCK | 112 (CI) |
| 25 | | --- | BUSY | 113 (DA) |

- POSITIVE VOLTAGE EQUALS BINARY ZERO, SIGNAL SPACE, CONTROL ON, LED ON.
 - NEGATIVE VOLTAGE EQUALS BINARY ONE, SIGNAL MARK, CONTROL OFF, LED OFF.

100 Nashua St.,
 Prov., R.I. 02904.
 Tel. (401) 274-5100
 TWX 710-381-0285



INTERNATIONAL DATA SCIENCES INC.
 PROVIDENCE, R. I., U.S.A.




300 Kbits/sec



TWO-WIRE



250 Kbits/sec
Transfer rate



- 77 TRACKS
- 26 SECTORS
- 128 BYTES/SECTOR
- 3328 BYTES/TRACK
- 256 256 BYTES/DISKETTE

| GAP | ID AM | TRACK NUMBER | ZEROS | SECTOR NUMBER | SECTOR LENGTH | CRC 1 | CRC 2 | GAP | DATA AM | DATA FIELD | CRC 1 | CRC 2 |
|----------|-------|--------------|-------|---------------|---------------|-------|-------|-----|------------|------------|-------|-------|
| ID FIELD | | | | | | | | | DATA FIELD | | | |


IDAM = ID Address Mark - DATA=(FE)₁₆ CLK = (C7)₁₆
 Data AM = Data Address Mark - DATA=(FB, F9, FA, or FB), CLK = (C7)₁₆

(

(

(

(



VOLLAB ⇒ VOLUME LABEL


VTOC ⇒ VOLUME TABLE OF CONTENTS

FILE

LIBRARY

MEMBER

LTOC ⇒ LIBRARY TABLE OF CONTENTS






L1LIB
















PRLIB

CONSLIB

Communication Processor 4101



PORT 0 1 2 3 4 5 6 7





| | | | | |
|-----|-----|----|----|-----|
| CLP | CLP | DV | DV | END |
| 02 | 02 | 02 | 02 | 9D |

| | | | | |
|-----|-----|----|----|-----|
| CLP | CLP | DV | DV | END |
| 02 | 02 | 02 | 02 | 9D |

| | | | | | | |
|-----|-----|-----|-------|--|-----|------|
| STX | ESC | CMD | ----- | | ETX | CRCC |
| 02 | 2F | | | | 03 | |

| | |
|-----|----|
| TTD | 2D |
| 02 | |

| | |
|-----|----|
| EOT | 37 |
|-----|----|

| | | |
|-----|---|----|
| ACK | 0 | 70 |
| 10 | | |

| | | |
|-----|---|----|
| ACK | 1 | 61 |
| 10 | | |

| | |
|------|----|
| WACK | 6B |
| 10 | |

| | |
|-----|----|
| NAK | 3D |
|-----|----|

| | |
|-----|----|
| RVE | 7C |
| 10 | |

| | | | | | | | |
|-----|-----|----|-----|-------|--|------------|------|
| STX | CLD | DV | AID | ----- | | ETX or ETB | CRCC |
| 02 | | | | | | 03 or 26 | |

| | | | | | | | | |
|-----|----|----|-----|-----|----|--------|-------|-----|
| SOH | % | R | STX | CLD | DV | Status | Sense | ETX |
| 01 | 6C | D9 | 02 | | | | | 03 |

| | | | | | | | |
|-----|----|----|-----|-------|--|------------|------|
| SOH | % | ✓ | STX | ----- | | ETX or ETB | CRCC |
| 01 | 6C | 61 | 02 | | | 03 or 26 | |

| | |
|-----|----|
| END | 9D |
|-----|----|

| | | | |
|-----|----|-----|----|
| SYN | 32 | SYN | 32 |
|-----|----|-----|----|

IBM
BSC

