



**IBM**

**International Technical Support Centers  
Using 3174 in TCP/IP Networks**

GG24-4172-00

# **Using 3174 in TCP/IP Networks**

Document Number GG24-4172-00

June 1994

International Technical Support Organization  
Raleigh Center

**Take Note!**

Before using this information and the product it supports, be sure to read the general information under "Special Notices" on page xxiii.

**First Edition (June 1994)**

This edition applies to the 3174 Network Controller Configuration Support-C3 through C5 TCP/IP Support.

Order publications through your IBM representative or the IBM branch office serving your locality. Publications are not stocked at the address given below.

An ITSO Technical Bulletin Evaluation Form for reader's feedback appears facing Chapter 1. If the form has been removed, comments may be addressed to:

IBM Corporation, International Technical Support Organization  
Dept. 985, Building 657  
P.O. Box 12195  
Research Triangle Park, NC 27709-2195

When you send information to IBM, you grant IBM a non-exclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

© Copyright International Business Machines Corporation 1994. All rights reserved.

Note to U.S. Government Users — Documentation related to restricted rights — Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

---

## **Abstract**

The 3174 Establishment Controller is a very important component in multi-protocol networks involving subarea SNA, Advanced Peer-to-Peer Networking (APPN), Peer Communication, Token-Ring and Ethernet LANs, X.25, Integrated Services Digital Network (ISDN), asynchronous communication, frame relay, and Transmission Control Protocol/Internet Protocol (TCP/IP).

This document focuses on the roles of the 3174 in TCP/IP networks. It includes functions introduced by the 3174 TCP/IP TELNET RPQ 8Q0935, enhancements such as TN3270, TCP/IP host printer, and SNMP MIB-II support offered by 3174 TCP/IP Enhancements RPQ 8Q1041 and the recently available IP Forwarding RPQ 8Q1289.

This document is intended to help customers and systems engineers understand the functionality provided and how to customize the 3174 for participation in a TCP/IP network. It is organized to help the reader understand the basics of the TCP/IP Architecture in general and the 3174 implementation specifically. The scenarios include sample configuration files and panels for the 3174 and other TCP/IP hosts in the network. The reader is assumed to have a basic knowledge of TCP/IP as implemented by the other products used in the scenarios.

(373 pages)



---

# Contents

<b>Abstract</b> .....	iii
<b>Special Notices</b> .....	xxiii
<b>Preface</b> .....	xxv
How This Document is Organized .....	xxv
Related Publications .....	xxvi
International Technical Support Organization Publications .....	xxvii
Acknowledgments .....	xxviii
<b>Chapter 1. An Introduction to 3174 TCP/IP Support</b> .....	1
1.1 3174 Functional Overview .....	1
1.2 TCP/IP Overview .....	3
1.3 TCP/IP Architecture .....	3
1.3.1 Transmission Control Protocol (TCP) .....	3
1.3.2 Telnet .....	5
1.3.3 Internet Protocol (IP) .....	5
1.3.4 Internet Control Messaging Protocol (ICMP) .....	6
1.3.5 User Datagram Protocol (UDP) .....	6
1.3.6 Address Resolution Protocol (ARP) .....	6
1.3.7 Simple Network Management Protocol (SNMP) .....	7
1.3.8 Domain Name System .....	7
1.3.9 Packet Internet Groper (PING) .....	7
1.3.10 TCP/IP Gateways .....	7
1.4 TCP/IP Protocols Supported .....	7
<b>Chapter 2. 3174 TCP/IP Telnet Support</b> .....	9
2.1 Support before 3174 TCP/IP Telnet RPQ 8Q0935 .....	9
2.2 Support with 3174 TCP/IP Telnet RPQ 8Q0935 .....	9
2.3 Support with Configuration Support-C Release 3 .....	10
2.4 Support with 3174 TCP/IP Enhancements RPQ 8Q1041 .....	10
2.5 Support with Configuration Support-C Release 5 .....	10
2.6 Support with 3174 IP Forwarding RPQ 8Q1289 .....	11
2.7 TELNET Emulation and NLS Support .....	11
2.8 3174 Models Supported .....	12
2.8.1 Gateway 3174 Configuration .....	12
2.8.2 DSPU 3174 Configuration .....	13
2.9 Devices Supported .....	14
2.10 Hosts Supported .....	15
2.11 Storage Requirements .....	15
2.11.1 Sessions .....	15
2.11.2 TCP/IP Data Buffers .....	15
2.12 Microcode Packaging .....	16
<b>Chapter 3. Adding 3174 to TCP/IP Network</b> .....	19
3.1 IP Addresses .....	19
3.2 Subnet Masks .....	20
3.3 Customizing IP Addresses .....	21
3.4 Names .....	21
3.5 Name Servers .....	21
3.6 3174 Nicknames .....	21

3.7	How the 3174 TCP/IP Telnet Support Looks at Names	22
3.8	Routes	23
3.9	Customizing 3174 TCP/IP Telnet Support	24
3.9.1	Example Scenario	24
3.9.2	Panel Flow	26
3.9.3	Configure AEA and TCP/IP	26
3.9.4	Enabling AEA and TCP/IP	28
3.9.5	Defining Port Set	29
3.9.6	Mapping Port to Port Set	30
3.9.7	Defining 3270 Host and Display Station Sets	32
3.9.8	Defining TCP/IP Station Sets	33
3.9.9	Defining Default Destinations	38
3.9.10	Defining TCP/IP Options	39
3.9.11	Defining TCP/IP Routing Information	40
3.9.12	Defining Domain Name Services	41
3.9.13	Defining TCP/IP Nicknames	43
3.9.14	Configure Complete	44
3.9.15	Token-Ring Considerations	44
3.9.16	Ethernet Considerations	44
3.10	How to Use the 3174 TCP/IP Telnet Support	45
3.11	Terminal Operation with the 3174 TCP/IP Telnet Support	46
3.11.1	Opening a Connection	46
3.11.2	Escaping to Local Mode	47
3.11.3	Returning to The Connection Menu	48
3.11.4	Returning to the Telnet Session	48
3.11.5	TELNET Session Resources	48
3.11.6	Operation: Telnet to RS/6000 Host	49
3.11.7	Operation: Telnet to MVS TCP/IP Host	51
3.11.8	Local Mode Commands	51
3.11.9	Special Considerations for ASCII Terminals	59
3.11.10	Special Considerations for 3270 Terminals	60
3.11.11	Special Considerations for 3270 Emulation	61
3.12	If Things Go Wrong...	61
3.13	Telnet Codes	63
3.14	Data Flows	64
 <b>Chapter 4. Scenario 1: TCP/IP Using 3174 Peer Communication Only</b>		<b>67</b>
4.1	Scenario 1 Configuration Diagram	67
4.2	Scenario 1 Configuration Description	68
4.3	Communications Manager/2 Definitions	69
4.4	TCP/IP V1.2.1 for OS/2 Installation/Configuration	75
4.5	Installation: TCP/IP LAN Adapter and Protocol Support (TCPLAPS)	78
4.6	Personal Communications/3270 Definitions	82
4.6.1	Personal Communications/3270 Configuration Program	82
4.7	Installation: TCP/IP for DOS	91
4.7.1	System Files	96
4.8	Using TCP/IP Application for Windows	99
4.8.1	Overview of the TCP/IP for Windows	99
4.8.2	Windows Ping	100
4.8.3	Windows TELNET	101
4.9	RISC System/6000 Definitions	105
4.9.1	SMIT TCP/IP	105
4.9.2	Minimum Configuration and Setup	106
4.10	3174-11R Customization	107
4.10.1	SDLC	107

4.10.2	Common SNA	108
4.10.3	Common Network	108
4.10.4	Ring Address Assignment	109
4.11	3174-Peer Definition	109
4.11.1	Question 650: 3174-Peer Support	110
4.11.2	Question 651: Bridge Support	110
4.11.3	Question 652: LAN Manager Support	111
4.11.4	Question 653: 3174-Peer Online Test Updates	111
4.11.5	Question 660: 3174-Peer Port Address Range	112
4.11.6	Question 661: Percentage of Discard Threshold	113
4.11.7	3174-Peer Bridge Profile	113
4.11.8	LAN Manager Profile	117
4.12	Display 3174-Peer Status	118
 <b>Chapter 5. Scenario 2: Concurrent Access to SNA and TCP/IP Hosts</b>		<b>119</b>
5.1	Scenario 2 Configuration Diagram	119
5.2	Scenario 2 Configuration Description	120
5.3	3174-12L Multi-Host Customization	121
5.3.1	Common Network (1B Host)	127
5.3.2	Ring Address Assignment (1B Host)	128
5.3.3	Ring Transmission Definition (1B Host)	128
5.3.4	Configure Complete	130
5.4	3174 TCP/IP Customizing	131
5.4.1	Enabling AEA And TCP/IP	131
5.4.2	Defining Port Set	132
5.4.3	Mapping Port To Port Set	133
5.4.4	Defining 3270 Host and Display Station Sets	134
5.4.5	Defining TCP/IP Station Sets	135
5.4.6	Defining Default Destinations	138
5.4.7	Defining TCP/IP Options	139
5.4.8	Defining TCP/IP Routing Information	140
5.4.9	Defining Domain Name Services	141
5.4.10	Defining TCP/IP Nicknames	142
5.4.11	Configure Complete	142
5.5	Operation: TELNET to RISC System/6000	143
5.6	RISC System/6000 Definitions	146
5.6.1	SNA Services	146
5.6.2	Configure SNA Profiles	147
5.6.3	Quick Configuration	147
5.6.4	Quick Configuration for a 3270 Communication Connection: Information	148
5.6.5	Command Status	148
5.6.6	Advanced SNA Configuration	149
5.6.7	Physical Units	150
5.6.8	Token-Ring	150
5.6.9	SNA Token Ring Attachment Profile Name	151
5.6.10	Change/Show SNA Token Ring Attachment Profile	151
5.6.11	Manage SNA Services	152
5.6.12	Start SNA Resources	152
5.6.13	Start an SNA Link Station	153
5.6.14	Display SNA Resources	153
5.6.15	Command Status	154
5.6.16	AIX 3270 Host Communication Program/6000 (HCON)	155
5.6.17	HCON User Functions	156
5.6.18	Add an HCON Session	156



5.6.19	Add SNA Display Session	157
5.6.20	Command Status	157
5.6.21	HCON Session	158
<b>Chapter 6. Scenario 3: APPN and TCP/IP via 3174 to AS/400 and VTAM</b>		<b>159</b>
6.1	Scenario 3 Configuration Diagram	159
6.2	Scenario 3 Configuration Description	160
6.3	3174-11R APPN, Peer Communication and TCP/IP Customization	161
6.3.1	Customize Control Disk Menu	161
6.4	3174 as an APPN Network Node	161
6.5	3174 APPN and Peer Communication Customization	162
6.5.1	SDLC	164
6.5.2	Common SNA	164
6.5.3	Common Network	168
6.5.4	Ring Address Assignment	168
6.5.5	APPN Node Definition	169
6.6	Network Resources Definition	170
6.6.1	Network Resources	171
6.6.2	Associated LUs	172
6.7	COS Definitions	172
6.7.1	Mode/COS Correlation	173
6.8	3174-Peer Definitions	175
6.8.1	3174-Peer Definition Panel	176
6.8.2	3174-Peer Bridge Profile	177
6.9	AS/400 Definitions	178
6.9.1	Network Attributes	178
6.9.2	Configuration Status	178
6.9.3	Controller Description Screens (C31742)	179
6.9.4	Device Description Screens (PS2COAX)	181
6.10	Communications Manager/2 Definitions for 5250 Emulation	182
6.10.1	Communications Manager/2 Installation and Setup	182
6.10.2	Communications Manager Setup	183
6.10.3	Open Configuration	183
6.10.4	Communications Manager Configuration Definition-PSEN3174	184
6.10.5	Communications Manager Profile List Sheet	185
6.10.6	Token-Ring or Other LAN Types DLC Adapter Parameters	185
6.10.7	Local Node Characteristics	186
6.10.8	SNA Features List	186
6.10.9	5250 Emulation	187
6.11	LAN Adapter and Protocol Support	188
6.11.1	LAN Adapter and Protocol Support	188
6.11.2	Configure LAN Transports	188
6.11.3	Configure Workstation	189
6.11.4	Parameters for 3270 Adapter for 3174 Peer Communications	189
6.11.5	LAN Adapter and Protocol Support	190
6.11.6	3174-11R Online Display	191
6.12	VTAM Definition List	192
6.13	3174 TCP/IP Definitions	198
6.13.1	AEA And TCP/IP Configure	198
6.13.2	Defining Port Set	198
6.13.3	Mapping Port To Port Set	200
6.13.4	Defining 3270 Host and Display Station Sets	200
6.13.5	Defining TCP/IP Station Sets	201
6.13.6	Defining Default Destinations	202
6.13.7	Defining TCP/IP Options	202

6.13.8	Defining TCP/IP Routing Information	203
6.13.9	Defining Domain Name Services	204
6.13.10	Defining TCP/IP Nicknames	205
6.13.11	Configure Complete	205
6.13.12	TELNET to AS/400	206
6.13.13	TELNET Prompt	206
6.13.14	AS/400 Sign-On Screen	207
6.13.15	AS/400 Main Menu	207
6.14	Display 3174-Peer Status	208
<b>Chapter 7.</b>	<b>Scenario 4: TCP/IP via 3174 and RS/6000 Router to VAX</b>	<b>209</b>
7.1	Scenario 4 Configuration	209
7.2	Scenario 4 Description	210
7.3	3174-11R TCP/IP and Peer Support Customization	211
7.3.1	Customize Control Disk Menu	211
7.4	3174-Peer Definition	212
7.4.1	3174-Peer Definition Panel	212
7.5	3174 TCP/IP Definitions	213
7.5.1	AEA and TCP/IP Configure	213
7.5.2	Defining Port Set	214
7.5.3	Mapping Port to Port Set	215
7.5.4	Defining 3270 Host and Display Station Sets	215
7.5.5	Defining TCP/IP Station Sets	216
7.5.6	Defining Default Destinations	217
7.5.7	Defining TCP/IP Options	217
7.5.8	Defining TCP/IP Routing Information	218
7.5.9	Defining Domain Name Services	219
7.5.10	Defining TCP/IP Nicknames	220
7.6	RS/6000 Definitions	221
7.6.1	Router Definition on RISC System/6000	221
7.6.2	Command Status	223
7.6.3	Router Definition on DEC VAX	223
7.7	TELNET to VAX Host	224
<b>Chapter 8.</b>	<b>3174 Ethernet Considerations</b>	<b>227</b>
8.1	3174 Configuration Support C, Release 4	227
8.1.1	Configurations	228
8.1.2	Alternate Configurations	228
8.1.3	Storage Requirements	228
8.1.4	Configuration Examples	230
8.1.5	MAC Layer	232
8.1.6	LLC Layer	234
8.1.7	Frame Format Discovery Process	236
8.2	3174 Ethernet Adapter	244
8.2.1	Capacity	244
8.2.2	Configurations	244
8.2.3	CSMA/CD LAN Physical Interfaces	244
8.2.4	Hardware Group and Type Number	246
8.2.5	Field Replaceable Unit Identification (FRU ID)	246
8.2.6	Status Codes	247
8.3	3174 Ethernet Customization	248
8.4	Configuration Questions	248
8.4.1	Model/Attach Panel	249
8.4.2	Ethernet Description Panel	251
8.4.3	Local Area Network Panel	253

8.4.4	Common Network Panel (Gateway 900)	254
8.4.5	Gateway 940 Panel	255
8.4.6	Gateway 941 Panel	255
8.4.7	TCP/IP Options Menu	255
8.4.8	End-User Productivity Panel	255
8.5	Online Test ("/TEST")	256
8.5.1	/1 -- Logs Display	256
8.5.2	/2 -- Display Customization	256
8.5.3	/9 -- LAN Tests	257
8.5.4	/15 - Host Status Summary	261
8.5.5	/17 - APPN Tests	261
<b>Chapter 9. 3174 TCP/IP Enhancements RPQ 8Q1041</b>		<b>263</b>
9.1	Configurations	264
9.2	Devices	265
9.3	Hosts	265
9.4	3174 Microcode and Packaging	265
9.5	Storage Requirements	267
9.5.1	Sessions	267
9.5.2	Data Buffers	267
9.6	Protocols	269
9.7	TN3270	269
9.7.1	Function	270
9.7.2	ASCII TELNET vs TN3270	272
9.8	Line Printer Daemon (LPD)	273
9.8.1	Printer Pooling	274
9.8.2	LPD Data Stream	276
9.8.3	Banner Page	279
9.8.4	Internal Queuing	279
9.8.5	Translation Support	280
9.9	MIB-II	280
9.10	TCP/IP Enhancements Customization	291
9.10.1	AEA and TCP/IP Configure	291
9.10.2	Defining TN3270 Station Set	292
9.10.3	Defining Printer Station Set	293
9.10.4	Defining Default Destinations	294
9.10.5	Defining TCP/IP Options	294
9.11	Scenario 1 - 3174 Line Printer Daemon (LPD)	295
9.11.1	Scenario Description	295
9.11.2	3174 Line Printer Daemon Customization	296
9.11.3	Defining 3270 Printer Station Set	296
9.11.4	Defining Default Destinations	297
9.11.5	Defining TCP/IP Options	297
9.11.6	3174 Line Printer Daemon Configuration for OS/2	297
9.11.7	Printing with the 3174 Line Printer Daemon from TCP/IP for OS/2	301
9.11.8	3174 Line Printer Daemon Configuration for DOS	301
9.11.9	Printing with the 3174 Line Printer Daemon from TCP/IP for DOS	303
9.11.10	3174 Line Printer Daemon Configuration for AS/400	303
9.11.11	Printing with the 3174 Line Printer Daemon on AS/400	310
9.11.12	3174 Line Printer Daemon Configuration for RS/6000	311
9.11.13	Manage Local Printer Subsystem	313
9.11.14	Manage Remote Printer Subsystem	316
9.11.15	Server Services	318
9.11.16	Printing with the 3174 Line Printer Daemon from RS/6000	319
9.11.17	3174 Line Printer Daemon Configuration for HP-UX Workstation	320

9.11.18 3174 Line Printer Daemon Configuration for SunOS Workstation	328
9.12 Scenario 2 - TN3270 to MVS Host	331
9.12.1 Scenario Description	332
9.12.2 TN3270 Customization	332
9.12.3 Defining Default Destinations	333
9.12.4 Defining TCP/IP Options	333
9.12.5 Defining TCP/IP Routing Information	334
9.12.6 Defining Domain Name Services	334
9.12.7 Connection Menu	335
9.13 Scenario 3 - TN3270 to CICS/6000	340
9.13.1 Scenario Description	340
9.13.2 TN3270 Customization	340
9.13.3 Defining Default Destinations	341
9.13.4 Defining TCP/IP Options	342
9.13.5 Defining TCP/IP Routing Information	342
9.13.6 Defining Domain Name Services	343
9.13.7 Defining TCP/IP Nicknames	343
9.13.8 CICS/6000 Overview	344
9.13.9 CICS/6000 Environment	344
9.13.10 CICS/6000 TELNET Server	345
9.13.11 TCP/IP Port Number	345
9.13.12 Connection Menu	346
9.13.13 CICS Signon Screen	348
9.13.14 Working with Your CICS/6000 Region	349
<b>Chapter 10. 3174 Configuration Support C, Release 5</b>	<b>351</b>
10.1 Multiprotocol Frame Relay	352
10.2 DLCI	352
10.3 IP Support	352
10.4 Interoperability	352
10.5 Migration - Coexistence	352
10.6 Frame Relay Customization	353
10.6.1 Model/Attach Panel	353
10.6.2 Frame Relay Host Panel Layout for the 1A Host	354
10.6.3 Frame Relay Host Panel Layout for the 1B - 1H Hosts	354
10.6.4 Frame Relay Description Panel Layout	355
10.6.5 Customization Error Messages	357
<b>Appendix A. Address Bit Order for Ethernet Addresses</b>	<b>359</b>
<b>Appendix B. SNMP Variables</b>	<b>363</b>
<b>Abbreviations</b>	<b>371</b>
<b>Index</b>	<b>373</b>



---

## Figures

1.	TCP Logical Connections	4
2.	TCP Connection Establishment	5
3.	Using Ports to Direct Datagrams	6
4.	Protocols Supported by the 3174 TCP/IP Telnet Support	8
5.	3174 Gateway Configurations with 3174 TCP/IP Telnet Support	13
6.	3174 DSPU Configuration with 3174 TCP/IP Telnet Support	14
7.	Classes of IP Addresses	19
8.	TCP/IP Resolving Name/Destination	22
9.	TCP/IP Router Example	23
10.	TCP/IP Router Example Customization	24
11.	TCP/IP Example Scenario	25
12.	TCP/IP Customization Panel Flow	26
13.	Define AEA and TCP/IP Option	27
14.	Configure AEA and TCP/IP Option	27
15.	AEA and TCP/IP Configure Panel	28
16.	Port Set Panel	29
17.	Port to Port Set Map Panel (1 of 3)	30
18.	Port to Port Set Map Panel (2 of 3)	31
19.	Port to Port Set Map Panel (3 of 3)	32
20.	AEA and TCP/IP Station Set Panel (1 of 4)	32
21.	AEA and TCP/IP Station Set Panel (2 of 4)	34
22.	AEA and TCP/IP Station Set Panel (3 of 4)	37
23.	AEA and TCP/IP Station Set Panel (4 of 4)	37
24.	AEA and TCP/IP Default Destination Panel	38
25.	TCP/IP Options Menu	39
26.	TCP/IP Routing Information	40
27.	TCP/IP Domain Name Services	41
28.	TCP/IP 3174 Defined Nicknames	43
29.	AEA and TCP/IP Configure Complete	44
30.	Connection Menu Immediately after 3174 IMLed	45
31.	Connection Menu after 3174 Becomes Active	45
32.	Connection Menu after 3174 Becomes Active And Enter Pressed	46
33.	TCP/IP Resources Not Available	48
34.	Selecting Connection to RS/6000 Host	49
35.	TELNET Local Mode	49
36.	RS/6000 after Login	50
37.	RS/6000 after Invoking SMIT	50
38.	Logging On to MVS TSO	51
39.	TCP/IP Using NAMES Command	52
40.	TCP/IP Using PING Command - to Default Destination	53
41.	TCP/IP Using PING Command - with Parameters	53
42.	TCP/IP Using PING Command - Help	53
43.	TCP/IP Using PING Command - Messages	54
44.	TCP/IP Using CLOSE Command	55
45.	TCP/IP Using STATUS Command	56
46.	TCP/IP Using DISPLAY Command	57
47.	Online Test /3,3,26	62
48.	TCP/IP Connection Establishment	65
49.	TCP/IP Access through 3174 Peer Communication	67
50.	Communications Manager/2 Installation and Setup	69
51.	Communications Manager Setup	70

52.	Open Configuration	71
53.	Communications Manager Configuration Definition for 3270 Emulation	72
54.	3270 Emulation through Token-Ring	73
55.	Communications Manager Configuration Definition for 3270 Emulation	74
56.	TCP/IP V1.2.1 for OS/2 ICAT Introduction Panel	75
57.	TCP/IP V1.2.1 for OS/2 ICAT Installation Panel	76
58.	ICAT Configuration Menu	77
59.	ICAT Configure Network Interface Parameters	77
60.	IFCONFIG Statement in SETUP.CMD File	78
61.	TCPLAPS Introduction Panel	78
62.	TCPLAPS Installation Panel	79
63.	TCPLAPS Reinstall Selection	79
64.	Target Drive	79
65.	TCPLAPS Configuration Panel	80
66.	TCPLAPS Configuration Selection	80
67.	CONFIG.SYS Update	81
68.	Updated CONFIG.SYS	81
69.	PC/3270 Logo	82
70.	PC/3270 Create Configuration File	83
71.	PC/3270 Choose Configuration	83
72.	PC/3270 Attachment Types	84
73.	PC/3270 Advanced Options for 3174 Peer Communication	84
74.	PC/3270 Advanced Options for 3174 Network Stations	85
75.	PC/3270 Screen Sizes	85
76.	PC/3270 Keyboard and Code Pages	86
77.	PC/3270 Startup Options	86
78.	PC/3270 End of Link Option	87
79.	PC/3270 End of Configuration (Before Save)	87
80.	PC/3270 End of Configuration (After Save)	88
81.	PC/3270 Customize Communication (Windows Mode)	89
82.	Customize Communication - 3270 Host (Windows Mode)	89
83.	IEEE 802.2 (Windows Mode)	90
84.	IEEE 802.2 Advanced (Windows Mode)	90
85.	IBM TCP/IP for DOS Installation Tool	91
86.	IBM TCP/IP for DOS CUSTOM	93
87.	Read TCP/IP Configuration	93
88.	NDIS Interface and Protocol Manager Configuration	94
89.	NDIS Interfaces	94
90.	Read TCP/IP Configuration	95
91.	Write TCP/IP Configuration	96
92.	The TCP/IP Program Group	100
93.	PING	100
94.	HOST	101
95.	Ping (OK)	101
96.	TELNET	102
97.	IBM TCP/IP TELNET Configure	102
98.	Define Session	103
99.	IBM TCP/IP TELNET Connection	103
100.	Open Session	104
101.	Session Establishment	104
102.	SMIT TCP/IP	105
103.	Minimum Configuration and Startup	106
104.	3174-11R Customization	107
105.	Customizing the 3174-11R for an SDLC Link	107
106.	Names to Identify the 3174-11R Network Node	108

107.	Token-Ring Definition for the 3174-11R	108
108.	Ring Address Assignment	109
109.	Enabling 3174 Peer Communication Functions	110
110.	Format of 3174-Peer Device Address	112
111.	3174-Peer Bridge Parameters	114
112.	Display 3174-Peer Status	118
113.	3174 MLT Access to SNA 3270 and TCP/IP Hosts	119
114.	3174-11L Multi-Host Customization	121
115.	Multi-Host Definition	122
116.	Customizing the 3174-12L for an ESCON Connection	123
117.	Names to Identify the 3174-12L Network Node	124
118.	Token-Ring Definition for the 3174-12L	124
119.	Ring Address Assignment	125
120.	Ring Transmission Definition	125
121.	Port Assignment	126
122.	Port Address	126
123.	Customizing the 3174-12L for an ESCON Connection (1B Host)	127
124.	Token-Ring Definition for the 3174-12L	127
125.	Ring Address Assignment (1B Host)	128
126.	Ring Transmission Definition (1B Host)	128
127.	Port Assignment (1B Host)	129
128.	Port Address (1B Host)	129
129.	Configure Complete	130
130.	AEA and TCP/IP Configure Panel	131
131.	Port Set Panel	132
132.	Port to Port Set Map Panel (1 of 3)	133
133.	AEA and TCP/IP Station Set Panel (1 of 3)	134
134.	AEA and TCP/IP Station Set Panel (2 of 3)	136
135.	AEA and TCP/IP Station Set Panel (3 of 3)	137
136.	AEA and TCP/IP Default Destination Panel	138
137.	TCP/IP Options Menu	139
138.	TCP/IP Domain Name Services	141
139.	TCP/IP 3174 Defined Nicknames	142
140.	AEA And TCP/IP Configure Complete	142
141.	Connection Menu Immediately after 3174 IMLed	143
142.	Connection Menu after 3174 Becomes Active	143
143.	Connection Menu after 3174 Becomes Active and Enter Pressed	144
144.	Selecting Connection to RS/6000 Host	144
145.	TELNET Local Mode	145
146.	RS/6000 after Login	145
147.	RS/6000 after Invoking SMIT	145
148.	SNA Services	146
149.	Configure SNA Profiles	147
150.	Quick Configuration	147
151.	Quick Configuration for a 3270 Communication: Information	148
152.	Command Status	148
153.	Advanced SNA Configuration	149
154.	Physical Units	150
155.	Token Ring	150
156.	SNA Token Ring Attachment Profile Name	151
157.	Change/Show SNA Token Ring Attachment Profile	151
158.	Manage SNA Services	152
159.	Start SNA Resources	152
160.	Start SNA Link Station	153
161.	Display SNA Resources	153



162.	COMMAND STATUS	154
163.	AIX 3270 Host Communication Program/6000 (HCON)	155
164.	HCON User Functions	156
165.	Add an HCON Session	156
166.	Add SNA Display Session	157
167.	COMMAND STATUS	157
168.	Host	158
169.	3174 in an APPN, TCP/IP and SNA Environment	159
170.	Customize Control Disk Menu	161
171.	3174 Customization Panel Flow Sequence	163
172.	Customizing the 3174-11R for an SDLC Link	164
173.	Names to Identify the 3174-11R Network Node	165
174.	Token-Ring Definition for the 3174-11R	168
175.	Ring Address Assignment	168
176.	APPN Node Definition	169
177.	Network Resources	171
178.	Associated LUs	172
179.	COS Definition	172
180.	Correlating Mode Names with COS Table Names	174
181.	Enabling 3174 Peer Communication Functions	176
182.	Parameters for the Internal Bridge Function	177
183.	Network Attributes of the AS/400	178
184.	Configuration Status	178
185.	Controller Description (C31742) 1 of 4	179
186.	Controller Description (CP31742) 2 of 4	179
187.	Controller Description (CP31742) 3 of 4	179
188.	Controller Description (CP31742) 4 of 4	180
189.	Device Description (PS2COAX) 1 of 2	181
190.	Device Description (PS2COAX) 2 of 2	181
191.	Communications Manager/2 Installation and Setup	182
192.	Communications Manager Setup	183
193.	Open Configuration	183
194.	Communications Manager/2 Configuration Definition for 5250 Emulation	184
195.	Communications Manager Profile List Sheet	185
196.	Token-Ring or Other LAN Types DLC Adapter Parameters	185
197.	Local Node Characteristics	186
198.	SNA Features List	186
199.	5250 Emulation	187
200.	LAN Adapter and Protocol Support	188
201.	Configure LAN Transports	188
202.	Configure Workstation	189
203.	Network Adapter Address	189
204.	LAN Adapter and Protocol Support	190
205.	Display of Nodes Adjacent to the 3174-11R.	191
206.	AEA and TCP/IP Configure Panel	198
207.	Port Set Panel	198
208.	Port To Port Set Map Panel	200
209.	AEA and TCP/IP Station Set Panel (1 of 2)	200
210.	AEA and TCP/IP Station Set Panel (2 of 2)	201
211.	AEA and TCP/IP Default Destination Panel	202
212.	TCP/IP Options Menu	202
213.	TCP/IP Routing Information	203
214.	TCP/IP Domain Name Services	204
215.	TCP/IP 3174 Defined Nicknames	205

216.	AEA and TCP/IP Configure Complete	205
217.	Selecting Emulation for AS/400	206
218.	Command and Destination	206
219.	AS400 Sign On Screen	207
220.	AS/400 Main Menu	207
221.	Display 3174-Peer Status	208
222.	TCP/IP to DEC VAX and AS/400 Hosts	209
223.	Customize Control Disk Menu	211
224.	Enabling 3174 Peer Communication Functions	212
225.	AEA and TCP/IP Configure Panel	213
226.	Port Set Panel	214
227.	Port to Port Set Map Panel	215
228.	AEA and TCP/IP Station Set Panel	215
229.	AEA and TCP/IP Station Set Panel	216
230.	AEA and TCP/IP Default Destination Panel	217
231.	TCP/IP Options Menu	217
232.	TCP/IP Routing Information	218
233.	TCP/IP Domain Name Services	219
234.	TCP/IP 3174 Defined Nicknames	220
235.	SMIT TCP/IP	221
236.	Further Configuration	221
237.	Static Routes	222
238.	Add Static Route	222
239.	Command Status	223
240.	Selecting Connection to VAX Host	224
241.	TELNET Connection to VAX host	224
242.	TELNET Cession to VAX host	225
243.	NCU Configuration	230
244.	Gateway Configuration	230
245.	APPN Configuration	231
246.	TCP/IP Configuration	232
247.	Frame Format	233
248.	Frame Format Discovery for TCP/IP	237
249.	Hardware Configuration Table	246
250.	Model / Attach	249
251.	Model / Attach	249
252.	Ethernet Description Panel	251
253.	Local Area Network Panel	253
254.	Common Network	254
255.	Common Network	254
256.	3174 Test Menu	256
257.	LAN Test Menu	257
258.	LAN Test Menu	257
259.	Monitor LAN Status	258
260.	Ethernet Adapter Status Summary	259
261.	Link Status Test	260
262.	3270 Host Status Summary	261
263.	Link Status	261
264.	3174 TCP/IP in a LAN	264
265.	TCP/IP Protocols Provided by the 3174	269
266.	3174 Processing for ASCII TELNET and TN3270	272
267.	3174 LPD Support	273
268.	Printer Queue Validation Flow	275
269.	AEA and TCP/IP Configure Panel	291
270.	AEA and TCP/IP Station Set Panel	292

271.	AEA and TCP/IP Station Set Panel	293
272.	AEA and TCP/IP Default Destination Panel	294
273.	TCP/IP Options Menu	294
274.	3174 LPD Support	295
275.	AEA and TCP/IP Station Set Panel	296
276.	AEA and TCP/IP Default Destination Panel	297
277.	TCP/IP Options Menu	297
278.	TCP/IP Configuration	298
279.	TCP/IP Configuration Configure Services Page 1 of 3	298
280.	TCP/IP Configuration Configure Services Page 2 of 3	299
281.	TCP/IP Configuration Configure Services Page 3 of 3	300
282.	Closing TCP/IP Configuration	300
283.	Network Services	301
284.	Printer Services	302
285.	AS/400 Main Menu	303
286.	Communications	304
287.	Network Configuration	304
288.	Configure Communications and Remote Hardware	305
289.	Configure TCP/IP	305
290.	Work with TCP/IP Links	306
291.	Display TCP/IP Link	306
292.	Configure TCP/IP	307
293.	Work with TCP/IP Host Table Entries	307
294.	Communications	308
295.	Network Management	308
296.	TCP/IP Administration	309
297.	TCP/IP Administration	309
298.	TCP/IP Administration	310
299.	Send TCP/IP Spooled File SNDTCPSPLF	310
300.	TCP/IP Administration	311
301.	RISC System/6000	312
302.	System Management (SMIT Text Interface)	312
303.	Spooler Print Jobs	313
304.	Manage Local Printer Subsystem	313
305.	Add a Local Queue	313
306.	Queue to Change / Show	314
307.	Change / Show Characteristics of a Queue	314
308.	Local Printer Queues	315
309.	QUEUE Name	315
310.	Start a Queue	315
311.	Command Status Panel	316
312.	Spooler Print Jobs	316
313.	Manage Remote Printer Subsystem	316
314.	Client Services	317
315.	Queue to Change / Show	317
316.	Change / Show Characteristics of a Queue	318
317.	Manage Remote Printer Subsystem	318
318.	Server Services	318
319.	lpd Remote Printer Subsystem	319
320.	Start Using the lpd Subsystem	319
321.	Spooler Print Jobs	319
322.	Start a Print Job	320
323.	Command Status Panel	320
324.	Login at HP Host	321
325.	System Administrations Manager (SAM) Panel	322

326.	Printer/Plotter Menu Bar	322
327.	Printer/Plotter Manager	323
328.	Add Remote Printer/Plotter	323
329.	Add Remote Printer/Plotter	324
330.	Enable Printer/Plotter	325
331.	Printer/Plotter Status	325
332.	Start Up Print Spooler	326
333.	Print Spooler Running	326
334.	TELNET with HP Workstation	327
335.	Login at HP Host	327
336.	Ping Command to SunOS Host	328
337.	TELNET with SunOS Host	328
338.	Login to SunOS Host	329
339.	Ipc Program	330
340.	TN3270 to MVS Host	331
341.	AEA and TCP/IP Station Set Panel	332
342.	AEA and TCP/IP Default Destination Panel	333
343.	TCP/IP Options Menu	333
344.	TCP/IP Routing Information	334
345.	TCP/IP Domain Name Services	334
346.	Connection Menu Immediately after 3174 IMLed	335
347.	Connection Menu after 3174 Becomes Active and Enter Pressed	335
348.	TELNET Local Mode	336
349.	NETVIEW ACCESS	336
350.	Application Selection	337
351.	TSO Logon	337
352.	ISPF/PDF Primary Option Menu	338
353.	ISPF/PDF Primary Option Menu	338
354.	TSO Command Processor	339
355.	TSO Command Processor	339
356.	netstat devlinks	339
357.	TN3270 to RS/6000 Host	340
358.	AEA and TCP/IP Station Set Panel	341
359.	AEA and TCP/IP Default Destination Panel	341
360.	TCP/IP Options Menu	342
361.	TCP/IP Routing Information	342
362.	TCP/IP Domain Name Services	343
363.	TCP/IP 3174 Defined Nicknames	343
364.	cicsteld Protocol	345
365.	TCP/IP Port Number	346
366.	Connection Menu after 3174 Becomes Active and Enter pressed	346
367.	TELNET Local Mode	347
368.	Checking User	347
369.	Searching Available Regions	347
370.	Available CICS Regions	347
371.	Connect to Region	348
372.	CESN - CICS Signon Screen	348
373.	Inquire Task	349
374.	3174 Frame Relay Communications Feature	351
375.	Model / Attach	353
376.	Frame Relay Connection Parameter	354
377.	Frame Relay Connection Parameter	354
378.	Frame Relay Description	355
379.	B-1. Ethernet Address	359
380.	B-2. Example of Address with the Leftmost Bit Transmitted First	359

381. B-3. An Example of How an Ethernet Address is Converted . . . . . 361

---

## Tables

1.	Function Availability Matrix	2
2.	3174 TCP/IP Telnet RPQ Storage Requirements	15
3.	3174-Peer Online Test Updates Allowed	111
4.	Alternative Configurations	228
5.	3174 CS-C4 TCP/IP TELNET Storage Requirements	228
6.	Transmission Table for SNA Frame Format Discovery	239
7.	10base-5 AUI Connector Pin Assignment	245
8.	10base-T RJ-45 Connector Pin Assignment	246
9.	TCP/IP Enhancements RPQ Storage Requirements	267
10.	ASCII Control Codes for 3270 Printers	274
11.	LPD Commands	277
12.	LPD Control File Commands	278
13.	Customization Error Messages	357
14.	Address Conversion Table	360



---

## Special Notices

This publication is intended to help IBM and customer system engineers, system planners, system programmers and network administrators implement the TCP/IP TELNET Support and Peer Support provided by the 3174 Network Controller Configuration Support-C Licensed Internal Code. The information in this publication is not intended as the specification of any programming interfaces that are provided by 3174 Network Controller Configuration Support-C Licensed Internal Code. See the PUBLICATIONS section of the IBM Product Announcement (193-121) for the IBM 3174 Establishment Controller Networking Enhancements for more information about what publications are considered to be product documentation.

References in this publication to IBM products, programs or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM product, program, or service is not intended to state or imply that only IBM's product, program, or service may be used. Any functionally equivalent program that does not infringe any of IBM's intellectual property rights may be used instead of the IBM product, program or service.

Information in this book was developed in conjunction with use of the equipment specified, and is limited in application to those specific hardware and software products and levels.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Licensing, IBM Corporation, 208 Harbor Drive, Stamford, CT USA 10577.

The information contained in this document has not been submitted to any formal IBM test and is distributed AS IS. The information about non-IBM (VENDOR) products in this manual has been supplied by the vendor and IBM assumes no responsibility for its accuracy or completeness. The use of this information or the implementation of any of these techniques is a customer responsibility and depends on the customer's ability to evaluate and integrate them into the customer's operational environment. While each item may have been reviewed by IBM for accuracy in a specific situation, there is no guarantee that the same or similar results will be obtained elsewhere. Customers attempting to adapt these techniques to their own environments do so at their own risk.

The following terms, which are denoted by an asterisk (\*) in this publication, are trademarks of the International Business Machines Corporation in the United States and/or other countries:

ACF/VTAM	AIX
APPN	AS/400
CICS/6000	IBM
OS/2	Presentation Manager
PS/2	RISC System/6000
RS/6000	VTAM

Other trademarks are trademarks of their respective companies.





---

## Preface

The 3174 Establishment Controller is a very important component in multi-protocol networks involving subarea SNA, Advanced Peer-to-Peer Networking (APPN), Peer Communication, Token-Ring and Ethernet LANs, X.25, Integrated Services Digital Network (ISDN), asynchronous communication, frame relay, and Transmission Control Protocol/Internet Protocol (TCP/IP).

This document focuses on the roles of the 3174 in TCP/IP networks. It includes functions introduced by the 3174 TCP/IP TELNET RPQ 8Q0935, enhancements such as TN3270, TCP/IP host printer, and SNMP MIB-II support offered by 3174 TCP/IP Enhancements RPQ 8Q1041 and the recently available IP Forwarding RPQ 8Q1289.

This document is intended to help customers and systems engineers understand the functionality provided and how to customize the 3174 for participation in a TCP/IP network. It is organized to help the reader understand the basics of the TCP/IP Architecture in general and the 3174 implementation specifically. The scenarios include sample configuration files and panels for the 3174 and other TCP/IP hosts in the network. The reader is assumed to have a basic knowledge of TCP/IP as implemented by the other products used in the scenarios.

---

## How This Document is Organized

The document is organized as follows:

- Chapter 1, "An Introduction to 3174 TCP/IP Support" on page 1
  - This chapter gives a functional overview of 3174 TCP/IP support. It also contains a description of the TCP/IP architecture.
- Chapter 2, "3174 TCP/IP Telnet Support" on page 9
  - This chapter provides information on how to implement the 3174 to support TCP/IP.
- Chapter 3, "Adding 3174 to TCP/IP Network" on page 19
  - This chapter describes the terminal operation with 3174 TCP/IP TELNET support what is required to add the 3174 to a TCP/IP network.
- Chapter 4, "Scenario 1: TCP/IP Using 3174 Peer Communication Only" on page 67
  - This scenario shows how a PS/2 workstation, coax-attached to a 3174 Establishment Controller, can communicate with other TCP/IP host on the LAN via the 3174 Peer Communications bridge.
- Chapter 5, "Scenario 2: Concurrent Access to SNA and TCP/IP Hosts" on page 119
  - This scenario shows a RS/6000 workstation using the 3174 Gateway to access the 3270 SNA host while the 3270 coax-attached terminal use the 3174 TCP/IP TELNET client support to access the RS/6000 as a TCP/IP host.
- Chapter 6, "Scenario 3: APPN and TCP/IP via 3174 to AS/400 and VTAM" on page 159

- This chapter (Scenario 3) shows the capability of a PS/2 EN utilizing an 3174 NN to communicate to an AS/400 NN and Subarea Node simultaneously. An 3270 CUT terminal using the 3174 Gateway to establish TCP/IP session with the TCP/IP on the AS/400 and establish a session with the SNA host.
- Chapter 7, “Scenario 4: TCP/IP via 3174 and RS/6000 Router to VAX” on page 209
  - This chapter (Scenario 4) shows the capability of a PS/2 and 3270 3270 CUT terminal using the 3174 Gateway to establish a TCP/IP session to the VAX host which is connected via Ethernet on the RS/6000 router. Simultaneously the PS/2 and the 3270 CUT terminal using the 3174 Gateway to establish a TCP/IP session to an AS/400 host.
- Chapter 8, “3174 Ethernet Considerations” on page 227
  - This chapter discusses, in general, the 3174 Ethernet support. This include the microcode, adapter and customization.
- Chapter 9, “3174 TCP/IP Enhancements RPQ 8Q1041” on page 263
  - This chapter discusses the enhancements made to the 3174 TCP/IP support in the 3174 TCP/IP Enhancements RPQ 8Q1041.
- Chapter 10, “3174 Configuration Support C, Release 5” on page 351
  - This chapter discusses the ability to for the 3174 to communicate using TCP/IP protocol over a frame relay link, provided in Configuration Support-C Release 5
- Appendix A, “Address Bit Order for Ethernet Addresses” on page 359
  - This Appendix discusses addressing issues when using 3174 Ethernet support.
- Appendix B, “SNMP Variables” on page 363
  - This Appendix contains a table of the SNMP variables supported by the 3174.

---

## Related Publications

The publications listed in this section are considered particularly suitable for a more detailed discussion of the topics covered in this document.

- *3174 Establishment Controller Functional Description*, GA23-0218
- *3174 Establishment Controller Configuration Support-C Release 3 Planning Guide*, GA27-3918
- *3174 Establishment Controller Configuration Support-C Release 3 Utilities Guide*, GA27-3920
- *3174 Establishment Controller Status Codes*, GA27-3832
- *3174 Establishment Controller Supplemental Customer Information for Configuration Support-C Release 4 Ethernet Adapter*, GA27-3994
- *3174 Establishment Controller Customer Problem Determination*, GA23-0217
- *3174 Establishment Controller Terminal User's Reference for Expanded Functions*, GA23-0332
- *Communications Manager/2 Configuration Guide*, SC31-6171

- *IBM Transmission Control Protocol/Internet Protocol Version 2.0 for OS/2: User's Guide*, SC31-6076
- *NTS/2 LAN Adapter and Protocol Support Configuration Guide*, S96F8489
- *IBM Transmission Control Protocol/Internet Protocol Version 2.1.1 for DOS: Installation and Administration*, SC31-7047
- *IBM Transmission Control Protocol/Internet Protocol Version 2.1.1 for DOS: User's Guide*, SC31-7045
- *AIX Version 3 RISC System/6000, Communication Concepts and Procedure*, GC23-2203
- *AIX System Management System/6000, Communication Concepts and Procedure*, GC23-2487
- *Sun Microsystems System and Network Administration*, 800-3805-10
- *HP-UX System Administration Manual, Release 9.0*, 800-3805-10

---

## International Technical Support Organization Publications

- *3174 Establishment Controller, Installation Guide*, GG24-3061
- *3174 Establishment Controller APPN Implementation Guide*, GG24-3702
- *IBM Personal Communication/3270 Version 3.0 Implementation Guide*, GG24-3949
- *IBM TCP/IP V2.1 for VM Installation and Interoperability*, GG24-3624
- *TCP/IP Tutorial and Technical Overview*, GG24-3531

A complete list of International Technical Support Organization publications, with a brief description of each, may be found in:

*Bibliography of International Technical Support Organization Technical Bulletins*, GG24-3070.

To get listings of ITSO technical bulletins (redbooks) online, VNET users may type:

TOOLS SENDTO WTSPOK TOOLS REDBOOKS GET REDBOOKS CATALOG

### How to Order ITSO Technical Bulletins (Redbooks)

IBM employees in the USA may order ITSO books and CD-ROMs using PUBORDER. Customers in the USA may order by calling 1-800-879-2755 or by faxing 1-800-284-4721. Visa and Master Cards are accepted. Outside the USA, customers should contact their local IBM office.

Customers may order hardcopy redbooks individually or in customized sets, called GBOFs, which relate to specific functions of interest. IBM employees and customers may also order redbooks in online format on CD-ROM collections, which contain the redbooks for multiple products.

---

## Acknowledgments

The advisor for this project was:

Fran Collins  
International Technical Support Organization, Raleigh

The author of this document is:

Josef Minderlein  
IBM Germany

This publication is the result of a residency conducted at the International Technical Support Organization, Raleigh.

Thanks to the following people for the invaluable advice and guidance provided in the production of this document:

Tony Tan  
IBM Australia

Cathy Cunningham  
David Clark  
David Galloway  
3174 Development  
Research Triangle Park, Raleigh

Rita Steffes-Hollaender  
Andrea Paravan  
IBM Germany

Thanks to the following people for the invaluable editorial advice and guidance provided in the production of this document:

Shawn Walsh  
Gail Wojton  
Janet Yoho  
International Technical Support Organization, Raleigh

---

## Chapter 1. An Introduction to 3174 TCP/IP Support

Transmission Control Protocol/Internet Protocol (TCP/IP) is a set of standards that have been widely accepted by the computer industry, both users and manufacturers, for communication between multivendor systems.

The 3174, traditionally a cluster controller for 3270 host devices, was enhanced with the TCP/IP Telnet client capability to allow 3270 displays operating in CUT mode, and ASCII displays attached to the Asynchronous Emulation Adapter (AEA), to access TCP/IP Telnet servers in TCP/IP networks. This capability was offered, in March 1992, as a no-charge 3174 TCP/IP Telnet RPQ 8Q0935, based on Configuration Support-C Release 2 LIC.

In May 1993, Configuration Support-C Release 3 was announced. Its base microcode includes the base functions of previous releases of 3174 Licensed Internal Code. In addition, the functions provided by the 3174 TCP/IP Telnet RPQ 8Q0935 are now integrated in the base functions of Configuration Support-C Release 3. This integrated capability is referred to as the *3174 TCP/IP Telnet Support* in this document. Configuration Support-C Release 3 became available in June 1993.

In May 1993, Configuration Support-C Release 4 was also announced. Included in this announcement was the 3174 TCP/IP Enhancements RPQ 8Q1041, which provides TN3270 support, TCP/IP-dependent host printer support, and SNMP MIB-II support. This RPQ, available as of April 1994, combines the token-ring support of Configuration Support-C Release 3 with the Ethernet support of Configuration Support-C Release 4.

Currently the 3174 performs the function of a bridge for TCP/IP hosts that are coax-attached using the 3174 Peer Communications support. In this case there is no routing of IP traffic being done by the 3174. RPQ 8Q1289, scheduled for July 1994, expands the 3174 services of programmable workstation running TCP/IP by providing IP forwarding, via static routing.

This document focuses on the TCP/IP functions provided by the Configuration Support-C Release 3 and Configuration Support-C Release 4 base microcode and the RPQ 8Q1041. A brief discussion on TCP/IP support in Configuration Support-C Release 5 has been included to assist in doing some preliminary planning.

This chapter provides an overview of TCP/IP, and briefly describes the TCP/IP protocols supported by the 3174. This chapter uses material from the following document:

- *TCP/IP Tutorial and Technical Overview*, GG24-3531

---

### 1.1 3174 Functional Overview

The following table is an overview of the functionality available in the different 3174 Configuration Support C microcode releases and RPQs.

**Table 1. Function Availability Matrix**

Function	T/R	APPN	Peer	ISDN	Enet	Frame Relay	Telnet	TN3270 LPD MIB-2	Date
C2	Y	Y	Y	Y	N	N	N	N	now
RPQ 8Q0935	Y	Y	Y	Y	N	N	Y	N	now
C3	Y	Y	Y	Y	N	N	Y	N	now
C4	N	Y	Y	Y	Y	N	Y	N	12/93
RPQ 8Q1041	Y	Y	Y	Y	Y	N	Y	Y	04/94
C5	Y	Y	Y	Y	Y	Y	Y	N	06/94
RPQ 8Q1289	Y	Y	Y	Y	Y	Y	Y	Y	07/94

**Note:** With Configuration Support-C Release 2 the End-User Productivity Enhancements became available, which are described in *IBM 3174 Establishment Controller Installation Guide, GG24-3061-04*.

---

## 1.2 TCP/IP Overview

TCP/IP includes a set of network standards specifying the details for computer communication, as well as a set of conventions for interconnecting networks and routing traffic. Its primary use is for interconnection of networks providing universal communication services. The collection of these networks interconnected through TCP/IP is known as an *internet*.

Each network uses a gateway, a bridge or a router to connect into an internet. All nodes on all networks within an internet communicate with each other as if all other nodes were in the same network. TCP/IP connectivity includes routing capabilities for both local area and wide area networks.

When TCP/IP is used on a token-ring network, all the normal token-ring network management functions are available because token-ring network management is independent of the higher-level protocol. This applies as well to environments using an SNA network as the transport mechanism for TCP/IP.

In today's multivendor and multiprotocol world, SNA networks and TCP/IP networks need to run side by side to allow users to access, from a single display station, any application in the network.

Together with the 3174 TCP/IP Telnet Support, the 3174 is now able to support TCP/IP environments via the token-ring network.

---

## 1.3 TCP/IP Architecture

This section briefly describes the TCP/IP architectural layers supported by the 3174 TCP/IP Telnet Support.

The internet protocols are modeled into four functional layers:

- Application

This is a user process cooperating with another process on the same or different host.

- Transport

This layer provides the end-to-end data transfer.

- Internetwork

This layer provides the "virtual network" image of internet and shields the higher levels from the network architecture below it. It is probably the most important protocol.

- Network Interface

This layer is the interface to the actual network hardware.

### 1.3.1 Transmission Control Protocol (TCP)

Most of the user application protocols, such as Telnet and FTP, use TCP as the underlying protocol. TCP is a connection-oriented, end-to-end reliable protocol providing logical connections between pairs of processes.

For applications making use of this protocol, TCP provides the following:

- Stream data transfer



From the application's viewpoint, TCP transfers a contiguous stream of bytes through the internet. First it groups the data into TCP segments, before passing the segments to IP for transmission to its destination.

- Reliability

TCP assigns a sequence number to each transmitted byte and expects a positive acknowledgment (ACK) from the receiving TCP. If the ACK is not received within a timeout interval, the data is retransmitted.

- Flow control

The receiving TCP, when sending an ACK back to the sender, indicates to the sender the number of bytes it can receive beyond the last received TCP segment, without causing overruns or overflows.

- Multiplexing

With this technique datagrams are directed through the use of ports.

- Logical connections

The reliability and flow control mechanism described above requires that TCPs initialize and maintain certain status information for each "data stream." The combination of this status, including sockets, sequence numbers and window sizes, is called a logical connection (or virtual circuit). Each connection is uniquely identified by the pair of sockets used by the sending and receiving process.

- Full-duplex

TCP provides for concurrent data streams in both directions.




Figure 1. TCP Logical Connections

### Establishing a TCP Connection

Before any data can be transferred, a connection has to be established between the two processes. One of the processes issues a "passive OPEN" call, the other an "active OPEN" call. The passive OPEN call remains dormant until another process tries to connect to it by an active OPEN.




Figure 2. TCP Connection Establishment

This whole process is known as a three-way handshake. Note that the exchanged TCP segments include the initial sequence numbers from both sides to be used on subsequent data transfers.

Closing the connection is done implicitly by sending a TCP segment with the FIN bit set (no more TCP data). As the connection is full-duplex (two independent data streams, one in each direction), the FIN segment only closes the data transfer in one direction. The other process will now send the remaining data it still has to transmit and also ends with the TCP segment where the FIN bit is set. The connection is deleted once the data stream is closed in both directions.

### 1.3.2 Telnet

The Telnet protocol provides a standardized interface, which allows a program on one host (the Telnet client) to access the resources of another host (the Telnet server). One example of this would be an ASCII device on an ASCII host accessing an S/390 application with TCP/IP installed. Another example would be a 3270 CUT display attached to a 3174 with Configuration Support-C Release 3 installed and customized for TCP/IP Telnet support, accessing a RISC System/6000\* (or other TCP/IP Telnet server).

### 1.3.3 Internet Protocol (IP)

The Internet Protocol is the layer that hides the underlying physical network by creating a virtual network view. This is a connectionless protocol and hence offers no reliability, flow control or error recovery.

IP uses addresses to identify the source and target hosts on the internet. The internet (IP) address is 32 bits long and consists of two parts:

IP address = < network address > < host address >

The network part of the IP address identifies the network within the internet; the host part of the IP address identifies the individual host or gateway within that network. The division between the network and host parts of the IP address is determined by the first one to four bits of the IP address (see 3.1, "IP Addresses" on page 19).

The 32-bit IP address is usually represented in dotted decimal form w.x.y.z (for example, 9.67.38.87) for easy reference.

### 1.3.4 Internet Control Messaging Protocol (ICMP)

ICMP is a standard protocol. The IP is used for datagram services in an interconnected set of networks (internets). The network connection devices are IP gateways that exchange routing information between themselves using special TCP/IP protocols. ICMP functions are characterized as:

- ICMP uses IP as if it were a higher-level protocol. It is also an integral part of IP and is implemented in every IP module.
- ICMP is used to report errors found during datagram processing, and is used by:
  - The gateway
  - The destination host

### 1.3.5 User Datagram Protocol (UDP)

UDP is an application interface to IP. It serves as a “multiplexer/demultiplexer” for sending and receiving IP datagrams, using ports to direct the datagrams.




Figure 3. Using Ports to Direct Datagrams

Standard applications using UDP are:

- Trivial File Transfer Protocol
- Host Name Server and Domain Name Server
- Remote Procedure Call, used by Network File System (NFS)
- Network Computing System
- Simple Network Management Protocol (SNMP)

### 1.3.6 Address Resolution Protocol (ARP)

The ARP is responsible for converting the higher-level protocol addresses (IP addresses) to physical network addresses. On a single physical network, individual hosts are known on the network by their physical hardware address. Higher-level protocols address a destination host in the form of a symbolic address (IP address in the internet environment). When such a protocol wants to send a datagram to destination IP address w.x.y.z, the device driver does not understand this address.

Hence, ARP is used to translate this high-level address to the physical address of the destination host. ARP uses a lookup table to perform this translation. When an address is not found, a broadcast, known as an “ARP request,” is sent out onto the network. If one of the machines on the network recognizes this

address, an "ARP reply" is sent back to the requesting host with the physical hardware address of the host and source route information. This is then stored for future use.

### **1.3.7 Simple Network Management Protocol (SNMP)**

SNMP is used to communicate management information between the network management stations and the agents in the network elements.

### **1.3.8 Domain Name System**

The Domain Name System, through the use of a server application, provides the translation between high-level machine names and the IP addresses. The client function (called the resolver) is transparent to the user and is called by most of the other applications to resolve the symbolic high-level names into real IP addresses.

### **1.3.9 Packet Internet Groper (PING)**

PING is an application that sends out an ICMP datagram to a specified destination and waits for its return. The server counterpart merely echoes the frame it receives back to the originator. PING, therefore, can be used to determine if the destination host can be reached, that is, to check the connectivity path between two machines.

### **1.3.10 TCP/IP Gateways**

Gateways interconnect multiple networks to form an internet. In the IBM\* environment we use the following definitions for bridges, routers and gateways:

- **Bridge**

A bridge interconnects LAN segments at the data link layer and forwards frames between them. It performs the function of a MAC relay and is independent of any higher layer protocols.

- **Router**

A router interconnects networks at the network layer and route packets between them. Because it needs to understand the network addressing schemes used, a router is protocol-dependent. Routers are able to optimize packet sizes and transmission paths.

- **Gateway**

A gateway interconnects networks at higher layers than bridges or routers, ranging from the network layer to the application layer. It usually supports address mapping from one network to another.

In the TCP/IP environment, the terms "gateway" and "internet gateway" are used to qualify what is defined above as being a router.

---

## **1.4 TCP/IP Protocols Supported**

The 3174 supports the following protocols:

- Tel. (client only)
- TCP - Transmission Control Protocol
- IP - Internet Protocol

- ICMP - Internet Control Messaging Protocol
- UDP - User Datagram Protocol
- ARP - Address Resolution Protocol
- SNMP - Simple Network Management Protocol (MIB-I agent only)
- DNS - Domain Name System (resolver client only)
- PING - Packet Internet Groper

Figure 4 shows the protocols, within the detailed TCP/IP architectural model, supported by the 3174 TCP/IP Telnet Support.




Figure 4. Protocols Supported by the 3174 TCP/IP Telnet Support

The SNMP agent responds to requests for MIB variable information from an SNMP manager elsewhere in the network.

Using the 3174 TCP/IP Telnet Support, any dependent terminal that is attached to a 3174 can operate in Telnet mode. ASCII displays are supported via the AEA. Coax-attached 3270 displays operating in CUT or DFT-E mode are supported as VT100, VT220, IBM 3101 or DG 210 devices. These displays are supported as 24 x 80 full-screen devices. When accessing TCP/IP on an IBM host (for example, TCP/IP for MVS or VM), only line-by-line mode is supported. TN3270 operation, in which the IBM host sends a full-screen 3270 data stream to the display, is not supported by Configuration Support-C Release 3. TN3270 will be supported by the 3174 TCP/IP Enhancements RPQ 8Q1041 (see Chapter 9, "3174 TCP/IP Enhancements RPQ 8Q1041" on page 263).

---

## Chapter 2. 3174 TCP/IP Telnet Support

Existing IBM program products, TCP/IP for DOS and TCP/IP for OS/2\*, provide TCP/IP support for intelligent workstations. These workstations may be attached using a Token-Ring, IBM PC Network, Ethernet, 3174 Peer (LAN over COAX), or Asynchronous Serial Line Internet Protocol (SLIP). 3174 TCP/IP Telnet support, provides TCP/IP host access to CUT and ASCII terminals directly attached.

This chapter describes the 3174 TCP/IP Telnet Support, including the 3174 models supported, the customization required, and operational aspects of this capability. This chapter uses material from the following document:

- *3174 TCP/IP Telnet RPQ Diskettes Installation Instruction* (provided with the RPQ 8Q0935 package).

The 3174 TCP/IP Enhancements RPQ 8Q1041 and Configuration Support-C Release 5 enhancements are described, in later chapters.

---

### 2.1 Support before 3174 TCP/IP Telnet RPQ 8Q0935

With the addition of the Peer Communication LIC feature or the Peer Communication RPQ 8Q0718 in a 3174 that is attached to a Token-Ring, the intelligent workstations can be coax-attached to the 3174 and participate in TCP/IP networking. For this configuration, the workstations require the appropriate LAN-Over-Coax device drivers provided by the following:

- For DOS, Workstation Peer Communication Support Program
- For OS/2, Extended Services, OS/2 LAN Server or NTS/2

**Note:**

The DOS Workstation Peer Communications Support Program has been replaced with the NDIS compliant driver, IBMXLN.DOS.

The 3174, in this instance, provides nothing more than an internal ring and an internal bridge to allow the coax-attached workstations access to the Token-Ring; it has no TCP/IP capability and dependent (CUT, DFT-E or ASCII) terminals attached to the 3174 cannot participate in TCP/IP networking.

The TCP/IP hosts to be accessed by the intelligent workstations may be attached directly to the same Token-Ring, or they may be accessible through the Token-Ring via bridges or routers.

---

### 2.2 Support with 3174 TCP/IP Telnet RPQ 8Q0935

With the announcement of the 3174 TCP/IP Telnet RPQ 8Q0935 and Configuration Support-C Release 2 in March 1992, a new capability was added to a Token-Ring attached 3174: the 3174 could now be customized to provide TCP/IP Telnet client services to allow dependent (CUT, DFT-E or ASCII) terminals attached to the 3174 to communicate with TCP/IP Telnet servers.

With the 3174 TCP/IP Telnet RPQ 8Q0935, a dependent (CUT, DFT-E and ASCII) terminal attached to the 3174 can establish a TCP/IP Telnet connection with a TCP/IP host/server anywhere in the existing LAN/WAN network. The TCP/IP

hosts to be accessed by the dependent terminals may be attached directly to the same Token-Ring, or they may be accessible through the Token-Ring via bridges or routers.

Each terminal user can have up to five logical terminals (LTs) if Multiple Logical Terminal (MLT) is customized. These five LTs can be used to access 3270, ASCII or TCP/IP host sessions; that is, all five LTs may be used to access five 3270 host sessions, or five ASCII host sessions, or five TCP/IP host sessions, or some combination of 3270, ASCII and TCP/IP host sessions. The desired host connection can be selected by means of the Connection Menu, or established by default. Any LT can be used to access the TCP/IP "pipe," very much the same way that a dial-out AEA port is accessed. For each TCP/IP LT, a simple set of commands allows the user to request and operate a session with any TCP/IP host in the network.

As seen above, the 3174 TCP/IP Telnet RPQ 8Q0935 works in conjunction with MLT and AEA functions. You can also use the 3174 TCP/IP Telnet RPQ 8Q0935 concurrently with all other functions that a given 3174 is capable of, such as Peer Communication and APPN\*.

---

### **2.3 Support with Configuration Support-C Release 3**

In May 1993, Configuration Support-C Release 3 was announced. Its base microcode includes the base functions of previous releases of 3174 Licensed Internal Code. In addition, the functions provided by the 3174 TCP/IP Telnet RPQ 8Q0935 are now integrated in the base functions of Configuration Support-C Release 3. This integrated capability is referred to as the *3174 TCP/IP Telnet Support* in this document.

In other words, the TCP/IP capabilities provided by the 3174 TCP/IP Telnet RPQ 8Q0935 are now provided by Configuration Support-C Release 3 base microcode.

---

### **2.4 Support with 3174 TCP/IP Enhancements RPQ 8Q1041**

In May 1993, Configuration Support-C Release 4 was also announced. Included in this announcement was the 3174 TCP/IP Enhancements RPQ 8Q1041, which will provide TN3270 support, TCP/IP dependent host printer support, and SNMP MIB-II support. This RPQ, was made available April 1994, and is based on Configuration Support-C Release 4. With RPQ 8Q1041, therefore, the TCP/IP capabilities of the 3174 are extended even further.

---

### **2.5 Support with Configuration Support-C Release 5**

Configuration Support-C Release 5 and frame relay support expands the 3174 connectivity for 3174 TCP/IP support. Prior to Configuration Support-C Release 5 all TCP/IP access to and from the 3174 assumed LAN (token-ring or Ethernet). With Configuration Support-C Release 5, you are able to telnet to TCP/IP host in the network via frame wide area network links. As of the publication date of this document, 3174 TCP/IP Enhancements RPQ 8Q1041 was not available for Configuration Support-C Release 5.

---

## 2.6 Support with 3174 IP Forwarding RPQ 8Q1289

3174 IP Forwarding RPQ 8Q1289 enables intelligent workstation that are not directly attached to the 3174 using Peer Communications, access to TCP/IP hosts via the 3174 the frame relay link(s). The 3174 actually, provides static IP routing for LAN (token-ring or Ethernet) attached intelligent workstation running as TCP/IP hosts.

---

## 2.7 TELNET Emulation and NLS Support

The 3174 TCP/IP Telnet Support allows CUT terminals to have up to five TELNET sessions. The supported emulators for National Language Support (NLS) are:

- VT100
- VT220 7-bit

**Note:** IBM3101, DG210 and VT220 8-bit emulation are not supported for NLS

In our scenario, we have tested NLS for the German and Canadian/Bilingual languages. In TELNET session with the RISC System/6000, we use the SMIT (Systems Management Interface Tool) facility.

German NLS experience:

- VT100 emulation:
  - All PF keys useable.
  - Use Alt instead of Esc key.
- VT220 7-bit emulation:
  - SMIT panel displays OK.
  - All PF keys usable.

Canadian/Bilingual NLS experience:

- VT100 emulation:
  - All PF keys, except the PF8, PF9 and PF10 keys, are usable.
  - PF8, PF9 and PF10 keys only capable in conjunction with Esc key.
  - Use Alt instead of Esc key.
- VT220 7-bit emulation:
  - SMIT panel displays OK.
  - All PF keys usable.

**Note:** If you are using a PS/2\* with a 3270 CUT mode emulation program, you have to respond to 3174 customization Question 168 with 1. This function allows you to define the Home key as hot key.

Using this emulation will require you to define some additional keys. For more information about the different keyboard maps, see *Terminal User's Reference for Expanded Functions*, GA23-0332.



---

## 2.8 3174 Models Supported

The 3174 TCP/IP Telnet Support allows display devices that are attached to a 3174 to communicate with any TCP/IP host that is accessible via the LAN (token-ring or Ethernet). The TCP/IP host may be attached directly to the LAN (token-ring or Ethernet), or it may be bridged or routed to the LAN (token-ring or Ethernet) from elsewhere in the network.

The 3174 can be attached to a LAN (token-ring or Ethernet), either as a gateway, DSPU or stand-alone. Stand-alone requires no SNA host, and was first available in Configuration Support-C Release 4. For Configuration Support-C Release 3 and earlier versions the only way to customize the token-ring adapter was as a gateway or DSPU. Once you have the LAN (token-ring or Ethernet) attachment, the 3174 TCP/IP Telnet Support can be used on most models of the 3174.

### 2.8.1 Gateway 3174 Configuration

In a gateway configuration, the 3174 is attached to the SNA 3270 host either by a channel or a teleprocessing attachment. The 3174 gateway allows other devices on the LAN (token-ring or Ethernet) to access the 3270 host. The 3174 TCP/IP Telnet Support supports this configuration, allowing terminals that are attached to the 3174 gateway to access TCP/IP hosts via the LAN (token-ring or Ethernet).

The following 3174 models, customized as gateways, can be used with the 3174 TCP/IP Telnet Support; each of these 3174s requires a LAN adapter (IBM Token-Ring Adapter feature #3026, #3030 or #3044 or IBM Ethernet Adapter feature #3045):

- Models 01L, 01R, 02R
- Models 11L, 11R, 12L, 12R, 14R
- Models 21L, 21R, 22L, 22R, 24R
- Models 51R, 61R, 62R, 64R

One and only one LAN adapter can be customized and operational.

Figure 5 on page 13 shows a gateway configuration. In this configuration, the RISC System/6000 is using the 3174 gateway to access the 3270 host. The RISC System/6000, in turn, is being accessed as a TCP/IP host by the 3174 terminals. The token ring, in this case, can be replaced by an Ethernet LAN.




Figure 5. 3174 Gateway Configurations with 3174 TCP/IP Telnet Support

The 3174 provides the TCP/IP connection as an additional path for the user on a logical terminal (LT) basis. Each display may have up to five LTs which can be shared between the 3270 and the RISC System/6000 hosts.

## 2.8.2 DSPU 3174 Configuration

In a DSPU configuration, the 3174 uses the LAN (token-ring or Ethernet) to access SNA 3270 hosts. The 3174 TCP/IP Telnet Support allows dependent terminals that are attached to the 3174 DSPU to access TCP/IP hosts via the LAN (token-ring or Ethernet). Again, each display's LTs may be shared between the 3270 and the TCP/IP (RISC System/6000) hosts.

The following 3174 models are supported:

Each of these 3174s has an IBM Token-Ring Adapter as a standard feature:

- Models 3R, 13R, 23R, 53R and 63R

Each of these 3174s has an IBM Ethernet Adapter as a standard feature:

- Models 14R, 24R and 64R

The 3174 TCP/IP Telnet Support may also be used on a 3174 with a LAN (token-ring or Ethernet) adapter that is customized as a Model x3R or x4R, using the Alternate IML capability.

Figure 6 on page 14 shows a DSPU configuration. The 3174 DSPU must be customized for at least one SNA host attachment.




Figure 6. 3174 DSPU Configuration with 3174 TCP/IP Telnet Support

## 2.9 Devices Supported

The 3174 TCP/IP Telnet Support allows all displays that attach to the 3174, except DFTs, to operate in Telnet mode. The supported displays include the following:

- 3270 displays that are attached to the 3174 coax ports

These 3270 displays must be operating in CUT mode (CUT displays, or the CUT side of a DFT-E display). They are supported as DEC VT100, DEC VT200, IBM 3101, or DG Dasher 210 devices, using the ASCII emulation microcode for the 3174 (an AEA adapter is not required). NLS support for these devices is the same as that provided by the AEA.

The 3174 TCP/IP Telnet Support supports these devices in 24x80 mode only; the 132-column support for DEC VT220 provided in Configuration Support-C Release 2 is not available for the TCP/IP sessions.

- ASCII displays that are attached to the 3174 AEA ports

The 3174 TCP/IP Telnet Support negotiates support for the specific terminal type when setting up the Telnet connection. If the specific terminal support is not available, simple line mode is used (ANSITERM).

## 2.10 Hosts Supported

The 3174 TCP/IP Telnet Support connects the supported devices to any host or device attached to the network that can communicate with TCP/IP and Telnet protocols, including IBM and non-IBM hosts. The TCP/IP hosts may be attached directly to the LAN (token-ring or Ethernet), or they may be bridged or routed to the LAN (token-ring or Ethernet) from elsewhere in the network.

Access to IBM TCP/IP hosts (TCP/IP for VM or MVS), however, is limited to line mode only, when using base Configuration Support-C Release 3 or 4. This is because the 3174 TCP/IP Telnet Support currently available in the base Configuration Support-C Release 3 or 4 does not support TN3270 protocols. Support for TN3270 is available in 3174 TCP/IP Enhancements RPQ 8Q1041 (see Chapter 9, "3174 TCP/IP Enhancements RPQ 8Q1041" on page 263).

## 2.11 Storage Requirements

Table 2 shows the additional storage your 3174 must have for the 3174 TCP/IP Telnet Support. These additional requirements must be added to the amounts that are needed by your 3174 without TCP/IP.

	With AEA Customized	Without AEA Customized
Basic TCP/IP Telnet	231KB	362KB
Per session	7KB	
TCP/IP data buffers	See 2.11.2, "TCP/IP Data Buffers."	
Split Screen	If you expect to use split screen functions while accessing TELNET sessions, add 2 KB for each non-EAB Telnet LT and 4 KB for each EAB Telnet LT to your base MLT calculation.	
SNMP	50	

### 2.11.1 Sessions

When you customize for the 3174 TCP/IP Telnet Support, you must select the maximum number of concurrent Telnet connections you want to allow. This is given by your response to question 058 on the TCP/IP Options Menu. The 3174 creates a pool of session resources, available to terminal users on a first-come, first-served basis. They are not assigned to any particular 3174 terminal port or LT. Each session requires the amount of storage shown in the table.

### 2.11.2 TCP/IP Data Buffers

When you customize for the 3174 TCP/IP Telnet Support, storage is automatically reserved for 40 data buffers. Using customization question 060 on the TCP/IP Options Menu, you can include an additional amount of storage for data buffers. This additional amount should be included in your storage calculations.

A 3174 TCP/IP data buffer has roughly 100 bytes available for data. To determine how much storage your 3174 will need for these buffers, you should consider the types of host applications that your users will be accessing. For example, applications that send only one line at a time to the user's screen will use only one buffer at a time for a message. However, applications that send a

full screen of information with screen formatting controls included may send much larger messages, requiring many 3174 buffers at a time. Your decision will also be affected by the number of concurrent sessions you select in question 058.

When the 3174 runs out of buffers:

- The 3174 discards data from the TCP/IP network, causing retransmissions and adversely affecting response times.
- Requests to establish host connections will be rejected, and the users must retry to establish the connection.

---

## 2.12 Microcode Packaging

- RPQ 8Q0935 packaging

The information in this section is included for completeness.

The 3174 TCP/IP Telnet RPQ 8Q0935 is a Control/Utility/Extension disk RPQ. This means that you receive a complete set of 3174 diskettes with each order of the RPQ. It is based on Configuration Support-C Release 2 LIC and provides all Configuration Support-C Release 2 functions. Just as with other Configuration Support-C releases, any DSL or feature microcode must be merged onto the Control Extension diskette before the feature can be used.

**Notes:**

1. The 3174 TCP/IP Telnet RPQ 8Q0935 may not be compatible with other Configuration Support-C Release 2 RPQs. You should check with your IBM marketing representative if you have questions about RPQ compatibility.
2. The 3174 TCP/IP Telnet RPQ 8Q0935 should not be used in configurations that has the TCP/IP capability disabled (via customization).

- Configuration Support-C Release 3 packaging

The 3174 TCP/IP Telnet Support functions are integrated in Configuration Support-C Release 3, which is shipped as follows:

- One Utility diskette
- Two Control diskettes
- One Control Extension diskette

- Configuration Support-C Release 4 packaging

The 3174 TCP/IP Telnet Support functions are enhanced for Ethernet connectivity in Configuration Support-C Release 4, which is shipped as follows:

- One Utility diskette
- Two Control diskettes
- One Control Extension diskette

- 3174 TCP/IP Enhancements RPQ 8Q1041 packaging

The 3174 TCP/IP functions are enhanced in 3174 TCP/IP Enhancements RPQ 8Q1041, with TN3270, LPD and SNMP MIB-II, which is shipped as follows:

- One Utility diskette

- Two Control diskettes
- One Control Extension diskette (pre-merged)

**Notes:**

1. Depending on IBM business and technical judgements, the 3174 TCP/IP Enhancements RPQ 8Q1041 may be integrated into the Configuration Support-C base microcode in the future.
- Configuration Support-C Release 5 packaging  
Configuration Support-C Release 5 adds the additional connectivity option of frame relay to 3174 TCP/IP, which is shipped as follows:
    - One Utility diskette
    - Two Control diskettes
    - One Control Extension diskette(pre-merged)
    - One optional frame relay DSL
  - 3174 IP Forwarding RPQ 8Q1289 packaging  
3174 IP Forwarding RPQ 8Q1289 provides static IP routing for LAN (token-ring or Ethernet) attached intelligent workstations via 3174 frame relay link(s), which is shipped as follows:
    - One mergeable RPQ diskette



## Chapter 3. Adding 3174 to TCP/IP Network

Before you can customize your 3174 for the 3174 TCP/IP Telnet Support, you must assign an IP address and a TCP/IP host name to the 3174. If you are adding the 3174 to an existing TCP/IP network, you should get the name and address from the administrator of the network. A brief overview of IP addresses and network names is provided here; if you are unfamiliar with these TCP/IP concepts, see the *TCP/IP Tutorial and Technical Overview*.

### 3.1 IP Addresses

Each computer that attaches to the TCP/IP network is called a host, even though it may not provide functions you would normally attribute to a host. The 3174, for example, is a terminal server, but it is still called a TCP/IP "host."

Each host has a unique 32-bit IP address. These addresses are usually written as a series of four decimal numbers from 0 to 255, separated by periods, for ease of reference by humans (this is also known as dotted decimal notation). For example, a host address referred to as 9.67.7.218 is converted as follows:

Address in decimal:                    9        67        7        218  
Address in binary:                    00001001 01000011 00000111 11011010

The address always has two logical parts: the network address or identifier (ID) and the host ID. The bits at the beginning of the address determine how the address is split into its parts, as shown in Figure 7.




Figure 7. Classes of IP Addresses

In other words, an IP address can easily be classified by the first number in the dotted decimal notation as follows:

- Class A: first number between 1 and 127 (first byte 00000001 min. 01111111 max.)
- Class B: first number between 128 and 191 (first byte 10000000 min. 10111111 max.)
- Class C: first number between 192 and 223 (first byte 11000000 min. 11011111 max.)
- Class D: first number between 224 and 239 (first byte 11100000 min. 11101111 max.).

(An address of all 0s or all 1s has special meaning.)



We can see that 9.67.7.218 is a Class A address, with 9 (the first byte) as the network ID and 67.7.218 (the next three bytes) as the host ID.

You will, therefore, need an IP address for the 3174 being customized (see your system/network administrator).

---

## 3.2 Subnet Masks

A single TCP/IP network, however, can be further divided into multiple smaller networks, known as subnetworks or subnets. You may wish to divide a single large TPC/IP network at your organization into several subnets, for example, by department.

To identify these subnets, we use some of the host ID bits to form the subnet ID. A subnet mask determines which bits of the host ID will be used. The subnet mask contains a 1 for each bit of the IP address that is used for the network or subnet ID. For example, using a subnet mask of 255.255.255.0 and applying it to the address 9.67.7.218 yields the following:

Address in decimal:	9	67	7	218
Address in binary:	00001001	01000011	00000111	11011010
Subnet mask in binary:	11111111	11111111	11111111	00000000
Subnet mask in decimal:	255	255	255	0
Address interpretation:	Network ID	Subnet ID		Host ID

What this means is that:

- The first eight bits are used as the network ID (because it is a Class A address)
- The next 16 bits are used as the subnet ID (because of the 1 bits in the subnet mask)
- The last eight bits are used as the host ID (because of the 0 bits in the subnet mask).

If a different subnet mask is used, the bits are interpreted differently. For example, using a subnet mask of 255.255.240.0 and applying it to the address 9.67.7.218 yields the following:

Address in decimal:	9	67	7	218
Address in binary:	00001001	01000011	00000111	11011010
Subnet mask in binary:	11111111	11111111	11110000	00000000
Subnet mask in decimal:	255	255	240	0
Address interpretation:	Network ID	Subnet ID		Host ID

Now, what this means is that:

- The first eight bits are used as the network ID (as before).
- The next 12 bits are used as the subnet ID.
- The last 12 bits are used as the host ID.

Using subnet mask 255.255.255.0 on IP address 9.67.7.218 shows that the host is identified as being in network ID 9, subnet ID 17152, host ID 218. Using subnet mask 255.255.240.0 on the same IP address shows that the host is identified as being in network ID 9, subnet ID 1072, host ID 2010.

If your TCP/IP network is split into subnets, you will, therefore, have to know the subnet mask to use when you customize the 3174.

---

### 3.3 Customizing IP Addresses

Whenever you are asked to provide an IP address on the 3174 customization panels, you must give the full address, with leading zeros. The panels provide the "dots." For example, 9.67.7.218 is entered as:

009.067.007.218

When you enter a network or subnet address, you must provide all four parts of the address. For example, network 9 is entered as:

009.000.000.000

Subnet 9.67 is entered as:

009.067.000.000

---

### 3.4 Names

Since most people can remember names better than numeric addresses, TCP/IP allows you to assign names to each host. These names can be grouped into domains, so that they do not have to be unique across the entire network. For example, OURNET.OURDEPT.HOST1 is a different host from YOURNET.YOURDEPT.HOST1. When you customize the 3174 for the 3174 TCP/IP Telnet Support, you must give both a host name and a domain name. When appended, these give the fully-qualified name of your host in the network.

---

### 3.5 Name Servers

Unfortunately, most communication protocols including TCP/IP, do not work with character-string names very well and must instead use numeric addresses. To convert names to addresses, your network may have Domain Name Servers. These servers maintain tables of name-to-address correlations. A TCP/IP host can send a server a name, and the server returns the IP address assigned to that name. This means the hosts do not need to maintain extensive tables for name-to-address resolution, and only the server's table is updated when hosts are added to or deleted from the network.

---

### 3.6 3174 Nicknames

The 3174 TCP/IP Telnet Support allows you to define a set of nicknames for your users. You provide an IP address to associate with each nickname.


If your network does not have name servers, these nicknames can make life a little easier for your users, as they will not have to remember numeric IP addresses.

### 3.7 How the 3174 TCP/IP Telnet Support Looks at Names

A person sitting at a terminal attached to the 3174 may select the desired remote TCP/IP host by giving one of the following destinations:

- The host's IP address, in dotted decimal form
- A nickname
- An unqualified host name, different from any nicknames, if the remote host is in the same domain as the 3174
- A fully-qualified host name

The 3174 TCP/IP Telnet Support uses the destination as follows:



**Note:** The 3174 TCP/IP Telnet Support sends the query to the first server in the list and waits approximately two seconds for a response, before sending the query to the next server, if there is more than one. If no server responds, the 3174 repeats the process with a four-second timeout, then six seconds, then eight seconds.

Figure 8. TCP/IP Resolving Name/Destination

## 3.8 Routes

If your users want to access remote hosts that are on other networks or subnets, at least one TCP/IP router must be on the same subnet as your 3174. You will need to know the router's IP address when you customize for the 3174 TCP/IP Telnet Support, and this will be your default router. If there are other routers in your network, you can define these to the 3174, by giving their IP addresses and the destinations that they service.

The routes that you configure tell the 3174 the best way to get the TCP/IP traffic to the desired destinations. As an example, in Figure 9, the 3174's IP address is 9.67.5.80, and the subnet mask being used is 255.255.255.000. That means the network is 9, and 67.5 identifies the subnet. Router 2 connects the 3174's network to Network 10, Router 1 connects the 3174's subnet to subnet 67.4, and Router 3 provides access to all other external networks.




Figure 9. TCP/IP Router Example

In the 3174 customization, you would have three route entries for this configuration, telling the 3174 where to route traffic for destinations that are not part of the 3174's subnet:

1. For destinations on subnet 9.67.4 use Router 1, whose address on the local subnet is 9.67.5.1.
2. For destinations on network 10., use Router 2, whose address on the local subnet is 9.67.5.2.
3. For any other destinations that are not on the local subnet, use the default Router 3, with address on the local subnet of 9.67.5.3.

TCP/IP Routing Information		
Destination IP Address	Type (N,S,H,D)	Router IP Address
009 . 067 . 004 . 000	S	009 . 067 . 005 . 001
010 . 000 . 000 . 000	N	009 . 067 . 005 . 002
XXX . XXX . XXX . XXX	D	009 . 067 . 005 . 003
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 10. TCP/IP Router Example Customization

### 3.9 Customizing 3174 TCP/IP Telnet Support

In many respects, the 3174 TCP/IP Telnet Support can be thought of as providing ASCII host access across a TCP/IP network. Because of this similarity, customizing for the 3174 TCP/IP Telnet Support uses many of the concepts that were introduced with the AEA. If you are familiar with customizing for AEA, adding the 3174 TCP/IP Telnet Support will be very simple.

If you are not familiar with the AEA, and you are not installing an AEA in your 3174, the following explanations include suggested responses for many of the customization questions. These suggestions will result in a very simple configuration where all coax ports are set up the same. After you have done this once, you will be able to see how to change it if you want a different setup for some ports. Your coax-attached terminals will use the ASCII emulation function when connected to a TCP/IP host; therefore, the customization questions that affect ASCII emulation operation are the ones that you will have to answer.

For more information on AEA customization, refer to the *3174 Installation Guide*, GG24-3061.

#### 3.9.1 Example Scenario

In the example shown in Figure 11 on page 25, one important point must be emphasized regarding the 3174-11L channel-attached to MVS18. The 3174 does support TCP/IP access via the LAN (token-ring or Ethernet) on which it is resides (Configuration Support-C Release 5 adds frame relay as an additional transport). This means that the channel can be used for SNA traffic, but in order to access MVS18 as a TCP/IP host, the traffic must flow over the token ring. The 3172 will serve as a router to MVS18, making it possible for the 3174 to have a Telnet to MVS18.




Figure 11. TCP/IP Example Scenario

We will use this example as the basis for the 3174 customization that follows.

### 3.9.2 Panel Flow

Figure 12 shows the panel flow sequence when customizing the 3174 TCP/IP Telnet Support.




Figure 12. TCP/IP Customization Panel Flow

### 3.9.3 Configure AEA and TCP/IP

After you have IMLed your 3174 from a Utility diskette, select **Customize the Control Disk** from the Master Menu. The Customize Control Disk Menu panel is displayed (see Figure 13 on page 27).

```
_____ Customize Control Disk Menu _____

Select Option; press ENTER

Option      Description
  1         Configure
  2         Define Devices
  3         Merge RPQs
  4         Modify Keyboards
  5         Define AEA and TCP/IP
  6         Define APPN Node
  7         Define COS
  8         Define 3174-PEER

Select ==> 5

PF: 3=Quit  4=Default  7=Back  8=Fwd  9=Check  12=File
```

*Figure 13. Define AEA and TCP/IP Option*

Select Option 5 to configure the 3174 TCP/IP Telnet Support. The AEA and TCP/IP Menu panel is displayed (see Figure 14).

```
_____ AEA and TCP/IP Menu _____

Select Option; press ENTER

Option      Description
  1         Configure AEA and TCP/IP
  2         Define UDT
  3         Define UDX

Select ==> 1

PF: 3=Quit  4=Default  7=Back  8=Fwd  9=Check  12=Done
```

*Figure 14. Configure AEA and TCP/IP Option*

Select Option 1 to configure the 3174 TCP/IP Telnet Support. The AEA and TCP/IP Configure panel is displayed (see Figure 15 on page 28).



### 3.9.4 Enabling AEA and TCP/IP




Figure 15. AEA and TCP/IP Configure Panel

For a detailed description of each customizing question, see the *3174 Installation Guide*, GG24-3061. This section will highlight information relevant to customizing the 3174 TCP/IP Telnet Support.

#### Question 700: Configure the AEA and TCP/IP Feature

Question 700 has been changed from a one-digit response that allows the AEA feature to be customized, to a two-digit response that allows the AEA feature and the 3174 TCP/IP Telnet Support to be customized. The two digits are used as follows:

- **Digit 1 - AEA Feature**
  - 0 = Turns off the AEA feature (default response).
  - 1 = Turns on the AEA feature.
- **Digit 2 - TCP/IP Feature**
  - 0 = Turns off the TCP/IP feature (default response).
  - 1 = Turns on the TCP/IP feature without SNMP.
  - 2 = Turns on the TCP/IP feature with SNMP.

For our example, we have customized for both AEA and TCP/IP capabilities.

#### Question 702: Control Key Assignment

This question allows you to specify the control key when using ASCII emulation.

- 0 = Use the Alt key.
- 1 = Use the Ctrl key (default response).

If you select 0, the same end-user keyboard interface is provided as in 3174 Configuration Support-B Release 1.

**Notes:**

1. Option 0 is valid only for USA English.
2. If option 0 is selected, DEC VT220 and DG D210 emulation are not permitted.
3. When option 0 is selected, KDU mappings are ignored during ASCII emulation; the keyboard reverts to its normal layout.
4. The microcode upgrade process defaults this question to a 1 during upgrade from Configuration Support-B Release 2.

If you have never used the AEA feature before, use the default value.

**Question 703: Request MLT for AEA**

This question allows you to specify if you are using MLT on ASCII terminals. It is not affected by the 3174 TCP/IP Telnet Support.

- 0=No AEA MLT support (default response).
- 1=Request AEA MLT support.

**Questions 710 through 713: Miscellaneous ASCII Feature Options**

Each of these four questions has an eight-digit response. Each digit determines whether certain modes of operation are enabled or not enabled. The only one that you need to consider for the 3174 TCP/IP Telnet Support is question 710 digit 1: Reverse Video Blanks-to-Hyphens Option. For 3270 displays without EABs, specifying this digit as 1 causes reverse video blanks to be displayed as hyphens.

**3.9.5 Defining Port Set**

Port Set				
Name	Session Limit	Port Type	Modem Type	Password
1 = 3270DISP	5	1	-	_____
2 = 3163DISP	4	3	-	_____
3 = _____	-	-	-	_____
4 = _____	-	-	-	_____
5 = _____	-	-	-	_____
6 = _____	-	-	-	_____
7 = _____	-	-	-	_____
8 = _____	-	-	-	_____
9 = _____	-	-	-	_____
10 = _____	-	-	-	_____
11 = _____	-	-	-	_____
12 = _____	-	-	-	_____
13 = _____	-	-	-	_____
14 = _____	-	-	-	_____
15 = _____	-	-	-	_____
16 = _____	-	-	-	_____

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 16. Port Set Panel

If you have already customized for the AEA, you may not need to change this panel. If you want to allow 3270 displays to access TCP/IP destinations and the displays have not been included in a port set, then add them to this panel.

If you do not have an AEA, you should use this panel to define port set 1 for your 3270 displays to allow them to access TCP/IP destinations:

- Enter the name **3270DISP** in the Name field.
- Select a session limit that matches the number of LTs you want the 3270 displays to have (the default is 1). This number may be larger than the number of addresses assigned by questions 117 and 118.
- Enter a 1 in the Port Type field for our 3270 displays, where:
  - 1=3270 devices
  - 2=Switched (for ASCII devices connected via modems and switched lines)
  - 3=Direct (for ASCII devices connected via null modems)
  - 4=Non-Switched (for ASCII devices connected via modems and non-switched lines).
- Leave the Modem Type and Password fields blank.

For our example, we have customized a port set for coax attached 3270 displays and another port set for 3163 displays that are attached to the AEA via null modems.

### 3.9.6 Mapping Port to Port Set

\_\_\_\_\_ Port to Port Set Map \_\_\_\_\_

Page 01 of 03

Type the port set number to group the 3174 ports

3270 Ports	0	1	2	3	4	5	6	7
<b>26-00 to 26-07</b>	1	1	1	1	1	1	1	_
26-08 to 26-15	_	_	_	_	_	_	_	_
26-16 to 26-23	_	_	_	_	_	_	_	_
26-24 to 26-31	_	_	_	_	_	_	_	_

Port Sets	2 =	3 =	4 =
1 = 3270DISP	3163DISP		
5 =			
9 =			
13 =			

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=PageBack    11=PageFwd

Figure 17. Port to Port Set Map Panel (1 of 3)

If you have already customized for the AEA, you may not need to change this panel. If you have added a port set for 3270 displays in the Port Set panel, you will need to assign the 3270 ports to that new port set using this panel.

If you do not have an AEA, you should use this panel to assign coax ports to the port set, named 3270DISP, that you have defined in the Port Set panel:

- Enter the port set number for each port that you wish to use the 3174 TCP/IP Telnet Support. We have entered 1. This assigns that port to the 3270 display port set.

There are three pages for mapping ports to the port sets you have defined. The first page shows ports in hardware group 26, the first 32 coax ports. The second page shows ports in hardware group 27, the next 32 coax ports (provided by the 3270 Port Expansion Feature). The third page shows ports in hardware groups 21, 22 and 23, ASCII ports (provided by the AEA).

For our example, we have:

- Mapped the first seven coax ports to the port set number 1 (1=3270DISP) in Figure 17 on page 30.
- No ports are mapped for the 3270 Port Expansion Feature in Figure 18.
- Mapped the first seven ASCII ports to the port set number 2 (2=3163DISP) in Figure 19 on page 32.

Port to Port Set Map Page 02 of 03

Type the port set number to group the 3174 ports

3270 Ports	0	1	2	3	4	5	6	7
27-00 to 27-07	—	—	—	—	—	—	—	—
27-08 to 27-15	—	—	—	—	—	—	—	—
27-16 to 27-23	—	—	—	—	—	—	—	—
27-24 to 27-31	—	—	—	—	—	—	—	—

Port Sets			
1 = 3270DISP	2 = 3163DISP	3 =	4 =
5 =	6 =	7 =	8 =
9 =	10 =	11 =	12 =
13 =	14 =	15 =	16 =

All responses are correct  
 PF: 3=Quit 4=Default 7=Back 8=Fwd 10=PageBack 11=PageFwd

Figure 18. Port to Port Set Map Panel (2 of 3)

Port to Port Set Map

Page 03 of 03

Type the port set number to group the 3174 ports

AEA Ports	0	1	2	3	4	5	6	7
21-00 to 21-07	2	2	2	2	2	2	2	
22-00 to 22-07	—	—	—	—	—	—	—	—
23-00 to 23-07	—	—	—	—	—	—	—	—

Port Sets				
1 = 3270DISP	2 = 3163DISP	3 =	4 =	
5 =	6 =	7 =	8 =	
9 =	10 =	11 =	12 =	
13 =	14 =	15 =	16 =	

All responses are correct  
 PF: 3=Quit 4=Default 7=Back 8=Fwd 10=PageBack 11=PageFwd

Figure 19. Port to Port Set Map Panel (3 of 3)

### 3.9.7 Defining 3270 Host and Display Station Sets

AEA and TCP/IP Station Set

1	721 - 3270 HOST	722 - 3H	723 -	725 - 1
	731 - 1	732 - 1	733 - 0	734 -
	735 - 0	736 - 1	737 -	
	741 - 000	742 - 015	743 - 1	744 - 0
	745 - 0	746 - 0	0	
	751 -	752 -		
	761 - 1	762 - 1	763 - 1	764 - 1
	765 - 0			
	771 - 1	772 - 1	773 - 1	774 - 1
	775 - 1	776 - 1		
	781 - 0	782 - 0	783 - 066	784 - 1
	785 - 11111000	786 - 132	787 - 0	
	790 - 000 . 000 . 000 . 000			

2	721 - 3270 DISPLAY	722 - 3D	723 - 3270DISP	725 - 1
	731 - 1	732 - 1	733 - 0	734 -
	735 - 0	736 - 1	737 -	
	741 - 000	742 - 015	743 - 1	744 - 0
	745 - 0	746 - 0	0	
	751 -	752 -		
	761 - 1	762 - 1	763 - 1	764 - 1
	765 - 0			
	771 - 1	772 - 1	773 - 1	774 - 1
	775 - 1	776 - 1		
	781 - 0	782 - 0	783 - 066	784 - 1
	785 - 11111000	786 - 132	787 - 0	
	790 - 000 . 000 . 000 . 000			

PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

Figure 20. AEA and TCP/IP Station Set Panel (1 of 4)

If you have already customized for AEA, you will have defined station sets for the 3270 host and the 3270 displays that are attached to your 3174. You will still need to define station sets for TCP/IP access, so do not skip this panel. You may, however, proceed to 3.9.8, "Defining TCP/IP Station Sets" on page 33.

If you do not have an AEA, you should define two station sets, one for the 3270 host and one for the 3270 displays we have added. You will also need to define

station sets for TCP/IP access (see 3.9.8, "Defining TCP/IP Station Sets" on page 33). We will start by defining station set 1 for the 3270 host:

**Q721** Enter a station set name for the 3270 host to be accessed. Whatever name you enter here will be displayed on the Connection Menu as a possible destination for the LT. If your 3270 host has a common name that the terminal users will recognize, enter that name.

In our example, we have used the name 3270 HOST.

**Q722** Enter 3H as the station type for the 3270 host.

Leave all other questions at their default values.

Next, we will define station set 2 for the 3270 displays:

**Q721** Enter a station set name for the 3270 displays we have added in the Port Set panel.

**Q722** Enter 3D as the station type for the 3270 displays.

**Q723** Enter 3270DISP as the port set name (the name we defined on the Port Set panel) to which the 3270 displays will be mapped.

**Q725** Leave the response at its default value of 1.

This allows the terminal users to use the Connection Menu to select alternative host connections for an LT. After you are more familiar with Connection Menu operation, you may wish to change this to 0.

Response 0 means that the terminal users in this station set will not be allowed to select host connections from the Connection Menu; they are restricted to access only the connection defined in their Default Destination.

Leave all other responses at their default values.

### 3.9.8 Defining TCP/IP Station Sets

A station set for TCP/IP access defines a set of ASCII emulation characteristics and an optional host IP address. The 3174 TCP/IP Telnet Support supports the following ASCII terminal emulation:

- DEC VT100
- IBM 3101
- DG D210 (USA English only)
- DEC VT220, 7-bit control
- DEC VT220, 8-bit control

Each TCP/IP station set you define will be displayed on the host Connection Menu for the terminal user to select as a connection.

For each station set definition, you may specify an IP host address, or use the default response (all zeros), in question 790. Your response is used as follows:

- If you specify an address, the 3174 *does not* automatically connect to that address when the station set is selected from the Connection Menu. The address is used if the user issues a PING or an OPEN command without specifying a destination.

- If you do not specify an address (default all zeros), then the user will need to specify the destination when issuing the PING or the OPEN command.

So, if your users at the 3270 coax terminals will use the 3174 TCP/IP Telnet Support to access only one TCP/IP host and that host supports DEC VT100 devices, then you only need to define one TCP/IP station set (the DEC VT100 station set). You will specify that host's IP address in question 790 so that the users do not have to remember it. To access that host, the user selects the DEC VT100 station set from the Connection Menu, which puts the display into local mode, and then issues the OPEN command without specifying a destination.

If your users will access more than one hosts, you probably should define five TCP/IP station sets, one for each type of ASCII Emulation supported. This allows the users to select the required station set from the Connection Menu. Again, if you specify an address in question 790, it will be used when the user issues a PING or OPEN command without a destination. If you do not specify an address in question 790 (default all zeros), then the user will need to specify the destination when issuing the PING or OPEN command.

For our example, we have defined five station sets (station set numbers 3 through 7 in the following panels) for TCP/IP access. Station set number 3 also has a "default destination" customized in question 790. Station set number 8 defines 3163 displays that are attached to the 3174 AEA; they can also select the TCP/IP connections from their Connection Menu.

\_\_\_\_\_ AEA and TCP/IP Station Set \_\_\_\_\_

```

3 721 - TELNET VT100          722 - TH 723 - \          725 - 1
   731 - 1 732 - 1          733 - 0 734 - _ 735 - 0 736 - 1 737 - _
   741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
   751 - 1 752 - _____
   761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
   771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
   781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
   790 - 009 . 067 . 038 . 071

4 721 - TELNET IBM3101          722 - TH 723 -          725 - 1
   731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
   741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
   751 - 2 752 - _____
   761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
   771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
   781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
   790 - 000 . 000 . 000 . 000

All responses are correct
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

```

Figure 21. AEA and TCP/IP Station Set Panel (2 of 4)

To define each station set for TCP/IP access, respond to the following questions:

- Q721** Enter a station set name that you wish displayed on the Connection Menu.
- Q722** Enter TH as the station type for the TCP/IP host.

**Q751** Specify the data stream supported by the TCP/IP host:

- 1=DEC VT100
- 2=IBM 3101
- 3=DG D210 (USA English only)
- 4=DEC VT220, 7-bit control
- 5=DEC VT220, 8-bit control

Your response to this question only affects the operation of 3270 displays. It determines the type of ASCII emulation that the 3174 provides for the 3270 display when the user selects this station set as the destination. When the user at an ASCII terminal selects a TCP/IP destination, the value of this field is ignored.

**Q761** Respond only for VT100 or VT220 data stream, that is, if question 751=1, 4 or 5. The valid responses are:

- 0=Auto XON/XOFF disabled.,
- 1=Auto XON/XOFF enabled (default response).

**Q762** Respond only for VT100 or VT220 data stream, that is, if question 751=1, 4 or 5. The valid responses are:

- 0=Wraparound option disabled.
- 1=Wraparound option enabled (default response).

**Q763** Respond only for VT100 or VT220 data stream, that is, if question 751=1, 4 or 5. The valid responses are:

- 0=New line option disabled.
- 1=New line option enabled (default response).

Your response to this question depends on the host applications you will be using. If not answered correctly, characters may be placed in the wrong positions on the screen. When set to 1, the 3174 treats a line feed character from the host as a new line (line feed followed by carriage return).

**Note:** For connections to RS/6000\* hosts, question 763 should be 0.

**Q764** Respond only for VT100 or VT220 data stream, that is, if question 751=1, 4 or 5. The valid responses are:

- 0=Margin bell disabled.
- 1=Margin bell enabled (default response).

**Q765** Respond only for VT100 or VT220 data stream, that is, if question 751=1, 4 or 5. The valid responses are:

- 0=DEC host ASCII character set is NRC (default response).
- 1=DEC host ASCII character set is MCS.

**Q771** Respond only for IBM 3101 data stream, that is, if question 751=2. The valid responses are:

- 0=Automatic line feed disabled.
- 1=Automatic line feed enabled (default response).

The receipt of a carriage return from the host will cause a carriage return and a line feed at the terminal.



- Q772** Respond only for IBM 3101 data stream, that is, if question 751=2. The valid responses are:
- 0=Enter causes a carriage return only.
  - 1=Enter causes a carriage return and a line feed (default response).
- Q773** Respond only for IBM 3101 data stream, that is, if question 751=2. The valid responses are:
- 0=Automatic new line at column 80 disabled.
  - 1=Cursor automatically moves to the first position of the next line after reaching column 80 (default response).
- Q774** Respond only for IBM 3101 data stream, that is, if question 751=2. The valid responses are:
- 0=Scrolling disabled.
  - 1=Scrolling enabled (default response).
- Q775** Respond only for IBM 3101 data stream, that is, if question 751=2. The valid responses for the line turnaround character to be used are:
- 0=Use EOT (end of transmission).
  - 1=Use CR (carriage return) (default response).
  - 2=Use XOFF (transmit off).
  - 3=Use ETX (end of text).
- Q790** Enter the host IP address that is the default destination for the 3174. You may leave the response at its default value (all zeros). The user will need to specify the destination when issuing the PING or the OPEN command.
- If you do specify an address, the 3174 attempts to connect to that address as the default destination or when this station set is selected from the Connection Menu.

You can leave all other responses at their default values.

```

_____ AEA and TCP/IP Station Set _____

5 721 - TELNET D210                722 - TH 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 3 752 - _____
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

6 721 - TELNET VT220 7 BIT          722 - TH 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 4 752 - _____
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

All responses are correct
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

```

Figure 22. AEA and TCP/IP Station Set Panel (3 of 4)

```

_____ AEA and TCP/IP Station Set _____

7 721 - TELNET VT220 8 BIT          722 - TH 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 5 752 - _____
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

8 721 - 3163 DISPLAY                722 - I3 723 - 3163DISP 725 - 1
731 - 1 732 - 1 733 - 6 734 - _ 735 - 1 736 - 1 737 - _
741 - 000 742 - 015 743 - 0 744 - 0 745 - 2 746 - 0 0
751 - _ 752 - _____
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

All responses are correct
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

```

Figure 23. AEA and TCP/IP Station Set Panel (4 of 4)

### 3.9.9 Defining Default Destinations

AEA and TCP/IP Default Destination							
Station Set	Station Set Name	Session Limit	Session				
			LT1	LT2	LT3	LT4	LT5
1	3270 HOST	0	---	---	---	---	---
2	3270 DISPLAY	5	---	---	---	---	---
3	TELNET VT100	0	---	---	---	---	---
4	TELNET IBM3101	0	---	---	---	---	---
5	TELNET D210	0	---	---	---	---	---
6	TELNET VT220 7 BIT	0	---	---	---	---	---
7	TELNET VT220 8 BIT	0	---	---	---	---	---
8	3163 DISPLAY	4	---	---	---	---	---
9		0	---	---	---	---	---
10		0	---	---	---	---	---
11		0	---	---	---	---	---
12		0	---	---	---	---	---
13		0	---	---	---	---	---
14		0	---	---	---	---	---
15		0	---	---	---	---	---

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=Page Back    11=Page Fwd

Figure 24. AEA and TCP/IP Default Destination Panel

This panel determines what the terminal user will see on each LT when it is first accessed. You specify default destinations only for station sets that represent devices; you do not specify default destinations for host station sets. If you have already customized for the AEA, you should make changes here only if you want a TCP/IP session to be the default destination. If you are not using the AEA, what you enter here will affect your end users as follows:

- If you select the 3270 host station set as the default destination, the LT is initially assigned to the 3270 host. You should do this if you do not want things to look different to your users after you have installed the 3174 TCP/IP Telnet Support.
- If you select a TCP/IP host station set as the default destination, the LT is initially assigned to TCP/IP and the user will see the following prompt at the top of the screen:  
**3174 TELNET>**
- If you select the Connection Menu as the default destination (leave the fields in the Session LTx columns blank), the Connection Menu will be displayed as the first screen and the user can choose the desired connection.

For each LT, enter either the 3270 host station set number, one of the TCP/IP station set numbers, or leave blank to request the Connection Menu as the default destination.

**Note:** You cannot change the information in the Station Set Name or Session Limit columns. The Station Set Name is your response to question 721 and the Session Limit is your response to the Session Limit for that station set in the Port Set panel.

For our example, we have specified the Connection Menu as the default destination for all the attached displays (both 3270 and ASCII).

### 3.9.10 Defining TCP/IP Options

```
_____ TCP/IP Options Menu _____

3174 IP Address      052 - 009 . 067 . 038 . 088
Subnet Mask         054 - 255 . 255 . 255 . 192

Maximum TELNET Connections  058 - 020 (001 - 250)
TCP/IP Buffer Space      060 - 0256 K (K = 1024 bytes)

Routing Field Support  062 - Y (Y,N)
All Routes Broadcast  064 - Y (Y,N)

PF: 3=Quit  4=Default  7=Back  8=Fwd
```

Figure 25. TCP/IP Options Menu

#### Question 052: 3174 IP Address

Enter the IP address assigned to your 3174. Each of the four fields of your response should contain a decimal number between 000 and 255. For example, the IP address of our 3174-13R is 9.67.38.88; it is entered as:

009.067.038.088

#### Question 054: Subnet Mask

Enter the subnet mask for your network. Each of the four fields of your response should contain a decimal number between 000 and 255. For example, the subnet mask of our network at ITSO Raleigh is 255.255.255.192; it is entered as:

255.255.255.192

The mask contains a 1 for each bit of the address that is part of the network or subnet identifier.

#### Question 058: Maximum Telnet Connections

Enter the maximum number of concurrent connections you wish to have available for terminal users. This pool of connections is available on a first-come-first-served basis. Each connection requires an additional 7KB of storage.

Your response should be a decimal number between 001 and 250. For our example, we have specified 20 connections as the maximum.

### Question 060: TCP/IP Buffer Space

Enter the amount of additional memory you wish to allocate for TCP/IP data buffers. When you configure for TCP/IP, storage is assigned for 40 data buffers. Each data buffer has approximately 100 bytes available for data. See 2.11, "Storage Requirements" on page 15 for more information.

Your response should be a decimal number between 0000 and 1024, and specifies the number of 1024-byte (1KB) increments.

### Question 062: Routing Field Support

Your response should be as follows:

- Y=If you wish the TCP/IP frames to use token-ring network source routing (default response). This allows communication through bridges.
- N=If you want to disable bridge access.

### Question 064: All Routes Broadcast

Your response should be as follows:

- Y=All Routes Broadcast (default response).
- N=Single Route Broadcast.

**Note:** The response to question 064 is meaningful only if question 062=Y.

## 3.9.11 Defining TCP/IP Routing Information

TCP/IP Routing Information		
Destination IP Address	Type (N,S,H,D)	Router IP Address
009 . 067 . 038 . 134	H	009 . 067 . 038 . 096
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX

PF: 3=Quit   4=Default   7=Back   8=Fwd

Figure 26. TCP/IP Routing Information

This panel contains information about the routers that you want the 3174 to use. You can define four types of routes:

- Type = N means route to a specific network.
- Type = S means route to a specific subnet.
- Type = H means route to a specific host IP address.
- Type = D means this is the default router.

For host, subnet and network entries, you must fill in all fields in the row:

- The Destination IP Address is the specific host, subnet or network address.
- The Type is H (host), S (subnet) or N (network).
- The Router IP Address is the network IP address of the router that should receive that destination's traffic. This IP address must have the same network and subnet values as the 3174 you are customizing.

The default router (Type=D) is used for all other destinations that are not on the local network (or subnet). The Destination IP Address field for the default router must be left as:

XXX.XXX.XXX.XXX

**Notes:**

1. You should have only one default router entry.
2. If you define a route to a subnet, it must be on the same network as the 3174 you are customizing.
3. Do not add a route to the network or the subnet of the 3174 you are customizing.

For our example, we have defined one extra destination host, 9.67.38.134, which is reachable through 9.67.38.96. The 3172 (9.67.38.96) is the router for MVS18 (9.67.38.134) and MVS20 (9.67.38.96), but since MVS20 is in the same subnet as the 3174-13R (9.67.38.88), a routing statement is not required.

### 3.9.12 Defining Domain Name Services

```
_____ TCP/IP Domain Name Services _____

3174 Hostname
317413R_____

3174 Domain Name
ITSO RALEIGH IBM COM_____
_____
_____

Domain Nameserver IP Addresses

009 . 067 . 038 . 096

009 . 067 . 038 . 134

XXX . XXX . XXX . XXX

XXX . XXX . XXX . XXX

PF: 3=Quit 4=Default 7=Back 8=Fwd
```

Figure 27. TCP/IP Domain Name Services

### **3174 Hostname**

A response is required for this field. Enter the name assigned to your 3174. Observe the following rules when defining the 3174 Hostname:

- The name may be up to 63 characters long.
- Only alphabetic (A through Z), numeric (0 through 9) and the hyphen characters are allowed.
- Use the dollar sign (\$) to represent a hyphen.
- No imbedded blanks are allowed.
- Although you enter the name in uppercase characters, the 3174 converts it to lowercase before using it.

### **3174 Domain Name**

Enter the name of the domain that your 3174 is in. This name can be made up of several parts. Observe the following rules when defining the 3174 Domain Name:

- Each part of the name may be up to 63 characters long.
- Only alphabetic (A through Z), numeric (0 through 9) and the hyphen characters are valid.
- Use the dollar sign (\$) to represent a hyphen.
- Use blanks to separate the parts of the name.

For example, you would enter MYDEPT.MY-COMPANY.MYNET as MYDEPT MY\$COMPANY MYNET.

- Although you enter the name in uppercase characters, the 3174 converts it to lowercase before using it.

A domain name is required if any Domain Nameserver IP Address is entered.

### **Domain Nameserver IP Addresses**

Enter the IP addresses of the name servers that the 3174 should use to resolve names to IP addresses. Enter the primary name server's address first. These responses are optional.

### 3.9.13 Defining TCP/IP Nicknames

TCP/IP 3174 Defined Nicknames	
Nickname	IP Address
RS60001	009 . 067 . 038 . 071
RS60002	009 . 067 . 038 . 072
RS60003	009 . 067 . 038 . 073
MVS20	009 . 067 . 038 . 096
MVS18	009 . 067 . 038 . 134
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 28. TCP/IP 3174 Defined Nicknames

Since users remember names better than numeric IP addresses, this panel allows you to define up to 16 host nicknames and their associated IP addresses. Observe the following rules when defining nicknames:

- The nickname can be up to 20 characters long.
- Only alphabetic (A through Z) and numeric (0 through 9) characters are allowed.
- No imbedded blanks are allowed.
- Although you enter these names in uppercase characters, the 3174 converts them to lowercase before using them.



### 3.9.14 Configure Complete




Figure 29. AEA and TCP/IP Configure Complete

You have now completed customizing for the 3174 TCP/IP Telnet Support.

### 3.9.15 Token-Ring Considerations

You may have noticed that we have not mentioned any token-ring network customization questions. Since your 3174 must be either a x3R model customized for at least one 3270 host attachment, or a model customized as a token-ring gateway, you have already set up the token-ring network interface previously. No changes to your token-ring network customization are required for the 3174 TCP/IP Telnet Support.

### 3.9.16 Ethernet Considerations

We are not using Ethernet in this example, but if we were the 3174 could be a DSPU, Ethernet Gateway, or a standalone Telnet terminal server. For DSPU, or a Ethernet Gateway, there are no changes to your LAN (token-ring or Ethernet) customization. As a standalone Telnet terminal server, the 3270 host is not and has not been defined, thus you must customize for the use of the Ethernet adapter. Refer to Chapter 8, "3174 Ethernet Considerations" on page 227, for information on customizing the the Ethernet adapter.

### 3.10 How to Use the 3174 TCP/IP Telnet Support




Figure 30. Connection Menu Immediately after 3174 IMLed

Re-IML the 3174 after you have completed your customizing procedures. Since we have specified the Connection Menu as the default destination for all our attached terminals, this screen appears immediately after the re-IML. Note the status displayed:

- 1 The 3270 host status is a question (?) mark.
- 2 The TCP/IP host status is Down.




Figure 31. Connection Menu after 3174 Becomes Active

When the 3270 host attachment becomes active, the status changes, without user intervention, to the following:

1 The 3270 host status is now Up and, if selected, the session will be established between the LT and the host.

2 The TCP/IP host status continues to be Down.

```

                                     Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME                STATUS   NUM NAME                STATUS
1 3270 HOST              Up
2 TELNET VT100          Up
3 TELNET IBM3101        Up
4 TELNET D210           Up
5 TELNET VT220 7 BIT    Up
6 TELNET VT220 8 BIT    Up

PF: 3=End      6=Terminal Disconnect    12=Host Disconnect

=====>To:
```

Figure 32. Connection Menu after 3174 Becomes Active And Enter Pressed

When you press the Enter key, the status shows all hosts active, only if the LAN (token-ring or Ethernet) adapter has successfully opened. You can now select any one of the hosts from the Connection Menu.

### 3.11 Terminal Operation with the 3174 TCP/IP Telnet Support

When you select a TCP/IP option from the Connection Menu, your LT is placed into the local mode. You know you are in local mode when the following prompt is displayed:

```
3174 TELNET >
```

In the local mode, you are interacting with the 3174, just as if it were a "host computer." You ask the 3174 to perform functions on your behalf. The most important function is opening a connection with a remote TCP/IP host.

#### 3.11.1 Opening a Connection

Once in the local mode, there are two ways to open a connection with a TCP/IP host:

- If you have specified an address in question 790 and it is the desired destination, type the following at the Telnet prompt and press Enter:

```
3174 TELNET > open
```

- If you have specified an address in question 790 and it is not the desired destination, or if you have not specified an address in question 790, type the following at the Telnet prompt and press Enter:

```
3174 TELNET > open destination
where destination = {IPaddress|hostname}
```

Once your connection is opened, you leave the local mode and enter into session with the remote host.

When you are in session with the host, you can return to the local mode temporarily, without losing your connection to the host, by pressing the escape key.

### 3.11.2 Escaping to Local Mode

To escape to the local mode while you are in an active Telnet session, use the escape key (the escape key usually involves pressing more than one key and is not the key marked Esc or ESC on your keyboard). To find out what the escape key is, type the following at the Telnet prompt and press Enter:

```
3174 TELNET > display
```

Figure 46 on page 57 shows an example of the resulting display. Note the line that shows:

```
escape  [^L]
```

This is the default setting; it means that:

- If you have a Ctrl key on your keyboard and your display is setup offline for native mode (Standard), press and hold the Ctrl key (a ← shows in the OIA) and then press the L key.
- If you do not have a Ctrl key, enter Extension mode (for example, press and hold Alt, and then press Erase EOF), then press and release the C key, which puts you into the Ctrl mode (a ← now shows in the OIA), then press the L key.

If you find this cumbersome, use the SET command to define your preferred escape key (for example, the \$ key) before you open the connection:

```
3174 TELNET > set escape $
```

Once you have escaped to the local mode, you can enter local commands (see 3.11.8, "Local Mode Commands" on page 51). If you enter the CLOSE or the QUIT command, the connection will be ended.

After the command is performed, you automatically return to your host session, unless the command was a request to end the connection. You may have to press Enter once to regain the host prompt.

If you did not issue any command when you escaped to the local mode, just press Enter once and you will be returned to your host session.

When you return to your host session, you may need to request the host application to refresh the screen. For example, if you are working with SMIT (System Management Interface Tool) on the RS/6000, press the PF2 key to refresh. Otherwise, the commands and responses that were displayed during local mode remain on the screen until they are replaced by data from the host.

### 3.11.3 Returning to The Connection Menu

The procedure used to return to the Connection Menu from your Telnet session depends on the type of device you are using.

For 3270 devices:

- If a Telnet session is active, enter into Extension mode and then press the M key.
- If a Telnet session is not active, do either of the following:
  - Enter into Extension mode and then press the M key.
  - Type the following at the Telnet prompt and press Enter:  
3174 TELNET > quit

For ASCII devices, escape to the local mode first, and then escape to the Connection Menu; that is, press the escape key twice.

### 3.11.4 Returning to the Telnet Session

When you have returned to the Connection Menu:

- If you choose the same host connection as the host session you came from, you will be returned to that session.
- If you choose a different destination, the previous session is disconnected and you will be placed into the local mode to allow you to open a new connection.

### 3.11.5 TELNET Session Resources

When you first request a TCP/IP destination from the Connection Menu, one of the Telnet session resources reserved by question 058 must be available. If it is not, your request is rejected (see Figure 33).

```

                                     Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME                STATUS   NUM NAME                STATUS
1 IBM HOST              ?
2 TELNET VT100          Busy
3 TELNET IBM3101        Busy
4 TELNET D210           Busy
5 TELNET VT220 7 BIT    Busy
6 TELNET VT220 8 BIT    Busy

PF: 3=End      6=Terminal Disconnect    12=Host Disconnect
802 03 No 'TELNET VT220 8 BIT' ports are available

=====>To:
```

Figure 33. TCP/IP Resources Not Available

Once your request is accepted, a session resource is allocated for you until you do either of the following:

- You enter a QUIT command from the local mode.
- You return to the Connection Menu and successfully select a different destination from the menu.

### 3.11.6 Operation: Telnet to RS/6000 Host

```

                                     Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME                STATUS   NUM NAME                STATUS
1 3270 HOST              Up
2 TELNET VT100          Up
3 TELNET IBM3101        Up
4 TELNET D210           Up
5 TELNET VT220 7 BIT    Up
6 TELNET VT220 8 BIT    Up

PF: 3=End      6=Terminal Disconnect    12=Host Disconnect

*****=>To: 2
```

Figure 34. Selecting Connection to RS/6000 Host

```
3174 TELNET> open 9.67.38.73
```

Figure 35. TELNET Local Mode

```

IBM AIX Version 3 for RISC System/6000
(C) Copyrights by IBM and by others 1982, 1991.
login: root
root's Password:
*****
*
*
* Welcome to IBM AIX Version 3.2!
*
*
* Please see the README file in /usr/lpp/bos for information pertinent to
* this release of the AIX Operating System.
*
*
*****

Last unsuccessful login: Fri Oct  2 11:07:03 CDT 1992 on hft/0
Last login: Tue Oct  6 12:21:51 CDT 1992 on pts/8 from rs60002
[YOU HAVE NEW MAIL]
swcons: console output redirected to: /log/060ct92
<rs60003># smit

```

Figure 36. RS/6000 after Login

```

                                System Management

Move cursor to desired item and press Enter.

Installation and Maintenance
Devices
Physical & Logical Storage
Security & Users
Diskless Workstation Management
Communications Applications and Services
Spooler (Print Jobs)
Problem Determination
Performance & Resource Scheduling
System Environments
Processes & Subsystems
Applications
Using SMIT (information only)

F1=Help           F2=Refresh       F3=Cancel       Esc+B=Image
Esc+9=Shell      Esc+0=Exit      Enter=Do

```

Figure 37. RS/6000 after Invoking SMIT

### 3.11.7 Operation: Telnet to MVS TCP/IP Host

```
3174 TELNET> open mvs20
Finding address of mvs20
Trying...
Connected to 9.67.38.96
Application Id required, no installation default
Enter Application Name:
tso
IKJ56700A ENTER USERID -
IKJ56714A ENTER CURRENT PASSWORD FOR TONYTAN-
  ICH70001I TONYTAN LAST ACCESS AT 13:51:50 ON TUESDAY, OCTOBER 6, 1992
IKJ56481I THE PROCEDURE NAME $ASNETDA IS A DEFAULT NAME - YOU MAY CHANGE IT
IKJ56455I TONYTAN LOGON IN PROGRESS AT 13:54:24 ON OCTOBER 6, 1992
  SA20 was converted to ESA 4.2 on OCT 9
INVALID TERMINAL ACCESS METHOD, ISPF VERSION 3 REQUIRES ACF/VTAM.
READY
IKJ56470I TONYTAN LOGGED OFF TSO AT 13:55:41 ON OCTOBER 6, 1992
*****
Connection closed by foreign host.

3174 TELNET>
```

Figure 38. Logging On to MVS TSO

### 3.11.8 Local Mode Commands

The 3174 converts all local mode commands and arguments into lowercase before processing. Any numeric arguments that are required must be given in decimal. IP addresses must be entered in dotted decimal form, with no imbedded spaces, and leading zeros are not necessary.

In the following explanations of the commands, arguments must be given in the order shown. We have adopted the following convention:

- A command is shown in uppercase.
- An argument, option or variable (for example, hostname) is shown in lowercase.

Parentheses () denote optional arguments. If you wish to specify any optional argument, you must specify all the arguments that precede it. Abbreviations for commands and parameters are allowed. If the correct input cannot be determined, you will receive either an "invalid" or an "ambiguous" message.

You can use "?" after any command to get help.

#### **NAMES Command**

**Purpose:** The NAMES command will display any host nicknames that you have customized at your 3174 (see 3.9.13, "Defining TCP/IP Nicknames" on page 43) together with its associated IP address.

**Command Format:** NAMES



### Example Display:

```
3174 TELNET> names
rs60001      9.67.38.71
rs60002      9.67.38.72
rs60003      9.67.38.73
mvs20        9.67.38.96
mvs18        9.67.38.134
```

Figure 39. TCP/IP Using NAMES Command

Figure 39 shows the display for the nicknames defined in 3.9.13, "Defining TCP/IP Nicknames" on page 43.

### PING Command

**Purpose:** The PING command is used to query the availability of a remote host. Once issued, the PING operation will continue until the 3174 has sent a specified number of packets to the remote host (if it is available). You can stop the PING operation at any time by pressing any key.

**Command Format:** PING (*destination (count (size))*)

Where:

*destination* Is the remote host being queried. The *destination* can be:

- A nickname
- An unqualified hostname, if the host is part of the same domain as the 3174 you are attached to
- A fully qualified hostname
- An IP address

If no destination is given, the IP address, if customized in question 790 for the selected station set, is used.

*count* Is the number of packets the 3174 should send. If count=0, the 3174 will send packets until you stop the query. Possible values are 0 through 1000 (default 10).

*size* Is the number of bytes to send in each query. Possible values are 8 through 64 (default 64).

### Example Display:

```
3174 TELNET> ping
...sending 00064 characters to 9.67.38.71
Received reply to packet 00000, delay (ms) = 00020
Received reply to packet 00001, delay (ms) = 00020
Received reply to packet 00002, delay (ms) = 00020
Received reply to packet 00003, delay (ms) = 00020
Received reply to packet 00004, delay (ms) = 00020
Received reply to packet 00005, delay (ms) = 00027
Received reply to packet 00006, delay (ms) = 00039
Received reply to packet 00007, delay (ms) = 00020
Received reply to packet 00008, delay (ms) = 00020
Received reply to packet 00009, delay (ms) = 00020

Summary for PING to 9.67.38.71

Packets sent: 00010 Packets received: 00010
Round-trip (ms) ( min avg max ) = 00020 00022 00039

3174 TELNET>
```

Figure 40. TCP/IP Using PING Command - to Default Destination

In this display, the PING command was issued, without a destination, from an LT that selected the DEC VT100 station set number 3 (see Figure 21 on page 34). The default destination is, therefore, as customized in question 790.

```
3174 TELNET> ping mvs20 8 2

Finding address of mvs20
...sending 00008 characters to 9.67.38.96
Received reply to packet 00000, delay (ms) = 00047
Received reply to packet 00001, delay (ms) = 00021

Summary for PING to 9.67.38.96

Packets sent: 00002 Packets received: 00002
Round-trip (ms) ( min avg max ) = 00021 00034 00047

3174 TELNET>
```

Figure 41. TCP/IP Using PING Command - with Parameters

In this display, the PING command is issued, specifying the destination host name as mvs20, data packet size 8 bytes, and two packets to be sent for the PING operation.

```
3174 TELNET> ping ?

Usage: ping host size count
      host - destination host name or address
      size - size of data packet (8-64)
      count - number of packets (0-1000)
If unspecified, size=64 and count=10.

3174 TELNET>
```

Figure 42. TCP/IP Using PING Command - Help

In this display, the help information is provided to show the format and valid values that can be specified.

You can request help with any command by typing in the command followed by the question mark (or by the word help).

```
3174 TELNET> ping mvs30

Finding address of mvs30 1
Unknown host

3174 TELNET> ping mvs18

Finding address of mvs18 2
...sending 00064 characters to 9.67.38.134

Summary for PING to 9.67.38.134

Packets sent: 00010 Packets received: 00000
Percent packet loss: 100

3174 TELNET>
```

Figure 43. TCP/IP Using PING Command - Messages

- 1** Messages displayed for a destination that is not known.
- 2** Messages displayed for a destination that is not available.

### OPEN Command

**Purpose:** The OPEN command opens a connection to a remote host.

**Command Format:** OPEN (*destination (remote\_port)*)

Where:

*destination* Is a remote host to which you wish to connect. The *destination* can be:

- A nickname
- An unqualified hostname, if the host is part of the same domain as the 3174 you are attached to
- A fully qualified hostname
- An IP address.

If no destination is given, the IP address, if customized in question 790 for the selected station set, is used.

*remote\_port* Is the port number of the Telnet server at the remote host, if you want a port other than the standard Telnet port 23. Possible values are 0 through 65535.

**Example Display:** See Figure 35 on page 49 and Figure 38 on page 51.

## CLOSE Command

**Purpose:** The CLOSE command will end the connection with the remote host; that is, it is used to disconnect from a remote host. Your LT will remain in Telnet local mode.

**Command Format:** CLOSE

**Example Display:**

```
login: root
root's Password:
*****
*
*
* Welcome to IBM AIX Version 3.1!
*
*
* Please see the README file in /usr/lpp/bos for information pertinent to
* this release of the AIX Operating System.
*
*
*****

1 unsuccessful login attempt since last login
Last unsuccessful login: Fri Oct 9 08:14:26 1992 on pts/1 from 9.67.38.88
Last login: Fri Oct 9 08:13:52 1992 on pts/1 from 9.67.38.88
[YOU HAVE NEW MAIL]
<rs60001>#
3174 TELNET> close 1
Connection closed by user request
3174 TELNET>
```

Figure 44. TCP/IP Using CLOSE Command

- 1 At this point, you are in session with the RS/6000 host.
- 2 At this point, you have escaped to the local mode and issued the CLOSE command. The resulting message shows the connection was closed at your request and you are returned to the Telnet prompt.

## QUIT

**Purpose:** The QUIT command will end any open connection and return the LT to the Connection Menu.

**Command Format:** QUIT

**Example Display:** No example display is provided.

## STATUS Command

**Purpose:** The STATUS command is used to display the status of the current connection, showing the address of the remote host, and the mode of operation.

**Command Format:** STATUS

**Example Display:**

```
login: root
root's Password:
*****
*
*
* Welcome to IBM AIX Version 3.1!
*
*
* Please see the README file in /usr/lpp/bos for information pertinent to
* this release of the AIX Operating System.
*
*
*****

1 unsuccessful login attempt since last login
Last unsuccessful login: Fri Oct 9 08:14:26 1992 on pts/1 from 9.67.38.88
Last login: Fri Oct 9 08:13:52 1992 on pts/1 from 9.67.38.88
[YOU HAVE NEW MAIL]
<rs60001># 1
3174 TELNET> status 2
Connected to 9.67.38.71
Operating in character-at-a-time mode.
escape [$]
3
<rs60001># 4
```

Figure 45. TCP/IP Using STATUS Command

- 1** At this point, you are in session with the RS/6000 host.
- 2** At this point, you have escaped to the local mode and issued the STATUS command. The resulting three messages show the connection status, the operating mode, and the character that will allow you to escape to the local mode.
- 3** The display will stay at this point until you press Enter.
- 4** When you press Enter, you are again in session with the RS/6000.

## DISPLAY Command

**Purpose:** The DISPLAY command, without any argument, will show the current operating parameters and their settings. The settings can be changed by the SET or TOGGLE command.

**Command Format:** DISPLAY

(option (option (option ... )))

Where:

*option* is one of the options set by the SET or TOGGLE command.

**Example Display:**

```
3174 TELNET> display
 2 won't - map received carriage returns
 1 won't - recognize local control characters
  won't - wrap long output lines
 will - translate backspace/delete

 3 escape      4
 terminal DEC-VT100
 erase      [^H]
 interrupt [^Z]
 kill      [^U]
 quit      [^X]

3174 TELNET>
```

Figure 46. TCP/IP Using DISPLAY Command

This display shows the current parameters and their settings:

1 Shows the parameters that can be changed by the TOGGLE command from "will" to "won't" and vice versa.

2 Shows the current TOGGLE values. For example, if you issue the following command:

```
TELNET> toggle crmod
```

The result will show the following change:

**will** - map received carriage returns

3 Shows the parameters that can be changed by the SET command.

4 Shows the current SET values. For example, if you issue the following command:

```
TELNET> set escape $
```

The result will show the following change:

```
escape [$]
```

## SET Command

**Purpose:** The SET command allows you to assign a function to a specific keystroke. You can also set a terminal type string to send in response to a terminal type negotiation (for ASCII terminals).

**Command Format:** SET *option key*

Where:

*option* Is one of the following:

- escape** Is the character that will place you in local mode.
- terminal** Is the string which will be used in terminal type negotiation.

The following need "localchars" to be toggled on:

- erase** A character that will cause an Erase character.
- interrupt** A character that will cause a Telnet interrupt.
- kill** A character that will cause an Erase line.
- quit** A character that will cause a Break.

*key* Is one of the following:

- ¬x** A control key (¬e represents Ctrl-e or X'05').
- x** A non-alphanumeric character.
- string** The terminal type for host negotiation.

## TOGGLE Command

**Purpose:** The TOGGLE command allows you to switch the setting (from "will" to "won't," or vice versa) of certain local functions.

**Command Format:** TOGGLE *option (option (option ... ))*

Where:

*option* Is one of the following:

- crmod** Mapping of received carriage returns.
- localchars** Recognize local control characters.
- wrap** Wrap long output lines.
- bs** Backspace as a delete character function.

## SEND Command

**Purpose:** The SEND command allows you to send special control sequences to the remote host. It also gives you the ability to pass the current escape character to the remote host, since the 3174 will intercept this character if it is typed on the keyboard.

**Command Format:** SEND *option (option (option ... ))*

Where:

*option* Is one of the following:

<b>ayt</b>	TELNET "Are You There" command.
<b>brk</b>	TELNET "Break" command.
<b>break</b>	TELNET "Break" command.
<b>ec</b>	Erase Character.
<b>el</b>	Erase Line.
<b>escape</b>	The current escape character.
<b>ip</b>	TELNET "Interrupt" command.
<b>interrupt</b>	TELNET "Interrupt" command.
<b>intp</b>	TELNET "Interrupt" command.
<b>intr</b>	TELNET "Interrupt" command.
<b>nop</b>	TELNET "No Operation" command.
<b>synch</b>	TELNET "Synch Operation" command.

### HELP Command

**Purpose:** The 3174 displays help information for the requested commands, for example, if you need an explanation of a command and its options. It is the same as the ? (question mark) command.

**Command Format:** {HELP[?]} (*command (command (command ... ))*)

Where:

*command* Is one of the other local mode commands.

### 3.11.9 Special Considerations for ASCII Terminals

When you are accessing a Telnet destination from an ASCII terminal, the data received from your terminal is sent to the remote host unchanged.

#### Terminal Types

If you are using a 3174 User Defined Terminal (UDT), use the SET command to enter the name of your terminal. Do this before you issue an OPEN command. The 3174 will send this character string to the host, in response to a terminal type negotiation request.

If you do not use the SET command, the 3174 uses predefined character strings as answers when the host asks for the terminal type. The character string is determined by the station type of the terminal, as follows:

<b>Station Type</b>	<b>Character String Sent to Host</b>
<b>A2</b>	ADDS-VIEWPOINT-A2
<b>A7</b>	ADDS-VIEWPOINT/78
<b>E1</b>	HAZELTINE-1500
<b>E7</b>	HAZELTINE-ESPRIT
<b>H2</b>	HP-2621
<b>I1</b>	IBM-3101
<b>I2</b>	IBM-3151



<b>I5</b>	IBM-3161
<b>I7</b>	IBM-3162
<b>I4</b>	IBM-3164
<b>L1</b>	LSI-ADM-11
<b>L3</b>	LSI-ADM-3A
<b>L7</b>	LSI-ADM-1178
<b>T1</b>	TELEVIDEO-912
<b>T7</b>	TELEVIDEO-970
<b>V1</b>	DEC-VT100
<b>V6</b>	DEC-VT220
<b>V2</b>	DEC-VT241
<b>V5</b>	DEC-VT52
<b>M1</b>	MINTEL-1B
<b>W1</b>	WYSE-50
<b>X4</b>	TEKTRONIX-4205
<b>S1</b>	ANSI
<b>Others</b>	UNKNOWN

### **Operation: ASCII Terminal**

Some other things to note about using the 3174 TCP/IP Telnet RPQ from an ASCII terminal are:

- To request the Connection Menu, enter the escape key while in local mode.  
If you have an active Telnet session, enter the escape key twice - the first time, to enter local mode, and the second time to access the Connection Menu.
- If your terminal uses MLT to access more than one session, you must invoke the Connection Menu before using the Change Screen sequence.
- You cannot use Copy Session to Session functions while your LT is in Telnet mode.
- An LT in Telnet mode cannot be part of a Split Screen workgroup.

### **3.11.10 Special Considerations for 3270 Terminals**

When you are accessing a Telnet destination from a 3270 terminal, the data received from your terminal is converted into an ASCII data stream that the remote host understands. Your terminal may operate differently from the way it does when you access a 3270 host. For example, there may be a delay after you press a key before the corresponding character appears on your screen. This is because the remote host usually provides the echoing of the keystroke. Also, the functions provided by some keys may be different from those you are used to. For a full description of how to use your 3270 terminal with ASCII hosts, refer to *Terminal User's Reference for Expanded Functions*.

### **Operation: 3270 Terminal**

Some special things to note about using the 3174 TCP/IP Telnet RPQ from a 3270 terminal are:

- You can use Copy Session to Session function only to copy from a Telnet screen to a 3270 screen. You cannot copy to a Telnet screen.
- LTs in Telnet mode may be part of a Split Screen workgroup. However, you cannot do Split Screen setup functions from an LT in TELNET mode. You must access the Connection Menu on the LT before entering Split Screen setup.

### **3.11.11 Special Considerations for 3270 Emulation**

Because most 3270 emulation software, filter the keys labeled **CTRL** and **ALT**, it is sometimes necessary to select a different key as the extension mode key. **Q168**, allows you select an additional extension mode key. Extension mode is required to execute any control mode functions (like escaping to local mode). Even if the emulator support native (standard) scancodes, extension mode is the prerequisite mode to control (Ctrl) mode. Once in extension mode, you press and release the C key to enter control mode. Control mode is indicated by a left arrow in the OIA.

#### **Question 168: Additional Extension Mode Key**

Your response should be as follows:

- 0=No Additional Key Specified.
- 1=Home Key.
- 2=Print ID Key.

---

### **3.12 If Things Go Wrong...**

The 3174 TCP/IP Telnet Support adds the following online tests:

- Test 2 Option 4 - to display AEA and TCP/IP configuration panels.
- Test 3 Option 3 - to display 3270 device status, including TCP/IP connections and information.

Here are some actions you can take if you have trouble with your session:

1. If you are communicating with a TCP/IP host, escape to the local mode. Use the STATUS command to get the status of the session.
2. If your session appears hung, or you want to interrupt the host, escape to the local mode and use the SEND command to send an interrupt to the host.
3. If you want to end the session, escape to the local mode and use the CLOSE command.
4. To see if a host is active, use the PING command. Since you cannot use the PING command from an active connection, you may need to use another LT, or CLOSE the active connection before issuing the PING command.
5. You can use the 3174 online tests /3 (for 3270 terminals) or /12 (for ASCII terminals) to display the connectivity of the LTs at any port. If an LT has selected a TCP/IP destination from the Connection Menu but has not used the OPEN command to start a session, these online tests will indicate the LT

is in the local mode. If there is an active connection with a remote TCP/IP host, the host IP address is shown (see Figure 47 on page 62).

```

BKBCP235          Connectivity for PN 03, HG 26

Adapter (HG) status:      Enabled
Port (PN) status:        Powered on
Device type:              Video display (MLT)

Current connectivity-

      LT   Bound   Host
      LT   Bound   Addr   IDn   HG_PN  Host/Station Name
ACTIVE 1   Yes    002    1A1   16    3270 host
      2   n/a    n/a    n/a   16    009.067.038.071
      3   n/a    n/a    n/a   16    TELNET Local Mode
      4   No    014    1A4   16    LT not available
      5   n/a    n/a    1A5   16    LT not available

```

To go directly to other tests, enter: /Test,Option  
Select Test; press ENTER ==>

PF: 3=Quit 12=Test Menu

Figure 47. Online Test /3,3,26

- 1 LT-1 has a session with a 3270 host; the ACTIVE indicates this LT is currently being displayed on the screen.
- 2 LT-2 has an active connection to the Telnet host shown.
- 3 LT-3 is in Telnet local mode.
- 4 LT-4 is displaying the Connection Menu and has a local address customized in the PAST.
- 5 LT-5 is displaying the Connection Menu but does not have a local address customized in the PAST.

---

### 3.13 Telnet Codes

Some messages that you see during Telnet local mode operation contain a return code to help in problem determination.

<b>Code</b>	<b>Meaning</b>
00007	Argument list too long
00013	Permission denied
00014	Bad address
00022	Invalid argument
00031	Too many links
00032	Broken pipe
00033	Argument too large
00034	Result too large
00035	Operation would block
00036	Operation now in progress
00040	Message too long
00042	Protocol not available
00043	Protocol not supported
00044	Socket type not supported
00048	Address already in use
00050	Network is down
00051	Network is unreachable
00054	Connection reset by peer
00055	No buffer space available
00056	Socket is already connected
00057	Socket is not connected
00058	Can't send after socket is shutdown
00060	Connection timed out
00061	Connection refused
00064	Host is down
00065	No route to host

---

### 3.14 Data Flows

Figure 48 on page 65 shows an example flow of TCP/IP traffic to initiate a session for an LT. The flow shows these steps:

1. The user has already selected one of the Telnet options from the Connection Menu. He then types in "open MVS1.HOST1".
2. The 3174 TCP/IP Telnet Support uses the Domain Name Service function to determine the IP address associated with that host name. If the current routing table does not contain an entry for this host, a request is sent into the network to the Domain Name Server to resolve the address. For this flow, assume that the 3174 TCP/IP Telnet Support already has an entry for MVS1.HOST.
3. The 3174 TCP/IP Telnet Support determines that the request should be forwarded to the router at 128.10.0.2.
4. It does not know the MAC address of the router, so it uses ARP to find out.
5. The 3174 TCP/IP Telnet Support forwards the request to start a session (the first TCP message sent to do this is a SYN request).
6. The router discovers that the host is on a network that it can address directly and uses ARP to seek out the host's MAC address. It forwards the request.
7. The host processes the request, builds a reply and consults its routing tables which point to the router.
8. On the return journey, neither the host nor the router needs to use ARP, because they have both seen recent ARP activity which identifies the MAC addresses they need. These combinations are kept in a sort of cache and are discarded at regular intervals so that any changes can be reflected. Thus, such discovery activity is not restricted to the login, but could happen at any point during the user's host session.




Figure 48. TCP/IP Connection Establishment



## Chapter 4. Scenario 1: TCP/IP Using 3174 Peer Communication Only

Scenario 1 is used to illustrate the 3174 support for IBM TCP/IP products, such as TCP/IP for DOS and TCP/IP for OS/2, used in intelligent workstations coax-attached to a 3174 with the Peer Communication LIC feature. For this scenario, is not required to customize the 3174 for 3174 TCP/IP Telnet Support since the 3174 is not being used a Telnet terminal server. The 3174 is providing the bridge from the internal peer segment to the real token-ring network segment. This scenario will show the PS/2 workstations accessing a TCP/IP host and an SNA host through the 3174.

### 4.1 Scenario 1 Configuration Diagram




Figure 49. TCP/IP Access through 3174 Peer Communication



---

## 4.2 Scenario 1 Configuration Description

Scenario 1 shows an OS/2 and a DOS PS/2 workstation, each coax-attached to the 3174-11R using the Peer Communication LIC feature in Configuration Support-C Release 3 to bridge to the real token-ring network.

The composite network has the following components:

- An S/370 MVS host with ACF/VTAM\* V4.1
- A channel-attached 3745 with ACF/NCP V6.2
- A 3174-11R Establishment Controller:
  - As a token-ring gateway to the S/370 host
  - With Peer Communication (LAN-Over-Coax) support enabled.
- A PS/2 OS/2 workstation, coax-attached to the 3174-11R, with:
  - OS/2 V2.0
  - Communications Manager/2 V1.0
  - Token-Ring address (400031742992)
  - Peer attachment (LAPS)
  - TCP/IP V1.2.1 for OS/2.
- A PS/2 DOS workstation, coax-attached to the 3174-11R, with:
  - PC DOS V5.02
  - Personal Communications/3270 V3.0
  - Token-Ring address (400031744992)
  - Peer attachment (Peer NDIS Driver in LAN Support Program V1.33)
  - TCP/IP V2.1 for DOS.

### 4.3 Communications Manager/2 Definitions

On the OS/2 workstation, we start Communications Manager/2.

- Communications Manager Installation/Setup
- Communication Setup
- Open Configuration
- Communication Manager Configuration Definition - 3270TCP
- 3270 Emulation through Token-Ring
- Communication Setup Close

#### Communications Manager/2 Installation and Setup




Figure 50. Communications Manager/2 Installation and Setup

To initiate setup, either click OK on the CMSETUP panel if Communications Manager/2 is already installed, or enter **cmsetup** from the command prompt if this is the initial installation.

Refer to the *Communications Manager/2 Installation Guide* for more details.

**Note:** If you do not have LAPS installed, you will have to do so prior to cmsetup.

## Communications Manager Setup




Figure 51. Communications Manager Setup

- Select **Setup** to create or modify a configuration definition and proceed to Figure 52 on page 71.
- Select **Installation** to install necessary product files to support a configuration, if this is your initial installation.
- Select **Close** to end Communications Manager Setup process.

We have selected **Setup** since we are creating a new configuration definition.

## Open Configuration




Figure 52. Open Configuration

- Enter a configuration name in the **Configuration** field.
- Enter a description of the configuration in the **Description** for documentation purposes.
- You will be asked, **Will this configuration be used for this workstation.**  
Click on **Yes** and continue to the next step. If a new file is being created, Communications Manager/2 will store all files in the **E:\CMLIB\3270TCP** subdirectory.
- Click on **OK** to get to the next panel, shown in Figure 53 on page 72.

This configuration will be used by the OS/2 workstation to access the 3270 host via the 3174-11R token-ring gateway.

## Communications Manager Configuration Definition - 3270TCP





Figure 53. Communications Manager Configuration Definition for 3270 Emulation

- Select **Token-ring or other LAN types**.
- Select **3270 emulation**.
- Click on **Configure** to get to the next the panel, shown in Figure 54 on page 73.

Even though, we are using the physical coax 3278 adapter, we configure for **Token-ring or other LAN types** since the Peer Communication support is transparent to Communications Manager/2. LAPS will provide the API interface to the physical adapter. What we are configuring is the logical connection.

## 3270 Emulation through Token-Ring



3270 Emulation through Token-Ring

Network ID USIBMRA

Local node name PS2COAX

Local node ID (hex) 05D 42992

LAN destination address (hex) 400031740002

Number of terminal sessions 1

OK Advanced... Cancel Help

Figure 54. 3270 Emulation through Token-Ring

- Enter the network ID, local node name and local node ID for the OS/2 workstation.
- Enter the token-ring network address of the 3174-11R gateway in the **LAN destination address** field.
- Enter the number of 3270 sessions you want for the OS/2 workstation.
- Click on **OK**.

The Communications Manager Configuration Definition - 3270TCP panel reappears.

## Communications Manager Configuration Definition - 3270TCP




Figure 55. Communications Manager Configuration Definition for 3270 Emulation

You have now completed Communications Manager Configuration Definition.

- Click on **Close**.

If your configuration requires additional installation, refer to the *Communications Manager/2 Configuration Guide*, SC31-6171 for further information.

## 4.4 TCP/IP V1.2.1 for OS/2 Installation/Configuration

This section provides information on how to install and configure TCP/IP V1.2.1 for OS/2 on your PS/2 workstation which is coax-attached to the 3174. For more information, see *TCP/IP V1.2.1 for OS/2 Installation and Interoperability*, GG24-3531.

### Installation and Configuration Automation Tool (ICAT)

The following sections describe the installation and configuration of TCP/IP V1.2.1 for OS/2 at a PS/2 which already has OS/2 V2.0 and Communications Manager/2 installed.

ICAT is a Presentation Manager\* application that uses standard input and output conventions.

### Installation Using ICAT

To start the installation process with ICAT, insert the TCP/IP V1.2.1 for OS/2 diskette labeled **B-1** into drive A and enter the following command at a command prompt in OS/2 full-screen or Windows mode:

```
A:\icat
```

The panel in Figure 56 is displayed.




Figure 56. TCP/IP V1.2.1 for OS/2 ICAT Introduction Panel

To install TCP/IP V1.2.1 for OS/2 click on **Install**; the panel in Figure 57 on page 76 is displayed.






Figure 57. TCP/IP V1.2.1 for OS/2 ICAT Installation Panel

We only choose the **Base Product** to install on this PS/2 host. The base directory to install TCP/IP V1.2.1 for OS/2 is D:\tcpip. Select **Install**; ICAT will start the installation process on your PS/2. You are prompted to insert the appropriate diskette ICAT needs.

When ICAT has finished the installation, you are asked if ICAT can make changes to the CONFIG.SYS file for you. Select **Yes** and ICAT will update the statements in the CONFIG.SYS file.

Then you get a message to run TCPLAPS to complete the installation. Select **OK**. Then, on the ICAT introduction panel select **Exit**. This completes your installation.

### Configuration using ICAT

The next step is to configure your system using ICAT. At a minimum, the OS/2 TCP/IP system should be customized to include its IP address in the **Configure Network Interface Parameters** panel.

To start configuring, enter **ICAT** at an OS/2 command prompt. The ICAT introduction panel appears. Select **Configure** to display the **Configuration Menu**.




Figure 58. ICAT Configuration Menu

The detailed information about the different options are described in *TCP/IP V1.2.1 for OS/2 Installation and Interoperability*, GG24-3531. Select **Network Interface Parameters**.

Your responses in the **Configure Network Interface Parameters** panel change the IFCONFIG statement in the SETUP.CMD file.




Figure 59. ICAT Configure Network Interface Parameters

When updating the ICAT Network Interface Parameters menu, enter the IP Address, the Subnet Mask (if the IP network is using subnets) and the Routing Metric Count if you use routers in your network. Let the other IFCONFIG values default.

With the responses shown in Figure 59, ICAT creates the following IFCONFIG statements in the SETUP.CMD file:

```
route -fh
arp -f
ifconfig lan0 9.67.38.98 netmask 255.255.255.192 metric 01 mtu 1462
REM ifconfig lan1
REM ifconfig lan2
REM ifconfig lan3
REM ifconfig sl
```

Figure 60. IFCONFIG Statement in SETUP.CMD File

As you can see, ICAT allows the configuration of up to four LAN adapters at a time.

**Note:** The Maximum Transmission Unit size depends on the type of adapter in your PS/2.

For more information about the IFCONFIG parameters, see *TCP/IP V1.2.1 for OS/2 Installation and Maintenance*.

## 4.5 Installation: TCP/IP LAN Adapter and Protocol Support (TCPLAPS)

TCPLAPS is a Presentation Manager based utility, which allows you to install and configure your system to run the NDIS version of TCP/IP V1.2.1 for OS/2. It is used to associate the IBM TCP/IP protocol with one or more network adapters. To install TCPLAPS on a workstation, insert the diskette labeled **LAPS** in the diskette drive and enter the following command at an OS/2 prompt:

```
A:\laps
```

The panel shown in Figure 61 is displayed.




Figure 61. TCPLAPS Introduction Panel

Select **Install** to begin the LAN adapter and protocol support installation process. You are prompted with the panel shown in Figure 62 on page 79.




Figure 62. TCPLAPS Installation Panel

Select **LAN Adapter and Protocol Support** and then **Continue**. TCPLAPS checks if a previous version or other version of LAPS is already installed. If it finds one, the panel in Figure 63 is displayed.




Figure 63. TCPLAPS Reinstall Selection

Select **Yes** to reinstall the LAN adapter and protocol support. TCPLAPS now updates the LAPS drivers. When completed, the TCPLAPS introduction panel is displayed.

If there is no previous version installed, the panel in Figure 64 is displayed.




Figure 64. Target Drive

Type in the letter of the drive where LAPS will be installed. TCPLAPS now installs the LAPS drivers. When completed, the TCPLAPS introduction panel, is displayed again. Select **Configure** to start TCPLAPS configuration. The panel in Figure 65 on page 80 is displayed.




Figure 65. TCPLAPS Configuration Panel

Select **Configure LAN transports** and then **Continue** to get the panel shown in Figure 66.




Figure 66. TCPLAPS Configuration Selection

In the **Network Adapters** section of this panel, all supported adapters are listed.

In the **Protocols** section, the available protocols are shown.

In the **Current Configuration** section, the selected adapter and protocols for 3174 Peer Communication are shown.

Now select **OK** to complete the TCP/IP V1.2.1 for OS/2 installation process.

Because ICAT did not complete the installation, TCPLAPS will add additional statements to your CONFIG.SYS file. Figure 67 on page 81 shows the drive in which the updates will be made:




Figure 67. CONFIG.SYS Update

Select **Continue** and TCPLAPS updates the following statements of the CONFIG.SYS file for you.

```
LIBPATH=E:\IBMCOM\DLL;. ; E:\OS2\DLL; E:\OS2\MDOS; E:\; E:\OS2\APPS\DLL; E:\CMLIB\DLL;
E:\MUGLIB\DLL; D:\TCPIP\DLL;
SET PATH=E:\OS2; E:\OS2\SYSTEM; E:\OS2\MDOS\WINOS2; E:\OS2\INSTALL; E:\; E:\OS2\MDOS;

SET HELP=E:\OS2\HELP; E:\OS2\HELP\TUTORIAL; E:\CMLIB; D:\TCPIP\HELP;

SET ETC=D:\TCPIP\ETC
SET TMP=D:\TCPIP\TMP

RUN=D:\TCPIP\BIN\CNTRL.EXE
```

Figure 68. Updated CONFIG.SYS

You will now be returned to the TCPLAPS Introduction panel shown in Figure 61 on page 78. Select **Exit** to complete the configuration process.

---

## 4.6 Personal Communications/3270 Definitions

On the PS/2 DOS workstation, we do the following:

- Create Configuration File
- Choose Configuration
- Attachment Types
- Advanced Option for 3174 Peer Communication
- Advanced Option for Network Stations
- Screen Sizes
- Keyboard and Code Pages
- PC/3270-Startup Option
- Link Option

### 4.6.1 Personal Communications/3270 Configuration Program

Personal Communications/3270 (PC/3270) was installed on directory d:/pcom/pcom3f.

To start the configuration process, enter the following command at the DOS command prompt of the subdirectory:

```
d:\PCOM\PCOM3F> config
```

The logo panel, shown in Figure 69, is displayed.




Figure 69. PC/3270 Logo

## Create Configuration File

```
----- Create Configuration File ----- More: +
Enter the required information and press F8 to continue.

Name of an existing configuration
file (optional) . . . . .

Drive and directory in which you will store
PC/3270 configuration data files  D:\PCOM\PCOM3F

Name of the new configuration file
(This is what you will type
to start PC/3270). . . . .  PC3270

F1=Help  F3=Exit          F8=Forward
```

Figure 70. PC/3270 Create Configuration File

The Create Configuration File panel allows you to specify your own subdirectory and startup batch file name. Enter your preferred responses, then press **F8** to take you to the Choose Configuration panel.

## Choose Configuration

```
----- Choose Configuration ----- More: -+
Press F10 to change the choice.

Type of configuration . . . . . Network station
Advanced link options . . . . . Yes
! More than one LAN or communications adapter !
! More than one type of host connection !
! Connection to more than one gateway !
! X.25 connection !
-----
Use expanded memory . . . . . No
Use a Task Swapper . . . . . No
Update CONFIG.SYS . . . . . No

F1=Help  F3=Exit  F7=Backward  F8=Forward  F9=Prev choice  F10=Next choice
```

Figure 71. PC/3270 Choose Configuration

The Choose Configuration panel allows you to specify the type of configuration you require. For more details on configuring, refer to *IBM Personal Communications/3270 Version 3.0 Implementation Guide*, GG24-3949.

Select **Yes** for **Advanced link options** for the simplest of configuration scenarios.



Press **F8** to take you to the Attachment Types panel.

### Attachment Types

```
Attachment Types                                     More: -+
-----
Enter the required information.

Total number of sessions for:

Distributed Function Terminal (DFT) . . . . . 0
LAN via 802.2 protocol . . . . . 0
LAN via NetBIOS . . . . . 0
3174 Peer Communication . . . . . 1
Synchronous Data Link Control (SDLC) . . . . . 0
Asynchronous Data Link Control (ASYNCH) . . . . . 0
  (for attachment to a Series/1 SNA gateway only)
CCITT X.25 Network (X.25) . . . . . 0

F1=Help F3=Exit F7=Backward F8=Forward
```

Figure 72. PC/3270 Attachment Types

On the Attachment Types panel, select **3174 Peer Communication** by entering the number of sessions required.

Press **F8** to display the Advanced Options for 3174 Peer Communication panel.

### Advanced Options for 3174 Peer Communication

```
Advanced Options for 3174 Peer Communication       More: -+
-----
Enter the required information.

Total number of LAN sessions . . . . . 1
Link name . . . . . lan1
Destination address . . . . . 400031740002
Number of sessions for this gateway . . 1
Physical Unit ID . . . . . 00000
Adapter number . . . . . 0
Remote SAP/Local SAP . . . . . 04 / 08
Block ID . . . . . 061
PIU size . . . . . 0265

F1=Help F3=Exit F7=Backward F8=Forward
```

Figure 73. PC/3270 Advanced Options for 3174 Peer Communication

Enter the destination address of the 3174.

Press **F8** to go to the Advanced Options for Network Station panel.

## Advanced Options for 3174 Network Stations

```
-----
Advanced Options for Network Stations                               More: --+
-----
Enter the required information.

File-transfer packet size for non-SNA . . . 07160
File-transfer packet size for SNA . . . . . 02500

Session ID   Link name   Adapter number   LU address/
              name           number           LT number
              (optional)

a            lan1       0                LU

F1=Help F3=Exit F7=Backward F8=Forward
```

Figure 74. PC/3270 Advanced Options for 3174 Network Stations

The Advanced Options for Network Stations panel allows you to specify the file transfer packet size. We decided to take the default values.

Press **F8** to take you to the Screen Sizes panel.

## Screen Sizes

```
-----
Screen Sizes                                                       More: --+
-----
Press F9 or F10 to change the choices.

Session ID   Link name   Screen size
a            lan1       24 x 80

F1=Help F3=Exit F7=Backward F8=Forward F9=Prev choice F10=Next choice
```

Figure 75. PC/3270 Screen Sizes

On the Screen Size display, choose **24 x 80**.

Press **F8** to take you to the Keyboard and Code Pages panel.

## Keyboard and Code Pages




Figure 76. PC/3270 Keyboard and Code Pages

On the Keyboard and Code Pages panel, select the options for your country configuration.

Press **F8** to get the PC/3270-Startup Options panel, shown in Figure 77.

### PC/3270 Startup Options




Figure 77. PC/3270 Startup Options

On the PC/3270-Startup Options panel we specify the options shown.

You have now completed the configuration of the link options. You can move on to the Advanced Configuration Options panel by selecting **Yes** in the End of Link Options panel (next panel) if required.

## End of Link Option

```
----- End of Link Options ----- More: -+
-----
Press F10 to change the choice.

You have completed the configuration for connectivity.

Do you wish to add or change
Advanced Configuration Options? . . . . .No
-----
! Advanced Configuration Options are:      !
! Facilities                               !
!   EHLLAPI (High-Level-Language Application-Program Interface) !
!   PCSPCLK interface for GDDM-PCLK       !
!   LLAPI (Low-Level Application-Program Interface) for PS/PC etc. !
!   ECF (Enhanced Connectivity Facilities) !
!   Automatic-Logon Facility              !
!   Presentation-Space Copy               !
!   Record/Play                           !
!   SNA Data Compression                  !
!   Display options (font, appearance, DOS graphics) !
!   Print options (local copy, host-directed printing) !
-----
F1=Help F3=Exit F7=Backward F8=Forward F9=Prev choice F10=Next choice
```

Figure 78. PC/3270 End of Link Option

On the End of Link Options panel we have entered **No** for the **Advanced Configuration Options** field.

Press **F8** to take you to the End of Configuration panel.

## End of Configuration (Before Save)

```
----- End of Configuration ----- More: -
-----
You have now completed your selections and are ready to save the configuration.

Press one of the following keys to proceed:

F6: Save configuration file

F7: Review and change your selections

-----
F1=Help F3=Exit F6=Save F7=Backward
```

Figure 79. PC/3270 End of Configuration (Before Save)

On this panel, press **F6** to save the configuration file. The message **Your configuration file has been saved successfully; press F3 to exit to DOS** is displayed when completed (see next panel).

## End of Configuration (After Save)

```
-----
                        End of Configuration                        More: -
-----
You have now completed your selections and are ready to save the configuration.
Press one of the following keys to proceed:

  F6: Save configuration file
  F7: Review and change your selections

-----
!                               Exit to DOS                               !
-----
!Your configuration file has been saved successfully; press F3 to exit to DOS. !
!                                                                           !
!                                                                           !
!                                                                           !
!                               F3=Exit                               !
-----

F1=Help  F3=Exit  F6=Save  F7=Backward
```

Figure 80. PC/3270 End of Configuration (After Save)

Press F3 to exit to the DOS prompt.

You have now completed configuring PC/3270 for Scenario 1.

In Windows mode, the Customize Communication panel allows you to configure PC/3270. The next few steps show how you can configure PC/3270 in Windows mode.




Figure 81. PC/3270 Customize Communication (Windows Mode)

Click on **COAX card** and **3174 Peer Communication**, then click on **Configure**. The Customize Communication - 3270 Host panel appears.




Figure 82. Customize Communication - 3270 Host (Windows Mode)

On this panel, specify the panel size, session type and host code page as shown. (If you click on **Configure SNA...**, you will be able to enable/disable SNA data compression and specify the compression buffer size.) Click on **Configure Link...** and the IEEE 802.2 panel is displayed.

Adapter Number:	0
Destination Address:	400031740002
Physical Unit ID:	00000
Remote SAP:	04
Block ID:	061
PIU Size:	265

Figure 83. IEEE 802.2 (Windows Mode)

Enter the **Destination Address** and the **Remote SAP** of the 3174-11R gateway. Click on **Advanced...** to get the next panel.

Local SAP:	08
Receive-Buffer Count:	12
Lnk-Station Count:	1

Figure 84. IEEE 802.2 Advanced (Windows Mode)

In this panel, specify the **Local SAP** of the PS/2.

**Note:** The local SAP should not have the same SAP number as the SAP for TCP/IP. Therefore we specified Local SAP as **08**.

Click on **OK** to take you to the panel shown in Figure 83.

Then, click on **OK** to take you to the panel shown in Figure 82 on page 89.

Then, click on **OK** to take you to the panel shown in Figure 81 on page 89.

Finally, click on **OK** to complete the configuration process. You have now completed configuring PC/3270 in Windows mode for Scenario 1.

## 4.7 Installation: TCP/IP for DOS

This section provides information on how to install and configure TCP/IP for DOS V2.1 on your PS/2 which is coax-attached to the 3174-11R and using the Peer Communication support in the 3174-11R.

For more information, see *IBM Transmission Control Protocol/Internet Protocol Version 2.1 for DOS: Installation and Administration*, SC31-7047.

### Installation

To install TCP/IP for DOS V2.1:

1. Insert the TCP/IP for DOS base product distribution diskette B-1 into drive A.
2. At the DOS prompt, type the following and press Enter:

```
A:\> \install
```

3. When the INSTALL program displays the IBM logo, press Enter and continue with step 4.





Figure 85. IBM TCP/IP for DOS Installation Tool



4. The INSTALL program displays the default path, and prompts you to specify the hard disk drive and base directory into which to copy the TCP/IP for DOS files.

If **Use the default** is checked, press Enter.



5. As the INSTALL program prompts you, insert each additional base product distribution diskette in drive A.
6. Update the AUTOEXEC.BAT and CONFIG.SYS files.

When the INSTALL program prompts you, specify whether you want the INSTALL program to update the AUTOEXEC.BAT and CONFIG.SYS system files on your PC.

If you allow the INSTALL program to update the files, the INSTALL program renames and saves the original files as AUTOEXEC.BK and CONFIG.BK.

For more information, see *Appendix C, IBM Transmission Control Protocol/Internet Protocol Version 2.1 for DOS: Installation and Administration*, SC31-7047.

The following shows the new statements in the CONFIG.SYS file:

```
DEVICE=D:\TCPDOS21\BIN\PROTMAN.DOS /I D:\TCPDOS21\ETC
DEVICE=D:\TCPDOS21\BIN\DOSTCP.SYS
```

The following shows the new statements in the AUTOEXEC.BAT file:

```
D:\TCPDOS21\BIN\NETBIND
SET ETC=D:\TCPDOS21\ETC
PATH C:\WIN31;C:\DOS52;D:\TCPDOS21\BIN;
```

7. Restart your PC to begin using the updated system files.
8. The files for the TCP/IP for DOS V2.1 base product are now installed.

If you are installing one or more optional kits, continue with **Installing Optional Kits** as described in Chapter 1, *IBM Transmission Control Protocol/Internet Protocol Version 2.1 for DOS: Installation and Administration*, SC31-7047.

If you are not installing optional kits, use the CUSTOM program for Configuration.

### Configuration

1. Start the CUSTOM program.
2. Change the current directory to the base directory containing TCP/IP for DOS.
3. At the DOS prompt, type the following and press Enter:

```
A:\custom
```



## NDIS Interface and Protocol Manager Configuration

```

Configure Verify Help (general)
-----
| NDIS Interfaces          | ==  =====  =====
| SLIP Interfaces         |
| Routing Information     | ===  =====  =====
| Name Resolution         | ===  =====  =====
| Network Services       | ===  =====  =====
| Auto-start              | ===  =====  =====
| Ftp User List           | ===  =====  =====
| NetBIOS                 | ===  =====  =====
| Windows                 | ==  =====  =  =====
| Protocol Manager        |
-----
| Exit - Save Changes     | Alt-X | P/IP for DOS |
| Quit - Discard Changes  | Alt-Q | CUSTOM              |
-----
                    rsion 2.1
-----

(C) Copyright IBM Corporation 1992, 1993
Program property of IBM - all rights reserved.
US Government Users Restricted Rights - Use, duplication
or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

F10 Menu Alt-X Exit F1 Help (specific)

```

Figure 88. NDIS Interface and Protocol Manager Configuration

Select **NDIS Interfaces** from the menu bar and press Enter; the panel shown in Figure 89 is displayed.

### NDIS Interfaces

```

Configure Verify Help (general)
-----
----- NDIS Interfaces -----
Interface
(x) ND0          * IP address  9.67.38.87
() ND1
() ND2          * Subnet mask  255.255.255.192
() ND3

Broadcast
Options
(x) Enable interface  Destination
() 802.3
(x) arp              * Bound adapter  IBM 3174 Peer Support
(x) allroutes
() trailers
() canonical        * = Required

TAB to move between fields. Arrows to move within a group.
SPACEBAR to select check options.

--OK--  Cancel  Help  Calculate Broadcast
-----

F10 Menu Alt-X Exit F1 Help (specific)

```

Figure 89. NDIS Interfaces

1. Select **ND0**.
2. Select the **Options** as shown on the panel.
3. Type in the **IP address** of your workstation.
4. Type in the **Subnet mask**.


On **Bound adapter** field, you should select **IBM 3174 Peer Support**.

**Note:** If you do not get the IBM 3174 Peer Support on the menu bar you should first do the Protocol Manager Selection as described in *IBM Transmission Control Protocol/Internet Protocol Version 2.1 for DOS: Installation and Administration*, SC31-7047.

5. Select **OK** and press Enter.

The Read TCP/IP Configuration panel appears.

### Read TCP/IP Configuration



**Figure 90.** Read TCP/IP Configuration

Press Enter and you get the Write TCP/IP Configuration panel with a warning message.

## Write TCP/IP Configuration




Figure 91. Write TCP/IP Configuration

Press Enter; the Write TCP/IP Configuration is completed and you are returned to the DOS prompt.

### 4.7.1 System Files

This section describes changes to system CONFIG.SYS, AUTOEXEC.BAT and PROTOCOL.INI files when installing and configuring TCP/IP for DOS V2.1. Some of the changes are required to use the product and others are optional. You can use either of the following methods to make the changes:

- You can choose to let the INSTALL and CUSTOM programs make most of the changes automatically during installation and configuration.
- You can choose to make the changes yourself if they are needed for your configuration.

For more information about changes to the system files, see Appendix C, *IBM Transmission Control Protocol/Internet Protocol Version 2.1 for DOS: Installation and Administration*, SC31-7047.

#### CONFIG.SYS for TCPDOS

```
DEVICE=C:\DOS52\SETVER.EXE
DEVICE=C:\WIN31\HIMEM.SYS
REM DOS=HIGH
FILES=30
BUFFERS=40
DEVICE=C:\WIN31\SMARTDRV.EXE /DOUBLE_BUFFER
STACKS=9,256
REM DEVICE = C:\DOS52\ANSI.SYS
DEVICE = D:\TCPDOS21\BIN\PROTMAN.DOS /I D:\TCPDOS21\ETC
DEVICE = D:\TCPDOS21\BIN\IBMXLN.DOS
DEVICE = D:\TCPDOS21\BIN\DOSTCP.SYS
DEVICE=\LSP133\DXMA0MOD.SYS 001
DEVICE=\LSP133\DXME0MOD.SYS
```

```
DEVICE=\LSP133\DXMT0MOD.SYS 0=N ES=2 EST=3
DEVICE = C:\DOS52\ANSI.SYS
```

### **CONFIG.SYS for TCPWIN**

```
DEVICE=C:\DOS52\SETVER.EXE
DEVICE=C:\WIN31\HIMEM.SYS
REM DOS=HIGH
FILES=30
BUFFERS=40
DEVICE=C:\WIN31\SMARTDRV.EXE /DOUBLE_BUFFER
STACKS=9,256
DEVICE = D:\TCPWIN21\BIN\PROTMAN.DOS /I D:\TCPWIN21\ETC
DEVICE = D:\TCPWIN21\BIN\IBMXLN.DOS
DEVICE = D:\TCPWIN21\BIN\DOSTCP.SYS
DEVICE=\LSP133\DXMA0MOD.SYS 001
DEVICE=\LSP133\DXME0MOD.SYS
DEVICE=\LSP133\DXMT0MOD.SYS 0=N ES=2 EST=3
DEVICE = C:\DOS52\ANSI.SYS
```

### **AUTOEXEC.BAT for TCPDOS**

```
D:\TCPDOS21\BIN\NETBIND
SET ETC=D:\TCPDOS21\ETC
C:\WIN31\SMARTDRV.EXE /L
@ECHO OFF
PROMPT $P$G
REM OLD PATH STATEMENT
REM PATH C:\WIN31;C:\DOS52;D:\PCS\RUMBAPCS;C:\RUMBAPCS
REM OLD PATH STATEMENT
REM PATH C:\WIN31;C:\DOS52;D:\PCS\RUMBAPCS;C:\RUMBAPCS;D:\TCPDOS21\BI
PATH C:\WIN31;C:\DOS52;D:\TCPDOS21\BIN;
KEY
TEMP=C:\DOS52
C:\WIN31\MOUSE.COM /Y
```

### **AUTOEXEC.BAT for TCPWIN**

```
\LSP133\NETBIND
SET ETC=D:\TCPWIN21\ETC
C:\WIN31\SMARTDRV.EXE /L
@ECHO OFF
PROMPT $P$G
REM OLD PATH STATEMENT
REM PATH C:\WIN31;C:\DOS52;D:\PCS\RUMBAPCS;C:\RUMBAPCS
REM OLD PATH STATEMENT
REM PATH C:\WIN31;C:\DOS52;D:\PCS\RUMBAPCS;C:\RUMBAPCS;D:\TCPDOS21\BI N
PATH C:\WIN31;C:\DOS52;D:\TCPWIN21\BIN;
DOSKEY
SET TEMP=C:\DOS52
C:\WIN31\MOUSE.COM /Y
```

### **PROTOCOL.INI for TCPDOS**

```
; ----- Protocol Manager Definition -----
{PROTMAN_MOD}
    DriverName = PROTMANS

; ----- Protocol Driver Definition -----
; IBM TCP/IP V2.1 for DOS
;
{TCPIP_V21}
    DriverName = DOSNDIS$
```

```

; ---- Bindings Statement ----
    Bindings = IBMXLN,,,

; ----- IBM LAN Support Program V1.3 -----
{DXMEQ_MOD}
    DriverName = DXMEQ$
    Bindings = IBMXLN

{DXMTQ_MOD}
    DriverName = DXMTQ$
    Bindings = IBMXLN

; ----- Adaptor Definitions -----

; ----- IBM Token Ring Adapter Definition -----
{IBMTOK}
; IBM Token Ring
; IBMTOK.DOS
    DriverName = IBMTOK$

; ----- IBM Token Ring Adapter Definition (2nd one) -----
{IBMTOK2}
; IBM Token Ring (2nd)
; IBMTOK.DOS
    DriverName = IBMTOK2$

; ----- IBM PS/2 Adapter/A for Ethernet Networks -----
{IBMAC}
; IBM Ethernet
; MACETH.DOS
    DriverName = MACETH$
    IRQ = 10
    RamAddress = 0xC800
;
; Specify IOBase only for IBM PC Family adapters. (Must match adapter jumpers!)
;
    IOBase = 0x200
    ReceiveBuffers = 16
    ReceiveChains = 16
    MaxRequests = 10
    MaxTransmits = 10
    ReceiveBufSize = 256

; ----- IBM PS/2 Adapter/A for Ethernet Networks (2nd one) -----
{IBMAC2}
; IBM Ethernet (2nd)
; MACETH2.DOS
    DriverName = MACETH2$
    IRQ = 15
    RamAddress = 0xD800
;
; Specify IOBase only for IBM PC Family adapters. (Must match adapter jumpers!)
;
    IOBase = 0x280
    ReceiveBuffers = 16
    ReceiveChains = 16
    MaxRequests = 10
    MaxTransmits = 10
    ReceiveBufSize = 1500

; ----- 3Com Network Adapter Definition -----
{TCMAC2}
; 3COM Etherlink MC
; ELNKMC.DOS
    DriverName = ELNKMC$
    MaxTransmits = 10

{STCMAC2}
; 3COM Ethlink.MC (2nd)
; ELNKMC.DOS
    DriverName = ELNKMC2$
    MaxTransmits = 10
    SlotNumber = 2

```

```

{TCMAC}
; 3COM Etherlink II
; ELNKII.DOS
  DriverName = ELNKII$
  Interrupt = 3
  IOAddress = 0x280
  DMAChannel = 1
  MaxTransmits = 10
  Transceiver = Onboard

{STCMAC}
; 3COM Ethlink.II (2nd)
; ELNKII.DOS
  DriverName = ELNKII2$
  Interrupt = 3
  IOAddress = 0x280
  DMAChannel = 1
  MaxTransmits = 10
  Transceiver = Onboard

; ----- Western Digital Network Adapter Definition -----
{WDMAC}
; Western Dig. Ethernet
; MACWD.DOS
  DriverName = MACWD$
  IRQ = 3
  RamAddress = 0x0800
;
; Specify IOBase only for IBM PC Family adapters. (Must match adapter jumpers!)
;
  IOBase = 0x280
  ReceiveBuffers = 16
  ReceiveChains = 16
  MaxRequests = 10
  MaxTransmits = 10
  ReceiveBufSize = 1500

; ----- IBM 3174 Peer Support -----
{IBMXLN}
; IBM 3174 PEER SUPPORT
; IBMXLN.DOS
  DriverName = IBMXLN$
  Maxtransmits = 6
  NETADDRESS = 400031744992
  Maxtransmits = 6

;**** END OF FILE ****

```

**Note:** The IBMXLN must be configured for 3174 Peer Support.

---

## 4.8 Using TCP/IP Application for Windows

These applications enable you to perform the primary network user tasks: file transfer, remote printing, mail management, terminal emulation, and verification of remote host connections. This section introduces the TCP/IP TELNET and PING applications for Windows.

For further information of TCP/IP applications, see Chapter 7, *IBM Transmission Control Protocol/Internet Protocol Version 2.1 for DOS: User's Guide*, SC31-7045.

### 4.8.1 Overview of the TCP/IP for Windows

The TCP/IP applications for the Windows environment are installed as a TCP/IP program group, each with its own icon, as shown in Figure 92 on page 100.

**Note:** If you are running TCP/IP for Windows, you must run TCPSTART before you load Windows.



## IBM TCP/IP for DOS

After loading Windows, you get the Program Manager panel. Click on the icon **IBM TCP/IP for DOS**, and the following panel appears.




Figure 92. The TCP/IP Program Group

All of the applications have a similar graphical user interface so that once you are familiar with one application, you will understand how to work with the others.

### 4.8.2 Windows Ping

Ping for Windows enables you to:

- Start and stop a Ping session.
- Display running Ping information.
- Display summary information for Ping sessions.
- Specify the number of times to Ping.
- Define hosts as side-bar push buttons.

#### Ping

On the IBM TCP/IP for DOS panel, click on the **Ping** icon, and the Ping panel is displayed.




Figure 93. PING

From the option-bar select **Host**, and the following panel appears.

## Host




Figure 94. HOST

Here you enter the internet address of the host you want to ping. Press the **OK** push button and the Ping panel reappears.

## Ping (OK)




Figure 95. Ping (OK)

If the foreign host is up, you get the information summary of the chosen ping session in this display.

### 4.8.3 Windows TELNET

TELNET for Windows enables you to:

- Emulate up to eight host sessions.
- Use a configuration file defined by SetTerm.
- Specify emulator preferences.
- Select a font size for a panel session.
- Access online help.

## TELNET




Figure 96. TELNET

On the IBM TCP/IP for DOS panel, click on the **TELNET** icon, and the IBM TCP/IP TELNET panel appears.

### TELNET Configure

Select **Configure**; and the actions-bar displayed.




Figure 97. IBM TCP/IP TELNET Configure

Press the **Define** push button and the Define Session panel appears, which allows you to define session parameters.

## Define Session

Define Session

Hostname: 9.67.38.73

Optional

Host nickname: joe

Configuration file:

Auto-start session

Emulator

Port number: 23

Negotiate as:

1st Choice: VT220

2nd Choice: VT100

3rd Choice: IBM-3278

Figure 98. Define Session

In the **Hostname** field, type in your destination host internet address. Using a host nickname is optional. Specify your preferred emulator negotiation choices.

**Note:** The option emulator negotiation works only for DOS TELNET. Windows TELNET does not use the emulator negotiation order information that SetTerm generates. For detailed information of the Emulator Negotiation Order, see Chapter 8, *IBM Transmission Control Protocol/Internet Protocol Version 2.1 for DOS: User's Guide*, SC31-7045.

Press the **Define** push button, and the IBM TCP/IP TELNET connection is displayed (left side of panel).

## TELNET Connection




Figure 99. IBM TCP/IP TELNET Connection

Select the **Open** icon and the Open Session panel appears.

## Open Session

Open Session

Hostname: 9.67.38.73

Optional

Host nickname: joe

Configuration file:

Emulator

Port number: 23

Negotiate as:

1st Choice: VT220

2nd Choice: VT100

3rd Choice: IBM-3278

Figure 100. Open Session

Press the **Open** push button to establish a TCP/IP TELNET session with the predefined host. The following panel appears after the session is established.

## Session Establishment

```
joe
Commands  Font  Screen Width  Help

IBM AIX Version 3 for RISC System/6000
IBM Copyrights by IBM and by others 1982, 1991.
login: joe
joe's Password:
*****
* Welcome to IBM AIX Version 3.2!
*
* Please see the README file in /usr/lpp/bos for information pertinent to
* this release of the AIX Operating System.
*
*****
Last unsuccessful login: Mon May 17 18:48:05 CDT 1993 on pts/5 from 9.67.38.87
Last login: Mon May 17 18:48:18 CDT 1993 on pts/5 from 9.67.38.87
```

Figure 101. Session Establishment

In our example, we opened a session with the RISC System/6000.

---


## 4.9 RISC System/6000 Definitions

On the RISC System/6000, we type in the following at the command prompt:

```
smit tcpip
```

The panel shown in Figure 102 is displayed.

### 4.9.1 SMIT TCP/IP



*Figure 102. SMIT TCP/IP*

Select **Minimum Configuration and Startup**. The panel shown in Figure 103 on page 106 is displayed.

## 4.9.2 Minimum Configuration and Setup

**Minimum Configuration & Startup**

To Delete existing configuration data, please use Further Configuration menus

Type or select values in entry fields.  
Press Enter AFTER making all desired changes.

	-Entry Fields-	
* HOSTNAME	-rs60001-	
* Internet ADDRESS (dotted decimal)	-9.67.38.71-	
Network MASK (dotted decimal)	-255.255.255.192-	
* Network INTERFACE	tr0	
NAMESERVER		
Internet ADDRESS (dotted decimal)	--	
DOMAIN Name	--	
Default GATEWAY Address (dotted decimal or symbolic name)	-9.67.46.193-	
RING Speed	4	+
START Now	no	+

F1=Help	F2=Refresh	F3=Cancel	F4=List
F5=Undo	F6=Command	F7=Edit	F8=Image
F9=Shell	F10=Exit	Enter=Do	

*Figure 103. Minimum Configuration and Startup*

On the Minimum Configuration and Startup menu, do the following:

- Type in your hostname.
- Specify the IP address of your workstation.
- Specify the network mask.
- Specify the network interface.
- Specify the default gateway address.
- Define the ring speed.

If you have completed your input, press Enter; the Minimum Configuration and Setup is completed.

## 4.10 3174-11R Customization

In 3174-11R customization, do the following:

- Specify the 3174-11R SDLC address
- Define the upper limit address for DSPUs
- Specify the 3174-11R network ID
- Specify the token-ring address for the 3174-11R
- Specify the token-ring address for each PS/2.

```

_____ Model / Attach _____

098 _____
099 - 3174 11R SDLC ITSO RALEIGH BY J MINDERLEIN 19 MAY 93
100 - 11R
101 - 2

PF: 3=Quit 4=Default      8=Fwd
```

Figure 104. 3174-11R Customization

### 4.10.1 SDLC

```

_____ SDLC _____

SDLC

104 - C1 1 105 - C8 2 108 - 0000000 110 - 1 0000 116 - 2 _ _
121 - 01 123 - 0 125 - 00000000 126 - 00000000 127 - 0 0
132 - 0 0 0 0 136 - 1 0 0 1 137 - 0 0 0 0 138 - 0
141 - A 150 - 1 0 3 165 - 1 166 - A 168 - 0
173 - 00000000 175 - 179 - 0 0 0 190 - 00
213 - 1 215 - 00000 220 - 0
310 - 0 313 - 1 317 - 0 318 - 0 340 - 1
365 - 0 370 - 1

PF: 3=Quit 4=Default 7=Back 8=Fwd
```

Figure 105. Customizing the 3174-11R for an SDLC Link

- 1 Question 104 specifies the SDLC address of the 3174-11R.
- 2 Question 105 defines the upper limit poll address for DSPUs. We will use poll address:



- C3 for the PS/2 DOS coax-attached workstation
- C5 for the PS/2 OS/2 coax-attached workstation

**3** Question 150= 10 enables the token-ring gateway function for DSPUs.

### 4.10.2 Common SNA

```

_____ Common SNA _____
C1/SDLC

500 - 0      501 - _____  502 - _____

APPN Support Fields:

510 - 0      511 - _____  512 - _____

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

```

Figure 106. Names to Identify the 3174-11R Network Node

Use default responses on this panel.

### 4.10.3 Common Network

```

_____ Common Network _____
C1/SDLC

900 - 4000 3174 0002 04 1 905 - 1      908 - IBMLAN
911 - 0      912 - 00

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

```

Figure 107. Token-Ring Definition for the 3174-11R

**1** Question 900 specifies the token-ring address of the 3174-11R.

## 4.10.4 Ring Address Assignment

940: Ring Address Assignment							
S	Ring Address	SAP	T	S	Ring Address	SAP	T
C1	4000 3174 0002	04					
C2	4000 3174 1992	04	0	C3	4000 3174 4992	1 04	0
C4	4000 3174 3992	04	0	C5	4000 3174 2992	2 04	0
C6	4000 3174 5992	04	0	C7	4000 3174 6992	04	0
C8	4000 3174 0003	04	1				

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

Figure 108. Ring Address Assignment

- 1 C3 for the PS/2 DOS coax-attached workstation
- 2 C5 for the PS/2 OS/2 coax-attached workstation

---

## 4.11 3174-Peer Definition

3174 Peer Communication is referred to in the customizing panels as the 3174-Peer Support.

3174-Peer Support provides a logical internal token-ring segment and a bridge to a real external token-ring network segment. Each coax-attached PS/2 workstation appears to be attached to the internal token-ring.

In the customizing panel descriptions, the following terms are used:

- *3174-Peer device* refers to a coax-attached PS/2 workstation.
- *3174-Peer port* refers to the coax port to which a PS/2 workstation is attached.
- *3174-Peer bridge* refers to the internal bridge.
- *3174-Peer segment* refers to the internal token-ring segment .
- *Token-Ring segment* refers to the external token-ring segment.

Each 3174-Peer device can have a token-ring address:

- Specified as a DXML1MOD.SYS parameter in its CONFIG.SYS file or the parameter NETADDRESS in the PROTOCOL.INI file.
- Assigned by the 3174-Peer Support according to its port number, with some portion of the address specified by the user.

The 3174-Peer Definition panels allow you to:

- Enable the internal token-ring segment
- Enable the internal bridge function
- Customize the internal bridge parameters
- Enable LAN Manager support

- Specify the middle six hexadecimal digits of the 3174-assigned token-ring address for the 3174-Peer devices.

3174-Peer Definition		
3174-Peer Support		
650 - Y	3174-Peer Support	(Y,N)
3174-Peer Options		
651 - Y	Bridge Support	(Y,N)
652 - N	LAN Manager Support	(Y,N)
653 - Y	3174-Peer Online Test Updates	(Y,N)
3174-Peer Station Parameters		
660 - 4000 3174 91 PN	3174-Peer Port Address Range	(0000 00 - FFFF FF)
661 - 05	Percentage of Discard Threshold	(00 - 99)
PF: 3=Quit    4=Default    8=Fwd		

Figure 109. Enabling 3174 Peer Communication Functions

#### 4.11.1 Question 650: 3174-Peer Support

The response indicates whether the internal token-ring segment is to be enabled. Valid responses are:

Y = Yes

N = No (default response)

If the response is Y, then the Peer Communication function will be included and operational when the 3174 is IMLed. A Y response increases the total control storage required on the 3174.

For Scenario 1, the DOS and OS/2 workstations will use 3174-Peer Support to form an internal token-ring segment.

#### 4.11.2 Question 651: Bridge Support

The response indicates whether the internal bridge function is to be enabled. This bridge function requires that the 16/4 Mbps Token-Ring Network Adapter be installed in the 3174. Valid responses are:

Y = Yes

N = No (default response)

You must respond with a Y if you want the 3174-Peer devices to communicate:

- With devices on the external token-ring for server/requester functions, for example, a 3174-Peer device requester accessing an external server or an external requester accessing a 3174-Peer device server.
- As DSPUs to the 3174 gateway (the 3174 you are now customizing).

A Y response increases the total control storage required on the 3174.

For Scenario 1, the DOS and OS/2 workstations on the internal token-ring segment will use the 3174-Peer bridge to bridge to the external token-ring network.

### 4.11.3 Question 652: LAN Manager Support

**Note:** The **LAN Manager** referred to here does not mean the IBM LAN Manager V1 and V2, or the Microsoft LAN Manager, or the LAN Network Manager V1.0 products. The first product officially supported is the IBM LAN Network Manager V1.1.

The response indicates whether support for a LAN Network Manager is to be enabled. Valid responses are:

Y = Yes

N = No (default response).

If your response is Y, then LAN Network Manager will support the LAN Reporting Mechanism in the 3174-Peer bridge and provide functions such as:

- LAN Bridge Server
- Ring Parameter Server
- Configuration Report Server (for the 3174-Peer segment only)
- Ring Error Monitor (for the 3174-Peer segment only)

If the LAN Manager support is enabled, the 3174-Peer bridge must also be enabled (Question 651=Y). LAN Network Manager V1.1 is required to manage a 3174-Peer segment.

For Scenario 1, no LAN Manager is used. You should respond with an N.

With the LAN Manager support disabled, you can update 3174-Peer status and bridge profile parameters via online Test 9 (LAN tests).

A Y response increases the total control storage required on the 3174.

### 4.11.4 Question 653: 3174-Peer Online Test Updates

The response is used in conjunction with Questions 651 and 652 to determine the update options you are allowed to perform via the LAN Test Menu. Valid responses are:

Y = Yes

N = No (default response)

<i>Table 3. 3174-Peer Online Test Updates Allowed</i>			
<b>Q651: Bridge Support</b>	<b>Q652: LAN Manager Support</b>	<b>Q653: 3174-Peer Online Test Updates</b>	<b>Updates Allowed Via</b>
N/A	Y	Y	Test 9, option 12 LAN Manager profile
Y	N	Y	Test 9, option 9 3174-Peer status Test 9, option 10 3174-Peer bridge profile
N	N	Y	Test 9, option 9 3174-Peer status

You must enter a password in Question 98 (Online Test Password) if you want to use the 3174-Peer Online Test Updates capability. If a password is not provided in Question 98, this capability is deconfigured when the 3174 is IMLed.

#### 4.11.5 Question 660: 3174-Peer Port Address Range

We have mentioned before that there are two ways to give a 3174-Peer device a token-ring address:

- As a DXML1MOD.SYS parameter in its CONFIG.SYS file
- Assigned by the 3174 Peer Communication function according to its port number, with some portion of the address specified by the user

Question 660 allows you to enter the user-specified portion of the address.

The format of the address is as shown in Figure 110.




Figure 110. Format of 3174-Peer Device Address

- 1** 4000 is a protected field and cannot be modified.
- 2** XXXXXX is the user-specified portion of the address. The valid range is from hexadecimal '000000' to 'FFFFFF'.
- 3** PN is the port number to which the 3174-Peer device is attached. This value ranges from 00 (HG26-00) to 63 (HG27-31).

As shown in Figure 109 on page 110, we have entered 317491 as the user-specified portion of the address. This means that a 3174-Peer device attached to port HG26-23 will have a 3174-assigned address of 400031749123. Another 3174-Peer device attached to port HG27-23 will have a 3174-assigned address of 400031749155.

**Note:** The *3174 Planning Guide* description for Question 660 gives an impression that the addresses in this example would be 400031749117 (port HG26-23 decimal 23 converted to X'17') and 400031749137 (port HG27-23 decimal 55 converted to X'37'). Using Online Test 9 option 9, the addresses are displayed with the port numbers in decimal.

In addition, if the LAN Manager Support is enabled in Question 652, then the 3174 has an address with a PN of FF on the internal token-ring. In our example, this address is 4000317491FF.

Note that if an address is specified via the DXML1MOD.SYS driver:

- It will override the 3174-assigned address.
- It must be outside the range of addresses available for assignment by the 3174 if you wish to have port-independent addressing. In our example, it should be outside the range 400031749100 to 400031749163.
- It must not be the address of the 3174 when the LAN Manager Support is enabled. In our example, it must not be 4000317491FF.

If 3174-Peer Support and Bridge Support are both enabled, you should check that no other device uses any of the 3174-Peer Support addresses in Questions 106, 107, 900 and 940.

**Recommendation:** We recommend that you specify 3174-Peer device addresses via the DXML1MOD.SYS driver. This will give you addressing independent of the port numbers and allow 3174-Peer devices to be swapped from one port to another without problems.

#### **4.11.6 Question 661: Percentage of Discard Threshold**

As a 3174-Peer device becomes congested, it cannot receive as many frames and starts to discard those it cannot receive. The more frames it discards within a given time interval, the more congested the device becomes.

Question 661 allows you to specify a threshold to use in deciding when a device has become congested. The valid range of response is 00 to 99. The default response is 05; this means that we consider a device to be congested if more than 5% of the frames are discarded in any one-minute interval. If you specify 00, it means that we consider a device to be congested if it discards any frame at all in any one-minute interval.

#### **4.11.7 3174-Peer Bridge Profile**

The 3174-Peer Bridge Profile panel allows you to specify parameters to be used by the internal bridge function. These parameters include:

- The internal bridge number
- The internal ring segment number
- The external token-ring network segment number
- The number of hops over which a broadcast frame can cross
- Whether frames will be forwarded by the bridge
- Setting threshold for bridge congestion
- How long to wait before logging a bridge congestion
- How long to wait before sending an alert about a congested bridge

3174-Peer Bridge Profile		
670 - 1	Bridge Number	(0-F)
671 - BB3	Token-Ring Segment Number	(001-FFF)
672 - 002	3174-Peer Segment Number	(001-FFF)
673 - 7	Token-Ring Hop Count	(1-7)
674 - Y	Frame Forwarding Active	(Y,N,W)
675 - 0010	Bridge Performance Threshold (Frames Discarded Per 10,000)	(0000-9999)
676 - 02 00	Logging Interval	(00-99 Hours 00-59 Minutes)
677 - 010	Alert Threshold	(000-255)

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 111. 3174-Peer Bridge Parameters

### Question 670: Bridge Number

The response assigns a number to the internal 3174-Peer bridge. The valid range of response is a hexadecimal value from 0 to F, with 1 being the default. The bridge number is required for source routing.

If there is more than one 3174-Peer segment on the same token-ring network, the 3174-Peer bridge number can be the same for all the 3174-Peer bridges.

### Question 671: Token-Ring Segment Number

The response assigns a number to the external (real) token-ring network segment. The valid range of response is a hexadecimal value from 001 to FFF, with no default. It is required for source routing.

If the 3174 is attached to an existing token-ring network, you should use the segment number already assigned to the token-ring network for question 671.

If an IBM Token-Ring Network Bridge Program station is active on the token-ring network, you must use the segment number assigned by the Bridge Program for question 671. If the numbers do not match, the 3174-Peer bridge will not be able to communicate on the token-ring network.

If there is more than one 3174-Peer segment on the same token-ring network, the token-ring network segment number must be the same for all the 3174-Peer segments (obviously, since they are attached to the same token-ring network).

The token-ring network segment number, however, cannot be the same as the 3174-Peer segment number.

### Question 672: 3174-Peer Segment Number

The response assigns a number to the internal ring segment (the 3174-Peer segment). The valid range of response is a hexadecimal value from 001 to FFF, with no default.

If there is more than one 3174-Peer segment on the same token-ring network, the 3174-Peer segment number must be different for all the 3174-Peer segments.

It must also be different from the token-ring network segment number. If the token-ring network is bridged to other token-ring networks, you must ensure that all 3174-Peer segment numbers are unique throughout the entire network.

### **Question 673: Token-Ring Hop Count**

The response specifies the maximum number of bridges that a broadcast frame can cross. The valid range of response is a from 1 to 7, with 7 as the default.

Note that the 3174-Peer bridge is counted as one hop when frames cross from the 3174-Peer segment to the external token-ring network or vice versa.

### **Question 674: Frame Forwarding Active**

The response indicates whether the 3174-Peer bridge is to forward frames it receives. Valid responses are:

Y=Yes (default response)

N=No

W=Wrap mode

Enter:

- Y if you want the 3174-Peer bridge to forward frames as well as process frames received from the token-ring network, or if a wrap plug is used on the Token-Ring Adapter in the 3174.
- N if you do not want the 3174-Peer bridge to forward frames received from the token-ring network. In fact, it will discard any frames it receives and stop incrementing the discard frame counters.
- W if a token-ring adapter cable is connected to the Token-Ring Adapter in the 3174 but not to the token-ring network (that is, not plugged into, for example, an 8230 Controlled Access Unit) and you want the adapter to open in wrap mode. Wrap mode allows 3174-Peer devices to access the 3174 token-ring gateway function for host communication without requiring the 3174 to be physically connected to a token-ring.

#### **Note:**

Before Configuration Support-C Release 3, you could put the 3174 into wrap mode by doing one of the following (depending on the microcode level):

- Install a wrap plug (PN 6165899) instead of the Token-Ring Adapter cable at the 3174 Token-Ring Adapter port; respond to question 674 with a Y.
- Install a Token-Ring Adapter cable at the 3174 Token-Ring Adapter port and apply patch TR 824501 (3174 Peer Communication Wrap Mode); respond to question 674 with a Y.

**Note:** Patch TR 824501 is only valid for the Peer Communications RPQ 8Q0718 (Configuration Support-B Release 4). This patch is not needed for Configuration Support-C Release 1 and later because Online Test /9,10 support for wrap mode was added.

- Install a Token-Ring Adapter cable at the 3174 Token-Ring Adapter port; use Online Test /9,10 to set the **Frame Forwarding Active** response to W.



With Configuration Support-C Release 3, you could put the 3174 into wrap mode by doing one of the following:

- Install a wrap plug (PN 6165899) instead of the Token-Ring Adapter cable at the 3174 Token-Ring Adapter port; respond to question 674 with a Y.
- Install a Token-Ring Adapter cable at the 3174 Token-Ring Adapter port; respond to question 674 with a W (Wrap).
- Install a Token-Ring Adapter cable at the 3174 Token-Ring Adapter port; use Online Test /9,10 to set the **Frame Forwarding Active** response to W.

Configuration Support-C Release 3 allows you to set the wrap mode through customization instead of using Online Test /9,10. The token-ring adapter is still required.

### **Question 675: Bridge Performance Threshold**

The response specifies the maximum percentage of information frames that may be discarded by the internal bridge within a one-minute interval before a count is incremented. The valid range is from 0000 to 9999; the number is in hundredths of a percent or the number of frames per 10,000. The default is 0010 and means that the discard counter will be incremented by one if 0.1% (10 hundredths of a percent) of the frames received within any one-minute interval are discarded. It is the same as saying the discard counter will be incremented by one if 10 out of every 10,000 frames received within any one-minute interval are discarded.

A separate count is maintained for frames received from the token-ring network and frames received from the 3174-Peer segment.

### **Question 676: Logging Interval**

When the internal bridge performance threshold is exceeded at the end of a one-minute interval, the bridge is congested. To measure how serious the congestion is, you can specify a time interval during which the congestion is monitored.

The monitoring begins at the end of the one-minute interval when the congestion occurred, counting that one-minute interval as the first minute of the monitoring interval. At the end of the monitoring interval, the Log Manager is invoked to record the number of minutes in that interval during which the bridge was congested. The number of minutes and a non-alertable status code are recorded in the event log. This information is time stamped.

Question 676 allows you to set the monitoring interval. The valid range of response is from 00 Hours 00 Minutes to 99 Hours 59 Minutes, with the default being 02 00 (every two hours). If 00 Hours 00 Minutes is specified, then no logging of the bridge congestion is invoked. If you specify any interval other than 0000, then logging begins only after bridge congestion has been detected.

### **Question 677: Alert Threshold**

Within the monitoring interval set by Question 676, you can set another threshold to raise an alert if the congestion is serious. Question 677 allows you to set this alert threshold. The valid range of response is from 000 to 255, with the default being 010 minutes.

Using the default logging interval (0200) and default alert threshold (010) as an example, if bridge congestion is detected then monitoring begins. If bridge congestion total time is less than 10 minutes (the alert threshold), no alert is raised and logging is invoked at the end of two hours.

As soon as bridge congestion total time reaches 10 minutes (the alert threshold), an alert is raised, the Log Manager is immediately invoked to record a status code and the alert threshold in the event log and the logging interval is treated as if it has completed.

#### **4.11.8 LAN Manager Profile**

The LAN Manager Profile panel allows you to specify a password for each reporting link. The following rules apply to the reporting link passwords:

- The passwords need not be unique.
- Each password must be six to eight characters in length.
- Each character must be in the range 0-9 and A-Z.
- No blanks preceding or imbedded in the password are allowed
- The default is all blanks (no password specified).

The following questions allow you to specify the passwords:

- Question 690: Reporting Link 0 Password
- Question 691: Reporting Link 1 Password
- Question 692: Reporting Link 2 Password
- Question 693: Reporting Link 3 Password

## 4.12 Display 3174-Peer Status

```
----- Display 3174-Peer Status - HG 26 -----
Port Address      Current      Functional  Group      Discarded  Device
Address          Address      Address     Address    Frame Ctr  Status
00
01
02
03
04
05 4000 3174 2992 ..... 0 1 1
06 4000 3174 4992 ..... 0 1 1
06
07
08
09
10
11
12
13
14
15

To go directly to other tests, enter: /Test,Option
Select Test; press ENTER ==>
PF: 3=Quit 5=Refresh 8=Fwd 9=Ctr->0 12=Test Menu
```

Figure 112. Display 3174-Peer Status

**1** The **1** means the interface is enabled

For detailed information about Online Test Status Information see Chapter 5 in the *Customer Problem Determination Guide*, , GA23-0217.

---

## Chapter 5. Scenario 2: Concurrent Access to SNA and TCP/IP Hosts

This scenario shows the concurrent ability of the:

- RISC System/6000 workstation to access the 3270 SNA host, using the 3174-12L as the SNA gateway.
- The 3270 terminal to access the 3270 SNA host, using the 3174-12L as a cluster controller.
- The same 3270 terminal to access the RISC System/6000, using the 3174-12L as the TCP/IP TELNET client.

The 3174-12L is attached to the S/390 host via an ESCON channel connection.

---

### 5.1 Scenario 2 Configuration Diagram




Figure 113. 3174 MLT Access to SNA 3270 and TCP/IP Hosts

---

## 5.2 Scenario 2 Configuration Description

The composite network has the following components:

- An S/390 host with VTAM\* V4.1
- A 3174-12L Establishment Controller with:
  - An ESCON connection
  - Token-ring address of 400031740004
- A RISC System/6000
  - Token-ring address of 100054AF58CE
- 3270 terminal

### 5.3 3174-12L Multi-Host Customization

In 3174-12L customization, we do the following:

- Define a multi-host connection.
- Specify the 3174-12L SNA channel addresses.
- Specify the 3174-12L network ID.
- Specify the token-ring address for the 3174-12L.
- Specify the token-ring address for the RISC System/6000.

#### Model/Attach

```

_____ Model / Attach _____
098 _____
099 - 3174 12L ESCON ITS0 RALEIGH BY JM 28 MAY          93
100 - 12L
101 - M 1

PF: 3=Quit 4=Default      8=Fwd
```

Figure 114. 3174-11L Multi-Host Customization

**1** Question 101 response is M for multi-host attachment.

## Multi-Host Definition

Multi-Host Definition Entry 01 of 16

Fill in a new host, change a host or select a host for configuring

Host	Adapter	Host	Hardware	Include	Host Descriptor
ID	Type	Attach	Group	in IML	
1A	1	5			PRIMARY_SNA_CH30
2A	-	-	-	-	_____
3A	-	-	-	-	_____
1B	2			1	VCU2_1B_CH37
-	-	-	-	-	_____
-	-	-	-	-	_____
-	-	-	-	-	_____
-	-	-	-	-	_____
-	-	-	-	-	_____
-	-	-	-	-	_____
-	-	-	-	-	_____
-	-	-	-	-	_____

Select ==>

PF: 3=Quit                      7=Back                      11=PageFwd    12=Done

Figure 115. Multi-Host Definition

- 1 On this panel we define host ID 1A as the primary host via channel address 30.
- 2 We define host ID 1B as the secondary host via channel address 37.

## Local (SNA) 1A Host

LT=	Local (SNA)				LOCL
	1A = PRIMARY SNA CH30				
104 - 60 <b>1</b>	105 - 6F <b>2</b>	108 - 23CQ302	110 - 4 0000	116 - 1_ _	
121 - 03	123 - 0	125 - 01000100	126 - 00000000	127 - 0 0	
132 - 0 0 0 0	136 - 1 0 0 1	137 - 0 0 0 0	138 - 0		
141 - A	150 - 1 0 <b>3</b>	165 - 1	166 - A	168 - 1	
173 - 00000000	175 -	179 - 1 0 1	190 - 00		
213 - 1	215 - 00000	220 - 0			
240 - 0 <b>4</b>	241 - 0	242 - 0			

PF: 3=Quit 4=Default 8=Fwd

Figure 116. Customizing the 3174-12L for an ESCON Connection

- 1** Question 104 specifies the controller address of the 3174-12L.
- 2** Question 105 defines the upper limit address.
- 3** Question 150=10 enables the token-ring gateway function for DSPUs.
- 4** Question 240 is the controller logical address.



## Common SNA

```
Common SNA
IA = PRIMARY SNA CH30
C66/LOCL

500 - 0      501 - _____  502 - _____
APPN Support Fields:
510 - 0      511 - _____  512 - _____

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH
```

Figure 117. Names to Identify the 3174-12L Network Node

Use the defaults on this panel.

## Common Network

```
Common Network
IA = PRIMARY SNA CH30
C66/LOCL

          1 2
900 - 4000 3174 0004 04 905 - 1      908 - IBMLAN
911 - 0      912 - 00

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH
```

Figure 118. Token-Ring Definition for the 3174-12L

**1** Question 900 specifies the token-ring address of the 3174-12L.

**2** SAP=04 for the primary host.

**Note:** In multi-host connections, the primary host has SAP=04. The secondary host must have a different SAP number.

## Ring Address Assignment

940: Ring Address Assignment							
1A = PRIMARY SNA CH30							
				C60/LOCL			
S	Ring Address	SAP	T	S	Ring Address	SAP	T
60	4000 3174 0004	1 04					
61	1000 5A4F 58CE	2 04	0	62	XXXX XXXX XXXX	04	0
63	XXXX XXXX XXXX	04	0	64	XXXX XXXX XXXX	04	0
65	XXXX XXXX XXXX	04	0	66	XXXX XXXX XXXX	04	0
67	XXXX XXXX XXXX	04	1				

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

Figure 119. Ring Address Assignment

- 1 The token-ring gateway address is assigned to host address 60.
- 2 The token-ring address of the RISC System/6000 is assigned to host address 61.

## Ring Transmission Definition

941: Ring Transmission Definitions								
1A = PRIMARY SNA CH30								
				C60/LOCL				
S	Ring Address	SAP	F	W	S	Ring Address	SAP	T
60	4000 3174 0004	04						
61	1000 5A4F 58CE	04	1	1 7 2	62	XXXX XXXX XXXX	04	0
63					64			0
65					66			0
67								

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

Figure 120. Ring Transmission Definition

- 1 Is the value of transmit I-frames (1 = 521 bytes).

For detailed information about transmit I-frames, see *AIX Version 3 RISC System/6000, Communication Concepts and Procedures, Volume 2, GC23-2203*.

- 2 Maximum-Out (transmit window size) - the number of transmits before waiting to receive an acknowledgment.

## Port Assignment

```

117: Port Assignment
LT=
IA = PRIMARY SNA CH30
Host addresses
Port IS 1 2 3 4 5
26-00 1
26-02 1
26-04 1
26-06 1
26-08 1
26-10 0
26-12 0
26-14 0
26-16 0
26-18 0
26-20 0
26-22 0
26-24 0
26-26 0
26-28 0
26-30 0
Host addresses
Port IS 1 2 3 4 5
26-01 1
26-03 1
26-05 1
26-07 1
26-09 1
26-11 0
26-13 0
26-15 0
26-17 0
26-19 0
26-21 0
26-23 0
26-25 0
26-27 0
26-29 0
26-31 0
60/LOCL

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH 11=PageFwd

```

Figure 121. Port Assignment

This is a panel that appears during the Configure procedure if you respond to Question 116 with 1 or 2. For detailed information, see *3174 Establishment Controller Planning Guide, Configuration Support C Release 3, GA27-3918*.

## Port Address

```

118: Port Address
LT=010
IA = PRIMARY SNA CH30
Host addresses
Port IS 1 2 3 4 5
26-00 1 02
26-02 1 04
26-04 1 06
26-06 1 08
26-08 1 0A
26-10 0
26-12 0
26-14 0
26-16 0
26-18 0
26-20 0
26-22 0
26-24 0
26-26 0
26-28 0
26-30 0
Host addresses
Port IS 1 2 3 4 5
26-01 1 03
26-03 1 05
26-05 1 07
26-07 1 09
26-09 1 0B
26-11 0
26-13 0
26-15 0
26-17 0
26-19 0
26-21 0
26-23 0
26-25 0
26-27 0
26-29 0
26-31 0
60/LOCL

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH 11=PageFwd

```

Figure 122. Port Address

This panel appears on the screen after the 117 panel if you assign your own addresses. The customizer cannot enter information on this panel.

## Local (SNA) 1B Host

```

      _____ Local (SNA) _____
      1B = VCU2 1B CH37
104 - 80 1 105 - 8F 2
                                     LOCL
                                     116 - 1 _ _
                                     125 - 00*****0
                                     127 - 0 0

                                     150 - 1 0 3 165 - 0
                                     179 - 1 0 1 190 - 00
                                     215 - 00000 220 - 3 221 - 0

240 - 7 4

PF: 3=Quit 4=Default 8=Fwd

```

Figure 123. Customizing the 3174-12L for an ESCON Connection (1B Host)

- 1 Question 104 specifies the controller address of the 3174-12L.
- 2 Question 105 defines the upper limit address.
- 3 Question 150=10 enables the token-ring gateway function for DSPUs.
- 4 Question 240 is the controller logical address.

### 5.3.1 Common Network (1B Host)

```

      _____ Common Network _____
      1B = VCU 1B CH37
      1 2
900 - 4000 3174 0004 08 905 - 1 908 - IBMLAN
911 - 0 912 - 00

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

```

Figure 124. Token-Ring Definition for the 3174-12L

- 1 Question 900 specifies the token-ring address of the 3174-12L.
- 2 SAP=08 for the secondary host.

**Note:** In multi-host connections, the secondary host must have a SAP number different from the primary one. In our case, we have SAP=08.

### 5.3.2 Ring Address Assignment (1B Host)

940: Ring Address Assignment							
1B = VCU2 1B CH37							
							C67/LOCL
S	Ring Address	SAP	T	S	Ring Address	SAP	T
80	4000 3174 0008	1 04					
81	1000 5A4F 58CE	2 04	0	82	XXXX XXXX XXXX	04	0
83	XXXX XXXX XXXX	04	0	84	XXXX XXXX XXXX	04	0
85	XXXX XXXX XXXX	04	0	86	XXXX XXXX XXXX	04	0
87	XXXX XXXX XXXX	04	1				

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

Figure 125. Ring Address Assignment (1B Host)

- 1 The token-ring gateway address is assigned to host address 80.
- 2 The token-ring address of the RS/6000 is assigned to host address 81.

### 5.3.3 Ring Transmission Definition (1B Host)

941: Ring Transmission Definitions								
1B = VCU2 1B CH37								
							C76/LOCL	
S	Ring Address	SAP	F	W	S	Ring Address	SAP	T
80	4000 3174 0004	08						
81	1000 5A4F 58CE	04	1	1 2 2	82	XXXX XXXX XXXX	04	0
83					84			0
85					86			0
87								

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

Figure 126. Ring Transmission Definition (1B Host)

- 1 Is the value of transmit l-frames (1 = 521 bytes).
- 2 Maximum-Out (transmit window size) - the number of transmits before waiting to receive an acknowledgment.

## Port Assignment (1B Host)

```

117: Port Assignment
LT=          1B = VCU2 1B CH37          116=1          70/LOCL
Host addresses
Port IS 1 2 3 4 5          Port IS 1 2 3 4 5
26-00 1 _____
26-02 1 _____
26-04 1 _____
26-06 1 _____
26-08 1 _____
26-10 0 _____
26-12 0 _____
26-14 0 _____
26-16 0 _____
26-18 0 _____
26-20 0 _____
26-22 0 _____
26-24 0 _____
26-26 0 _____
26-28 0 _____
26-30 0 _____
26-01 1 _____
26-03 1 _____
26-05 1 _____
26-07 1 _____
26-09 1 _____
26-11 0 _____
26-13 0 _____
26-15 0 _____
26-17 0 _____
26-19 0 _____
26-21 0 _____
26-23 0 _____
26-25 0 _____
26-27 0 _____
26-29 0 _____
26-31 0 _____

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH          11=PageFwd

```

Figure 127. Port Assignment (1B Host)

This is a panel that appears during the Configure procedure if you respond to Question 116 with 1 or 2. For detailed information, see *3174 Establishment Controller Planning Guide, Configuration Support C Release 3, GA27-3918*.

## Port Address

```

118: Port Address
LT=010          1B = VCU2 1B CH37          116=1          70/LOCL
Host addresses          60/LOCL
Port IS 1 2 3 4 5          Port IS 1 2 3 4 5
26-00 1 02 _____
26-02 1 04 _____
26-04 1 06 _____
26-06 1 08 _____
26-08 1 0A _____
26-10 0 _____
26-12 0 _____
26-14 0 _____
26-16 0 _____
26-18 0 _____
26-20 0 _____
26-22 0 _____
26-24 0 _____
26-26 0 _____
26-28 0 _____
26-30 0 _____
26-01 1 03 _____
26-03 1 05 _____
26-05 1 07 _____
26-07 1 09 _____
26-09 1 0B _____
26-11 0 _____
26-13 0 _____
26-15 0 _____
26-17 0 _____
26-19 0 _____
26-21 0 _____
26-23 0 _____
26-25 0 _____
26-27 0 _____
26-29 0 _____
26-31 0 _____

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH          11=PageFwd

```

Figure 128. Port Address (1B Host)

This panel appears on the screen after the 117 panel if you assign your own addresses. The customizer cannot enter information on this panel.

### 5.3.4 Configure Complete




Figure 129. Configure Complete

## 5.4 3174 TCP/IP Customizing

### 5.4.1 Enabling AEA And TCP/IP

```

      _____ AEA and TCP/IP Configure _____
      700 - 0 1
      702 - 1
      703 - 0
      710 - 00000000      711 - 00000000      712 - 00000000      713 - 00000000

      PF: 3=Quit      4=Default      7=Back      8=Fwd

```

Figure 130. AEA and TCP/IP Configure Panel

For a detailed description of each customizing Question, see 3.9, "Customizing 3174 TCP/IP Telnet Support" on page 24 or *3174 Establishment Controller Planning Guide, Configuration Support C Release 3, GA27-3918*.

#### **Question 700: Configure AEA and TCP/IP Feature**

We only have 3270 terminals attached, thus we only to set digit 2 of Q170, to 1. For Scenario 2, we have customized only the TCP/IP capabilities.

Questions 702, 703 and 710 are not affected by the 3174 TCP/IP Telnet Support.



## 5.4.2 Defining Port Set

Port Set				
Name	Session Limit	Port Type	Modem Type	Password
1 = 3270DISP	4	1	-	_____
2 = _____	-	-	-	_____
3 = _____	-	-	-	_____
4 = _____	-	-	-	_____
5 = _____	-	-	-	_____
6 = _____	-	-	-	_____
7 = _____	-	-	-	_____
8 = _____	-	-	-	_____
9 = _____	-	-	-	_____
10 = _____	-	-	-	_____
11 = _____	-	-	-	_____
12 = _____	-	-	-	_____
13 = _____	-	-	-	_____
14 = _____	-	-	-	_____
15 = _____	-	-	-	_____
16 = _____	-	-	-	_____

PF: 3=Quit 4=Default 7=Back 8=Fwd

Figure 131. Port Set Panel

Use this panel to define a port set for the 3270 displays to allow them to access TCP/IP destinations:

- Enter **3270DISP** in the Name field.
- Select a session limit that matches the number of LTs you want the 3270 displays to have (the default is 1 and we have chosen 4).
- Enter a 1 in the Port Type field for our 3270 displays.

For our example, we have customized a port set for coax-attached 3270 displays.

### 5.4.3 Mapping Port To Port Set

Port to Port Set Map Page 01 of 03

Type the port set number to group the 3174 ports

3270 Ports	0	1	2	3	4	5	6	7
26-00 to 26-07	1	1	1	1	1	1	1	1
26-08 to 26-15	1	1						
26-16 to 26-23								
26-24 to 26-31								

Port Sets			
1 = 3270DISP	2 =	3 =	4 =
5 =	6 =	7 =	8 =
9 =	10 =	11 =	12 =
13 =	14 =	15 =	16 =

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=PageBack    11=PageFwd

Figure 132. Port to Port Set Map Panel (1 of 3)

Use this panel to assign coax ports to the port set, named 3270DISP, that you defined in the Port Set panel:

- Enter the port set number for each port that will use the 3174 TCP/IP Telnet Support function. This assigns that port to the 3270 display port set.

There are three pages for mapping ports to the port sets you have defined. The first page shows ports in hardware group 26, the first 32 coax ports. The second page shows ports in hardware group 27, the next 32 coax ports provided by the 3270 Port Expansion feature. The third page shows ports in hardware groups 21, 22 and 23, ASCII ports provided by the AEA.

For our example, we have mapped the first nine coax ports to port set 1 (3270DISP).

## 5.4.4 Defining 3270 Host and Display Station Sets

```

_____ AEA and TCP/IP Station Set _____

1 721 - 3270 HOST          722 - 3H 723 -          725 - 1
731 - 1 732 - 1 733 - 0 734 - 735 - 0 736 - 1 737 -
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 752 -
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

2 721 - 3270 DISPLAY      722 - 3D 723 - 3270DISP 725 - 1
731 - 1 732 - 1 733 - 0 734 - 735 - 0 736 - 1 737 -
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 4 752 -
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

```

Figure 133. AEA and TCP/IP Station Set Panel (1 of 3)

We have defined two station sets, one for the 3270 host and one for the 3270 displays.

First, we will define station set 1 for the 3270 host:

- Q721** Enter a station set name for the 3270 host to be accessed.
- Q722** Enter 3H as the station type for the 3270 host.

Leave all other responses at their default values.

Next, we will define station set 2 for the 3270 displays:

- Q721** Enter a station set name for the 3270 displays we added in the Port Set panel.
- Q722** Enter 3D as the station type for the 3270 displays.
- Q723** Enter 3270DISP as the port set name (the name we have defined).

Leave all other responses at their default values.

## 5.4.5 Defining TCP/IP Station Sets

A station set for TCP/IP access defines a set of ASCII emulation characteristics and an optional host IP address. The 3174 TCP/IP Telnet Support supports the following ASCII terminal emulation:

- DEC VT100
- IBM 3101
- DG D210 (USA English only)
- DEC VT220, 7-bit control
- DEC VT220, 8-bit control

Each TCP/IP station set you define will be displayed on the host Connection Menu for the terminal user to select as a connection.

For each station set definition, you may specify an IP host address, or use the default response (all zeros), in Question 790. Your response is used as follows:

- If you specify an address, the 3174 *does not* automatically connect to that address when the station set is selected from the Connection Menu. The address is used if the user issues a PING or an OPEN command without specifying a destination.
- If you do not specify an address (default all zeros), then the user will need to specify the destination when issuing the PING or the OPEN command.

So, if your users at the 3270 coax terminals will use the 3174 TCP/IP Telnet Support to access only one TCP/IP host and that host supports DEC VT100 devices, then you only need to define one TCP/IP station set (the DEC VT100 station set). You will specify that host's IP address in Question 790 so that the users do not have to remember it. To access that host, the user selects the DEC VT100 station set from the Connection Menu, which puts the display into local mode, and then issues the OPEN command without specifying a destination.

If your users will access more than one host, you probably should define five TCP/IP station sets, one for each type of ASCII emulation supported. This allows the users to select the required station set from the Connection Menu. Again, if you specify an address in Question 790, it will be used when the user issues a PING or OPEN command without a destination. If you do not specify an address in Question 790 (default all zeros), then the user will need to specify the destination when issuing the PING or OPEN command.

For our example, we have defined only one station set for TCP/IP access.

\_\_\_\_\_ AEA and TCP/IP Station Set \_\_\_\_\_

```

3 721 - TELNET VT100          722 - TH 723 -          725 - 1
731 - 1 732 - 1 733 - 0 734 - 735 - 0 736 - 1 737 -
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 1 752 -
-----
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 009 . 067 . 038 . 071

4 721 - TELNET IBM3101        722 - TH 723 -          725 - 1
731 - 1 732 - 1 733 - 0 734 - 735 - 0 736 - 1 737 -
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 2 752 -
-----
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

```

All responses are correct  
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

Figure 134. AEA and TCP/IP Station Set Panel (2 of 3)

To define each station set for TCP/IP access, respond to the following Questions:

**Q721** Enter a station set name that you wish displayed on the Connection Menu.

**Q722** Enter TH as the station type for the TCP/IP host.

**Q751** Specify the data stream supported by the TCP/IP host:

- 1=DEC VT100
- 2=IBM 3101
- 3=DG D210 (USA English only)
- 4=DEC VT220, 7-bit control
- 5=DEC VT220, 8-bit control

Your response to this Question only affects the operation of 3270 displays. It determines the type of ASCII emulation that the 3174 provides for the 3270 display when the user selects this station set as the destination. When the user at an ASCII terminal selects a TCP/IP destination, the value of this field is ignored.

**Q790** Enter the default host IP address.

You may leave the response at its default value (all zeros). The user will need to specify the destination when issuing the PING or the OPEN command.

If you do specify an address, the 3174 *does not* automatically connect to that address when this station set is selected from the Connection Menu. In this case, if the user issues a PING or an OPEN command:

- Without specifying an address, the address in Question 790 is used.
- Specifying an address, the address specified is used.

You can leave all other responses at their default values.

\_\_\_\_\_ AEA and TCP/IP Station Set \_\_\_\_\_

```

5 721 - TELNET VT220 7 BIT          722 - TH 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - - 735 - 0 736 - 1 737 - -
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 4 752 - _____
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 009 . 067 . 038 . 073

6 721 - TELNET VT220 8 BIT          722 - TH 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - - 735 - 0 736 - 1 737 - -
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 5 752 - _____
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000
  
```

All responses are correct

PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

Figure 135. AEA and TCP/IP Station Set Panel (3 of 3)

## 5.4.6 Defining Default Destinations

___ AEA and TCP/IP Default Destination ___							
Station Set	Station Set Name	Session Limit	Session				
			LT1	LT2	LT3	LT4	LT5
1	3270 HOST	0	---	---	---	---	---
2	3270 DISPLAY	5	---	---	---	---	---
3	TELNET VT100	0	---	---	---	---	---
4	TELNET IBM3101	0	---	---	---	---	---
5	TELNET VT220 7 BIT	0	---	---	---	---	---
6	TELNET VT220 8 BIT	0	---	---	---	---	---
7		0	---	---	---	---	---
8		0	---	---	---	---	---
9		0	---	---	---	---	---
10		0	---	---	---	---	---
11		0	---	---	---	---	---
12		0	---	---	---	---	---
13		0	---	---	---	---	---
14		0	---	---	---	---	---
15		0	---	---	---	---	---

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=Page Back    11=Page Fwd

Figure 136. AEA and TCP/IP Default Destination Panel

This panel determines what the terminal user will see on each LT when it is first accessed.

For Scenario 2, we select the Connection Menu as the default destination (leave the fields in the Session LTx columns blank). The Connection Menu will be displayed as the first screen and the user can choose the desired connection.

For more information about defining default destinations, refer to *IBM 3174 Establishment Controller Installation Guide*, GG24-3061.

## 5.4.7 Defining TCP/IP Options

```

      _____ TCP/IP Options Menu _____
3174 IP Address      052 - 009 . 067 . 038 . 087
Subnet Mask         054 - 255 . 255 . 255 . 192

Maximum TELNET Connections 058 - 020 (001 - 250)
TCP/IP Buffer Space  060 - 0256 K (K = 1024 bytes)

Routing Field Support 062 - Y (Y,N)
All Routes Broadcast 064 - N (Y,N)

PF: 3=Quit  4=Default  7=Back  8=Fwd

```

Figure 137. TCP/IP Options Menu

### Question 052: 3174 IP Address

Enter the IP address assigned to your 3174. For our example, the IP address of the 3174-12L is 9.67.38.87; it is entered as:

009.067.038.087

### Question 054: Subnet Mask

Enter the subnet mask for your network. For example, the subnet mask of our network at ITSO Raleigh is 255.255.255.192; it is entered as:

255.255.255.192

The mask contains a 1 for each bit of the address that is part of the network or subnet identifier.

### Question 058: Maximum TELNET Connections

Enter the maximum number of connections you wish to have available for terminal users. For our example, we have specified 20 connections as the maximum.

### Question 060: TCP/IP Buffer Space

Enter the amount of additional memory you wish to allocate for TCP/IP data buffers.

### Question 062: Routing Field Support

Your response should be as follows:

- Enter Y if you wish the TCP/IP frames to use Token-Ring source routing. This allows communication through bridges.
- Enter N if you want to disable bridge access.



**Question 064: All Routes Broadcast**

Your response should be as follows:

- Enter Y for All Routes Broadcast.
- Enter N for Single Route Broadcast.

**Note:** The response to Question 064 is meaningful only if Question 062=Y.

**5.4.8 Defining TCP/IP Routing Information**

Since the 3174 is in the same subnet as RS/6000 TCP/IP hosts, there is no routing information customized.

## 5.4.9 Defining Domain Name Services

```
_____ TCP/IP Domain Name Services _____  
  
3174 Hostname  
317412L _____  
  
3174 Domain Name  
ITSO RALEIGH IBM COM _____  
_____  
_____  
  
Domain Nameserver IP Addresses  
  
XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX  
  
PF: 3=Quit 4=Default 7=Back 8=Fwd
```

Figure 138. TCP/IP Domain Name Services

### 3174 Hostname

A response is required for this field. Enter the name assigned to your 3174.

### 3174 Domain Name

Enter the name of the domain that your 3174 is in.

### Domain Nameserver IP Addresses

In our example we have no Domain Nameserver so the responses are left as default XXXs.

## 5.4.10 Defining TCP/IP Nicknames

```
_____ TCP/IP 3174 Defined Nicknames _____  
  
      Nickname                IP Address  
RS60003 _____          009 . 067 . 038 . 073  
RS60002 _____          009 . 067 . 038 . 072  
RS60001 _____          009 . 067 . 038 . 071  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
_____                    XXX . XXX . XXX . XXX  
  
PF: 3=Quit  4=Default  7=Back  8=Fwd
```

Figure 139. TCP/IP 3174 Defined Nicknames

Since users remember names better than numeric IP addresses, this panel allows you to define up to 16 host nicknames and their associated IP addresses. Note that RS60003 is the name of the RISC System/6000 host in this scenario.

## 5.4.11 Configure Complete

```
_____ AEA and TCP/IP Configure Complete _____  
  
Press PF12 to save all responses  
and return to the AEA Menu  
  
PF: 3=Quit  4=Default  7=Back  8=Fwd  12=Done
```

Figure 140. AEA And TCP/IP Configure Complete

You have now completed customizing for the 3174 TCP/IP Telnet Support.

## 5.5 Operation: TELNET to RISC System/6000

```
Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME          STATUS  NUM NAME          STATUS
1 3270 HOST        ?       1
2 TELNET VT100     Down    2
3 TELNET IBM3101   Down
4 TELNET VT220 7 BIT Down
5 TELNET VT220 8 BIT Down

PF: 3=End        6=Terminal Disconnect    12=Host Disconnect

=====>To:
```

Figure 141. Connection Menu Immediately after 3174 IMLed

Re-IML the 3174 after you have completed your customizing procedures. Since we have specified the Connection Menu as the default destination for all our attached terminals, this screen appears immediately after the re-IML. Note the status displayed:

- 1 The 3270 host status is a Question (?) mark.
- 2 The TCP/IP host status is Down.

```
Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME          STATUS  NUM NAME          STATUS
1 3270 HOST        Up       1
2 TELNET VT100     Down    2
3 TELNET IBM3101   Down
4 TELNET VT220 7 BIT Down
5 TELNET VT220 8 BIT Down

PF: 3=End        6=Terminal Disconnect    12=Host Disconnect

=====>To:
```

Figure 142. Connection Menu after 3174 Becomes Active

When the 3270 host attachment becomes active, the status changes, without user intervention, to the following:

- 1 The 3270 host status is now Up and, if selected, the session will be established between the LT and the host.

**2** The TCP/IP host status continues to be Down.

```
Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME          STATUS  NUM NAME          STATUS
1 3270 HOST       Up      2 TELNET VT100    Up
2 TELNET VT100    Up      3 TELNET IBM3101  Up
3 TELNET IBM3101  Up      4 TELNET VT220 7 BIT Up
4 TELNET VT220 7 BIT Up      5 TELNET VT220 8 BIT Up
5 TELNET VT220 8 BIT Up

PF: 3=End        6=Terminal Disconnect    12=Host Disconnect

=====>To:
```

Figure 143. Connection Menu after 3174 Becomes Active and Enter Pressed

When you press the Enter key, the status shows all hosts active, once the LAN adapter is opened. You can now select any one of the hosts from the Connection Menu.

If you specified an address in the TCP/IP station set, type in the number to access the desired host session.

```
Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME          STATUS  NUM NAME          STATUS
1 3270 HOST       Up      2 TELNET VT100    Up
2 TELNET VT100    Up      3 TELNET IBM3101  Up
3 TELNET IBM3101  Up      4 TELNET VT220 7 BIT Up
4 TELNET VT220 7 BIT Up      5 TELNET VT220 8 BIT Up
5 TELNET VT220 8 BIT Up

PF: 3=End        6=Terminal Disconnect    12=Host Disconnect

=====>To: 4
```

Figure 144. Selecting Connection to RS/6000 Host

In our example, we selected NUM field 4 to get a connection to the host with IP address 9.67.38.73.

If you have not specified an address in the TCP/IP station set, select the emulation that you want to have on the RISC System/6000; you will get the 3174 TELNET prompt.

```
3174 TELNET> open 9.67.38.73
```

Figure 145. TELNET Local Mode

At the TELNET prompt, type in the command and destination IP address or hostname.

```
IBM AIX Version 3 for RISC System/6000
(C) Copyrights by IBM and by others 1982, 1991.
login: root
root's Password:
*****
*
*
* Welcome to IBM AIX Version 3.2!
*
*
* Please see the README file in /usr/lpp/bos for information pertinent to
* this release of the AIX Operating System.
*
*
*****

Last unsuccessful login: Thu May 27 11:07:03 CDT 1993 on hft/0
Last login: Fri May 28 12:21:51 CDT 1998 on pts/8 from rs60002
[YOU HAVE NEW MAIL]
swcons: console output redirected to: /log/28May93
<rs60003># smit
```

Figure 146. RS/6000 after Login

```
System Management

Move cursor to desired item and press Enter.

Installation and Maintenance
Devices
Physical & Logical Storage
Security & Users
Diskless Workstation Management
Communications Applications and Services
Spooler (Print Jobs)
Problem Determination
Performance & Resource Scheduling
System Environments
Processes & Subsystems
Applications
Using SMIT (information only)

F1=Help          F2=Refresh      F3=Cancel      Esc+8=Image
Esc+9=Shell     Esc+0=Exit     Enter=Do
```

Figure 147. RS/6000 after Invoking SMIT

---

## 5.6 RISC System/6000 Definitions

On the RISC System/6000, we do the following:

- Login as the *root* user.
- At the command prompt, type in:  
smit sna

You will get the following screen:

### 5.6.1 SNA Services




Figure 148. SNA Services

Select **Configure SNA Profiles** and press Enter.

## 5.6.2 Configure SNA Profiles




Figure 149. Configure SNA Profiles

Select **Quickly Configure a 3270 Communication Connection** and press Enter.

## 5.6.3 Quick Configuration




Figure 150. Quick Configuration

Select **Quick Configuration for a 3270 Communication Connection** and press Enter



## 5.6.4 Quick Configuration for a 3270 Communication Connection: Information

```
Quick Configuration for a 3270 Communications Connection: Information

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

                                Entry Fields
* Quick configuration name          TCPIP3174
  Link Station                      token_ring_call
  Link address                      400031740004

* System services control point (SSCP) ID (1-65535) *
  XID node ID                      *

Provide LU addresses (values of 2 to 254) or
address ranges for any of the following LU types:
  LU 1                             8
  LU 2                             2-4
  LU 3                             9

F1=Help      F2=Refresh      F3=Cancel      F4=List
F5=Undo      F6=Command     F7=Edit       F8=Image
F9=Shell     F10=Exit       Enter=Do
```

Figure 151. Quick Configuration for a 3270 Communication: Information

On this screen, type in the configuration data and press Enter. The next screen shows you the status of the created profiles.

## 5.6.5 Command Status

```
COMMAND STATUS

Command: OK          stdout: yes          stderr: no

Before command completion, additional instructions may appear below.

The Link Station Profile 'TCPIP317' has been created successfully.
The Connection Profile 'TCPIP317402' has been created successfully.
The Local LU Profile 'TCPIP317402' has been created successfully.
The Connection Profile 'TCPIP317403' has been created successfully.
The Local LU Profile 'TCPIP317403' has been created successfully.
The Connection Profile 'TCPIP317404' has been created successfully.
The Local LU Profile 'TCPIP317404' has been created successfully.
The Connection Profile 'TCPIP317408' has been created successfully.
The Local LU Profile 'TCPIP317408' has been created successfully.
The Connection Profile 'TCPIP317409' has been created successfully.
The Local LU Profile 'TCPIP317409' has been created successfully.

F1=Help      F2=Refresh      F3=Cancel      F6=Command
F8=Image     F9=Shell       F10=Exit
```

Figure 152. Command Status

At this time you have created the attachment profile successfully. You are now able to start the SNA Services.

**Note:** The SNA Services must be started from the *root* user.

## 5.6.6 Advanced SNA Configuration

Select **Advanced SNA Configuration** from the Configure SNA Profiles panel shown in Figure 149 on page 147.

For more information about Advanced SNA Configuration, see Chapter 13 Volume 2, *AIX Version 3.2 for RISC System/6000, Communication Concepts and Procedures*, GC23-2402.




Figure 153. Advanced SNA Configuration

Select **Physical Units** and press Enter. The next screen shows the the list of physical units.

## 5.6.7 Physical Units




Figure 154. Physical Units

Select **Token Ring** and press Enter.

## 5.6.8 Token-Ring




Figure 155. Token Ring

Select **Token Ring Attachment** and press Enter.

## 5.6.9 SNA Token Ring Attachment Profile Name

```

SNA Token Ring Attachment Profile Name

Type or select a value for the entry field.
Press Enter AFTER making all desired changes.

* PROFILE name                tcp3174      Entry Fields
                                     +

F1=Help      F2=Refresh      F3=Cancel      F4=List
F5=Undo      F6=Command      F7=Edit      F8=Image
F9=Shell     F10=Exit      Enter=Do
  
```

Figure 156. SNA Token Ring Attachment Profile Name

On this screen you type in the profile name, or you select the profile name from a list (F4).

If you have entered the profile name of your token-ring attachment, the SNA Token Ring Attachment Profile screen will be displayed next.

## 5.6.10 Change/Show SNA Token Ring Attachment Profile

```

Change / Show SNA Token Ring Attachment Profile

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

TOP
CURRENT profile name                tcp3174      Entry Fields
NEW PROFILE name
CONTROL POINT profile name          RS03TOK0    +
LOGICAL LINK profile name           RS03TOK0    +
PHYSICAL LINK profile name          RS03TOK0    +
STOP ATTACHMENT on inactivity?      no          +
  If yes, inactivity TIMEOUT (0-10 minutes)  0
RESTART on deactivation?             no          +
LU address REGISTRATION?            no          +
  If yes, LU address REGISTRATION PROFILE name  LDEFAULT    +
CALL type                            call        +
  If listen,
  AUTO-LISTEN?                       no          +
  MINIMUM SAP address (hex 04-ec)     04          X
  MAXIMUM SAP address (hex 04-ec)     EC          X
  If call, ACCESS ROUTING            link_address +
  If link-name, REMOTE LINK name
  If link-address,
  Remote LINK address                 400031740004 X
  Remote SAP address (hex 04-ec)      04          X
BOTTOM

F1=Help      F2=Refresh      F3=Cancel      F4=List
F5=Undo      F6=Command      F7=Edit      F8=Image
F9=Shell     F10=Exit      Enter=Do
  
```

Figure 157. Change/Show SNA Token Ring Attachment Profile

On this screen you can change some of the parameters.

The Remote Link address is the token-ring address of the 3174-12L, which is the gateway for the RISC System/6000 to the SNA host.

## 5.6.11 Manage SNA Services




Figure 158. Manage SNA Services

Select **Start SNA Resources** and press Enter.

## 5.6.12 Start SNA Resources




Figure 159. Start SNA Resources

Select **Start SNA Link Station** and press Enter.

### 5.6.13 Start an SNA Link Station

Start an SNA Link Station

Type or select a value for the entry field.  
Press Enter AFTER making all desired changes.

\* Link Station Profile name Entry Fields:  
TCP/IP314 +

F1=Help	F2=Refresh	F3=Cancel	F4=List
F5=Undo	F6=Command	F7=Edit	F8=Image
F9=Shell	F10=Exit	Enter=Do	

Figure 160. Start SNA Link Station

Use the Link Station Profile name, defined in the **Quick configuration name** field shown in Figure 151 on page 148.

### 5.6.14 Display SNA Resources

Display SNA Resources

Move cursor to desired item and press Enter.

Display the Status of SNA  
Display SNA Global Information  
Display Session Information  
**Display Active Link Information**  
Display APPN Topology Database  
Display APPN Directory Database  
Display SNA Gateway Information

F1=Help	F2=Refresh	F3=Cancel	F8=Image
F9=Shell	F10=Exit	Enter=Do	

Figure 161. Display SNA Resources

Select **Display Active Link Information** to check if the link station is active.

## 5.6.15 Command Status

```
COMMAND STATUS

Command: OK          stdout: yes          stderr: no

Before command completion, additional instructions may appear below.

  Link      Adjacent      Node      Device      State
  station   CP name        type      name
-----
@x25s0
@tok0
R1N2A1N    USIBMRA.RALYAS4A  NN    tok0    Active
RA62266    USIBMRA.RAP      EN    tok0    Active
TCP317     tok0              tok0    Active

F1=Help      F2=Refresh      F3=Cancel      F6=Command
F8=Image     F9=Shell        F10=Exit
```

Figure 162. COMMAND STATUS

The SNA link station is already started and active. Now you are able to start AIX\* 3270 Host Communication Program/6000 (HCON).

**Note:** The HCON program can be started by any user.

## 5.6.16 AIX 3270 Host Communication Program/6000 (HCON)

Do the following:

- Login with your user ID.
- At the command prompt, type in:  
smit hcon

You will get the following screen:




Figure 163. AIX 3270 Host Communication Program/6000 (HCON)

Select **HCON User Functions** to get the next screen.

**Note:** The 3174 must be customized for multiple logical terminal (MLT) support if HCON on the RISC System/6000 is to support multiple sessions.



## 5.6.17 HCON User Functions




Figure 164. HCON User Functions

Select **Add an HCON Session** and press Enter.

## 5.6.18 Add an HCON Session




Figure 165. Add an HCON Session

Select **Add SNA Display Session** and press Enter.

## 5.6.19 Add SNA Display Session

```

                                Add SNA Display Session

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

TOP                               Entry Fields
HCON user name                    joe
SESSION name                      a
Session USE                       Gateway 3174
* SNA logical connection prefix or profile TCP/IP317482
LANGUAGE                          English (U.S.A.)
* KEYBOARD table                  /usr/lib/hcon/e789_ktb>
* COLOR table                     /usr/lib/hcon/e789_ctb>
* File used by SAVES key          /e789_saves
* File used by REPLS key          /e789_repls
* Local printer used by PRINT key lp0
Host TYPE                         TSO
Host LOGIN ID
Autolog NODE ID
Autolog TRACE                      no
MORE...6

F1=Help      F2=Refresh      F3=Cancel      F4=List
F5=Undo      F6=Command      F7=Edit       F8=Image
F9=Shell     F10=Exit       Enter=Do

```

Figure 166. Add SNA Display Session

Type or select values in the entry fields.

After adding the SNA display session, you will get the following screen. If there are no errors, the screen will show an **OK** in the first status line.

## 5.6.20 Command Status

```

                                COMMAND STATUS

Command: OK      stdout: yes      stderr: no

Before command completion, additional instructions may appear below.

0789-540 Session a for user joe is added successfully to the HCON
system.

F1=Help      F2=Refresh      F3=Cancel      F6=Command
F8=Image     F9=Shell       F10=Exit

```

Figure 167. COMMAND STATUS

The HCON user functions are now completed. Press Enter as required to get back to a command prompt.

From the command prompt, you are now able to start the HCON session.



## Chapter 6. Scenario 3: APPN and TCP/IP via 3174 to AS/400 and VTAM

This scenario shows the ability of the 3174 to act as an SNA token-ring gateway, an APPN network node and a TCP/IP TELNET client simultaneously:

- A PS/2 end node uses the 3174 as an APPN network node server to access an AS/400\* network node via the 3174 Peer Communication capability and an external token-ring.
- The same PS/2 uses the 3174 as a token-ring gateway to access an S/370 host via the 3174 Peer Communication capability and the external token-ring.
- A 3270 CUT terminal uses the 3174 as a TCP/IP TELNET client to establish a TCP/IP connection with the AS/400 TCP/IP host capability.
- The same 3270 CUT terminal uses the 3174 as a traditional cluster controller to establish a session with an S/370 host application.

### 6.1 Scenario 3 Configuration Diagram




Figure 169. 3174 in an APPN, TCP/IP and SNA Environment

---

## 6.2 Scenario 3 Configuration Description

Scenario 3 shows a PS/2 APPN end node (PS2COAX) coax-attached to a 3174-11R, which is SDLC-attached to an S/370 host and token-ring attached to an AS/400. It also shows a 3270 CUT terminal (CUTCOAX) attached to the same 3174-11R.

The composite network has the following components:

- An S/370 host with VTAM V4.R1
- A 3745 with NCP V6.2, channel-attached to the S/370 host
- An AS/400 attached to the 3174-11R via a token-ring network
- A 3174-11R (CP31742), SDLC-attached to the 3745, as:
  - An APPN network node (NN) server for the PS/2 workstation
  - A token-ring gateway for the PS/2 workstation
  - A TCP/IP TELNET client for the 3270 CUT terminal
  - A cluster controller for the 3270 CUT terminal
  - With Peer Communication (LAN-Over-Coax) enabled.
- A PS/2 APPN end node (EN) (PS2COAX) with:
  - Communications Manager/2
  - 5250 emulation to access the AS/400 host
  - 3270 emulation to access the S/370 host
  - Token-ring address of 400031742992.
- A 3270 CUT terminal (CUTCOAX):
  - With access to the AS/400 host as a VT100 terminal
  - With access to the S/370 host as a 3270 terminal

**Note:** This chapter does not describe the Communications Manager/2 configuration required to enable the PS/2 workstation to access the S/370 host using 3270 emulation.

---

## 6.3 3174-11R APPN, Peer Communication and TCP/IP Customization

The following Control Disk Menu shows the customization options required to be selected for Scenario 3.

### 6.3.1 Customize Control Disk Menu




Figure 170. Customize Control Disk Menu

- 1 Option 1 is used to customize the 3174 for SNA functions.
- 2 Option 6 is used to customize the APPN functions.
- 3 Option 7 is used to define COS tables and mode/COS correlations.
- 4 Option 8 is used to define the Peer Communication function. In subsequent panels, the Peer Communication function is referred to as 3174-Peer support.
- 5 Option 5 is used to define TCP/IP functions.

---

## 6.4 3174 as an APPN Network Node

Using SDLC, token-ring network, or S/370 SNA channel, the 3174 NN supports LEN end node (LEN EN), APPN end node (EN) and APPN network node (NN) communication, including subarea VTAM and APPN VTAM communication, to the 3174 NN.

Using peer communication, intelligent workstations can attach to the 3174 Terminal Adapter (HG 26 and HG 27) ports as LEN ENs, ENs, or NNs. In addition, the 3174 NN provides network node services to LEN ENs and ENs.

The 3174 NN calculates the best route to a destination for resources it owns, using its knowledge of the network's topology and the desired COS. When a link fails and another path is available, the 3174 NN can re-establish a session using dynamic routing. Because routes are not predefined and ENs can register their

resources with the 3174 NN, network system definition is minimal. Nodes can be added or deleted without recustomizing.

Because a 3174 NN allows LU 6.2 traffic to flow on a single link, multiple subchannel addresses or multidrop links are not needed for T2.1 traffic.

---

## 6.5 3174 APPN and Peer Communication Customization

This chapter provides guidance on customizing the 3174 for APPN and Peer Communication functions. For a detailed description of each customizing question, refer to *3174 Establishment Controller Planning Guide Configuration Support-C Release 3, GA27-3918*.

The following chapters in the planning guide are important:

- Chapter 11: Planning for Common SNA
- Chapter 12: Planning for APPN
- Chapter 13: Planning for 3174 Peer Communication
- Appendix A: Configuration Worksheets

Figure 171 on page 163 shows the flow sequence of panels when customizing the 3174 for APPN and Peer Communications.




Figure 171. 3174 Customization Panel Flow Sequence



## 6.5.1 SDLC

SDLC				
				SDLC
104 - C1 <b>1</b>	105 - C8 <b>2</b>	108 - 0000000	110 - 1 0000	116 - 2 _ _
121 - 01	123 - 0	125 - 00000000	126 - 00000000	127 - 0 0
132 - 0 0 0 0	136 - 1 0 0 1	137 - 0 0 0 0	138 - 0	
141 - A	150 - 1 0 <b>3</b>	165 - 1	166 - A	168 - 0
173 - 00000000	175 -	179 - 0 0 0	190 - 00	
213 - 1	215 - 00000	220 - 0		
310 - 0	313 - 1	317 - 0	318 - 0	340 - 1
365 - 0	370 - 1 <b>4</b>			

PF: 3=Quit 4=Default 7=Back 8=Fwd

Figure 172. Customizing the 3174-11R for an SDLC Link

**1** Question 104 specifies the SDLC address of the 3174-11R which, in the VTAM definitions, is the PU that has XID=YES to allow T2.0/2.1 shared link support.

**2** Question 105 defines the upper limit poll address for DSPUs.

**3** Question 150=10 enables the token-ring gateway function for DSPUs.

**4** When APPN is selected and the connection is to NCP (which is the case here), the response should be a 1. This will allow inbound RU sizes up to 512 bytes to flow, as BINDs may be longer than 256 bytes and NCP does not support BIND reassembly.

## 6.5.2 Common SNA

The Common SNA panel is an important panel for APPN customization. The Common SNA panel allows you to:

- Give a name for the network in which the 3174 you are customizing resides.
- Give a name to the control point for the 3174.
- Give a name to the connection network.
- Enable the 3174 APPN functions.

Other responses on this panel are:

- Question 500: CSCM Unique
- Question 502: Logical Unit Name

These questions are for Central Site Change Management (CSCM) functions. The LU named in Question 502 can be a dependent or an independent LU but is not relevant to APPN functions.

The LU for CSCM is a dependent LU if APPN is not enabled (Question 510=0). It is also a dependent LU if APPN is enabled (Question 510=1) but the LUNAME (Question 502) and CPNAME (Question 511) are not the same. In both cases, the host CSCM LU definition should specify LOCADDR=1.

The LU for CSCM is an independent LU only if APPN is enabled and the LUNAME is the same as the CPNAME. In this case, the host CSCM LU definition should specify LOCADDR=0.

Common SNA

C1/SDLC

500 - 0            501 - USIBMRAA **1**    502 - CP3174\_\_

APPN Support Fields:

510 - 1 **2**            511 - CP31742 **3**    512 - CNET\_\_

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

Figure 173. Names to Identify the 3174-11R Network Node

- 1** The 3174-11R is customized as being in network ID USIBMRAA.
- 2** Question 510=1 enables the APPN functions.
- 3** Question 511 specifies the control point name used for the 3174-11R.

### Question 501: Network ID

The response is the name used to identify the network that the 3174 you are customizing is attached to. A network ID is required if you are using either of the following:

- CSCM (Question 500=1 or 2)
- APPN (Question 510=1).

The following rules apply to the network ID when APPN is enabled:

- It must not be the same as:
  - The control point name given in Question 511
  - The virtual node name given in Question 512
  - Any CPNAME on the Network Resources panel
  - Any CPNAME, LUNAME or SERVING NN name on the Associated LUs panel.
- It may be up to eight alphanumeric characters long. The first character must be alphabetic with no blanks or spaces allowed between characters.

### **Question 510: APPN Network Controller**

The response indicates whether APPN functions in the 3174 are enabled. Valid responses are:

- 0 = APPN not enabled (default response)
- 1 = APPN enabled.

If you enabled the 3174 APPN functions (Question 510=1), then:

- The link type for a channel-attached 3174 must be able to carry both T2.0 and T2.1 traffic (Question 242=1)
- The network ID (Question 501), the control point name (Question 511) and the virtual node name (Question 512) must be unique.

If you enabled the 3174 APPN functions and perform no further APPN customization, you will get a minimum APPN configuration using the IBM-supplied class of service definitions.

### **Question 511: APPN Control Point Name (CPNAME)**

The response is used as the control point name and identifies the 3174 network node to the network.

The following rules apply to the control point name:

- It is required when APPN is enabled.
- It must not be the same as:
  - The network ID given in Question 501
  - The virtual node name given in Question 512
  - Any other resource names in the network.
- It may be up to eight alphanumeric characters long. The first character must be alphabetic with no blanks or spaces allowed between characters.

### **Question 512: APPN Virtual Node Name (VNODE)**

A connection network is used to minimize definitions for nodes connected to a shared-access transport facility such as a token-ring network. Physically, the connection network is the token-ring network to which the 3174 network node is attached.

Question 512 allows you to give a name to a connection network so that all nodes using the same connection network can point to the same name.

The connection network name is also referred to as:

- The virtual node name in the 3174
- The connection network control point name (CNNCPNAME) in the AS/400
- The connection network name in NS/2

It is used fully qualified by the network ID.

The following rules apply to the connection network (or virtual node) name:

- It is required when Question 510=1 (APPN enabled) even if a connection network is not used.
- It must not be the same as:

- The network ID given in Question 501
  - The control point name given in Question 511
  - Any CPNAME on the Network Resources panel
  - Any CPNAME, LUNAME or SERVING NN name on the Associated LUs panel
  - Any other resource names in the network
- It may be up to eight alphanumeric characters long. The first character must be alphabetic with no blanks or spaces allowed between characters.

### 6.5.3 Common Network

```

_____ Common Network _____
C1/SOLC

900 - 4000 3174 0002 04 1 905 - 1      908 - IBMLAN
911 - 0                      912 - 00

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

```

Figure 174. Token-Ring Definition for the 3174-11R

1 Question 900 specifies the token-ring address of the 3174-11R.

### 6.5.4 Ring Address Assignment

```

_____ 940: Ring Address Assignment _____

S   Ring Address  SAP  T      S   Ring Address  SAP  T
C1  4000 3174 0002  04   C3  4000 3174 4992  04   0
C2  4000 3174 1992  04   0      C5  4000 3174 2992  1 04   0
C4  4000 3174 3992  04   0      C7  4000 2001 0002  04   0
C6  4000 2001 0001  04   0
C8  4000 3174 0003  04   1

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH

```

Figure 175. Ring Address Assignment

1 In our example, the PS2COAX EN is assigned to ring address 400031742992.

## 6.5.5 APPN Node Definition

The APPN Node Definition panel allows you to specify the capabilities of the 3174 network node:

- Question 610: APPN Sessions
- Question 611: APPN Nodes/Links
- Question 612: APPN Wildcard Option

APPN Node Definition	
610 SESSIONS - 1	611 NODES/LINKS - 1
612 WILDCARD - 0	613 HOST LINK - 0
PF: 3=Quit 4=Default	8=Fwd

Figure 176. APPN Node Definition

### Question 610: APPN Sessions

The response indicates the number of LU 6.2 intermediate sessions that may be activated through the 3174. Valid responses are:

- 1 = up to 225 sessions (default response)
- 2 = up to 500 sessions
- 3 = up to 750 sessions
- 4 = up to 1000 sessions

Your response is used to:

- Allocate control storage when the 3174 network node is initially loaded. Since APPN sessions are dynamically set up, dependent upon resources (buffers, control blocks, links) available at session initiation, this value may not always be achieved.
- Determine the total amount of storage required for the 3174.

The number of APPN sessions customized affects the amount of control storage required.

### Question 611: APPN Nodes/Links

The response indicates the number of T2.1 links to adjacent nodes that are supported by the 3174 network node. Valid responses are:

- 1 = up to 20 nodes/links (default response)
- 2 = up to 75 nodes/links
- 3 = up to 150 nodes/links
- 4 = up to 225 nodes/links.

Your response is used to:

- Allocate control storage when the 3174 network node is initially loaded. Since T2.1 links are dynamically activated as required, dependent upon

resources (control blocks and ports) available at link establishment, this value may not always be achieved.

- Determine the total amount of storage required for the 3174.

The number of nodes/links customized affects the amount of control storage required.

### **Question 612: APPN Wildcard Option**

The response indicates whether the 3174 network node you are customizing holds the wildcard connection to the host for the APPN network. Valid responses are:

0 = No (default response)

1 = Yes

The wildcard option allows LUs to be dynamically located in a subarea network. The wildcard option permits sessions to be established from LUs in the APPN network to LUs in or through a subarea network.

For detailed information about the 3174 APPN wildcard, see *IBM 3174 APPN Implementation Guide*, GG24-3702.

### **Question 613: APPN Wildcard Host Link**

The response indicates which host link to this 3174 NN will be used for wildcard routing. Valid responses are:

1A = Host link 1A is used for wildcard routing (default response).

1B = Host link 1B is used for wildcard routing.

1C = Host link 1C is used for wildcard routing.

1D = Host link 1D is used for wildcard routing.

1E = Host link 1E is used for wildcard routing.

1F = Host link 1F is used for wildcard routing.

1G = Host link 1G is used for wildcard routing.

1H = Host link 1H is used for wildcard routing.

---

## **6.6 Network Resources Definition**

The Network Resources and Associated LUs panels allow you to define nodes in the APPN network to the 3174 network node you are customizing. You may use these panels to define:

- LEN nodes for which the 3174 is acting as a server
- LUs that are located in the LEN nodes served by the 3174
- Network nodes that are adjacent to the 3174
- Nodes that share a link for both T2.0 and T2.1 traffic, such as a 3174-13R that is used for both 3270 DSPU and APPN functions
- Addresses of nodes to which the 3174 NN will initiate a connection when it is IMLed
- Resources that are to be preloaded in the 3174 directory cache to reduce the number of broadcasts in the network

## 6.6.1 Network Resources

Network Resources						
	CPNAME	NODE TYPE (1-4)	LUs (X)	DLC TYPE (1-3)	ADDRESS	
1	RALYAS4A	1 3	-	1	4000 2001 0001	04
1	RALYAS4B	2 3	-	1	4000 2001 0002	04
2	PS2COAX	3 1	X	1	4000 3174 2992	04

PF: 3=Quit 7=Back 8=Fwd 12=Test Menu

Figure 177. Network Resources

**1** RALYAS4A (AS/400) is defined as an adjacent network node with NODE TYPE of 3 (network node) and a DLC TYPE of 1 (token-ring attached).

**2** RALYAS4B (AS/400) is defined as an adjacent network node with NODE TYPE of 3 (network node) and a DLC TYPE of 1 (token-ring attached).

**3** PS2COAX is defined as NODE TYPE of 1 (LEN EN). An X in the LUs field indicates that its local LU is defined in the Associated LUs panel, as shown in Figure 178 on page 172. It also has a DLC TYPE of 1 (token-ring attached).

**Note:**

Valid NODE TYPES are:

- 1 = LEN end node (LEN EN)
- 2 = APPN end node (EN)
- 3 = APPN network node (NN)
- 4 = LEN end node (LEN SSCP)

Valid DLC TYPES are:

- 1 = Token-ring attached
- 2 = SDLC attached
- 3 = S/370 channel-attached



## 6.6.2 Associated LUs

The Associated LUs panel is displayed if an X has been entered in the LUs field for a node on the Network Resources panel.

Associated LUs					
CPNAME	LUNAME	LUNAME	LUNAME	LUNAME	SERVING NN
1 PS2COAX	PS2COAX	<b>1</b> _____	_____	_____	CP31742_

PF: 3=Quit 7=Back 12=Test Menu

Figure 178. Associated LUs

**1** PS2COAX LU is defined with the 3174-11R as the network node server.

## 6.7 COS Definitions

Modifying or deleting an IBM-supplied COS table, or creating new COS tables, should only be undertaken with careful planning for unique environments.

COS Definition	
Enter the number of the COS Definition and the number of the definition to be used as a model.	
COS Definition Number - <b>1</b> (1-14)	Model Definition Number - <b>2</b> (0-14)
-----Definition Numbers-----	
<b>3</b>	0. Clear Definition
<b>4</b>	1. #BATCH _____
	2. #BATCHSC _____
	3. #INTER _____
	4. #INTERSC _____
	5. #CONNECT _____
	6. _____
	7. _____
	8. _____
	9. _____
	10. _____
	11. _____
	12. _____
	13. _____
	14. _____
When using models 1-5, IBM-supplied defaults will always be invoked.	
PF: 3=Quit	8=Fwd

Figure 179. COS Definition

**1** The COS Definition Number is the COS table number you want to add or modify:

- If you enter a number from 1 to 5, you can modify one of the five IBM-supplied tables.
- If you enter a number from 6 to 14 and there is no name associated with that number, you can add a new COS table.
- If you enter a number from 6 to 14 and it is associated with a name, you can modify an existing user-defined COS table of that name.

**2** You may choose to add a new COS table. To reduce the effort involved in creating a new table, the Model Definition Number allows you to select a table to be used as a model.

To add a new table using a model:

- Enter a COS Definition Number that is not associated with a name. This will be the COS Definition Number of the new table.
- Enter the Model Definition Number to be used as the model.

If you enter 0 (Clear Definition) or leave it blank, then you will not be using a model; the definition screens that follow contain blank fields and you will have to enter all values required.

**Notes:**

1. If a COS Definition Number 1 to 5 is modeled on itself (that is, the COS Definition Number is the same as the Model Definition Number), a warning message that the existing values will be overwritten is displayed. This warning is provided to indicate that the IBM-supplied values will be presented and will replace all the values you have customized, if you continue by pressing Enter. If this is not desired, press PF3 to quit.
2. If a COS Definition Number 6 to 14 is modeled on itself, no warning message is displayed because the values you have customized will be presented.
3. If a COS Definition Number 1 to 14 is modeled on another COS Definition Number, a warning message that the existing values will be overwritten is displayed. This warning is provided to indicate that the values contained in the COS Definition Number table will be overwritten by values in the Model Definition Number table, if you continue by pressing Enter. If this is not desired, press PF3 to quit.
4. SNASVCMG and CPSVCMG are IBM reserved names and cannot be used as a COS table name or mode name.
5. If you modify an IBM-supplied COS table, you have actually modified a *copy* of the IBM-supplied table. This modified copy is then filed and used for routing calculations.

When you select the same IBM-supplied table again, it will display the table with your customized values. To restore the IBM-supplied values, model the IBM-supplied table you have modified on itself.

**3** Clear Definition presents you with definition screens that contain blank fields.

**4** #BATCH is one of the five IBM-supplied COS tables. The IBM-supplied COS table names are the only names allowed to begin with a # character. You will not be able to enter this character in the COS name field; when you press the # key, nothing happens.

### 6.7.1 Mode/COS Correlation

The Mode/COS Correlation panel allows you to correlate a mode name with a particular COS table name. You can specify up to 14 mode/COS name correlations.

The first five mode names are automatically filled in and cannot be modified. The first four mode names are correlated to COS tables of the same name by

default. The fifth mode name **blank** is correlated to #CONNECT. You may specify a maximum of nine other mode names.

The mode name points to a set of parameters for LU-LU sessions. Each mode name also points to the COS table to be used. The mode name must be unique.

If a mode name is specified, the COS table name must also be specified. Similarly, if a COS table name is specified, a mode name must also be specified. You may have different mode names pointing to the same COS table, as shown in Figure 180. But the same mode name may not be used to point to the different COS tables.

Mode/COS Correlation					
Mode Name	#	COS Name	Mode Name	#	COS Name
#BATCH_	-	#BATCH_	_____	-	_____
#BATCHSC	-	#BATCHSC	_____	-	_____
#INTER_	-	#INTER_	_____	-	_____
#INTERSC	-	#INTERSC	_____	-	_____
blank	-	#CONNECT	_____	-	_____
<b>5</b> QPCSUPP_	-	#CONNECT	_____	-	_____
_____	-	_____	_____	-	_____

Define Mode/COS pairs. To specify IBM-supplied COS names, place 1-5 in the #-column. 1=#BATCH 2=#BATCHSC 3=#INTER 4=#INTERSC 5=#CONNECT

PF: 3=Quit 4=Default 7=Back 8=Fwd

Figure 180. Correlating Mode Names with COS Table Names

**5** 5250 emulation in OS/2 and AS/400 uses a mode named QPCSUPP by default. QPCSUPP is also mapped to the COS table #CONNECT in the AS/400 by default. Therefore, we have correlated QPCSUPP with the COS table named #CONNECT in the 3174, as shown in Figure 180. If this is not done, you will get an error message indicating session negotiation failure.

---

## 6.8 3174-Peer Definitions

The 3174 Peer Communication, referred to in the customizing panels as 3174-Peer Support, is separate and distinct from the APPN function. The 3174-Peer Support can be used as a means to allow coax-attached LEN nodes to connect to a token-ring APPN network.

The 3174-Peer Support provides a logical internal token-ring segment and a bridge to a real external token-ring segment. Each coax-attached PS/2 workstation appears to be attached to the internal token-ring.

In the customizing panel descriptions, the following terms are used:

- *3174-Peer device* refers to a coax-attached PS/2 workstation.
- *3174-Peer port* refers to the coax port to which a PS/2 workstation is attached.
- *3174-Peer bridge* refers to the internal bridge.
- *3174-Peer segment* refers to the internal token-ring segment.
- *Token-Ring segment* refers to the external token-ring segment.

Each 3174-Peer device can have a token-ring address:

- Specified as a DXML1MOD.SYS parameter in the CONFIG.SYS file or as the NETADDRESS parameter in the PROTOCOL.INI.
- Assigned by 3174-Peer Support according to its port number, with some portion of the address specified by the user

## 6.8.1 3174-Peer Definition Panel

The 3174-Peer Definition panels allow you to:

- Enable the internal token-ring segment.
- Enable the internal bridge function.
- Customize the internal bridge parameters.
- Enable LAN Manager support.
- Specify the middle six hexadecimal digits of the 3174-assigned token-ring address for the 3174-Peer devices.

\_\_\_\_\_ 3174-Peer Definition \_\_\_\_\_

3174-Peer Support

650 - Y	<b>1</b>	3174-Peer Support	(Y,N)
---------	----------	-------------------	-------

3174-Peer Options

651 - Y	<b>2</b>	Bridge Support	(Y,N)
652 - N		LAN Manager Support	(Y,N)
653 - Y		3174-Peer Online Test Updates	(Y,N)

3174-Peer Station Parameters

660 - 4000 3174 91 PN	3174-Peer Port Address Range	(0000 00 - FFFF FF)
661 - 05	Percentage of Discard Threshold	(00 - 99)

PF: 3=Quit    4=Default    8=Fwd

Figure 181. Enabling 3174 Peer Communication Functions

- 1** Question 650 = 1 enables the 3174 Peer Support.
- 2** Question 651 = 1 enables the Bridge Support.

## 6.8.2 3174-Peer Bridge Profile

The 3174-Peer Bridge Profile panel allows you to specify parameters to be used by the internal bridge function. These parameters include:

- The internal bridge number
- The internal token-ring segment number
- The external token-ring segment number
- The number of hops over which a broadcast frame can cross
- Whether frames will be forwarded by the bridge
- Setting threshold for bridge congestion
- How long to wait before logging a congested bridge
- How long to wait before sending an alert about a congested bridge

3174-Peer Bridge Profile		
670 - 1	Bridge Number	(0-F)
671 - BB3	Token-Ring Segment Number	(001-FFF)
672 - 741	3174-Peer Segment Number	(001-FFF)
673 - 7	Token-Ring Hop Count	(1-7)
674 - Y	Frame Forwarding Active	(Y,N)
675 - 0010	Bridge Performance Threshold (Frames Discarded Per 10,000)	(0000-9999)
676 - 02 00	Logging Interval	(00-99 Hours 00-59 Minutes)
677 - 010	Alert Threshold	(000-255)

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 182. Parameters for the Internal Bridge Function

## 6.9 AS/400 Definitions

On the AS/400, we do the following:

- Specify the AS/400 network ID and control point name.
- Define the AS/400 node type.
- Define the local LU name.
- Define the connection from the AS/400 to the 3174-11R (Controller Description).

### Note:

Defining the controller description is not necessary if you specify **Autocreate Controller :\*Yes** on the AS/400 Line Description. We have done it here just to show the the matching of parameters and terminology between the AS/400 and the 3174.

### 6.9.1 Network Attributes

```
Display Network Attributes
System: RALYAS4A
Current system name . . . . . : RALYAS4A
Pending system name . . . . . :
Local network ID . . . . . : USIBMRAA
Local control point name . . . . . : RALYAS4A
Default local location . . . . . : RALYAS4A
Default mode . . . . . : BLANK
APPN node type . . . . . : *NETNODE
Maximum number of intermediate sessions . . . . : 200
Route addition resistance . . . . . : 128
Server network ID/control point name . . . . . :
```

Figure 183. Network Attributes of the AS/400

### 6.9.2 Configuration Status

```
Work with Configuration Status RALYAS4A
Opt Description Status -----Job-----
-- CP31742 VARIED ON
-- PS2COAX VARIED ON
--
--
--
--
--
--
--
```

Figure 184. Configuration Status

### 6.9.3 Controller Description Screens (C31742)

```
Display Controller Description                                RALYASYA
                                                           06/15/93 15:46:28
Controller description . . . . . : C3174C2
Option . . . . . : *BASIC
Category of controller . . . . . : *HOST

Link type . . . . . : *LAN
Online at IPL . . . . . : *YES
Active switched line . . . . . : *L31TR
Character code . . . . . : *EBCDIC
Maximum frame size . . . . . : 521
Remote network identifier . . . . . : USIBMRA
Remote control point . . . . . : CP31742
Local exchange identifier . . . . . : *LIND
Initial connection . . . . . : *DIAL
Dial initiation . . . . . : *LINKTYPE
Switched disconnect . . . . . : *NO
LAN remote adapter address . . . . . : 400031740002

Press Enter to continue
```

Figure 185. Controller Description (C31742) 1 of 4

```
Display Controller Description                                RALYASYA
                                                           06/15/93 15:46:28
Controller description . . . . . : C3174C2
Option . . . . . : *SWLINST
Category of controller . . . . . : *HOST

----- Switched Lines -----

L31TR

Press Enter to continue
```

Figure 186. Controller Description (CP31742) 2 of 4

```
Display Controller Description                                RALYASYA
                                                           06/15/93 15:46:28
Controller description . . . . . : C3174C2
Option . . . . . : *SWLINST
Category of controller . . . . . : *HOST

----- Attached Devices -----

PS2COAX

Press Enter to continue
```

Figure 187. Controller Description (CP31742) 3 of 4



```

                                Display Controller Description
                                06/15/93  RALYASYA 15:46:20
Controller description . . . . . : CP31742
Option . . . . . : *APPN
Category of controller . . . . . : *HOST

APPN-capable . . . . . : *YES
APPN CP session support . . . . . : *YES
APPN node type . . . . . : *NETNODE
APPN transmission group number . . . : 1
APPN minimum switch status . . . . . : *VRYONPND
Autodelete device . . . . . : 1440
User-defined 1 . . . . . : *LIND
User-defined 2 . . . . . : *LIND
User-defined 3 . . . . . : *LIND

Press Enter to continue

```

*Figure 188. Controller Description (CP31742) 4 of 4*

## 6.9.4 Device Description Screens (PS2COAX)

```
Display Device Description                                RALYASYA
                                                    06/15/93 15:46:20
Device description . . . . . : PS2COAX
Option . . . . . : *BASIC
Category of device . . . . . : *APPC

Automatically created . . . . . : NO
Remote location . . . . . : PS2COAX
Online at IPL . . . . . : *NO
Local location . . . . . : RALYAS4A
Remote network identifier . . . . . : *NETATR
Attached controller . . . . . : CP31742
Message queue . . . . . : QSYSOPR
Library . . . . . : *LIBL
Local location address . . . . . : 00
APPN-capable . . . . . : *YES
Single session:
  Single session capable . . . . . : *NO
Text . . . . . : AUTOMATICALLY CREATED BY QLUS
```

Figure 189. Device Description (PS2COAX) 1 of 2

```
Display Device Description                                RALYASYA
                                                    06/15/93 15:46:20
Device description . . . . . : PS2COAX
Option . . . . . : *MODE
Category of device . . . . . : *APPC

----- Mode -----
*NETATR
```

Figure 190. Device Description (PS2COAX) 2 of 2

## 6.10 Communications Manager/2 Definitions for 5250 Emulation

On the PS/2, we run Communications Manager/2 and do the following:

- Communications Manager Installation/Setup
- Communication Setup
- Open Configuration
- Communication Manager Configuration Definition - 5250
- 5250 Emulation through Token-Ring
- Communication Setup Close

### 6.10.1 Communications Manager/2 Installation and Setup




Figure 191. Communications Manager/2 Installation and Setup

To initiate setup you will have to either click on the CMSETUP icon if Communications Manager/2 is already installed, or enter *cmsetup* from the command prompt if this is the initial installation (see *Communications Manager/2 Installation Guide* for details).

## 6.10.2 Communications Manager Setup




Figure 192. Communications Manager Setup

Select **Setup...** to create or modify a configuration definition.

## 6.10.3 Open Configuration




Figure 193. Open Configuration

1. Enter a configuration name.

2. Enter a description of the configuration for documentation purposes.

Then you will be asked, **Will this configuration be used for this workstation;** press the **Yes** key and continue with the next step.

3. Press the **OK** key to get the panel shown in Figure 194

#### 6.10.4 Communications Manager Configuration Definition-PSEN3174




Figure 194. Communications Manager/2 Configuration Definition for 5250 Emulation

Here we define the logical connection from Communications Manager/2 to the AS/400.

- Select **Token-ring or other LAN types**.
- Select **5250 emulation**.
- Press the **Configure** push button to get the **Communications Manager Profile List Sheet** shown in Figure 195 on page 185.

## 6.10.5 Communications Manager Profile List Sheet




Figure 195. Communications Manager Profile List Sheet

In the **Action** and **Profile Name** fields, you select your needed profiles for configuration.

## 6.10.6 Token-Ring or Other LAN Types DLC Adapter Parameters





Figure 196. Token-Ring or Other LAN Types DLC Adapter Parameters

Here you select the adapter, window counts, I-field size and other SNA DLC information.

**Note:** Using this DLC requires that you have an appropriately installed and configured LAPS.

## 6.10.7 Local Node Characteristics




The dialog box titled "Local Node Characteristics" is divided into several sections. The "Required values" section contains text boxes for "Network ID" (USIBMRA), "Local node name" (PS2COAX), and "Your network node server address (hex)" (400031740002). The "Node type" section has three radio buttons: "End node to network node server" (selected), "End node - no network node server", and "Network node". The "Additional values" section includes text boxes for "Local node ID (hex)" (05D 42992), "Local node alias name" (PS2COAX), and an empty "Optional comment" box. A checked checkbox "Activate Attach Manager at start up" is at the bottom. Buttons for "OK", "Cancel", and "Help" are at the very bottom.

Figure 197. Local Node Characteristics

This panel is displayed if you select **SNA local node characteristics** shown in Figure 195 on page 185. This profile provides the base SNA information such as network ID, local node name, type of node (EN or NN) and your node ID.

## 6.10.8 SNA Features List



The dialog box titled "SNA Features List" contains a text box with instructions: "To create, change, or delete a definition of a feature, select a listbox item, then choose the appropriate pushbutton." Below this is a table with three columns: "Features", "Definition", and "Comment". The "Features" column lists: "Local LUs", "Partner LUs", "Modes", "Transaction program definitions", "Transaction program defaults", "Transaction program security", "Conversation security", "LU to LU security", and "CPI Communications side inform". The "Definition" and "Comment" columns are empty. At the bottom are buttons for "Create...", "Change...", "Delete", "Close", and "Help".


Features	Definition	Comment
Local LUs		
Partner LUs		
Modes		
Transaction program definitions		
Transaction program defaults		
Transaction program security		
Conversation security		
LU to LU security		
CPI Communications side inform		

Figure 198. SNA Features List

On the SNA Features List panel, you get a list of the available features. All of the LU6.2 information is provided from this window.

If you select **5250 emulation** in Figure 195 on page 185, you get the screen shown in Figure 199.

### 6.10.9 5250 Emulation



Short Session Name	Long Session Name	Type	Partner LU	Mode	Keyboard	Color
C	C	LT	AS400A	QPCSUPP	ACSCENUS	5250COLR

Figure 199. 5250 Emulation

Here you can select, create or modify keyboard and color profiles. This screen allows you to complete the customization of 5250 emulation.

If your configuration requires additional installation, see *Communications Manager/2 Configuration Guide*, SC31-6171, for further information.



## 6.11 LAN Adapter and Protocol Support

In LAN Adapter and Protocol Support, we do the following:

- Configure LAN transports
- Configure workstation
- Define network adapter address.

### 6.11.1 LAN Adapter and Protocol Support




Figure 200. LAN Adapter and Protocol Support

Select **Configure** to proceed to Figure 201.

### 6.11.2 Configure LAN Transports




Figure 201. Configure LAN Transports

Select **Continue** to proceed to Figure 202 on page 189.

### 6.11.3 Configure Workstation




Figure 202. Configure Workstation

1. Select **3270 Adapter for 3174 Peer Communications**.
2. Press the **OK** key to get to the panel shown in Figure 203

### 6.11.4 Parameters for 3270 Adapter for 3174 Peer Communications




Figure 203. Network Adapter Address

1. Enter the PS/2 network adapter address.
2. Press the **OK** key to get the panel shown in Figure 204 on page 190; note that your CONFIG.SYS file is updated at the same time.

## 6.11.5 LAN Adapter and Protocol Support




Figure 204. LAN Adapter and Protocol Support

Select **Exit** to end the LAN Adapter and Protocol Support process.

## 6.11.6 3174-11R Online Display

Adjacent Nodes							
LINKID	NETID	CPNAME	Type	Status	State	Num Sess	CP-CP
1	1	USIBMRAA	RALYAS4A	NN	OPEN	08	1 NO
2	4	USIBMRAA	PS2COAX	EN	OPEN	08	1 YES

To go directly to other tests, enter: /Test,Option  
Select Option; press ENTER ==>  
4729-Enter the LINKID to run Link Status Test  
PF: 3=Quit 5=Refresh 12=Test Menu

Figure 205. Display of Nodes Adjacent to the 3174-11R.

- 1 There is one session from the 3174-11R to the network node (RALYAS4A), but no CP-CP session exist
- 2 Shows one session from the 3174-11R (CP3174) to the end node PS2COAX and that CP-CP sessions exist between CP3174 and PS2COAX

## 6.12 VTAM Definition List

This VTAM definition list shows you the PU/LU specifications for the PU addresses C1 to C8 which are customized on our 3174.

```

NCPOPT  OPTIONS NEWDEFN=(YES,ECHO,NOSUPP),USERGEN=(FNMNDFGN)
*****
*          PCCU MACRO - VTAM THAT WILL ACTIVATE THIS NCP          *
*****
VTAMV321 PCCU CUADDR=930,          SA20 WTCOS MVS/XA.          *AK* *
          AUTODMP=NO,              ONLY ONE AUTODMP-HOST IF TWINTAIL *
          AUTOIPL=NO,              ONLY ONE AUTOIPL-HOST IF TWINTAIL *
          AUTOSYN=YES,             USE THE ALREADY LOADED NCP IF OK   *
          BACKUP=YES,              RESOURCE TAKEOVER PERMITTED      *
          CHANCON=COND,            CONDITIONAL CONTACT REQ. TO NCP SENT*
          DUMPDS=NCPDUMP,          DUMP DATASET                *
          MDUMPDS=NCPDMOSS,        MOSS DUMP DATASET           *
          CDUMPDS=NCPDCSP,         SCANNER DUMP DATASET        *
          MAXDATA=5000,            *
          OWNER=M25,               *
          VFYLM=YES,              VERIFY LMOD WHEN LOADING      *
          SUBAREA=25               WTCXA MVS/XA VTAM V3R1.1
*****
*          PCCU MACRO - VTAM 03 WILL ACTIVATE THIS NCP          *
*****
VTAM03  PCCU AUTODMP=NO,          ONLY ONE AUTODMP-HOST IF TWINTAIL *
          AUTOIPL=NO,              ONLY ONE AUTOIPL-HOST IF TWINTAIL *
          AUTOSYN=YES,             USE THE ALREADY LOADED NCP IF OK   *
          BACKUP=YES,              RESOURCE TAKEOVER PERMITTED      *
          CHANCON=COND,            CONDITIONAL CONTACT REQ. TO NCP SENT*
          DUMPDS=NCPDUMP,          DUMP DATASET                *
          MDUMPDS=NCPDMOSS,        MOSS DUMP DATASET           *
          CDUMPDS=NCPDCSP,         SCANNER DUMP DATASET        *
          MAXDATA=5000,            *
          OWNER=M25,               *
          VFYLM=YES,              VERIFY LMOD WHEN LOADING      *
          SUBAREA=03               WTCXA MVS/XA VTAM V3R1.1
*****
*          BUILD MACRO - NCP/CONTROLLER INFORMATION            *
*****
          BUILD BFRS=(240),        NCP BUFFER SIZE                *
          ADDSESS=300,             ALLOCATED SESSION CONTROL BLOCKS T2.1 *
          AUXADDR=300,             EXTRA ADDR. FOR ILU ACT AS PLU   T2.1 *
          MEMSIZE=4M,              4M TO USE                        *
          BRANCH=8000,             BRANCH TRACE ENTRIES            *
          CATRACE=(YES,100),        CHANNEL ADAPTER TRACE            *
          CWALL=26,                MIN. BUFFERS BEFORE SLOWDOWN     *
          DSABLTO=6.5,             *
          ENABLTO=6.5,             IBM 386X REQUIRE 6.5 AS MINIMUM  *
          ERLIMIT=16,              *
          LTRACE=4,                SIT FOR 4 LINES                  *
          LOADLIB=NCPLoad,         NCP LOAD MODULE LIBRARY         *
          MAXSSCP=8,               8 SSCP'S CAN ACTIVATE THIS NCP  *
          MAXSESS=5000,            MAX NUMBER OF SESSIONS FOR ILU  *
          MLTGORDR=MLTGPRI,        USE MLTGS IN ORDER OF PRIORITY  *
          MODEL=3745-61A,          3745 COMMUNICATION CONTROLLER  *
          NAMTAB=50,               MAX NUMBER SSCP, NETWORKS, CP T2.1 *
          NETID=USIBMRA,           REQUIRED                          *
          NPA=(YES,DR),            *

```

```

NEWNAME=RA6NCSF, NAME OF THIS LOAD MODULE *AK* *
NUMHSAS=6, 6 HOSTS MAY COMMUNICATE CONCURRENTLY*
PUNAME=RA6NCSF, NAME OF THIS PU *AK* *
SUBAREA=06, SUBAREA ADDRESS = 06 *
TRACE=(YES,64), 64 ADDRESS-TRACE ENTRIES *
TYPGEN=NCP, NCP ONLY *
TYP SYS=MVS, MVS OPERATING SYSTEM *
USGTIER=5, NCP USAGE TIER *
VERSION=V6R2F NDF VERSION INDICATOR
*****
* PATH SPECIFICATIONS *
*****
RA6NCP NCPPATH NETID=USIBMRA
PATH DESTSA=3, *
ER0=(9,6), *
ER1=(9,6), *
ER2=(9,6), *
ER3=(9,6), *
ER4=(9,6), *
ER5=(9,6), *
VR0=2, *
VRPWS00=(1,30),VRPWS01=(1,30),VRPWS02=(1,30), *
VR1=0, *
VRPWS10=(1,30),VRPWS11=(1,30),VRPWS12=(1,30), *
VR2=1, *
VRPWS20=(1,30),VRPWS21=(1,30),VRPWS22=(1,30)
*****
* LINE MACRO SPECIFICATION *
*****
L06143 LINE ADDRESS=(143,FULL), FULL DUPLEX *
ANS=CONTINUE, DON'T BREAK CROSS DOMAIN SESSIONS *
GP3174=AE, *
CLOCKNG=EXT, DTE CABLE 7837395 ATTACHED *
ISTATUS=ACTIVE, *
DUPLEX=(FULL), REQUEST TO SEND ALWAYS UP *
ETRATIO=30, DEFAULT *
MAXPU=20, ALLOW NO MORE THAN 9 PUS ON LINE *
SERVLIM=10, *
SPEED=9600, NPA AND SCANNER USE ### *
SRT=(,64)
* STATOPT=('3174 GW LINE')
*****
* SERVICE MACRO SPECIFICATION FOR SDLC (LINE 143) *
*****
SERVICE ORDER=(P06143A,P06143B,P06143C,P06143D,P06143E, *
P06143F,P06143G,P06143H,P06143I,P06143J,P06143K,P06143L,*
P06143M,P06143N,P06143O,P06143P,P06143Q,P06143R,P06143S,*
P06143T),MAXLIST=20
*****
* PU/LU SPECIFICATIONS *
*****
P06143A PU ADDR=C1, CLUSTER ADDRESS = 01 *
MAXDATA=265, MAXIMUM AMOUNT OF DATA *
MAXOUT=7, MAX SDLC FRAMES BEFORE RESPONSE *
PACING=0, PACING SET BY BIND IMAGE *
PASSLIM=8, *
PUDR=YES, *
PUTYPE=2, *
RETRIES=(,4,5), 7 RETRY PER SECOND FOR 5 TIMES *

```

```

                DISCNT=(NO),          (V) VTAM
                ISTATUS=ACTIVE,       (V) VTAM
                SSCPFM=USSSCS,       (V) VTAM
                USSTAB=US327X,       (V) VTAM
                VPACING=0             (V) VTAM
*                STATOPT=('3174',NOACTY)
T06143A1 LU LOCADDR=2,              FIRST LU MUST BE LOCADDR=2
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE       (V) VTAM
T06143A2 LU LOCADDR=3,              *
                MODETAB=MODEVR,DLOGMOD=VR03270, *
                ISTATUS=ACTIVE       (V) VTAM
T06143A3 LU LOCADDR=4,              *
                MODETAB=MODEVR,DLOGMOD=VR03270, *
                ISTATUS=ACTIVE       (V) VTAM
T06143A4 LU LOCADDR=5,              *
                MODETAB=MODEVR,DLOGMOD=VR03270, *
                ISTATUS=ACTIVE       (V) VTAM
P06143B PU ADDR=C2,                CLUSTER ADDRESS = 02
                MAXDATA=265,          MAXIMUM AMOUNT OF DATA
                MAXOUT=7,             MAX SDLC FRAMES BEFORE RESPONSE
                PACING=0,             PACING SET BY BIND IMAGE
                PASSLIM=8,
                PUDR=YES,
                PUTYPE=2,
                RETRIES=(,4,5),       7 RETRY PER SECOND FOR 5 TIMES
                DISCNT=(NO),          (V) VTAM
                ISTATUS=ACTIVE,       (V) VTAM
                SSCPFM=USSSCS,       (V) VTAM
                USSTAB=US327X,       (V) VTAM
                VPACING=0             (V) VTAM
*                STATOPT=('3174',NOACTY)
T06143B1 LU LOCADDR=2,              FIRST LU MUST BE LOCADDR=2
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE       (V) VTAM
T06143B2 LU LOCADDR=3,              *
                MODETAB=MODEVR,DLOGMOD=VR03270, *
                ISTATUS=ACTIVE       (V) VTAM
T06143B3 LU LOCADDR=4,              *
                MODETAB=MODEVR,DLOGMOD=VR03270, *
                ISTATUS=ACTIVE       (V) VTAM
T06143B4 LU LOCADDR=5,              *
                MODETAB=MODEVR,DLOGMOD=VR03270, *
                ISTATUS=ACTIVE       (V) VTAM
P06143C PU ADDR=C3,                CLUSTER ADDRESS = 03
                MAXDATA=265,          MAXIMUM AMOUNT OF DATA
                MAXOUT=7,             MAX SDLC FRAMES BEFORE RESPONSE
                PACING=0,             PACING SET BY BIND IMAGE
                PASSLIM=8,
                PUDR=YES,
                PUTYPE=2,
                RETRIES=(,4,5),       7 RETRY PER SECOND FOR 5 TIMES
                DISCNT=(NO),          (V) VTAM
                ISTATUS=ACTIVE,       (V) VTAM
                SSCPFM=USSSCS,       (V) VTAM
                USSTAB=US327X,       (V) VTAM
                VPACING=0             (V) VTAM
*                STATOPT=('3174',NOACTY)
T06143C1 LU LOCADDR=2,              FIRST LU MUST BE LOCADDR=2

```

```

      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
T06143C2 LU LOCADDR=3,
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
T06143C3 LU LOCADDR=4,
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
T06143C4 LU LOCADDR=5,
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
P06143D  PU ADDR=C4,      CLUSTER ADDRESS = 04
      MAXDATA=265,        MAXIMUM AMOUNT OF DATA
      MAXOUT=7,           MAX SDLC FRAMES BEFORE RESPONSE
      PACING=0,           PACING SET BY BIND IMAGE
      PASSLIM=8,
      PUDR=YES,
      PUTYPE=2,
      RETRIES=(,4,5),     7 RETRY PER SECOND FOR 5 TIMES
      DISCNT=(NO),        (V) VTAM
      ISTATUS=ACTIVE,     (V) VTAM
      SSCPFM=USSSCS,      (V) VTAM
      USSTAB=US327X,      (V) VTAM
      VPACING=0           (V) VTAM
*
      STATOPT=('3174',NOACTY)
T06143D1 LU LOCADDR=2,      FIRST LU MUST BE LOCADDR=2
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
T06143D2 LU LOCADDR=3,
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
T06143D3 LU LOCADDR=4,
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
T06143D4 LU LOCADDR=5,
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
P06143E  PU ADDR=C5,      CLUSTER ADDRESS = 05
      MAXDATA=265,        MAXIMUM AMOUNT OF DATA
      MAXOUT=7,           MAX SDLC FRAMES BEFORE RESPONSE
      PACING=0,           PACING SET BY BIND IMAGE
      PASSLIM=8,
      PUDR=YES,
      PUTYPE=2,
      RETRIES=(,4,5),     7 RETRY PER SECOND FOR 5 TIMES
      DISCNT=(NO),        (V) VTAM
      ISTATUS=ACTIVE,     (V) VTAM
      SSCPFM=USSSCS,      (V) VTAM
      USSTAB=US327X,      (V) VTAM
      VPACING=0           (V) VTAM
*
      STATOPT=('3174',NOACTY)
T06143E1 LU LOCADDR=2,      FIRST LU MUST BE LOCADDR=2
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
T06143E2 LU LOCADDR=3,
      MODETAB=MODEVR,DLOGMOD=VR03270,
      ISTATUS=ACTIVE      (V) VTAM
T06143E3 LU LOCADDR=4,
      MODETAB=MODEVR,DLOGMOD=VR03270,

```



```

                ISTATUS=ACTIVE      (V) VTAM
T06143E4 LU LOCADDR=5,
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
P06143F PU ADDR=C6,                CLUSTER ADDRESS = 06
                MAXDATA=265,        MAXIMUM AMOUNT OF DATA
                MAXOUT=7,           MAX SDLC FRAMES BEFORE RESPONSE
                PACING=0,           PACING SET BY BIND IMAGE
                PASSLIM=8,
                PUDR=YES,
                PUTYPE=2,
                RETRIES=(,4,5),     7 RETRY PER SECOND FOR 5 TIMES
                DISCNT=(NO),        (V) VTAM
                ISTATUS=ACTIVE,     (V) VTAM
                SSCPFM=USSSCS,     (V) VTAM
                USSTAB=US327X,     (V) VTAM
                VPACING=0           (V) VTAM
*
                STATOPT=('3174',NOACTY)
T06143F1 LU LOCADDR=2,            FIRST LU MUST BE LOCADDR=2
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
T06143F2 LU LOCADDR=3,
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
T06143F3 LU LOCADDR=4,
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
T06143F4 LU LOCADDR=5,
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
P06143G PU ADDR=C7,                CLUSTER ADDRESS = 07
                MAXDATA=265,        MAXIMUM AMOUNT OF DATA
                MAXOUT=7,           MAX SDLC FRAMES BEFORE RESPONSE
                PACING=0,           PACING SET BY BIND IMAGE
                PASSLIM=8,
                PUDR=YES,
                PUTYPE=2,
                RETRIES=(,4,5),     7 RETRY PER SECOND FOR 5 TIMES
                DISCNT=(NO),        (V) VTAM
                ISTATUS=ACTIVE,     (V) VTAM
                SSCPFM=USSSCS,     (V) VTAM
                USSTAB=US327X,     (V) VTAM
                VPACING=0           (V) VTAM
*
                STATOPT=('3174',NOACTY)
T06143G1 LU LOCADDR=2,            FIRST LU MUST BE LOCADDR=2
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
T06143G2 LU LOCADDR=3,
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
T06143G3 LU LOCADDR=4,
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
T06143G4 LU LOCADDR=5,
                MODETAB=MODEVR,DLOGMOD=VR03270,
                ISTATUS=ACTIVE      (V) VTAM
P06143H PU ADDR=C8,                CLUSTER ADDRESS = 08
                MAXDATA=265,        MAXIMUM AMOUNT OF DATA
                MAXOUT=7,           MAX SDLC FRAMES BEFORE RESPONSE

```

```

PACING=0,          PACING SET BY BIND IMAGE      *
PASSLIM=8,        *
PUDR=YES,         *
PUTYPE=2,         *
RETRIES=(,4,5),   7 RETRY PER SECOND FOR 5 TIMES *
DISCNT=(NO),      (V) VTAM                       *
ISTATUS=ACTIVE,   (V) VTAM                       *
SSCPFM=USSCS,    (V) VTAM                       *
USSTAB=US327X,   (V) VTAM                       *
VPACING=0         (V) VTAM                       *
* STATOPT=('3174',NOACTY)
T06143H1 LU LOCADDR=2, FIRST LU MUST BE LOCADDR=2 *
MODETAB=MODEVR,DLOGMOD=VR03270,                 *
ISTATUS=ACTIVE (V) VTAM
T06143H2 LU LOCADDR=3,                           *
MODETAB=MODEVR,DLOGMOD=VR03270,                 *
ISTATUS=ACTIVE (V) VTAM
T06143H3 LU LOCADDR=4,                           *
MODETAB=MODEVR,DLOGMOD=VR03270,                 *
ISTATUS=ACTIVE (V) VTAM
T06143H4 LU LOCADDR=5,                           *
MODETAB=MODEVR,DLOGMOD=VR03270,                 *
ISTATUS=ACTIVE (V) VTAM
GENEND INIT=ECLINIT,                             *
TMRTICK=ECLTICK,                                 *
UGLOBAL=ECLUGBL

```

## 6.13 3174 TCP/IP Definitions

### 6.13.1 AEA And TCP/IP Configure

\_\_\_\_\_ AEA and TCP/IP Configure \_\_\_\_\_

700 - 0 1 **1**

702 - 1 **2**

703 - 0

710 - 00000000      711 - 00000000      712 - 00000000      713 - 00000000

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 206. AEA and TCP/IP Configure Panel

**1** Question 700 allows enabling of the AEA and TCP/IP capability. For our example, we have customized for TCP/IP capability.

**2** Question 702 allows you to specify the control key when using ASCII emulation:

- 0=Use the Alt key
- 1=Use the Ctrl key (default response)

If you have never used the AEA feature before, use the default value.

### 6.13.2 Defining Port Set

\_\_\_\_\_ Port Set \_\_\_\_\_

Name	Session Limit	Port Type	Modem Type	Password
1 = 3270DISP <b>1</b>	5	1 <b>2</b>	-	_____
2 = _____	-	-	-	_____
3 = _____	-	-	-	_____
4 = _____	-	-	-	_____
5 = _____	-	-	-	_____
6 = _____	-	-	-	_____
7 = _____	-	-	-	_____
8 = _____	-	-	-	_____
9 = _____	-	-	-	_____
10 = _____	-	-	-	_____
11 = _____	-	-	-	_____
12 = _____	-	-	-	_____
13 = _____	-	-	-	_____
14 = _____	-	-	-	_____
15 = _____	-	-	-	_____
16 = _____	-	-	-	_____

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 207. Port Set Panel

**1** Enter **3270DISP** in the Name field.

**2** Enter a **1** in the Port Type field for 3270 displays. This allows your 3270 display defined to port set 1 to access the TCP/IP destination.

### 6.13.3 Mapping Port To Port Set

Port to Port Set Map Page 01 of 03

Type the port set number to group the 3174 ports

3270 Ports	0	1	2	3	4	5	6	7
26-00 to 26-07	1	1	1	1	1	1	1	1
26-08 to 26-15	-	-	-	-	-	-	-	-
26-16 to 26-23	-	-	-	-	-	-	-	-
26-24 to 26-31	-	-	-	-	-	-	-	-

Port Sets			
1 = 3270DISP	2 =	3 =	4 =
5 =	6 =	7 =	8 =
9 =	10 =	11 =	12 =
13 =	14 =	15 =	16 =

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=PageBack    11=PageFwd

Figure 208. Port To Port Set Map Panel

**1** You should use this panel to assign coax ports to the port set, named 3270DISP, that you have defined in the Port Set panel. Enter the port set number for each port that you wish to use the 3174 TCP/IP TELNET function.

### 6.13.4 Defining 3270 Host and Display Station Sets

AEA and TCP/IP Station Set

<b>1</b>	1	721 - 3270 HOST		722 - 3H	<b>3</b>	723 -	725 - 1
		731 - 1	732 - 1	733 - 0	734 -	735 - 0	736 - 1
		741 - 000	742 - 015	743 - 1	744 - 0	745 - 0	746 - 0 0
		751 -	752 -				
		761 - 1	762 - 1	763 - 1	764 - 1	765 - 0	
		771 - 1	772 - 1	773 - 1	774 - 1	775 - 1	776 - 1
		781 - 0	782 - 0	783 - 066	784 - 1	785 - 11111000	786 - 132
		790 - 000	000	000	000		

<b>2</b>	2	721 - 3270 DISPLAY		722 - 3D	<b>4</b>	723 - 3270DISP	725 - 1
		731 - 1	732 - 1	733 - 0	734 -	735 - 0	736 - 1
		741 - 000	742 - 015	743 - 1	744 - 0	745 - 0	746 - 0 0
		751 -	752 -				
		761 - 1	762 - 1	763 - 1	764 - 1	765 - 0	
		771 - 1	772 - 1	773 - 1	774 - 1	775 - 1	776 - 1
		781 - 0	782 - 0	783 - 066	784 - 1	785 - 11111000	786 - 132
		790 - 000	000	000	000		

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=Page Back    11=Page Fwd

Figure 209. AEA and TCP/IP Station Set Panel (1 of 2)

- 1** Is the station set name for the 3270 host.
- 2** Is the station set name for the 3270 displays.

Whatever name you enter here will be displayed on the Connection Menu as a possible destination for the LT.

- 3** Enter 3H as the station type for the 3270 host.

- 4 Enter 3D as the station type for 3270 displays.

You will also need to define station sets for TCP/IP access (see 6.13.5, "Defining TCP/IP Station Sets").

For detailed information about defining TCP/IP station sets, see 3.9, "Customizing 3174 TCP/IP Telnet Support" on page 24.

### 6.13.5 Defining TCP/IP Station Sets

```

_____ AEA and TCP/IP Station Set _____

1 3 721 - TELNET VT100 _____ 2 722 - TH 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
3 751 - 1 752 - _____
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 1111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

1 4 721 - TELNET VT220 8 BIT _____ 2 722 - TH 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
3 751 - 4 752 - _____
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 1111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000

All responses are correct
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

```

Figure 210. AEA and TCP/IP Station Set Panel (2 of 2)

To define each station set for TCP/IP access, respond to the following questions:

- 1 Enter the station set name that you wish displayed on the connection menu.
- 2 Enter TH as the station type of the TCP/IP host.
- 3 Enter the type of ASCII emulation (1=VT100, 4=VT220 7-bit).

### 6.13.6 Defining Default Destinations

AEA and TCP/IP Default Destination							
Station Set	Station Set Name	Session Limit	Session				
			LT1	LT2	LT3	LT4	LT5
1	3270 HOST	0	---	---	---	---	---
2	3270 DISPLAY	5	---	---	---	---	---
3	TELNET VT100	0	---	---	---	---	---
4	TELNET VT220 7 BIT	0	---	---	---	---	---
5		0	---	---	---	---	---
6		0	---	---	---	---	---
7		0	---	---	---	---	---
8		0	---	---	---	---	---
9		0	---	---	---	---	---
10		0	---	---	---	---	---
11		0	---	---	---	---	---
12		0	---	---	---	---	---
13		0	---	---	---	---	---
14		0	---	---	---	---	---
15		0	---	---	---	---	---

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=Page Back    11=Page Fwd

Figure 211. AEA and TCP/IP Default Destination Panel

This panel determines what the terminal user will see on each LT when it is first accessed.

### 6.13.7 Defining TCP/IP Options

TCP/IP Options Menu		
3174 IP Address	052 - 009 . 067 . 038 . 088	<b>1</b>
Subnet Mask	054 - 255 . 255 . 255 . 192	<b>2</b>
Maximum TELNET Connections	058 - 020 (001 - 250)	
TCP/IP Buffer Space	060 - 0256 K (K = 1024 bytes)	
Routing Field Support	062 - Y (Y,N)	
All Routes Broadcast	064 - Y (Y,N)	

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 212. TCP/IP Options Menu

**1** Is the IP address assigned to your 3174.

For example, the IP address of our 3174-11R is 9.67.38.88.

**2** Is the subnet mask of the network.

## 6.13.8 Defining TCP/IP Routing Information

TCP/IP Routing Information		
Destination IP Address	Type (N,S,H,D)	Router IP Address
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX

PF: 3=Quit   4=Default   7=Back   8=Fwd

Figure 213. TCP/IP Routing Information

Since all AS/400 and the 3174-11R are in the same subnet, there is no need for routing table entries.



## 6.13.9 Defining Domain Name Services

\_\_\_\_ TCP/IP Domain Name Services \_\_\_\_

3174 Hostname  
317411R **1** \_\_\_\_\_

3174 Domain Name  
ITSO RALEIGH IBM COM **2** \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Domain Nameserver IP Addresses

XXX . XXX . XXX . XXX

XXX . XXX . XXX . XXX

XXX . XXX . XXX . XXX

XXX . XXX . XXX . XXX

PF: 3=Quit 4=Default 7=Back 8=Fwd

*Figure 214. TCP/IP Domain Name Services*

- 1** Is the name assigned to our 3174.
- 2** Is the domain which our 3174 resides.

### 6.13.10 Defining TCP/IP Nicknames

```
_____ TCP/IP 3174 Defined Nicknames _____  
  
      Nickname                IP Address  
  
1 AS400B _____          009 . 067 . 038 . 083  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  _____                XXX . XXX . XXX . XXX  
  
PF: 3=Quit  4=Default  7=Back  8=Fwd
```

Figure 215. TCP/IP 3174 Defined Nicknames

Since users remember names better than numeric IP addresses, this panel allows you to define up to 16 host nicknames and their associated IP addresses.

**1** Is the nickname of the AS/400 TCP/IP host.

### 6.13.11 Configure Complete

```
_____ AEA and TCP/IP Configure Complete _____  
  
      Press PF12 to save all responses  
      and return to the AEA Menu  
  
PF: 3=Quit  4=Default  7=Back  8=Fwd  12=Done
```

Figure 216. AEA and TCP/IP Configure Complete

You have now completed customizing for the 3174 TCP/IP Telnet Support.

### 6.13.12 TELNET to AS/400

If you specified an address at the TCP/IP Station Set, type in the number of the host to which you want to have a session.




Figure 217. Selecting Emulation for AS/400

If you have not specified an address at the TCP/IP Station Set, select the emulation in the NUM Field of the Connection Menu and you get the 3174 TELNET prompt.

**1** VT100 is the selected emulation in our example.

### 6.13.13 TELNET Prompt




Figure 218. Command and Destination

At the TELNET prompt, type in the command and destination.

In our example, we entered the OPEN command and the IP address of the AS/400 (9.67.38.83).

The following AS/400 sign-on screen appears on the 3270 CUT terminal.

### 6.13.14 AS/400 Sign-On Screen




Figure 219. AS400 Sign On Screen

**1** Is the network name (or network ID) of the AS/400.

After signing on to the AS/400, you get the AS/400 Main Menu.

### 6.13.15 AS/400 Main Menu




Figure 220. AS/400 Main Menu

## 6.14 Display 3174-Peer Status

```
----- Display 3174-Peer Status - HG 26 -----
Port  Current      Functional      Group      Discarded      Device
Address Address        Address        Address        Frame Ctr      Status
00
01
02
03
04
05 4000 3174 2992 ..... 0 1 1
06
07
08
09
10
11
12
13
14
15

To go directly to other tests, enter: /Test,Option
Select Test; press ENTER ==>
PF: 3=Quit 5=Refresh 8=Fwd 9=Ctr->0 12=Test Menu
```

Figure 221. Display 3174-Peer Status

**1** The 1 means that the interface is enabled.

For detailed information about online test status information, see *Customer Problem Determination Guide, GA23-0217*.

## Chapter 7. Scenario 4: TCP/IP via 3174 and RS/6000 Router to VAX

This scenario shows the ability of a 3270 CUT terminal, using the 3174 TCP/IP Telnet Support, to establish TCP/IP sessions with a DEC VAX host which is connected via Ethernet to a RISC System/6000 router. Simultaneously, the PS/2 is using the 3174 Peer bridging function to access other TCP/IP host on the LANs. The emphasis in this scenario is the routing from token-ring network subnet to Ethernet subnet.

### 7.1 Scenario 4 Configuration




Figure 222. TCP/IP to DEC VAX and AS/400 Hosts

---

## 7.2 Scenario 4 Description

Scenario 4 shows a PS/2 workstation and a 3270 CUT Terminal coax-attached to the 3174-11R using the 3174 Peer Communication and 3174 TCP/IP Telnet Support, and the RISC System/6000 router to access a DEC VAX host via Ethernet.

The composite network has the following components:

- A 3174-11R with:
  - 3174 TCP/IP Telnet Support enabled
  - Peer Communication
- A PS/2 Communications Manager/2 (PS2COAX) with:
  - 3270 emulation
  - Token-ring address (400031742992)
- A 3270 CUT terminal (CUTCOAX)
- The AS/400 host
- The RISC System/6000 attached to a token-ring on one side and an Ethernet LAN on the other side, acting as a router
- A DEC VAX host attached to the same Ethernet LAN as the RISC System/6000

## 7.3 3174-11R TCP/IP and Peer Support Customization

The following Control Disk Menu shows the options that must be customized for Scenario 4.

### 7.3.1 Customize Control Disk Menu

```
_____ Customize Control Disk Menu _____

Select Option; press ENTER

Option   Description
-----
 1       Configure
 2       Define Devices
 3       Merge RPQs
 4       Modify Keyboards
 5 1    Define AEA and TCP/IP
 6       Define APPN Node
 7       Define COS
 8 2    Define 3174-PEER

Select ==>
Press PF12 to File, PF3 to Quit, or Select another Option
PF: 3=Quit  4=Default  7=Back  8=Fwd  9=Check  12=File
```

Figure 223. Customize Control Disk Menu

- 1** Option 5 is used to customize the TCP/IP functions.
- 2** Option 8 is used to define the Peer Communication functions.



## 7.4 3174-Peer Definition

The 3174-Peer support provides a logical internal token-ring segment and a bridge to a real external token-ring segment. Each coax-attached PS/2 workstation appears to be attached to the internal token-ring.

### 7.4.1 3174-Peer Definition Panel

The 3174-Peer Definition panels allow you to:

- Enable the internal token-ring segment.
- Enable the internal bridge function.
- Customize the internal bridge parameters.
- Enable LAN Manager support.
- Specify the middle six hexadecimal digits of the 3174-assigned token-ring address for the 3174-Peer devices.

\_\_\_\_\_ 3174-Peer Definition \_\_\_\_\_

3174-Peer Support

650 - Y	<b>1</b>	3174-Peer Support	(Y,N)
---------	----------	-------------------	-------

3174-Peer Options

651 - Y	<b>2</b>	Bridge Support	(Y,N)
652 - N		LAN Manager Support	(Y,N)
653 - Y		3174-Peer Online Test Updates	(Y,N)

3174-Peer Station Parameters

660 - 4000 3174 91 PN	3174-Peer Port Address Range	(0000 00 - FFFF FF)
661 - 05	Percentage of Discard Threshold	(00 - 99)

PF: 3=Quit    4=Default    8=Fwd

Figure 224. Enabling 3174 Peer Communication Functions

For Peer Communication to an external token-ring, the following responses are required:

- 1** 3174-Peer support is enabled.
- 2** Bridge support is enabled.

## 7.5 3174 TCP/IP Definitions

### 7.5.1 AEA and TCP/IP Configure

```
_____ AEA and TCP/IP Configure _____  
  
700 - 0 1 1  
702 - 1  
703 - 0  
710 - 00000000    711 - 00000000    712 - 00000000    713 - 00000000  
  
PF: 3=Quit    4=Default    7=Back    8=Fwd
```

*Figure 225. AEA and TCP/IP Configure Panel*

**1** We enable the TCP/IP capability only (second digit response). The first digit refers to the AEA.

## 7.5.2 Defining Port Set

Port Set				
Name	Session Limit	Port Type	Modem Type	Password
1 = 3270DISP <b>1</b>	5	1 <b>2</b>	-	_____
2 = _____	-	-	-	_____
3 = _____	-	-	-	_____
4 = _____	-	-	-	_____
5 = _____	-	-	-	_____
6 = _____	-	-	-	_____
7 = _____	-	-	-	_____
8 = _____	-	-	-	_____
9 = _____	-	-	-	_____
10 = _____	-	-	-	_____
11 = _____	-	-	-	_____
12 = _____	-	-	-	_____
13 = _____	-	-	-	_____
14 = _____	-	-	-	_____
15 = _____	-	-	-	_____
16 = _____	-	-	-	_____

PF: 3=Quit 4=Default 7=Back 8=Fwd

Figure 226. Port Set Panel

**1** Enter **3270DISP** in the Name field.

**2** Enter a 5 in the Session Limit field and a 1 in the Port Type field for this port set. It defines terminals belonging to this port set as 3270 displays, each with five sessions (MLT).

### 7.5.3 Mapping Port to Port Set

Port to Port Set Map Page 01 of 03

Type the port set number to group the 3174 ports

3270 Ports	0	1	2	3	4	5	6	7
26-00 to 26-07	1	1	1	1	1	1	1	1
26-08 to 26-15	-	-	-	-	-	-	-	-
26-16 to 26-23	-	-	-	-	-	-	-	-
26-24 to 26-31	-	-	-	-	-	-	-	-

Port Sets			
1 = 3270DISP	2 =	3 =	4 =
5 =	6 =	7 =	8 =
9 =	10 =	11 =	12 =
13 =	14 =	15 =	16 =

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=PageBack    11=PageFwd

Figure 227. Port to Port Set Map Panel

**1** You should use this panel to assign coax ports to the port set, named 3270DISP, that you have defined in the Port Set panel.

Enter the port set number for each port to be assigned to this port set.

### 7.5.4 Defining 3270 Host and Display Station Sets

AEA and TCP/IP Station Set

<b>1</b>	1	721 - 3270 HOST		722 - 3H	<b>3</b>	723 -		725 - 1
		731 - 1	732 - 1	733 - 0	734 -	735 - 0	736 - 1	737 -
		741 - 000	742 - 015	743 - 1	744 - 0	745 - 0	746 - 0 0	
		751 -	752 -					
		761 - 1	762 - 1	763 - 1	764 - 1	765 - 0		
		771 - 1	772 - 1	773 - 1	774 - 1	775 - 1	776 - 1	
		781 - 0	782 - 0	783 - 066	784 - 1	785 - 11111000	786 - 132	787 - 0
		790 - 000 . 000 . 000 . 000						

<b>2</b>	2	721 - 3270 DISPLAY		722 - 3D	<b>4</b>	723 - 3270DISP		725 - 1
		731 - 1	732 - 1	733 - 0	734 -	735 - 0	736 - 1	737 -
		741 - 000	742 - 015	743 - 1	744 - 0	745 - 0	746 - 0 0	
		751 -	752 -					
		761 - 1	762 - 1	763 - 1	764 - 1	765 - 0		
		771 - 1	772 - 1	773 - 1	774 - 1	775 - 1	776 - 1	
		781 - 0	782 - 0	783 - 066	784 - 1	785 - 11111000	786 - 132	787 - 0
		790 - 000 . 000 . 000 . 000						

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=Page Back    11=Page Fwd

Figure 228. AEA and TCP/IP Station Set Panel

**1** Is the station set name for the 3270 host.

**2** Is the station set name for the 3270 displays.

Whatever name you enter here will be displayed on the Connection Menu as a possible destination for the LT.

**3** Enter 3H as the station type for 3270 host.

**4** Enter 3D as the station type for 3270 displays.

You will also need to define station sets for TCP/IP access (see 7.5.5, "Defining TCP/IP Station Sets").

For detailed information about defining TCP/IP station sets, see 3.9, "Customizing 3174 TCP/IP Telnet Support" on page 24.

## 7.5.5 Defining TCP/IP Station Sets

```
_____ AEA and TCP/IP Station Set _____  
  
1 3 721 - TELNET VT100 _____ 2 722 - TH 723 - _____ 725 - 1  
731 - 1 732 - 1 733 - 0 734 - - 735 - 0 736 - 1 737 - -  
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0  
3 751 - 1 752 - _____  
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0  
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1  
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0  
790 - 000 . 000 . 000 . 000  
  
1 4 721 - TELNET VT220 7 BIT _____ 2 722 - TH 723 - _____ 725 - 1  
731 - 1 732 - 1 733 - 0 734 - - 735 - 0 736 - 1 737 - -  
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0  
3 751 - 2 752 - _____  
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0  
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1  
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0  
790 - 000 . 000 . 000 . 000  
  
All responses are correct  
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd
```

Figure 229. AEA and TCP/IP Station Set Panel

To define each station set for TCP/IP access, respond to the following questions:

**1** Enter the station set name that you wish displayed on the Connection Menu.

**2** Enter TH as the station type of the TCP/IP host.

**3** Enter 1 (VT100) and 4 (VT220 7-bit) as the ASCII emulation for the station set.

## 7.5.6 Defining Default Destinations

___ AEA and TCP/IP Default Destination ___							
Station Set	Station Set Name	Session Limit	Session				
			LT1	LT2	LT3	LT4	LT5
1	3270 HOST	0	---	---	---	---	---
2	3270 DISPLAY	5	---	---	---	---	---
3	TELNET VT100	0	---	---	---	---	---
4	TELNET VT220 7 BIT	0	---	---	---	---	---
5		0	---	---	---	---	---
6		0	---	---	---	---	---
7		0	---	---	---	---	---
8		0	---	---	---	---	---
9		0	---	---	---	---	---
10		0	---	---	---	---	---
11		0	---	---	---	---	---
12		0	---	---	---	---	---
13		0	---	---	---	---	---
14		0	---	---	---	---	---
15		0	---	---	---	---	---

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=Page Back    11=Page Fwd

Figure 230. AEA and TCP/IP Default Destination Panel

This panel determines what the terminal user will see on each LT when it is first accessed. Because the Session LTx fields are blank, the Connection Menu is the default.

## 7.5.7 Defining TCP/IP Options

___ TCP/IP Options Menu ___		
3174 IP Address	052 - 009 . 067 . 038 . 088	<b>1</b>
Subnet Mask	054 - 255 . 255 . 255 . 192	
Maximum TELNET Connections	058 - 020 (001 - 250)	
TCP/IP Buffer Space	060 - 0256 K (K = 1024 bytes)	
Routing Field Support	062 - Y (Y,N)	
All Routes Broadcast	064 - Y (Y,N)	

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 231. TCP/IP Options Menu

**1** The IP address of our 3174-11R is 9.67.38.88.

## 7.5.8 Defining TCP/IP Routing Information

TCP/IP Routing Information		
Destination IP Address	Type (N,S,H,D)	Router IP Address
009 . 067 . 032 . 000	S <b>1</b>	009 . 067 . 038 . 071 <b>2</b>
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX

PF: 3=Quit   4=Default   7=Back   8=Fwd

Figure 232. TCP/IP Routing Information

**1** Type=S means route to a specific subnet.

**2** The Router IP Address is the IP address of the router that should receive that destination's traffic. In our example, it is the RISC System/6000 with IP address 9.67.38.85.

## 7.5.9 Defining Domain Name Services

```
_____ TCP/IP Domain Name Services _____  
  
3174 Hostname  
317411R 1 _____  
  
3174 Domain Name  
ITSO RALEIGH IBM COM 2 _____  
_____  
_____  
_____  
  
Domain Nameserver IP Addresses 3  
  
XXX . XXX . XXX . XXX  
  
XXX . XXX . XXX . XXX  
  
XXX . XXX . XXX . XXX  
  
XXX . XXX . XXX . XXX  
  
PF: 3=Quit 4=Default 7=Back 8=Fwd
```

*Figure 233. TCP/IP Domain Name Services*

- 1** Is the name assigned to our 3174.
- 2** Is the domain which our 3174 resides.
- 3** In our example, we have not define a nameserver.



## 7.5.10 Defining TCP/IP Nicknames

TCP/IP 3174 Defined Nicknames	
Nickname	IP Address
1 VAX	009 . 067 . 032 . 071
2 RS60001	009 . 067 . 038 . 071
3 AS400	009 . 067 . 038 . 083
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX

PF: 3=Quit 4=Default 7=Back 8=Fwd

Figure 234. TCP/IP 3174 Defined Nicknames

Since users remember names better than numeric IP addresses, this panel allows you to define up to 16 host nicknames and their associated IP addresses.

- 1 Is the nickname of the DEC VAX.
- 2 Is the nickname of the RISC System/6000.
- 3 Is the nickname of the AS/400.

## 7.6 RS/6000 Definitions

Since the DEC VAX is in a different network than the 3174, we are you the RS/6000 as the static router between the two networks. This section discusses the definition that are in place at the RS/6000 to do static routing.

### 7.6.1 Router Definition on RISC System/6000

On the RISC System/6000, which is the router to the DEC VAX, we do the following:

- Login as the *root* user.
- At command prompt, type in the following and press Enter:

```
smit tcp/ip
```

You will get the screen shown in Figure 235.

#### SMIT TCP/IP




Figure 235. SMIT TCP/IP

Select **Further Configuration** and press Enter.

#### Further Configuration




Figure 236. Further Configuration

Select **Static routes** and press Enter.

### Static Routes




Figure 237. Static Routes

Select **Add a Static Route** and press Enter.

### Add Static Route




Figure 238. Add Static Route

Type the destination and gateway addresses in the Entry Fields.

In our example, we use address 9.67.32.64 as the destination address. Our default gateway address is 9.67.32.85.

## 7.6.2 Command Status

```
COMMAND STATUS
Command: OK          stdout: yes      stderr: no
Before command completion, additional instructions may appear below.

TOP
Routing tables
Destination Gateway      Flags Refcnt Use      Interface
Netmasks:
(root node)
(0)0
(0)0 ff00 0
(0)0 ffff ffc0 0
(root node)

Route Tree for Protocol Family 2:
(root node)
default      9.67.32.85      UG      0 711333 en0
2.2.4.0      9.67.38.91      UGH     0 0 tr0
2.2.4.1      9.67.38.91      UGH     0 0 tr0
2.2.4.2      9.67.38.91      UGH     0 0 tr0
9.67.32.64   9.67.32.85 1 U      4 21172 en0
9.67.32.192  9.67.38.67      UGH     0 0 tr0
9.67.32.242  9.67.38.67      UGH     0 279 tr0
9.67.38.64   9.67.38.71      U      28 168032 tr0
9.67.46.4    9.67.38.91      UGH     0 282 tr0
9.67.46.5    9.67.38.91      UGH     0 0 tr0
9.67.46.128  9.67.46.138     U      1 2189 tr1
9.67.46.192  9.67.46.195     U      1 30065 tr2
127          127.0.0.1       U      6 5050 lo0
191.10.10.64 191.10.10.81    U      1 277 xt0
(root node)

Route Tree for Protocol Family 6:
(root node)
(root node)

BOTTOM

F1=Help      F2=Refresh      F3=Cancel      F6=Command
F8=Image     F9=Shell        F10=Exit
```

Figure 239. Command Status

**1** Is the IP address of our router.

## 7.6.3 Router Definition on DEC VAX

On the DEC VAX host, we do the following:

- Login as a privileged user.
- At the command prompt, type in the following and press Enter:

```
multinet set/route/add=(dest=9.67.38.88,gate=9.67.32.85
```

**1**

**2**

**1** Is the IP address of our 3174-11R.

**2** Is the IP address of our RISC System/6000 router.

On the DEC VAX we are using the MultiNet\*\* V3.1 software.

For detailed information about the VAX MultiNet configuration, see:

- *MultiNet Users' Guide, VMS V5.0, MultiNet V3.1*
- *MultiNet System Administrators' Guide, VMS V5.0, MultiNet V3.1*

## 7.7 TELNET to VAX Host

If you specified an address at the TCP/IP station set, type in the number of the host to which you want to have a session.

```
Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME          STATUS   NUM NAME          STATUS
1 3270 HOST       Up
2 TELNET VT100    Up
3 TELNET VT220 7 BIT 1 Up

PF: 3=End      6=Terminal Disconnect    12=Host Disconnect

=====>To: 3
```

Figure 240. Selecting Connection to VAX Host

If you have not specified an address at the TCP/IP station set, select the emulation in the NUM Field of the Connection Menu and you get the 3174 TELNET prompt.

**1** VT220 7-BIT is the emulation selected.

### TELNET Prompt

```
3174 TELNET> open vax
Finding address of vax
Trying ....
Connected to 9.67.32.71

***** ITSC Open Network Management Lab *****

Username: System
Password:
```

Figure 241. TELNET Connection to VAX host

At the TELNET prompt, type in the command and destination.

In our example we entered the OPEN command and the nickname of the VAX host.

## VAX Host Login

```
3174 TELNET> open vax
Finding address of vax
Trying ....
Connected to 9.67.32.71

***** ITSC Open Network Management Lab *****

Username: System
Password:
Welcome to VAX/VMS version A5.5 on node ITSCV1
Last interactive login on Thursday, 10-Jun-1993 11:39
Last non-interactive login on Tuesday, 25-May-1993 08:50

You have 2 new Mail messages

International Technical Support Laboratory
Raleigh
ITCSV1

$
```

Figure 242. TELNET Cession to VAX host

The TELNET session to the VAX host is established.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...the network is a set of nodes connected by links.

...

...

...

...

...

...

...

...

...

...

...

...

...

...

---

## Chapter 8. 3174 Ethernet Considerations

This chapter provides the following general information about 3174 Establishment Controller Ethernet attachment:

- 3174 Configuration Support C, Release 4
- 3174 Ethernet adapter
- 3174 Ethernet customization

The new 3174 communications adapter that attaches the 3174 to CSMA/CD (Ethernet) LANs, in conjunction with Configuration Support-C Release 4, provides the following:

- Support for IEEE 802.3 frame formats and Ethernet V2 (DIX) frame formats
- Attachment via one of 3 types of connectors:
  1. 10base-2 BNC connector
  2. 10base-5 15-pin D-SUB connector
  3. 10base-T RJ-45 connector
- 802.2 LLC for both 802.3 and V2 frames

**Note:**

Ethernet support is also available in 3174 TCP/IP Enhancements RPQ 8Q1041 and Configuration Support-C Release 5. Any claims made in this section apply to all 3174 Ethernet Support.

---

### 8.1 3174 Configuration Support C, Release 4

LIC C4 allows the 3174 to participate in Ethernet configurations that are analogous to those token-ring configurations that the 3174 supports. That is, with the new x4R models, Ethernet may provide the upstream host attachment of the 3174, analogous to the x3R models. The 3174 may be an Ethernet gateway, connecting DSPUs on the Ethernet to an SDLC or channel-attached SNA host.

In both of these configurations, the following functions are available:

- TCP/IP TELNET client support (for locally attached ASCII or CUT displays only)
- APPN
- Peer Communications (for coax-to-coax communication on the same 3174)

**Note:** Coax-to-Ethernet bridging is not supported.

With Configuration Support-C Release 4, locally attached ASCII or CUT displays can also access a TCP/IP host through the Ethernet network without the 3174 configured as a gateway, or without SNA or APPN function being present.

APPN and TCP/IP can be used concurrently with either a LAN-attached DSPU controller or gateway. However, a LAN-attached DSPU controller and a gateway cannot be configured within the same 3174.



C4 supports the Ethernet adapter **in place of** a token-ring adapter. Just as with the token-ring network support, only one LAN adapter may be used.

### 8.1.1 Configurations

Ethernet attachment is possible with configurations supported by the following model designations: 11L, 11R, 12L, 12R, 14R, 21L, 21R, 22L, 22R, 24R, 61R, 62R, and 64R. The Ethernet Adapter is a base hardware feature with Models 14R, 24R, and 64R. The new models are essentially x3Rs with the token-ring card replaced by the Ethernet card.

### 8.1.2 Alternate Configurations

The following alternative configurations are possible with the new Ethernet adapter card and the C4 diskettes. The conversion of an x4R to a non-Ethernet model is not supported with the C4 diskettes.

Primary Configuration	Additional Adapter	Alternate Configuration
11L	Ethernet	14R
11R	Ethernet	14R
12R	Ethernet	14R
13R	Ethernet	14R
23R	Ethernet	24R
61R	Ethernet	64R
62R	Ethernet	64R

**Note:** Alternate configurations allow you to change the use of a given 3174 model; 11L can be used as a remote TP model by adding a type 1 card (PCA) and customizing as an 11R.

### 8.1.3 Storage Requirements

Ethernet applications should not require any more 3174 storage than the corresponding token-ring configuration. That is, an Ethernet gateway will have the same configuration as an equivalent token-ring gateway.

The size of LAN support code, which is included in the NCU or gateway numbers must be included separately and this amount is **150KB**.

TCP/IP storage calculation is done with the following scheme:

	With AEA Customized	Without AEA Customized
Basic TCP/IP TELNET	231KB	362KB
Per session	7KB	
TCP/IP data buffers	See 2.11.2, "TCP/IP Data Buffers" on page 15.	
Split Screen	If you expect to use split screen functions while accessing TELNET sessions, add 2KB for each non-EAB TELNET LT and 4KB for each EAB TELNET LT to your base MLT calculation.	
SNMP	50	

<i>Table 5 (Page 2 of 2). 3174 CS-C4 TCP/IP TELNET Storage Requirements</i>		
	<b>With AEA Customized</b>	<b>Without AEA Customized</b>
<b>No NCU, GW or APPN installed</b>	<b>150</b>	

## 8.1.4 Configuration Examples

An Ethernet adapter allows a 3174 to attach to an Ethernet for the following configurations:

- NCU/DSPU

Just like a 3174 token-ring model, a 3174 Ethernet model can communicate with up to 8 SNA hosts via the Ethernet, operating as a PU 2.0 in the network. This is called a Network Control Unit (NCU) or Downstream Physical Unit (DSPU). The terminals attached to the 3174 can access the 3270 applications provided by the hosts:




Figure 243. NCU Configuration

- Gateway

A 3174 SDLC or SNA channel model, with the new Ethernet adapter can operate as a gateway and connect 250 Ethernet DSPUs to the SNA host. 250 is the architectural limitation of the adapter and the 3174 microcode; however, a realistic limit for the LAN may be much lower.




Figure 244. Gateway Configuration

- APPN

Network node (NN) functions that are available in the C3 release over token-ring are now available over Ethernet. The only exception is that coax devices using peer communications cannot participate.




Figure 245. APPN Configuration

- Stand-alone (TCP/IP)

When an Ethernet adapter is in the 3174, the local terminals (CUT and ASCII) can reach TELNET servers via the Ethernet. So in the next picture, all of the "T's" can use the TCP/IP TELNET support to log on to the TCP/IP host. Notice that the 3174 attached to host C is not a gateway in this example. This is what is called the stand-alone option and the LAN is available strictly for TCP/IP communications. Prior to Configuration Support-C Release 4, the LAN adapter had to be customized for DSPU (NCU) or gateway support.







Figure 246. TCP/IP Configuration

All of the above configurations (NCU, Gateway, APPN and TCP/IP) can be used concurrently, except that gateway and NCU cannot coexist in a 3174.

### 8.1.5 MAC Layer

To support as many Ethernet environments as possible, The 3174 Ethernet adapter supports both 802.3 and DIX V2 frame formats. A 3174 customization question determines whether the 3174 provides 802.3, V2 or both. If both, the 3174 "discovers" which frame format to use for a given connection rather than requiring each connection to have a customized frame format. The discovery process is shown in 8.1.7, "Frame Format Discovery Process" on page 236.

Figure 247 on page 233 shows the frame formats. See also *ISO/IEC 8802-3 ANSI/IEEE Standard 802.3 and Ethernet: A Local Area Network Data Link Layer and Physical Layer Specification Version 2.0*.



- SFD - Start Frame Delimiter
- DA - Destination Address
- SA - Source Address
- DSAP - Destination Service Access Point
- PAD - Pad to minimum frame length
- PAD' - Pad of unknown use
- FCS - Frame Check Sequence

Figure 247. Frame Format

### **Bit Order of Ethernet Addresses**


Even though the architectural definition of Ethernet and token-ring hardware addresses appear the same, there is a subtle difference: Ethernet defines the Individual/Group address bit as the least significant bit of the byte, while token-ring defines it as the most significant bit. The order of bit transmission is also different: Ethernet transmits the Least Significant Bit first, while token-ring transmits the Most Significant Bit first. The addresses are stored in 3174 memory in the usual IBM manner, most significant bit on the left, and are also described that way in text: 400031740000 would be a locally administered, individual address. Therefore, the bits of each byte of the address are reversed before transmitting on the Ethernet. This does not present a problem for TCP/IP connections, since ARP handles the address resolution. For SNA over Ethernet, it is dependent upon how a particular connecting product is configured or implements addressing that determines how the addresses are customized at the 3174.

### **8.1.6 LLC Layer**

With 802.3 frames, C4 and the Ethernet adapter always use 802.2 Logical Link Control. The 802.2 LLC function is provided by microcode on the Ethernet adapter. C4 uses SAP AA for TCP/IP traffic, and SNA SAPs (multiples of 04) for NCU and gateway connections.

With V2 frames, SNA connections are provided by using the Ethernet type field 80D5, and using "LLC over Ethernet". As above, SNA SAPs (multiples of 04) provide the NCU and gateway connections. The LLC function is provided by microcode on Ethernet adapter. For TCP/IP, no LLC function is used; rather, TCP/IP traffic is identified by the Ethernet type fields 0800 (IP) and 0806 (ARP).

Here is a high-level view of 3174 processing of a frame from the Ethernet, showing the difference between SNA and TCP/IP. The diagram shows that TCP/IP is not supported using 802.2 LLC-over-Ethernet on V2.



Legend: ..... Ethernet Adapter process  
 .....  
 .....  
 .....  
 [ ] C4 process



## 8.1.7 Frame Format Discovery Process

The next sections describe how the 3174 determines the frame format (802.3 vs V2) to use, when the 3174 is customized to allow both frame formats.

### TCP/IP

For TCP/IP, the Address Resolution Protocol (ARP) is used to find the Ethernet address associated with an IP address. During ARP processing, the 3174 will also determine the frame format to use when sending datagrams to a particular IP address. The frame format associated with an IP address is only used for transmission; the 3174 accepts all received datagrams regardless of frame format.

The 3174 maintains an ARP table with entries for each remote host that it is talking to. Each entry contains the IP address of the host, the associated Ethernet physical address, the frame format to use, and some flags that show the state of the entry. When an entry is marked as complete, the physical address and frame format have been determined by ARP processing. This is done as follows:

1. If the 3174 wishes to send a datagram to IP address A.B, and no ARP table entry exists, the 3174 sends an ARP request to locate A.B. A table entry is created, but is not "complete". Since we are only discussing the "dynamic" case, the 3174 sends the ARP request in each format, sending the V2 format first. When a valid ARP response comes back, the 3174 marks the entry as complete, if it is not already complete, and assigns the frame format of the response to that entry, replacing the previous frame format. Any pending datagram is sent with that frame format. Therefore, if the remote host supports both frame formats, and answers both of the ARPs, the format of the second response would replace that of the first in the ARP entry.
2. When a remote TCP/IP host (X.Y) sends an ARP request containing the 3174's IP address, the 3174 creates an ARP table entry, if it does not already exist, and marks it complete. It also assigns the frame format of the request to the ARP entry and responds with that format. Therefore, if the requestor supports both frame formats, and sends ARPs in both formats, the 3174 would answer both requests; the format of the second request would be stored in the ARP entry.

Since TCP/IP operates in a "connectionless" environment, frames may be lost during ARP. If ARP processing does not complete, the datagram that caused the search is discarded. If this happens, the higher layers of the TCP/IP stack are responsible for recovering appropriately. For example, the 3174 PING function would not retry a frame if no response is received; rather, it would report the loss to the user. If a request to start a TELNET session is lost, the TCP layer times out and notifies the user, who can then attempt the session again.




## SNA Connections

For its SNA connections, the 3174 also goes through a discovery process, using LLC TEST and XID commands and responses. There is a key difference, however, between the LLC process and the TCP/IP ARP process: for the SNA connections, the 3174 must tell the adapter which format is to be used for a given end-to-end connection. There are 2 phases of the 3174 SNA LLC sessions:

1. **Link Establishment** -- this phase uses type 1 (connectionless) TEST and XID frames to determine the remote station's availability and readiness to communicate. This phase is managed by code in the 3174 which builds TEST and XID frames, and analyzes responses. (The only exception is when the adapter receives a TEST command; it automatically responds, without notifying the 3174.) Timeouts and retries are handled by the 3174 link establishment code.
2. **Connected** -- this phase uses type 2 (connection-oriented) frames to communicate with the remote station. This phase is managed by the LLC function in the adapter; it maintains sequence counts, responds to incoming frames and handles all retries and timeouts. Only data is passed to/from the 3174. When this phase is entered, the 3174 must tell the adapter which frame format to use for the connection; therefore, during the link establishment phase, the 3174 code will make the determination.

To dynamically discover the correct frame format, an FF (frame format) layer is added to the 3174 token-ring processing; this layer is inserted between the link establishment code and the transmit and receive interfaces to the adapter.



The FF layer works with 2 state variables: FFSENT and FFRCVD. A pair of these variables exists for each link station, and they have these possible values:

- 0 -- neither 802.3 nor V2
- 1 -- 802.3
- 2 -- V2
- 3 -- both 802.3 and V2

For example, if FFSENT is 1, then a frame has been sent in 802.3 format. And if FFRCVD is 3, then frames have been received from the remote station in both V2 and 802.3 formats. The FF layer can set these variables, but never clear them.

The link establishment layer clears the variables before starting link establishment, and between TEST and XID subphases.<sup>1</sup> It then uses the final values of these variables to determine what frame format to direct the adapter to use for the session. If FFRCVD is 2, use V2, otherwise use 802.3.

The FF layer has no knowledge of the type of frame (XID or TEST, command or response) it is handling. Its only job is to determine the frame format to use. For received data, the FF layer simply sets the FFRCVD variable according to the received frame. For transmitting data, Table 6 shows how the FF layer uses these variables. The underlying theme of this algorithm is that once the 3174 has received a frame in 802.3 format, it will transmit all future frames in that format.


*Table 6. Transmission Table for SNA Frame Format Discovery*

if FFRCVD =	... and FFSENT =	then send the frame with format =	and set FFSENT to
0	0	802.3	1
0	1	V2	3
0	2	n/a	
0	3	802.3	1
1	0	802.3	1
1	1	802.3	1
1	2	n/a	
1	3	802.3	1
2	0	V2	2
2	1	V2	3
2	2	V2	2
2	3	V2	3
3	0	802.3	1
3	1	802.3	1
3	2	802.3	3
3	3	802.3	3

<sup>1</sup> The TEST subphase does not necessarily give a true reading of the remote station's capabilities, since a TEST frame is sent to a remote SAP of 0, and not to a specific SAP. Also, the remote adapter may respond to a TEST frame of either frame format, while the higher layer SNA processing in the remote machine is not able to handle one or the other. Therefore, we use the FF layer processing to ensure that we try both formats during TEST subphase, but we cannot use the results of that phase to determine the real capabilities of the remote station.


The following flows show how this processing works with the 3174 link establishment code:

In this example, the remote device supports only V2 frames:




When XID negotiation is complete, FFRCVD = 2, so the 3174 opens the station to the adapter with frame format = V2.

In this example, the remote device supports only V2 frames, and is the initiator of the session:




When XID negotiation is complete, FFRCVD = 2, so the 3174 opens the station to the adapter with frame format = V2.

In this example, the remote device supports both types of frames, and is the initiator of the session. The first XID response from the local 3174 is lost in transmission and never received at the remote end:



When XID negotiation is complete, FFRCVD = 3, so the 3174 opens the station to the adapter with frame format = 802.3.

In this example, the remote device is an AS400 that supports only V2 frames (that is, it will transmit only V2, but will accept both as input):



When XID negotiation is complete, FFRCVD = 2, so the 3174 opens the station to the adapter with frame format = V2.



---

## 8.2 3174 Ethernet Adapter

The purpose of this adapter is to provide the 3174 with a high performance CSMA/CD and Ethernet Version 2.0 (DIX) communication facility via 16-bit MMIO transfers. This adapter performs the functions necessary to support one, and only one, CSMA/CD LAN when installed in the 3174.

Functional and operational highlights of the adapter are as follows:

- Interfaces the CSMA/CD logic to the 5005-Bus (MMIO) using 8 or 16-bit transfers.
- Provides physical access to a CSMA/CD and Ethernet Version 2.0 (DIX) LAN via one of the following physical media:
  - 10Base-2
  - 10Base-5
  - 10Base-T
- Supports universal addressing.
- Supports CDID (Card Detect and Identify facility).
- Provides the LLC (Logical Link Control) functions.

### 8.2.1 Capacity

This adapter provides physical and logical attachment to a single 10Mbps CSMA/CD or Ethernet Version 2.0 (DIX) LAN. LAN physical attachment is made via an RJ-45 connector (10base-T), coaxial connector (10base-2), or through an AUI and MAU attached to a 15-pin D-shell (10base-5). The MAU and AUI are not provided with the adapter.

### 8.2.2 Configurations

This adapter comes standard with no features which can be changed physically. There are no program pins or switches on the card that can be changed to alter any function of the adapter.

Cables for attaching the LAN to the adapter are not supplied with this adapter.

One BNC-T connector is supplied with the adapter. The T connector is supplied by IBM, and is included in the build group in USA.

Wrap plugs are supplied with the adapter, one for each physical interface. The wrap plugs are supplied by IBM, and are included in the build group in the USA.

### 8.2.3 CSMA/CD LAN Physical Interfaces

The CSMA/CD adapter provides three physical interfaces to the LAN. Only one of these physical interfaces may be used at a time.

The supported physical interfaces are:

- 10Base-2 which uses a BNC connector
- 10Base-5 which uses a 15-pin D-SUB connector
- 10Base-T which uses an RJ-45 connector

### 10Base-2 Connector

The adapter has a BNC male connector that provides attachment to the coaxial cable. The BNC connectors shall be of the 50 ohm constant impedance type.

### 10Base-5 Connector

Attachment between the adapter and Medium Attachment Unit (MAU) is done via an Attachment Unit Interface (AUI). The adapter has a female 15-pole connector.

For detailed information see *IEEE 802.3 CSMA/CD Specification*.

The pin assignments for the adapter are as follows:

CONTACT	CIRCUIT	USE
3	DO-A	Data Out circuit A
10	DO-B	Data Out circuit B
11	DO-S	Data Out circuit Shield
5	DI-A	Data IN circuit A
12	DI-B	Data IN circuit B
4	DO-S	Data In circuit Shield
7		Reserved
15		Reserved
8		Reserved
2	CI-A	Control In circuit A
9	CI-B	Control In circuit B
1	CI-S	Control In circuit Shield
6	VC	Voltage Common
13	VP	Voltage Plus
14	VS	Voltage Shield
Shell	PG	Protective Ground (Conductive Shell)

## 10Base-T Connector

Attachment between the adapter and the Telephone Twisted Pair (TTP) cable is made via an RJ-45 connector. The adapter has a female connector.

The pin assignments for the adapter are as follows:

CONTACT	CIRCUIT	USE
1	TD+	Transmit Data Positive for HI Signal
2	TD-	Transmit Data Negative for HI Signal
3	RD+	Receive Data Positive for HI Signal
4		Not Used for 10Base-T
5		Not Used for 10Base-T
6	RD-	Receive Data Negative for HI Signal
7		Reserved
8		Reserved

### 8.2.4 Hardware Group and Type Number

The hardware group (HG) number for the Ethernet adapter is 41. The type number for the Ethernet adapter is 9344. For more information about hardware group numbers and type numbers, refer to your base model maintenance information manual.

### 8.2.5 Field Replaceable Unit Identification (FRU ID)

The FRU ID numbers are used to build the hardware configuration table that is written on the disk used to IML the controller. The hardware configuration table is shown on the following screen. The hardware configuration table can be displayed using Online Test 2 or the offline test monitor.

```
_____ Hardware Configuration Table _____
HG TYPE LC DESCRIPTION      SC      HG TYPE LC DESCRIPTION      SC
01 9154 21 File Adpt          51 9344 12 Ethernet Adapter
01 0114 01 Diskette 1 - 2.4MB 51 9263 15 Tpl Concur. Com-EIA
02 0114 02 Diskette 2 - 2.4MB 87 9501 18 Processor
03 9132 03 Fixed Disk 1 - 20MB 87 9053 19 Storage-2MB
08 9501 18 Timer Disk 1 - 20MB 87 9053 20 Storage-2MB
09 9011 05 Ops Panel          87 9053 17 Storage-2MB
09 9520 05 Ops Panel Assembly
16 9210 11 Channel Adpt
16 9230 10 Channel Drvvr/Rcvr
26 9154 21 Terminal Adpt
26 9174 13 Terminal Adpt, 00-07
26 9174 16 Terminal Adpt, 08-15
26 9174 22 Terminal Adpt, 16-23
26 9172 23 Terminal Adpt, 24-31

Select test; press ENTER ==>> _
PF: 3=Quit 12=Test menu
```

Figure 249. Hardware Configuration Table

HG = Hardware Group  
TYPE = FRU Type number  
LC = FRU Location  
SC = Status code indicating an error on normal IML

**Note:** In the 3174, only those FRUs that are physically installed appear in this table.

For more information about FRU ID numbers, Online Test 2, and the offline test monitor, refer to the base model maintenance information manual.

## 8.2.6 Status Codes

For information about:

- Status codes that deal solely with Ethernet attachment, refer to *Supplemental Customer Information of Configuration Support C Release 4 - Ethernet Attachment, GA27-3994*.
- Status codes that apply to token-ring and Ethernet attachments, refer to *3174 Status Codes, GA27-3832*.
- Event log, refer to the base model maintenance information manual.

---

## 8.3 3174 Ethernet Customization

Since Configuration Support-C Release 4 function is essentially the same as token-ring, most of the existing customization panels that are available in Configuration Support-C Release 3, apply to Configuration Support-C Release 4, with a few changes. For 3174 TCP/IP Telnet Support there is no need for an SNA host over the primary link. 3174 TCP/IP Telnet Support under Configuration Support-C Release 4, does not require that customize the 3174 as an APPN node, gateway or DSPU. To do this, the LAN specific type question have been isolated to two new panels -- one for token-ring and one for Ethernet. The token-ring panel has been disabled in base Configuration Support-C Release 4 microcode. This isolates the common LAN information from the panels that pertain to specific functions that use the LAN.

The following pages show you the difference between Configuration Support-C Release 3 and Configuration Support-C Release 4 customization panels.

If you are planning microcode customization for the first time, read Part 1 and Chapter 5 of the *3174 Establishment Controller Planning Guide*. If you are experienced at planning microcode customization, you may want to skim those chapters.

---

## 8.4 Configuration Questions

As you follow the procedure in the *3174 Planning Guide* to answer the configuration questions and fill out the worksheets, use the information in this chapter for Ethernet-specific information. This information has been taken from the *3174 Ethernet Supplement*. For worksheets and configuration questions not included in this section, refer to the worksheets and configuration questions in the *3174 Planning Guide*.

## 8.4.1 Model/Attach Panel

Here is the C3 format of this panel:

```

_____ Model / Attach _____

098 _____
099 -
100 - XXX
101 - X

PF: 3=Quit 4=Default      8=Fwd
```

Figure 250. Model / Attach

Here is the C4 format of this panel:

```

_____ Model / Attach _____

Online Test Password  098 -
Product Assistance Data
099 - 3174 ETHERNET ADAPTER

3174 Model           100 - XXX

Host Attachment      101 - X  1-BSC           5-SNA Channel
                       2-SDLC           6-SDLC, X.21 Switched
                       3-X.25           7-Token-Ring
                       4-Non-SNA Channel 8-Ethernet
                       M-Multi-host

LAN adapter type     102 - X  0-none
                       1-Token Ring
                       2-Ethernet

NSO selection        103 - 0000000000000000

PF: 3=Quit 4=Default      8=Fwd
```

Figure 251. Model / Attach

Here are the changes to the Model/Attach panel:

### Question 100: 3174 Model

Response:

Enter the actual model number or the alternate configuration model number of the controller you plan to customize. See "Alternate Configurations", for the alternative configurations that can be used.

**Question 101: Host Attachment**

Response:

- |                       |                          |
|-----------------------|--------------------------|
| 1 = BSC               | 6 = SDLC (X.21 Switched) |
| 2 = SDLC              | 7 = Token-Ring Network   |
| 3 = X.25              | 8 = Ethernet             |
| 4 = Non-SNA (Channel) | M = Multi-Host Support   |
| 5 = SNA (Channel)     |                          |

This question allows a response of 8 to signify Ethernet host attachment.

**Question 102: LAN Adapter Type**

This is a new question.

Response:

- 0 = None
- 1 = Token-Ring
- 2 = Ethernet

This question determines the type of LAN, if any, to which the 3174 attaches.

Default is 0.

**Question 103: Non-Standard Operation Selection**

Response:

16-character hexadecimal string using hexadecimal digits 0-9 and A-F.

Default is 0000000000000000 which means feature is enabled. Each of the hexadecimal digits represents four NSO bits, and these bits control the NSO feature. If an NSO bit is 1, the NSO feature is enabled. If 0, it is disabled.

**Note:** Most installations require that the NSO bits be set to the default. Your customer support center will advise you if any of the NSO bits are applicable for your installation.

**Note:** New checks for these questions are:

1. For x3R, 7 and M are the only valid responses for Q101, and 1 (token-ring) is the only valid response for Q102.
2. For x4R, 8 and M are the only valid responses for Q101, and 2 (Ethernet) is the only valid response for Q102.

## 8.4.2 Ethernet Description Panel

This new panel is displayed if Q102 indicates that there is an Ethernet adapter in the box.

\_\_\_\_\_ Ethernet Description \_\_\_\_\_

Ethernet Address	084 - XXXX XXXX XXXX
Ethernet media type	086 - X    2-10base2 5-10base5 T-10baseT
Ethernet frame format	088 - X    1-IEEE 802.3 2-Ethernet V2 3-Both

PF: 3=Quit 4=Default                    8=Fwd

Figure 252. Ethernet Description Panel

The new questions are:

### Question 84: Ethernet Address

Response:

12-character hexadecimal address.

The address can be a locally administered address, a universal address, or all zeros.

A locally administered address is in the following format:

4000 XYYY YYYY

where XYYY and YYYY are the user-assigned portion of the locally administered address. The X should not be greater than hexadecimal 7.

A universal address is in the following format:

WWWW WWZZ ZZZZ

where WWWW WW = the ID of the adapter manufacturer (IBM's ID = 0800 5A).

ZZ ZZZZ = the unique address portion of this adapter's universal address.

**Warning:** When the product permits you to enter either type of address, the suggested choice is a locally administered address. If the universal address is used and the Ethernet adapter is replaced, the 3174 and the gateway will have to be recustomized with the new address.

An address of all zeros allows the registered universal address built into the adapter to be used.



**Note:** LAN address must be customized using a canonical form of hexadecimal representation. For information about bit order in addresses and a guideline for address conversion, see Appendix A, "Address Bit Order for Ethernet Addresses" on page 359.

**Question 86: Ethernet Media Type**

Response:

2 = 10base2

5 = 10base5

T = 10base-T

There is no default.

This shows the type of Ethernet media that the 3174 is attached to.

**Question 88: Ethernet Frame Format**

Response:

1 = IEEE 802.3

2 = Ethernet V2

3 = Both

The default is (3) both 802.3 and V2.

This question determines the frame format(s) that you want the 3174 to recognize.

### 8.4.3 Local Area Network Panel

This new panel is displayed if Q101 indicates that there is an Ethernet connection to the host.

```

_____ Local Area Network _____

106 - YYYY YYYY YYYY 04  107 - XXXX XXXX XXXX 04  108 - 00000000
110 - 0 0000              116 - 0_ __
121 - 01          123 - 0  125 - 00000000          126 - 00000000  127 - 0 0
132 - 0 0 0 0 0        136 - 0 0 0 0 0        137 - 0 0 0 0  138 - 0
141 - A                165 - 0                166 - A          168 - 0
173 - 00000000        175 - 000000          179 - 0 0 0
213 - 1                215 - 000000          220 - 0
382 - 0521             383 - 2
385 - IBMLAN          386 - 1

PF: 3=Quit  4=Default  7=Back  8=Fwd
```

Figure 253. Local Area Network Panel

Here are the changes to the LAN panel, which now appears if you specify an Ethernet host attachment.

#### New Title

"Token-Ring Network" becomes "Local Area Network"

#### Question 106: Address and SAP

Response:

12-character hexadecimal address and a 2-character hexadecimal service access point.

The address portion of this question is protected and filled in from the answer to Q84. Only the SAP can be changed.

#### Question 382: Transmit I-Frame Size

Response:

Four numeric characters.

The default is 0521.

For the Ethernet adapter, the valid response ranges from 265 to 1493 bytes.

**Note:** The response to this question depends on your gateway and LAN configuration.

## 8.4.4 Common Network Panel (Gateway 900)

Here is the C3 format of the common network panel:

```
Common Network

900 - XXXX XXXX XXXX 04   905 - 1           908 - IBMLAN
911 - 0                   912 - 00
920 - XXXXXXXX

PF: 3=Quit   4=Default   7=Back   8=Fwd   9=RtnH
```

Figure 254. Common Network

Here is the C4 format of this panel:

```
Common Network

900 - YYYY YYYY YYYY 04   905 - 0           908 - IBMLAN
                               912 - 00
920 - XXXXXXXX

PF: 3=Quit   4=Default   7=Back   8=Fwd   9=RtnH
```

Figure 255. Common Network

These are the changes to the common network panel:

### Question 900: Address and SAP

The address portion of this question is protected and filled in from the answer to Q84, depending on the LAN type. Only the SAP can be changed.

The default value for the SAP is 04.

### Question 905:

This question has no meaning for Ethernet, and the response should be ignored if Q102=2.

### Question 908: Link Subsystem Name for LAN

The default response is IBMLAN, which is automatically filled in during customization.

### Question 911: Ring Speed of the Gateway

This has been deleted and replaced by Q083 on the Token-Ring Description panel.

#### **8.4.5 Gateway 940 Panel**

The Gateway 940 panel has one change to support Ethernet adapters: The "T" column, which assigns a device type to each gateway DSPU, currently allows responses of 0 (workstation), 1 (3174) or 2 (8KB RU device). These responses are used to fill in an appropriate default frame size on the 941 panel. Since Ethernet has a max l-field size of 1493, the type 2 class of device is not applicable. So a response of 2 is not allowed for Ethernet.

#### **8.4.6 Gateway 941 Panel**

The 941 panel has only one change. The Transmit l-frame size column gives the maximum l-frame size to use when transmitting to the station. (Actually, this should really be "l-field" of the l-frames.) Responses of 3 (2KB), 4 (4KB) and 5 (8KB) are not applicable for Ethernet adapters, because with Ethernet, we can only send up to 1493 bytes of data. Therefore, response 3 for an Ethernet configuration will mean 1493 bytes, and responses larger than 3 are not allowed.

#### **8.4.7 TCP/IP Options Menu**

This menu appears in the AEA and TCP/IP utility. The last 2 questions on this panel are Routing Field Support and All Routes Broadcast; these 2 are not applicable for an Ethernet configuration, and the responses should be ignored.

#### **8.4.8 End-User Productivity Panel**

The option on this panel titled "Token-Ring T1 Timer" is changed to "LAN T1 Timer".

## 8.5 Online Test ("/TEST")

This section discusses online tests that involve Ethernet attachment.

Here are the options from the online test main panel:

```

      ____ 3174 Test Menu (XTEST) ____ (Page 1 of 2)
Test   Description
  0     Terminal check
  1     Display event logs and response time log
  2     Display configuration panels
  3     3270 device status information
  4     Reset logs and cable errors
  5     Display vital data
  6     Display Control Areas
  7     Color convergence
  8     Extended functions and program symbols
  9     LAN tests
 10     Port wrap tests
 11     Trace control
 12     Asynchronous emulation adapter tests
A,n    Alert to host ID n (n=1A-1H,2A-2D,3A-3D)
D,n,m  Dump device on port n, HG m (n=0-31, m=26-27)
 13     Enterprise Systems Connection (ESCON) Adapter tests
 14     3174 Operator Functions
 15     Display 3270 Host Status Summary
 16     Integrated Services Digital Network (ISDN) tests
 17     Advanced Peer-to-Peer Networking (APPN) tests

Select Test; press ENTER ==> _
PF: 3=Quit 8=Fwd
```

Figure 256. 3174 Test Menu

Configuration Support-C Release 4 causes changes to the following tests:

- /1 -- Logs display
- /2 -- Display customization
- /9 -- LAN tests
- /15 - Host status summary
- /17 - APPN tests

### 8.5.1 /1 -- Logs Display

The new hardware group number for Ethernet adapters is displayed here for log entries pertaining to the adapter. There are no code hits however, as the actual HG numbers are transparent to the LOG display code.

### 8.5.2 /2 -- Display Customization

The changes to the customization panels and sequences are reflected in this test.

### 8.5.3 /9 -- LAN Tests

Here is the current menu for /9, LAN tests:

```

_____ LAN Test Menu _____

Option  Description

  1      Monitor token-ring status
  2      Display token-ring adapter status summary
  3      Reset token-ring adapter status counters
  4      Display link status summary for all links
  5,*    Display link status summary
  6      Reset link status counters for all links
  7,*    Reset link status counters
  8      Display Gateway host status summary for all links
  8,h    Display host status summary for all host id h
  9,u    3174-Peer status (u=update)
  10,u   3174-Peer bridge profile (u=update)
  11     3174-Peer bridge status
  12,u   LAN Manager Profile (u=update)
  13     Re-open token-ring adapter
* = N or h or h,n where n=link address h=host ID

To go directly to other tests, enter: /Test,Option
Select option; press ENTER ==> _

PF: 3=Quit
```

Figure 257. LAN Test Menu

For C4, the panel is changed to "LAN" instead of "token-ring":

```

_____ LAN Test Menu _____

Option  Description

  1      Monitor LAN status
  2      Display LAN adapter status summary
  3      Reset LAN adapter status counters
  4      Display link status summary for all links
  5,*    Display link status summary
  6      Reset link status counters for all links
  7,*    Reset link status counters
  8      Display Gateway host status summary for all links
  8,h    Display host status summary for all host id h
  9,u    3174-Peer status (u=update)
  10,u   3174-Peer bridge profile (u=update)
  11     3174-Peer bridge status
  12,u   LAN Manager Profile (u=update)
  13     Re-open LAN adapter
* = N or h or h,n where n=link address h=host ID

To go directly to other tests, enter: /Test,Option
Select option; press ENTER ==> _

PF: 3=Quit
```

Figure 258. LAN Test Menu

For an Ethernet configuration, selections 10, 11 and 12 are not valid, since the bridge part of peer communications is not supported for Ethernet.

### /9, Option 1 -- Monitor LAN Status

This test puts the user in a monitor mode, where hardware interface information is displayed/updated until the user stops the operation. For token-ring, Signal Loss, Hard Error and Wire Fault are displayed. For Ethernet, these indicators are not appropriate; the following statuses are substituted<sup>2</sup>:

- No Carrier
- Collisions Detected

The C4 version of this panel is shown below.

In the panel, the first line will say which adapter type is installed. The message lines starting with "nnnn" are displayed for a 10base-2 or 10base-5 interface, while the "mmmm" lines are shown for a 10base-T interface. SSC numbers to replace xxxx, nnnn and mmmm are to be determined.

```
_____ Monitor LAN Status _____  
  
4739-Local LAN Adapter is Ethernet  
  
4697-Local LAN adapter closed  
  
4741-Media Error - Transceiver not working?  
      Cable fault?  
      Cable disconnected?  
      Hub not connected?  
4742-AUI 12-Volt Overcurrent Error - replace AUI cable  
  
4740-Adapter Check - service Ethernet adapter  
  
4694-The test has been active for 00000 minutes.  
  
4695-The test will terminate in n minutes.  
      Press PF9 to continue for another 10 minutes.  
  
To go directly to other tests, enter: /Test,Option  
Select option; press ENTER ==> _  
  
PF: 3=Quit 9=Cont 12=Test menu
```

Figure 259. Monitor LAN Status

<sup>2</sup> Based on IBM 3174 Ethernet Adapter RAS Characteristics, by D.L.Hough, October 8, 1992

### /9, Option 2 -- Display LAN Adapter Status Summary

This option displays error counters that are maintained by the LAN adapter. The following counters are defined for Ethernet:

```
_____ Ethernet Adapter Status Summary _____
Address - 400000000001 (Open ) Links: Customized - XXX Active - XXX

Counters      Overflow
Alignment errors      XXXXXXXX      0
FCS errors            XXXXXXXX      0
Single Collision Frames XXXXXXXX      0
Multiple Collision Frames XXXXXXXX      0
SQE Test Errors      XXXXXXXX      0
Late Collisions      XXXXXXXX      0
Internal MAC Transmit Errors XXXXXXXX      0
Carrier Sense Errors  XXXXXXXX      0
Excessive Deferrals  XXXXXXXX      0
Frames Too Long      XXXXXXXX      0
Frames Too Short     XXXXXXXX      0
Internal MAC Receive Errors XXXXXXXX      0

To go directly to other tests, enter: /Test,Option
Select option; press ENTER ==> _

PF: 3=Quit      12=Test menu
```

Figure 260. Ethernet Adapter Status Summary

### /9, Option 3 -- Reset LAN Adapter Status Counters

This test will reset all the counters displayed using option 2.



### **/9, Options 4, 5, 6, and 7**

These options allow the display and reset of link station information for LLC connections, including the LAN address of the remote device, and LLC states. Since these tests pertain to LLC level information, they will look the same for C4 as they do for token-ring, with one exception. The frame format being used for the station is added for Ethernet connections. The format of the new information is shown in the following panel.

```

                                Link Status Test

Link Address      XXXXXXXXXXXXXXXX
Primary/Secondary  XX/XX
Trans I-Frames    XXXXXX - 0
Rec I-Frames      XXXXXX - 0
Transmit Errors   XXXXXX - 0
Received Errors   XXXXXX - 0
T1 Expired        XXXXXX - 0
Com/Res Ind, Format  WW XX 802.3

To go directly to other tests, enter: /Test,Option
Select ===>
Informational message line
PF: 3=Quit                12=Test menu
```

Figure 261. Link Status Test

### **/9, Option 8**

Modify the panel to use "LAN" instead of "Token-Ring."

### **/9, Option 13 -- Re-open LAN adapter**

(This support was added for token-ring under DCR 287.54.) We will continue to support this function for Ethernet adapters. It allows a user (under password protection) to restart the LAN interface, often after some terminating error occurs. For most errors, the 3174 retries automatically, so this function is only used for catastrophic errors.

### 8.5.4 /15 - Host Status Summary

The only change here is that the new Ethernet attachment type is displayed as appropriate. Here is a sample panel:

3270 Host Status Summary					
ID	Host Descriptor	HG	Attach	Connection Status	
1A	3270 type IBM host	41	Ethernet	505-10	Down
1B	3270 type IBM Host	41	Ethernet	505-10	Down
1C	3270 type IBM host	41	Ethernet	500-01	Up
1D	3270 type IBM host	41	Ethernet	500-01	Up
1E	3270 type IBM host	41	Ethernet	500-01	Up
1F	3270 type IBM host	41	Ethernet	500-01	Up
1G	3270 type IBM host	41	Ethernet	500-01	Up
1H	3270 type IBM host	41	Ethernet	505-01	Down
2A	3270 type IBM host	51	X.25	504-03	Down
2B	3270 type IBM host	51	X.25	504-03	Down
2D	3270 type IBM host	51	X.25	500-01	Up
3A	3270 type IBM host	52	X.25	500-01	Up
3B	3270 type IBM host	52	X.25	500-01	Up
3C	3270 type IBM host	52	X.25	500-01	Up

To go directly to other tests, enter: /Test,Option  
Select test; press ENTER ==> \_

PF: 3=Quit 5=Refresh 8=Fwd 12=Test menu

Figure 262. 3270 Host Status Summary

### 8.5.5 /17 - APPN Tests

Only one panel in the APPN tests requires a change for C4. Option 3 from the APPN test menu requests Link Status. The panel is shown below. The Adapter type is "ENET" for an Ethernet adapter, the local and remote address information is displayed just like token-ring, and the hardware group (HG) is 41.

Link Status						
NETID	CPNAME	Type	Status	State	Route Addition Resistance	
nnnnnnnn	nnnnnnnn	nn	nnnnnn	nn	nnnn	
RCV Slam	SND Slam	Combined PU 2.0	Number APPN Sess	Congestion	Session Resource Depletion	
YES NO NA	YES NO NA	YES NO	nnn	YES NO	YES NO	
Adapter Type	Local Address	TG	HG	Remote Address	Product Information	
nnnn	aaaaaaaaaaa	nn	nn	aaaaaaaaaaaaaaaaaaaa	nnnnnnnnnnnnnnnnnn	

To go directly to other tests, enter: /Test,Option  
Select test; Press ENTER ==>

PF: 3=Quit 5=Refresh 12=Test menu

Figure 263. Link Status



---

## Chapter 9. 3174 TCP/IP Enhancements RPQ 8Q1041

With the availability of the 3174 TCP/IP Enhancements RPQ 8Q1041 in April 1994 new TCP/IP capabilities were added to the 3174.

The RPQ is based on Configuration Support-C Release 4, with token-ring and Ethernet adapter support enabled.

The RPQ 8Q1041 contains the following TCP/IP enhancements:

- TCP/IP TN3270

TN3270 support makes it possible for client terminals to use the TCP/IP protocol to access 3270 applications in full-screen mode. While products such as the RS/6000 do a good job of supporting ASCII terminals in full-screen mode over TCP/IP TELNET, using an ASCII terminal data stream, VM and MVS typically do not. Normal VM/MVS support for ASCII terminal communications is via line-by-line mode.

TN3270 makes it possible to use full-screen 3270 data stream communication between VM/MVS and a client terminal, instead of the line-by-line ASCII terminal data stream. This makes it feasible for client terminals to access mainframe 3270 applications via TCP/IP, as well as traditional SNA. Customers who prefer to avoid routing SNA over a TCP/IP network can now use the 3174's TN3270 support to build a pure TCP/IP network with IBM host access.

- LPD (Line Printer Daemon)

TCP/IP dependent host printer support allows TCP/IP hosts to send ASCII print output to the 3174 for printing on the attached printers. Thus, printers can be either coax-attached or AEA-attached.

Multiple 3174 attached printers provide print distribution for multiple TCP/IP hosts. A pool of printers can be defined as an LPD *queue*. The access to a queue can be open or restricted to a single host.

The addition of TCP/IP host printing services through the 3174 allows offloading of the TCP/IP printing from the existing TCP/IP printing facilities. Multiple 3174 attached TCP/IP hosts will further offload TCP/IP host printing facilities.

LPD provides only realtime printing. Spooling of the print jobs is not available. If the attached host does not support sending the control file before the data, MLT storage space is used to hold the data until the control file arrives.

- SNMP MIB-II

SNMP MIB-II support enhances the level of network management support offered by the 3174. SNMP now allows access to the network management parameters defined in RFC 1213 - Managing Information Base (MIB) for Network Management of TCP/IP-based Internets.

## 9.1 Configurations

You can use the TCP/IP Enhancements RPQ on all models of the 3174 that connect to a token-ring or an Ethernet, and has sufficient memory.

In Figure 264, all CUT-mode terminals can access both TCP/IP hosts and the traditional IBM 3270 host. Using the 3174 Multiple Logical Terminal (MLT) support, the users can **hot-key** among all these sessions. The printer that is attached to the 3174 can receive print jobs from both of the TCP/IP hosts. In this example, the channel-attached 3174 is also performing the 3174's SNA gateway function, enabling the LAN-attached 3174 to access the traditional 3270 host.

TCP/IP support in the 3174 can be used concurrently with all other 3174 functions, including APPN. For example, the two 3174s in Figure 264 might be acting as APPN network nodes at the same time that they are participating in TCP/IP.




Figure 264. 3174 TCP/IP in a LAN

---

## 9.2 Devices

The TCP/IP Enhancements RPQ allows all displays that attach to the controller, except DFTs, to operate in ASCII TELNET or TN3270 mode<sup>3</sup> :

- Coax displays operating in CUT mode (CUTs, or the CUT side of a DFT-E)

**ASCII TELNET** These are supported as DEC VT100, DEC VT200, IBM 3101 or Dasher D210 devices, using the ASCII emulation function of the 3174. (An AEA adapter is not required.)

The TCP/IP Enhancements RPQ supports these devices in 24X80 mode only; the 132-characters-per-line support for DEC VT220 made available in Configuration Support-C Release 2, is not available for the TCP/IP sessions.

**TN3270** Full 3270 function is provided for these devices, including color support, models 2, 3, 4 and 5 screen sizes and Write Structured Fields. Local functions, such as copy session-to-session and split screen, are fully enabled while in a TN3270 session.

- ASCII displays that are attached via an AEA

**ASCII TELNET** The ASCII data stream is passed to the terminal with no manipulation by the 3174

**TN3270** The 3174 performs 3270 emulation.

All printers that are directly attached to the 3174, either coax-attached or AEA-attached, can be used as LPD printers. HAP printers (printers attached to a port on a display) cannot be used for LPD. A printer that is being used for LPD cannot be used for 3270 host print sessions, nor can it be used for local copy printing.

---

## 9.3 Hosts

The 3174 connects the above devices to any host or device attached to the network, that can communicate over TCP/IP networks using ASCII TELNET, TN3270 or LPD protocols. This includes IBM and non-IBM hosts. In particular, TN3270 support allows full-function display access to TCP/IP in mainframe IBM hosts (TCP/IP for VM or MVS) and to CICS/6000\* workstations.

---

## 9.4 3174 Microcode and Packaging

The TCP/IP Enhancements RPQ is a Control/Utility/Extension disk RPQ. This means you receive a complete set of 3174 diskettes with each order of the RPQ. It is based on Configuration Support-C Release 4 (CS-C4) Licensed Internal Code, with token-ring support enabled. The TCP/IP Enhancements RPQ provides all CS-C4 functions. DSL device, AEA, Peer Communications and APPN feature microcode has already been merged onto the Extension disk for you.

The TCP/IP Enhancements RPQ may not be compatible with other CS-C4 RPQs. Please contact your IBM marketing representative if you have questions about RPQ compatibility.

---

<sup>3</sup> 9.6, "Protocols" on page 269 describes the difference between these 2 modes.

The RPQ diskettes should not be used in configurations without TCP/IP.

## 9.5 Storage Requirements

Table 9 shows the additional storage your 3174 must have for the TCP/IP Enhancements RPQ. These amounts should be added to the amounts that are needed by your 3174 without TCP/IP.

	With AEA customized	Without AEA customized
Basic TCP/IP TELNET	231KB	362KB
SNMP	50KB	
Per session (printer or display)	7KB	
TCP/IP data buffers	Q060 amount -- see following text	
LPD	You may wish to allocate additional MLT space for temporary storage of LPD data files.	
Split Screen and/or TN3270	For each LT that is involved in split screen operations while accessing TELNET sessions, or is accessing a TN3270 destination, add 2KB to your base MLT calculation if the associated device does not have an EAB and add 4KB if the device does have an EAB.	

### 9.5.1 Sessions

When you customize for the TCP/IP Enhancements RPQ, you must select the number of concurrent TELNET sessions you want to allow, and the number of printer sessions. These are given by your responses to Questions 58 and 59 on the TCP/IP Options Menu. Each session requires the amount of storage shown in the table. For display sessions, the 3174 creates a pool of session resources, available to terminal users on a first-come, first-served basis. They are not assigned to any particular 3174 terminal port or LT. For printers, sessions are allocated as TCP connection requests are received from the remote host, and freed when the connection is ended.

### 9.5.2 Data Buffers

When you customize for the TCP/IP Enhancements RPQ, storage is reserved for 40 TCP/IP data buffers. Using customization Question 60 on the TCP/IP Options Menu, you can include an additional amount of storage for TCP/IP data buffers. This additional amount should be included in your storage calculations.

A 3174 TCP/IP data buffer has roughly 100 bytes available for data. To determine how much storage your controller will need for these buffers, you should consider the types of host applications that your users will be accessing. For example, host applications that send only a line at a time to the user's screen will use only 1 buffer at a time for a message. However, applications that send a full screen of information with screen formatting control included may send much larger messages, requiring many 3174 buffers at a time. Your decision will also be affected by the number of concurrent sessions you select.

When you run out of buffers:

- The 3174 discards data from the TCP/IP network, causing retransmissions and affecting response times.



- Requests to establish host connections will be rejected, and the users must retry.

---

## 9.6 Protocols

The 3174 supports the TCP/IP family of protocols over a LAN (token-ring or Ethernet). The next figure shows the protocol stack in the 3174, including the new TN3270 and LPD applications provided by the TCP/IP Enhancements RPQ. The rest of this chapter describes how the 3174 supports SNMP, TN3270, ASCII TELNET and LPD with the TCP/IP Enhancements RPQ.




Figure 265. TCP/IP Protocols Provided by the 3174

---

## 9.7 TN3270

The 3174 TCP/IP TELNET function was originally shipped in August, 1992 as an RPQ on the C2 base, and has been incorporated into the base code for C3. This initial support provides connectivity to TCP/IP TELNET servers and hosts that communicate with an ASCII data stream. For the 3270 CUT terminals that are attached to the 3174, the controller's ASCII emulation function is used to convert between the ASCII data stream and the 3270 device control stream. For ASCII terminals, the controller's ASCII pass-through function is used, allowing the device and the server to exchange ASCII data with no manipulation by the 3174. For many TCP/IP hosts and servers, this ASCII support is required and sufficient.

IBM's TCP/IP function in VM and MVS does not support ASCII devices in full-screen mode; they can be used only in a line-by-line mode, which isn't exactly state-of-the-art! TCP/IP in VM and MVS use the TN3270 protocol to support terminals in full-screen mode. TN3270 is a TELNET session where a 3270 data stream is exchanged instead of an ASCII terminal data stream. This support in the mainframe allows client terminals to use TCP/IP to access existing 3270 applications in the mainframe.

The initial TCP/IP support in the 3174 is for token-ring access only. Because of this, the requirement to do TN3270 was not very strong; 3270 terminal users had an existing path to get to the 3270 mainframe applications, using the SNA support in the 3174. With the addition of Ethernet connectivity, however, there may be no 3270 path to the host, and TCP/IP may be the only way. Therefore, it is more important to have TN3270 in the 3174.

Also, a performance improvement is achieved with TN3270, since 3270 protocol is a block-mode exchange, rather than the typical character-mode used with ASCII data streams. Echoing of keystrokes is done by the 3174; when an Enter or function key is pressed, changes to the screen are sent to the host in blocks.

CICS/6000 is now available, allowing CICS applications to execute in an RS/6000. These applications typically support a 3270 data stream; they can be accessed via an ASCII data stream through TCP/IP TELNET, but this involves a conversion in the workstation from 3270 to the ASCII data stream. That is, they do the reverse of the 3174's ASCII emulation function. So with the existing 3174 TELNET support, a 3270 terminal's data stream is converted in the 3174 to ASCII, and then back to the 3270 in the RS/6000. By adding TN3270 in the 3174, we will eliminate the two conversions, and allow direct transfer of a 3270 data stream to a CICS/6000 platform.

### 9.7.1 Function

From the perspective of the TELNET protocols, TN3270 support is most easily understood as another TELNET terminal type. In a typical TELNET session establishment sequence, the host or server initiates terminal type negotiation (see RFC 930), by asking the client for its terminal type. If the server does not support that type of terminal, the server asks again. The client can answer with another type, if it can provide more than one type, or it can answer with the same type. Once a client responds twice with the same type, that means it can't do any others.

The 3174 will handle this by adding a new host data stream type in the station sets for TCP/IP hosts. When a host with the new **3270** type is selected as the destination from a 3270 terminal, the 3174 will send the 3270 device type during terminal-type negotiation.

The 3174 doesn't know the exact device type that is attached to a coax port. However, the 3174 does learn certain attributes of the device, that can be mapped into the device types that TCP/IP for VM and MVS understands.

The 3174 maps color devices to **3279** and monochrome to **3278**. The screen size determines the model attribute (2, 3, 4 or 5). And the presence of an EAB is represented by **E** at the end of the device name. So, the 3174 will return one of the following types for coax terminals:

- IBM-3278-2
- IBM-3278-3
- IBM-3278-4
- IBM-3278-5
- IBM-3278-2-E
- IBM-3278-3-E
- IBM-3278-4-E
- IBM-3278-5-E
- IBM-3279-2
- IBM-3279-3
- IBM-3279-2-E
- IBM-3279-3-E

For ASCII terminals, the station set type determines the model size that is emulated, and also whether color is supported. The TN3270 types that are returned for ASCII terminals are:

- IBM-3278-4
  - DEC VT100
- IBM-3278-5
  - IBM 3151 Model 31,41,51,61
  - IBM 3162
  - IBM-3279-2
    - FTTERM
    - IBM 3164
    - Tektronix 4205
  - IBM-3278-2
    - All others

If the host rejects the 3270 device type by asking for the terminal type a second time, the TCP session ends.

While in an active TN3270 session, the user cannot enter the 3174's local mode. The main uses of local mode during an active session are for manipulating ASCII terminal characteristics, so it is not needed during 3270 mode. Between sessions, the 3174's local mode is the existing line-by-line interface: 3270 terminals will emulate VT100; ASCII terminals are in ASCII pass-through mode.

Since CICS/6000 TN3270 must be reached via a TCP port other than the **well-known** TELNET port, a customization option has been added to the station set definition. This new field allows the customer to specify which TCP port to use when doing an automatic host connection. (Automatic host connection is attempted if the IP address field in the station set is non-zero.) When not using automatic connections, the 3174 already allows the terminal user to select a TCP port number.

While in a TN3270 session, all the keyboard functions used during other 3270 sessions will work. That is, the restrictions that currently apply to TELNET sessions are removed:

- Copy session-to-session can be done with the TN3270 session as either the source or destination session
- Split screen functions can be done, even on ASCII TN3270 sessions

## 9.7.2 ASCII TELNET vs TN3270

With the RPQ 8Q1041, the 3174 now provides two ways to access TCP/IP TELNET servers: ASCII TELNET and TN3270. When ASCII TELNET is used, an ASCII terminal data stream is carried on the TCP session; the server exchanges ASCII data with the 3174, usually a character at a time. When the 3174 device is a coax terminal, the 3174 performs ASCII emulation, and converts the ASCII terminal data stream so that it can be displayed on a 3270 coax device. When the 3174 device is an ASCII terminal, the 3174 merely passes the data stream on to the terminal, as it is already in ASCII characters.

When TN3270 is used, an EBCDIC 3270 data stream is carried in the TCP session; the server and the 3174 exchange messages, or blocks of data, rather than characters. When the 3174 device is a coax-attached terminal, the 3174 processes the data stream for display on the device. When the 3174 device is an ASCII terminal, the 3174 performs 3270 emulation, and converts the 3270 terminal data stream to the appropriate ASCII terminal data stream.

Figure 266 illustrates the difference between these two types of connections.




Figure 266. 3174 Processing for ASCII TELNET and TN3270

## 9.8 Line Printer Daemon (LPD)

The TCP/IP Enhancements RPQ expands the TCP/IP functions of the 3174 by allowing TCP/IP hosts to send print output to 3174 printers. With an LPD (Line Printer Daemon) server, the 3174 can accept print jobs for either coax or ASCII printers that are attached to the 3174. This function is **not** provided for printers that are attached to displays (HAPs).

The 3174 is not a spooling device; jobs are printed as they are received.

The 3174 assumes that the print data is ASCII. When the output printer is a 3270 printer, the ASCII emulation function of the 3174 is used; when the output printer is an ASCII printer (AEA-attached), the data is passed without conversion to the ASCII device. Figure 267 illustrates this processing.




Figure 267. 3174 LPD Support

When providing ASCII emulation for 3270 printers, the 3174 supports a basic set of ASCII control codes shown in Table 10. No other ASCII control codes or escape sequences are recognized by the 3174.

<i>Table 10. ASCII Control Codes for 3270 Printers</i>		
<b>Character</b>	<b>Hex Code</b>	<b>Action Taken</b>
BEL	X'07'	Sound audible alarm
CR	X'0D'	Carriage return
FF	X'0C'	Form feed
HT	X'09'	Tab --skip to next multiple of 8
LF	X'0A'	New line
US	X'1F'	Carriage return, line feed
VT	X'0B'	New line
XON	X'11'	Resume sending
XOFF	X'13'	Stop sending


### 9.8.1 Printer Pooling

You can configure the 3174 with any or all of these variations:

1. A set of similar<sup>4</sup> printers can be grouped into a pool, and any remote TCP/IP host can send jobs to that printer pool.
2. A set of similar printers can be grouped into a pool, and only one specific TCP/IP host can send jobs to that printer pool.
3. A set of similar printers can be grouped into a pool, and any TCP/IP host in a specified subnet can send jobs to that printer pool.
4. An individual printer can receive jobs from any remote TCP/IP host.
5. An individual printer can receive jobs from only one specific remote TCP/IP host.
6. An individual printer can receive jobs from any TCP/IP host in a specified subnet.

To provide these variations, the print queue name used by LPD to select a printer is mapped to the 3174 station set name. If the station set is assigned to a port set with more than one printer, an incoming job is sent to any available printer in that group. If the printer station set has an IP address specified that has 0 in the host portion of the address, jobs from any host on that subnet are accepted. If the printer station set has any other kind of IP address specified, only jobs from that IP address are accepted for that queue.

<sup>4</sup> **Similar** printers are those with the same connect type: AEA vs coax, direct vs. switched.



4172/417206

Figure 268. Printer Queue Validation Flow



## 9.8.2 LPD Data Stream

LPD function is defined in RFC 1179. The 3174 implements this RFC, but supports only a subset of the functions.

To use LPD, a TCP/IP client establishes a TCP connection with the 3174's LPD server. It then sends LPD commands as shown in Table 11 on page 277. A typical flow has two commands: receive control file, and receive data file. A control file contains another set of commands, shown in Table 12 on page 278. These commands determine how the data file is to be interpreted and printed.

Since the 3174 is not providing a spooling function, jobs are printed as they are received from the client. The 3174 listens on TCP port 515 for connection requests. Each connection can send data for only one print queue, but can send more than one pair of control and data files for that queue. The 3174 can accept either the control file or the data file first, but processing differs according to the command sequence that the host sends:

**Case 1, Receive Data File, Receive Control File:** When the data file comes first, the 3174 must buffer the entire file before printing. This is because the control file must be processed to determine how to print the data. The 3174 buffers the file in storage that is allocated from the MLT pool (Question 116).

**Note:**

If there is not enough MLT storage available to buffer the entire print job, the print request will be rejected.

**Case 2, Receive Control File First, Receive Data File:** This is the preferred sequence, because no extra buffer space is required to hold any files. The data file is printed as it is received.

**Case 3, Receive Control File, Receive Data File:** Same as case 2.

**Case 4, Receive Control File First, Receive Data File with Unspecified Length:** Same as case 2.

<i>Table 11. LPD Commands</i>			
<b>Command.</b>	<b>Explanation</b>	<b>3174 Support</b>	<b>Note</b>
01	Print any waiting jobs	No	3174 prints jobs as they arrive. We never have any waiting jobs.
02	Receive a printer job	Yes	
02 01	subcommand, abort job	Yes	
02 02	subcommand, receive control file	Yes	
02 03	subcommand, receive data file	Yes	
02 04	subcommand, receive control file first	Yes	
02 05	subcommand, receive data file with unspecified length	Yes	Supported only with the Control File First subcommand.
03	Send Queue State (short)	No	3174 prints jobs as they arrive, and does not really ever have a queue of jobs.
04	Send Queue State (long)	No	3174 prints jobs as they arrive, and does not really ever have a queue of jobs.
05	Remove Jobs	No	3174 prints jobs as they arrive, and does not really ever have a queue of jobs.

<b>Table 12. LPD Control File Commands</b>			
<b>Command</b>	<b>Explanation</b>	<b>3174 Support</b>	<b>Note</b>
C	Class for banner page	Yes	
H	Host name	Ignore	
I	Indent printing	Reject	
J	Job name for banner page	Yes	
L	Print banner page	Yes	
M	Mail when printed	Ignore	3174 has no way to send mail
N	Name of source file	Ignore	Only used for queries or when 'p' support is used
P	User Identification	Ignore	
S	Symbolic link data	Ignore	N/A (Unix)
T	Title for print	Ignore	Only used when 'p' support is used
U	Unlink data file	Ignore	
W	Width of output	Ignore	
1	troff R font	Ignore	No special fonts are supported
2	troff I font	Ignore	No special fonts are supported
3	troff B font	Ignore	No special fonts are supported
4	troff S font	Ignore	No special fonts are supported
c	plot CIF file	Reject	Plotting is not supported
d	print DVI file	Reject	TeX output not supported
f	print formatted file	Yes	Discard all control characters other than HT, CR, FF, LF and BS. Convert LF to CRLF. (see note below) The 3174 support of the f command is similar to OS/2: LF is converted to CRLF, since most clients do the reverse conversion in order to emulate Unix file structure.
g	plot file	Reject	plotting is not supported
l	print file leaving control characters	Yes	Transparent data
n	print ditroff output file	reject	ditroff not supported
o	print postscript output file	reject	postscript not supported
p	print file with 'pr' format	ignore	
r	print file with FORTRAN carriage control	reject	
t	print troff output file	reject	
v	print raster file	reject	(SUN)

### 9.8.3 Banner Page

If the control file contains an **L** command to request a banner page, the 3174 sends this data to the printer, followed by a formfeed (FF)<sup>5</sup>:

```
(blank line)
(blank line)
*****
*****
*****
***      Output from IBM 3174, printer_station_set_name      ***
***                                                         ***
***                                                         ***
***                                                         ***
***      first_50_bytes_of_the_job_name_XXXXXXXXXXXXXXXXXX  ***
***      first_50_bytes_of_the_job_name_XXXXXXXXXXXXXXXXXX  ***
***      first_50_bytes_of_the_job_name_XXXXXXXXXXXXXXXXXX  ***
***                                                         ***
***                                                         ***
***                                                         ***
***                                                         ***
***                                                         ***
***                                                         ***
***      31_byte_class_XXXXXXXXXXXXXXXXXXXX                 ***
***      31_byte_class_XXXXXXXXXXXXXXXXXXXX                 ***
***      31_byte_class_XXXXXXXXXXXXXXXXXXXX                 ***
***                                                         ***
***                                                         ***
***                                                         ***
*****
*****
*****
```

**first\_50\_bytes\_of\_the\_jobname** is gotten from a **J** command in the control file.  
**31\_byte\_class** is gotten from a **C** command in the control file. If no **C** command is used, the 3174's TCP/IP host name is inserted here.

### 9.8.4 Internal Queuing

If the 3174 receives more print requests for a given queue than there are printers in that queue, the extra requests are queued internally until a printer becomes available. The host may break the TCP connection during this time, if it wants to.

If the 3174 receives more LPD connections than there are TCP/IP printer sessions allowed. The extra connections are queued internally until a session becomes available. The host may break the TCP connection during this time, if it wants to.

<sup>5</sup> The 3174 assumes any previous print activity left the printer at the top of form

## 9.8.5 Translation Support

When printing to a 3270 printer, ASCII emulation requires translation of the characters from ASCII to internal code points. The type of translation is specified by Question 784 for each printer station set, and should match the character set of the sending host:

- IBM Code Page 850
- ISO 8859
- DEC NRC
- DEC MCS

**Note:** The printer queue name that you use at the sending host must be the same as the 3174 station set name. This name is case sensitive; since the 3174 station set name is always uppercase, you must use uppercase at the host when defining and selecting the queue.

---

## 9.9 MIB-II

The original 3174 TCP/IP SNMP support provided only MIB-I variables. The MIB-II support in the TCP/IP enhancements RPQ Q81041 expands the 3174's SNMP agent function to include MIB-II variables. The 3174 now supports the standard MIB defined by RFC 1231, the token-ring MIB from RFC 1231 and the Ethernet MIB from RFC 1398.

The 3174 agent responds to request for MIB variable information from SNMP clients elsewhere in the network. NetView/6000, for example, can operate as the SNMP client. The 3174 supports GET and GET\_NEXT requests for the variables listed in Appendix B, "SNMP Variables" on page 363. The 3174 does not honor SET requests, nor does the 3174 generate TRAPs. The 3174 uses the community name *public*.

SNMP support requires additional storage. You may customize the 3174 to run with or without SNMP, as shown in Figure 269 on page 291.

There are some variables that the 3174 cannot support; we return NOSUCHNAME indications to the remote SNMP client when these variables are requested. For example, some Ethernet counters are not available from our adapter.

The rest of this section describes the new MIB-II variables. Appendix B, "SNMP Variables" on page 363 shows all the variables supported by the 3174 in ASN.1 numeric order.

- The System group (MIB-II 1)
  - sysContact (system 4) - DisplayString  
The textual identification of the contact person for this managed node, together with information on how to contact this person. For 3174, this is the response to Q99.
  - sysName (system 5) - DisplayString  
An administratively assigned name for this managed node. By convention, this is the node's fully-qualified domain name. For 3174, this is created from the information on the Domain Name Service customization panel.

- sysLocation (system 6) - DisplayString
 

The physical location of this node (for example, telephone closet, third floor). For the 3174, this is the information entered via /5,2 (Update VPD).
- sysServices (system 7) - Integer
 

A value which indicates the set of services that this entity primarily offers. For the 3174, it is **8**
- The Interfaces group (MIB-II 2)
  - ifSpecific (ifEntry 22) - ObjectID
 

A reference to MIB definitions specific to the particular media being used to realize the interface. This is 1.3.6.1.2.1.10.9 when our interface is token-ring, and 1.3.6.1.2.1.10.7 when our interface is Ethernet.

Traffic counters in the interfaces group reflect only IP/ICMP traffic. They do not include traffic that is generated by other 3174 applications (SNA, APPN) that are also using the interface.
- The Address Translation group (MIB-II 3)
 

This group has been **deprecated** from MIB-I to MIB-II. This means that, although it is still included in MIB-II, it very likely will be removed in future MIB lists (for example, MIB-III). Address Translation tables are being distributed to the various network protocol groups.
- The IP group (MIB-II 4)
  - ipAdEntReasmMaxSize (ipAddrEntry 5) - Integer
 

The size of the largest IP datagram which this entity can reassemble from incoming IP fragmented datagrams received on this interface.

65535 for the 3174.
  - ipRouteMask (ipRouteEntry 11) - IP Address
 

The mask to be logically ANDed with the destination address before being compared to the value in the ipRouteDest field.

3174 provides this as follows:

    - Default route, mask - 0.0.0.0
    - Route entry from host route table, mask = 255.255.255.255
    - Route entry from network route table, if destination network is different from 3174's network: mask corresponds to type of network (255.0.0.0, 255.255.0.0, 255.255.255.0)
    - Route entry from network route table, if destination network is the same as 3174's, mask = 3174's subnet mask
  - ipRouteMetric5 (ipRouteEntry 12) - Integer
 

An alternate routing metric for this route. For 3174, this is **-1**
  - ipRouteInfo (ipRouteEntry 13) - ObjectID
 

A reference to MIB definitions specific to the particular routing protocol which is responsible for this route, as determined by the value specified in the route's ipRouteProto value. For 3174, this is 0.0.
  - ipNetToMediaTable (ip 22) - Aggregate

The IP Address Translation table used for mapping from IP addresses to physical addresses.

- ipNetToMediaEntry (ipNetToMediaTable 1) - Table

Each entry contains one IP Address to PhysAddress equivalence.

- ipNetToMediaIfIndex (ipNetToMediaEntry 1) - Integer  
The interface number on which this entry's equivalence is effective.
- ipNetToMediaPhysAddress (ipNetToMediaEntry 2) - PhysAddress  
The media-dependent **physical** address.
- ipNetToMediaNetAddress (ipNetToMediaEntry 3) - IP Address  
The IP address corresponding to the media-dependent **physical** address.
- ipNetToMediaType (ipNetToMediaEntry 4) - Integer  
The type of mapping. For 3174, this is **3** which is dynamic, since all the 3174's ARP entries are dynamic.

- ipRoutingDiscards (ip 23) - Counter

The number of routing entries which were chosen to be discarded even though they are valid.

- The ICMP group (MIB-II 5)

This group has no changes for MIB-II.

- The TCP group (MIB-II 6)

- tcpInErrs (tcp 14) - Counter

The total number of segments received in error (for example, bad TCP checksums).

- tcpOutRsts (tcp 15) - Counter

The number of TCP segments sent containing the RST flag.

- The UDP group (MIB-II 7)

- udpTable (udp 5) - Aggregate

A table containing UDP listener information.

- udpEntry (udpTable 1) - Table

Information about a particular current UDP listener.

- udpLocalAddress (udpEntry 1) - IP Address  
The local IP Address for this UDP listener.
- udpLocalPort (udpEntry 2) - Integer  
The local port number for this UDP listener.

- The EGP group (MIB-II 8)

This group is not implemented by the 3174.

- The CMOT group (MIB-II 9)

This group is not implemented by the 3174.

- The Transmission group (MIB-II 10)

When attached to Ethernet (either 802.3 or V2), this group contains the **dot3** variables that are defined in RFC 1398. When attached to a token-ring, this group contains the **dot5** variables that are defined in RFC 1231.

#### **dot3 (transmission 7)**

- dot3StatsTable ( dot3 2 ) - Aggregate

Statistics for a collection of Ethernet-like interfaces attached to a particular system.

- dot3StatsEntry ( dot3StatsTable 1 ) - Table

Statistics for a particular interface to an Ethernet-like medium.

- dot3StatsIndex ( dot3StatsEntry 1 ) - Integer

An index value that uniquely identifies an interface to an Ethernet-like medium. The interface identified by a particular value of this index is the same interface as identified by the same value of ifIndex. Right now, this is always 1 for the 3174, as we have only one interface to the TCP/IP network.

- dot3StatsAlignmentErrors ( dot3StatsEntry 2 ) - Counter

A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check.

This count is provided by the 3174 Ethernet adapter.

- dot3StatsFCSErrors ( dot3StatsEntry 3 ) - Counter

A count of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check.

This count is provided by the 3174 Ethernet adapter.

- dot3StatsSingleCollisionFrames ( dot3StatsEntry 4 ) - Counter

A count of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision.

This count is provided by the 3174 Ethernet adapter.

- dot3StatsMultipleCollisionFrames ( dot3StatsEntry 5 ) - Counter

A count of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.

This count is provided by the 3174 Ethernet adapter.

- dot3StatsSQETestErrors ( dot3StatsEntry 6 ) - Counter

A count of times that the SQE TEST ERROR message is generated by the PLS sublayer for a particular interface.

- dot3StatsDeferredTransmissions ( dot3StatsEntry 7 ) - Counter

A count of frames for which the first transmission attempt on a particular interface is delayed because the medium is busy. The count represented by an instance of this object does not include frames involved in collisions.

This count is not provided by the 3174 Ethernet adapter; therefore, the 3174 does not support this variable.

- dot3StatsLateCollisions ( dot3StatsEntry 8 ) - Counter



The number of times that a collision is detected on a particular interface later than 512 bit-times into the transmission of a packet.

This count is provided by the 3174 Ethernet adapter.

- dot3StatsExcessiveCollisions ( dot3StatsEntry 9 ) - Counter

A count of frames for which transmission on a particular interface fails due to excessive collisions.

This count is provided by the 3174 Ethernet adapter.

- dot3StatsInternalMacTransmitErrors ( dot3StatsEntry 10 ) - Counter

A count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error.

This count is provided by the 3174 Ethernet adapter.

- dot3StatsCarrierSenseErrors ( dot3StatsEntry 11 ) - Counter

The number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame on a particular interface.

- dot3StatsFrameTooLongs ( dot3StatsEntry 13 ) - Counter

A count of frames received on a particular interface that exceed the maximum permitted frame size.

This count is provided by the 3174 Ethernet adapter.

- dot3StatsInternalMacReceiveErrors ( dot3StatsEntry 16 ) - Counter

A count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error.

This count is provided by the 3174 Ethernet adapter.

- dot3CollTable ( dot3 5 ) - Aggregate

A collection of collision histograms for a particular set of interfaces.

This is not supported by the 3174; it is an optional variable, and the information it provides is not available from our adapter.

**dot5 (transmission 9)**

- dot5Table ( dot5 1 ) - Sequence of Dot5Entry

This table contains token-ring interface parameters and state variables, with one entry per 802.5 interface. There is only one entry for the 3174, as we have only one 802.5 interface.

- dot5Entry ( dot5Table 1 ) - Table

A list of token-ring status and parameter values for an 802.5 interface.

- dot5IfIndex ( dot5Entry 1 ) - Integer

The value of this object identifies the 802.5 interface for which this entry contains management information. For the 3174 today, this is always 1.

- dot5Commands ( dot5Entry 2 ) - Integer

This object is used with SNMP Set commands to initiate a change to the interface state (for example, open onto the ring). Currently 3174 does not support SETs at all, so the command values are not important. When read, this object always has a value of no-op(1).

- dot5RingStatus ( dot5Entry 3 ) - Integer

The current interface status which can be used to diagnose fluctuating problems that can occur on token-rings, after a station has successfully been added to the ring.

Before an open is completed, this object has the value for the **no status** condition. The dot5RingState and dot5RingOpenStatus objects provide for debugging problems when the station cannot even enter the ring.

The object's value is a sum of values, one for each currently applicable condition. The following values are defined for various conditions:

- 0 = No Problems detected
- 32 = Ring Recovery
- 64 = Single Station
- 256 = Remove Received
- 512 = Reserved
- 1024 = Auto-Removal Error
- 2048 = Lobe Wire Fault
- 4096 = Transmit Beacon
- 8192 = Soft Error
- 16384 = Hard Error
- 32768 = Signal Loss
- 131072 = No status, open not completed.

- dot5RingState ( dot5Entry 4 ) - Integer

- opened(1),
- closed(2),
- opening(3),
- closing(4),
- openFailure (5),
- ringFailure (6)

The current interface state with respect to entering or leaving the ring.

- dot5RingOpenStatus ( dot5Entry 5 ) - Integer

- noOpen(1), -- no open attempted
- badParam(2),
- lobeFailed(3),
- signalLoss(4),
- insertionTimeout(5),
- ringFailed(6),
- beaconing(7),
- duplicateMAC(8),
- requestFailed(9),
- removeReceived(10),
- open(11) -- last open successful

This object indicates the success, or the reason for failure, of the station's most recent attempt to enter the ring.

- dot5RingSpeed ( dot5Entry 6 ) - Integer

- unknown(1),
- oneMegabit(2),
- fourMegabit(3),

sixteenMegabit(4)

The ring's bandwidth.

- dot5UpStream ( dot5Entry 7 ) - MacAddress

The MAC address of the upstream neighbor station in the ring.

If the adapter is not OPEN, the 3174 returns an address of all 0s, since the true information is not available.

- dot5ActMonParticipate ( dot5Entry 8 ) - Integer ( true (1), false (2) )

If this object has a value of true (1) then this interface participates in the active monitor selection process. If the value is false (2) then it does not.

3174 value is always 2.

- dot5Functional ( dot5Entry 9 ) - MacAddress

The bit mask of all token-ring functional addresses for which this interface will accept frames.

If the adapter is not OPEN, the 3174 returns an address of all 0s, since the true information is not available.

- dot5StatsTable ( dot5 2 ) - SEQUENCE OF Dot5StatsEntry

A table containing token-ring statistics, with one entry per 802.5 interface.

- dot5StatsEntry ( dot5StatsTable 1 ) - Table.

An entry contains the 802.5 statistics for a particular interface.

- dot5StatsIfIndex ( dot5StatsEntry 1 ) - Integer

The value of this object identifies the 802.5 interface for which this entry contains management information. For now, this is always 1 for the 3174.

- dot5StatsLineErrors ( dot5StatsEntry 2 ) - Counter

This counter is incremented when a frame or token is copied or repeated by a station, the E bit is zero in the frame or token, and one of the following conditions exists: 1) there is a non-data bit (J or K bit) between the SD and the ED of the frame or token, or 2) there is an FCS error in the frame.

This count is provided by the 3174 token-ring adapter.

- dot5StatsBurstErrors ( dot5StatsEntry 3 )

This counter is incremented when a station detects the absence of transitions for five half-bit timers (burst-five error).

This count is provided by the 3174 token-ring adapter.

- dot5StatsACErrors ( dot5StatsEntry 4 ) - Counter

This counter is incremented when a station receives an AMP or SMP frame in where A is equal to C is equal to 0, and then receives another SMP frame where A is equal to C is equal to 0 without first receiving an AMP frame. It denotes a station that cannot set the AC bits properly.

- dot5StatsAbortTransErrors ( dot5StatsEntry 5 ) - Counter

This counter is incremented when a station transmits an abort delimiter while transmitting.

This count is provided by the 3174 token-ring adapter.

- dot5StatsInternalErrors ( dot5StatsEntry 6 ) - Counter

This counter is incremented when a station recognizes an internal error.

This count is provided by the 3174 token-ring adapter.

- dot5StatsLostFrameErrors ( dot5StatsEntry 7 ) - Counter

This counter is incremented when a station is transmitting and its TRR timer expires. This condition denotes a condition where a transmitting station in strip mode does not receive the trailer of the frame before the TRR timer goes off.

This count is provided by the 3174 token-ring adapter.

- dot5StatsReceiveCongestions ( dot5StatsEntry 8 ) - Counter

This counter is incremented when a station recognizes a frame addressed to its specific address, but has no available buffer space indicating that the station is congested.

This count is provided by the 3174 token-ring adapter.

- dot5StatsFrameCopiedErrors ( dot5StatsEntry 9 ) - Counter

This counter is incremented when a station recognizes a frame addressed to its specific address and detects that the FS field A bits are set to 1 indicating a possible line hit or duplicate address.

This count is provided by the 3174 token-ring adapter.

- dot5StatsTokenErrors ( dot5StatsEntry 10 ) - Counter

This counter is incremented when a station acting as the active monitor recognizes an error condition that needs a token transmitted.

This count is provided by the 3174 token-ring adapter.

- dot5StatsSoftErrors ( dot5StatsEntry 11 ) - Counter

The number of Soft Errors the interface has detected. It directly corresponds to the number of Report Error MAC frames that this interface has transmitted. Soft Errors are those which are recoverable by the MAC layer protocols.

- dot5StatsHardErrors ( dot5StatsEntry 12 ) - Counter

The number of times this interface has detected an immediately recoverable fatal error. It denotes the number of times this interface is either transmitting or receiving beacon MAC frames.

- dot5StatsSignalLoss ( dot5StatsEntry 13 ) - Counter

The number of times this interface has detected the loss of signal condition from the ring.

- dot5StatsTransmitBeacons ( dot5StatsEntry 14 ) - Counter

The number of times this interface has transmitted a beacon frame.

- dot5StatsRecoverys ( dot5StatsEntry 15 ) - Counter

The number of Claim Token MAC frames received or transmitted after the interface has received a Ring Purge MAC frame. This counter signifies the number of times the ring has been purged and then recovered back into a normal operating state.

- dot5StatsLobeWires ( dot5StatsEntry 16 ) - Counter

The number of times the interface has detected an open or short circuit in the lobe data path. The adapter will be closed and dot5RingState will signify this condition.

- dot5StatsRemoves ( dot5StatsEntry 17 ) - Counter

The number of times the interface has received a Remove Ring Station MAC frame request. When this frame is received the interface will enter the close state and dot5RingState will signify this condition.

- dot5StatsSingles ( dot5StatsEntry 18 ) - Counter

The number of times the interface has sensed that it is the only station on the ring. This will happen if the interface is the first one up on a ring, or if there is a hardware problem.

- dot5StatsFreqErrors ( dot5StatsEntry 19 ) - Counter

The number of times the interface has detected that the frequency of the incoming signal differs from the expected frequency by more than that specified by the IEEE 802.5 standard.

This count is provided by the 3174 token-ring adapter.

- dot5TimerTable ( dot5 5 )

Not supported by the 3174; this is an optional variable, and most of the values in it are not accessible to the 3174 as they are implemented on the token-ring card.

- The SNMP group (MIB-II 11)

This group is all new to MIB-II.

- snmplnPkts (snmp 1) - Counter

The total number of SNMP messages delivered to an SNMP entity from the transport service.

- snmpOutPkts (snmp 2) - Counter

The total number of SNMP messages which were passed from the SNMP protocol entity to the transport service.

- snmplnBadVersions (snmp 3) - Counter

The total number of SNMP messages which were delivered to the SNMP protocol entity and were for an unsupported SNMP version.

- snmplnBadCommunityNames (snmp 4) - Counter

The total number of SNMP messages delivered to the SNMP protocol entity which used an unknown SNMP community name.

- snmplnBadCommunityUses (snmp 5) - Counter

The total number of SNMP messages delivered to the SNMP protocol entity which represented an SNMP operation which was not allowed by the SNMP community named in the message.

For 3174, this is the number of SET commands received for valid variables, since the 3174 does not support SETs.

- snmplnASNParseErrs (snmp 6) - Counter

The total number of ASN.1 or BER errors encountered by the SNMP protocol entity when decoding received SNMP messages.

- (snmp 7) is not used.

- snmplnTooBigs (snmp 8) - Counter

The total number of SNMP PDUs which were delivered to the SNMP protocol entity and for which the value of the error-status field is **tooBig**

- snmplnNoSuchNames (snmp 9) - Counter

The total number of SNMP PDUs which were delivered to the SNMP protocol entity and for which the value of the error-status field is **noSuchName**

- snmplnBadValues (snmp 10) - Counter

The total number of SNMP PDUs which were delivered to the SNMP protocol entity and for which the value of the error-status field is **badValue**

- snmplnReadOnlys (snmp 11) - Counter

The total number of SNMP PDUs which were delivered to the SNMP protocol entity and for which the value of the error-status field is **readOnly**

- snmplnGenErrs (snmp 12) - Counter

The total number of SNMP PDUs which were delivered to the SNMP protocol entity and for which the value of the error-status field is **genErr**

- snmplnTotalReqVars (snmp 13) - Counter

The total number of MIB objects which have been retrieved successfully by the SNMP protocol entity as a result of receiving valid SNMP Get-Request and Get-Next PDUs.

- snmplnTotalSetVars (snmp 14) - Counter

The total number of MIB objects which have been altered successfully by the SNMP protocol entity as a result of receiving valid SNMP Set-Request PDUs.

- snmplnGetRequests (snmp 15) - Counter

The total number of SNMP Get-Request PDUs which have been accepted and processed by the SNMP protocol entity.

- snmplnGetNexts (snmp 16) - Counter

The total number of SNMP Get-Next PDUs which have been accepted and processed by the SNMP protocol entity.

- snmplnSetRequests (snmp 17) - Counter

The total number of SNMP Set-Request PDUs which have been accepted and processed by the SNMP protocol entity.

- snmplnGetResponses (snmp 18) - Counter

The total number of SNMP Get-Response PDUs which have been accepted and processed by the SNMP protocol entity.

- snmpInTraps (snmp 19) - Counter  
The total number of SNMP Trap PDUs which have been accepted and processed by the SNMP protocol entity.
- snmpOutTooBig (snmp 20) - Counter  
The total number of SNMP PDUs which were generated by the SNMP protocol entity and for which the value of the error-status field is **tooBig**
- snmpOutNoSuchNames (snmp 21) - Counter  
The total number of SNMP PDUs which were generated by the SNMP protocol entity and for which the value of the error-status field is **noSuchName**
- snmpOutBadValues (snmp 22) - Counter  
The total number of SNMP PDUs which were generated by the SNMP protocol entity and for which the value of the error-status field is **badValue**
- (snmp 23) is not used.
- snmpOutGenErrs (snmp 24) - Counter  
The total number of SNMP PDUs which were generated by the SNMP protocol entity and for which the value of the error-status field is **genErr**
- snmpOutGetRequests (snmp 25) - Counter  
The total number of SNMP Get-Request PDUs which have been generated by the SNMP protocol entity.
- snmpOutGetNexts (snmp 26) - Counter  
The total number of SNMP Get-Next PDUs which have been generated by the SNMP protocol entity.
- snmpOutSetRequests (snmp 27) - Counter  
The total number of SNMP Set-Request PDUs which have been generated by the SNMP protocol entity.
- snmpOutGetResponses (snmp 28) - Counter  
The total number of SNMP Get-Response PDUs which have been generated by the SNMP protocol entity.
- snmpOutTraps (snmp 29) - Counter  
The total number of SNMP Trap PDUs which have been generated by the SNMP protocol entity.
- snmpEnableAuthenTraps (snmp 30) - Integer  
Indicates whether the SNMP agent process is permitted to generate authentication-failure traps. For 3174, this is **2** (disabled).

## 9.10 TCP/IP Enhancements Customization

This section describes the changes to the different customization panels that are needed to support the TCP/IP enhancements.

### 9.10.1 AEA and TCP/IP Configure

```

_____ AEA and TCP/IP Configure _____

700 - 0 2
702 - 1
703 - 0
710 - 00000000    711 - 00000000    712 - 00000000    713 - 00000000

PF: 3=Quit    4=Default    7=Back    8=Fwd
```

Figure 269. AEA and TCP/IP Configure Panel

**Q700** The second field is used to select the level of TCP/IP function:

- 0 = no TCP/IP
- 1 = TCP/IP
- 2 = TCP/IP with SNMP

On this panel you are now able to define TCP/IP with SNMP.



## 9.10.2 Defining TN3270 Station Set

A new value of 6 is now allowed for Question 751, to indicate that the TN3270 data stream is used. 6 is only valid when the station set is for a TCP/IP host. It means Question 722 is set to TH.

The following screen will show you the TCP/IP Station Set panel.

```

_____ AEA and TCP/IP Station Set _____

721 - TN3270 _____ 722 - TH 723 - TN3270 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 6 752 - _____
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000 791 - 00000

721 - _____ 722 - _____ 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 2 752 - _____
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000 791 - 00000

All responses are correct
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd
```

Figure 270. AEA and TCP/IP Station Set Panel

To define the station set for TN3270 access, respond to the following questions:

- Q721** Enter a station set name that you wish displayed on the Connection Menu.
- Q722** Enter TH as the station type for the TCP/IP host.
- Q751** Specify the data stream supported by the TCP/IP host:
- 1=DEC VT100
  - 2=IBM 3101
  - 3=DG D210 (USA English only)
  - 4=DEC VT220, 7-bit control
  - 5=DEC VT220, 8-bit control
  - 6=TN3270

### 9.10.3 Defining Printer Station Set

Question 784 is now valid for a 3270 printer station set, when the station set is used for TCP/IP printing. The responses are used differently for 3270 printers than they are for ASCII printers.

The following screen will show you the Printer Station Set panel.

```

_____ AEA and TCP/IP Station Set _____

721 - PRINTER _____ 722 - 3P 723 - COAX 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - ? 752 - _____
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000 791 - 00000

721 - _____ 722 - _____ 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - _____ 752 - _____
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000 791 - 00000

All responses are correct
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd
```

Figure 271. AEA and TCP/IP Station Set Panel

To define the station set for LPD support, respond to the following questions:

- Q721** Enter a station set name that you wish displayed on the Connection Menu. We have selected **PRINTER**.
- Q722** Enter **3P** as the station type for the TCP/IP host.
- Q784** Specify the translation tables to be used for printing:
- 1=US ASCII
  - 4=PC code page 850
  - 2=ISO-8859/1.2
  - 3=DEC MCS
  - 4=User-Defined Translate table 1
  - 5=User-Defined Translate table 2
  - 6=User-Defined Translate table 3
- Q790** This question is now valid for a printer station set.
- Q791** This is a new question, which allows a TCP port number from 0001 to 56535.

## 9.10.4 Defining Default Destinations

AEA and TCP/IP Default Destination							
Station Set	Station Set Name	Session Limit	LT1	LT2	LT3	LT4	LT5
1	TN3270	0					
2	PRINTER	5	TP				
3		0					
4		0					
5		0					
6		0					
7		0					
8		0					
9		0					
10		0					
11		0					
12		0					

PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

Figure 272. AEA and TCP/IP Default Destination Panel

Allow **TP** as the default destination for a printer station set. This denotes that the station set is to be used for TCP/IP printing

## 9.10.5 Defining TCP/IP Options

Question 059 is new, and has been added to the TCP/IP Options Menu to set the **Maximum Printer Connections**. This question represents the number of concurrent printer sessions that you want to allow.

TCP/IP Options Menu			
3174 IP Address	052 -	009 . 067 . 038 . 087	
Subnet Mask	054 -	255 . 255 . 255 . 192	
. * Broadcast Address	056 -	000 . 000 . 000 . 000	
Maximum TELNET Connections	058 -	020	(001 - 250)
Maximum Printer Connections	059 -	005	(001 - 099)
TCP/IP Buffer Space	060 -	0256	K(K = 1024 bytes)
Routing Field Support	062 -	Y	(Y,N)
All Routes Broadcast	064 -	N	(Y,N)

PF: 3=Quit 4=Default 7=Back 8=Fwd

Figure 273. TCP/IP Options Menu

**Q059** Enter the maximum number of concurrent printer sessions.

**Note:** Each session requires 7KB of memory in the storage calculations. The allowed range is from 1 to 99.

## 9.11 Scenario 1 - 3174 Line Printer Daemon (LPD)

This configuration shows the capability of different TCP/IP hosts connected via Ethernet or token-ring to the 3174 Line Printer Daemon (LPD). It uses the 3174 RPQ 8Q1041 TCP/IP Enhancements.




Figure 274. 3174 LPD Support

### 9.11.1 Scenario Description

The composite network has the following components:

- 3174-11L with an Ethernet adapter, address 9.67.32.91
- RS/6000 with AIX 3.2.3 and address 9.67.32.85
- PS/2 with OS/2 2.0 and address 9.67.32.94
- PS/2 with DOS 5.2 and address 9.67.32.93
- AS/400 with address 9.67.32.95

### 9.11.2 3174 Line Printer Daemon Customization

For Line Printer Daemon customization questions were added or enhanced on the following customization panels.

- AEA And TCP/IP Station Set
  - Q790 is not new, but is used by LPD.
  - Q791 is for TN3270.
- AEA and TCP/IP Default Destination
  - New response of **TP**, for TCP/IP printer
- TCP/IP Options Menu
  - Q059 is new for LPD support.

### 9.11.3 Defining 3270 Printer Station Set

The following screen will show you the 3270 Printer Station Set panel.

```
_____ AEA and TCP/IP Station Set _____

 721 - 3174PRTQ _____ 722 - 3P 723 - COAXPRT 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 1 752 - _____
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000 791 - 00000

 721 - _____ 722 - 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - _ 735 - 0 736 - 1 737 - _
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - _____ 752 - _____
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000 791 - 00000

All responses are correct
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd
```

Figure 275. AEA and TCP/IP Station Set Panel

The following questions show the responses to the LPD support that we used in our scenario:

- Q721** The station set name we wish displayed on the Connection Menu.
- Q722** **3P** is the station type for the TCP/IP host.
- Q784** We specify **code page 850** for the printer (1 = code page 850).

## 9.11.4 Defining Default Destinations

___ AEA and TCP/IP Default Destination ___							
Station Set	Station Set Name	Session Limit	Session				
			LT1	LT2	LT3	LT4	LT5
1	3270 HOST	0	---	---	---	---	---
2	3270 DISPLAY	5	---	---	---	---	---
3	TELNET VT100	0	---	---	---	---	---
4	IBM3101	0	---	---	---	---	---
5	TELNET VT220 7 BIT	0	---	---	---	---	---
6	TELNET VT220 8 BIT	0	---	---	---	---	---
7	3174PRTQ	1	TP	---	---	---	---
8		0	---	---	---	---	---
9		0	---	---	---	---	---
10		0	---	---	---	---	---
11		0	---	---	---	---	---
12		0	---	---	---	---	---
13		0	---	---	---	---	---
14		0	---	---	---	---	---
15		0	---	---	---	---	---

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=Page Back    11=Page Fwd

Figure 276. AEA and TCP/IP Default Destination Panel

**TP** is the default destination for a printer station set. This denotes that the station set is to be used for TCP/IP printing.

## 9.11.5 Defining TCP/IP Options

___ TCP/IP Options Menu ___	
3174 IP Address	052 - 009 . 067 . 032 . 091
Subnet Mask	054 - 255 . 255 . 255 . 000
Maximum TELNET Connections	058 - 020 (001 - 250)
Maximum Printer Connections	<b>059</b> - <b>005</b> (001 - 099)
TCP/IP Buffer Space	060 - 0256 KB (KB = 1024 bytes)
Routing Field Support	062 - Y (Y,N)
All Routes Broadcast	064 - N (Y,N)

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 277. TCP/IP Options Menu

**Q059**    The maximum number of concurrent printer sessions is defined as **005**.

## 9.11.6 3174 Line Printer Daemon Configuration for OS/2

This section describes how to configure the 3174 Line Printer Daemon on the OS/2 workstation.

After invoking the TCP/IP configuration, you get the TCP/IP Configuration panel.




Figure 278. TCP/IP Configuration

Select the **Services** tab, and you get the panel as shown below.




Figure 279. TCP/IP Configuration Configure Services Page 1 of 3

On the TCP/IP Configuration Configure Services Page 1 of 3 window you define the CODEPAGE and the Hostname for the OS/2 machine.

Select Configure Services Page 2 of 3.




Figure 280. TCP/IP Configuration Configure Services Page 2 of 3

Enter the **Remote Print Server** Here you enter either the 3174 IP address or the 3174 Hostname which is defined in the TCP/IP Domain Name Service panel of the 3174 LPD customization.

Enter the **Remote Print Server's Printer** The definition of the Remote Print Server's Printer was done on the TCP/IP Station Set panel of the 3174 LPD customization panel.

This window also allows you to define the Maximum number of LPD Ports and the Username for Remote Printing.

Go to the next page of the TCP/IP Configuration panel.






Figure 281. TCP/IP Configuration Configure Services Page 3 of 3

On Page 3 of 3 you enter the IP address of the 3174 LPD and the IP address of local OS/2 TCP/IP station.

Press Enter and the Closing TCP/IP Configuration panel is displayed.




Figure 282. Closing TCP/IP Configuration

Select **SAVE** to close the TCP/IP Configuration Notebook Program. The 3174 Line Printer Daemon configuration on the OS/2 system.

**Note:** Notice the following changes to the different system files on OS/2 station.

These are the the Remote Print Server entries in the **CONFIG.SYS** file:

```
SET LPR_SERVER=TCP3174L
SET LPR_PRINTER=3174PRTQ
```

These are the Remote Print Server entries in the **\etc\hosts** file:

```
9.67.32.91      TCP3174L
9.67.32.94      os2
```

### 9.11.7 Printing with the 3174 Line Printer Daemon from TCP/IP for OS/2

At an OS/2 prompt enter the following command:

```
:E:\>lpr -p COAXPRT -s 3174PRTQ print.test
```

The lpr command enables you to transfer the contents of the file (print.test) from your workstation to the 3174 Line Printer Daemon that provides print services.

For a detailed description of the lpr command refer to *IBM Transmission Control Protocol/Internet Protocol Version 2.0 for OS/2: Command Reference, SX75-0070-02*.

### 9.11.8 3174 Line Printer Daemon Configuration for DOS

This section describes how to configure the 3174 Line Printer Daemon on the DOS workstation. To invoke the configuration for printer services on DOS, do the following:

At the DOS prompt, type the following and press Enter:

```
C:\>custom
```

The CUSTOM program displays the main menu and with the Enter key you step to the Configuration panel.




Figure 283. Network Services

Select **Network Services** from the action bar and press Enter the panel shown in Figure 283 is displayed. This panel allows you to describe the Printer Services.




Figure 284. Printer Services

Type in the field **Printer Server**, under Printer Services, the name of the 3174 print server. In our case, we typed **TCP3174L**. In the **Printer** field, type in the name of the 3174 device. This is the device name we defined on question 721 of the 3174 TCP/IP Station Set Customization panel. We entered **3174PRTQ**. In the **User name** field we enter **pcdos**; this is the hostname of the DOS machine.

If **OK** is highlighted on the Configuration panel, press Enter and the LPD configuration for DOS is finished.

**Note:** Notice the following changes to the different system files on DOS.

These are the Remote Print Server entries in the **config.sys** file:

```
SET LPR_SERVER=TCP3174L
SET LPR_PRINTER=3174PRTQ
```

These are the Remote Print Server entries in the **\etc\hosts** file:

```
#
# hosts
#
# This file contains the hostnames and their address for hosts in the network
# This file is used to resolve a hostname into an Internet address
#
#
# Internet Address      Hostname      Alias      # Comments
# 192.1.1.1             mentor_n1     mether     # Address of mentor in Network1
# 129.5.5.3             mentor_n2     m802_3 wise # Address of mentor in Network2
# 9.5.2.201             mentor_n3     mtok       # Address of mentor in Network3
# 9.5.2.205             babbage      # Address of mentor in Network3
# 9.67.32.91            TCP3174L     # Address of LPD Server
# 9.67.32.93            pcDOS        # Address of this User
```

These are the additional entries for Remote Printer Service in the **tcpdos.ini** file:

```
(lpr)
lpr.printer=3174PRTQ
lpr.server=TCP3174L
lpr.user=pcdos
```

### 9.11.9 Printing with the 3174 Line Printer Daemon from TCP/IP for DOS

At a DOS prompt enter the following command:

```
:E:\> lpr -p COAXPRT -s 3174PRTQ print.test
```

The lpr command sends the text file (print.test) to the remote printer.

For more information about the lpr command refer to *TCP/IP Version 2.1.1 for DOS: User's Guide, SC31-7045-01*.

### 9.11.10 3174 Line Printer Daemon Configuration for AS/400

This section describes how to configure the 3174 Line Printer Daemon on the AS/400.

On the AS/400 we do the following:

- Configure communication and remote hardware
  - Work with TCP/IP links
  - Work with TCP/IP host table entries
- TCP/IP administration
  - Start TCP/IP subsystem
  - Send TCP/IP spooled file

After signing on to the AS/400 the Main Menu is displayed.

```
MAIN                               AS/400 Main Menu                               System:  RALYAS4B
Select one of the following:
    1. User tasks
    2. Office tasks
    3. General system tasks
    4. Files, libraries, and folders
    5. Programming
    6. Communications
    7. Define or change the system
    8. Problem handling
    9. Display a menu
   10. Information Assistant options
   11. PC Support tasks

   90. Sign off

Selection or command
====> 6

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel  F13=Information Assistant
F23=Set initial menu
(C) COPYRIGHT IBM CORP. 1980, 1993.
```

Figure 285. AS/400 Main Menu

On the Main Menu type **6** to select the Communications panel

```
CMN                      Communications                      System:  RALYAS4B

Select one of the following:

    1. Communication status
    2. Messages
    3. Access a remote system
    4. Configure communications and remote hardware
    5. Network management
    6. Network configuration
    7. Verify communications
    8. Send or receive files
    9. Jobs

    70. Related commands

Selection or command
====> 6

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel  F13=Information Assistant
F16=AS/400 Main menu
C COPYRIGHT IBM CORP. 1980, 1993.
```

Figure 286. Communications

On the Communications panel type **6** to reach the Network Configuration panel.

```
NETCFG                   Network Configuration                   System:  RALYAS4B

Select one of the following:

    1. Work with system directory
    2. Configure distribution services
    3. Work with network job entries
    4. Configure VM/MVS bridge
    5. Work with remote document libraries

    10. Configure communications and remote hardware

    70. Related commands

Selection or command
====> 10

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel  F13=Information Assistant
F16=AS/400 Main menu
C COPYRIGHT IBM CORP. 1980, 1993.
```

Figure 287. Network Configuration

On the Network Configuration panel type **10**, to get the Configure communications and remote hardware panel.

```
CFGCMN          Configure Communications and Remote Hardware
                                                    System:  RALYAS4B

Select one of the following:

  1. Work with lines
  2. Work with communications controllers
  3. Work with work station controllers
  4. Work with communications devices
  5. Work with printers
  6. Work with display stations
  7. Work with modes
  8. Work with classes-of-service
  9. Work with configuration lists
 10. Work with network interfaces
 11. Work with connection lists

 20. Configure TCP/IP
                                                    More...

Selection or command
====> 20

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel  F13=Information Assistant
F16=AS/400 main menu
C  COPYRIGHT IBM CORP. 1980, 1993.
```

*Figure 288. Configure Communications and Remote Hardware*

On this panel type **20** to configure the TCP/IP on AS/400.

```
                                Configure TCP/IP
                                                    System:  RALYAS4B

Select one of the following:

  1. Work with TCP/IP host table entries
  2. Work with TCP/IP links
  3. Work with TCP/IP route entries
  4. Change local domain name
  5. Work with names for SMTP
  6. Work with TCP/IP remote system information

 10. Change remote name server
 11. Change TCP/IP attributes
 12. Work with TCP/IP port entries
 13. Change SMTP attributes
 14. Change TCP/IP tuning values

 25. Convert host table

Selection or command
====> 2

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel
C  COPYRIGHT IBM CORP. 1987, 1993.
```

*Figure 289. Configure TCP/IP*

Type **2** to work with TCP/IP links.

```

Work with TCP/IP Links
System: RALYAS4B
Type options, press Enter.
1=Add2=Change 4=Remove 5=Display 9=Start 10=End

Opt      Line      Internet      Link
  Description  Address      Type
-----
L71ETH   9.67.32.95  *ELAN

F3=Exit  F5=Refresh  F12=Cancel  F15=Print list  F17=Top  F18=Bottom
Bottom

```

Figure 290. Work with TCP/IP Links

On this panel you type in the desired line description and its associated Internet Address. In our configuration we use **L71ETH** for the Line Description. The Internet Address of the AS/400 is **9.67.32.95**. The Link Type that we used is **\*ELAN** for the Ethernet adapter.

Press Enter to get the display of the TCP/IP link description.

```

System: RALYAS4B
Line description . . . . . : L71ETH
Internet address . . . . . : 9.67.32.95
Link type . . . . . : *ELAN
Auto start link . . . . . : *YES

Press Enter to continue.
F3=Exit  F12=Cancel

```

Figure 291. Display TCP/IP Link

On this panel your TCP/IP link descriptions are displayed.

Press Enter and the TCP/IP Configuration panel appears again.




Figure 292. Configure TCP/IP

Select 1 on this panel to make the TCP/IP host table entries.




Figure 293. Work with TCP/IP Host Table Entries

After adding the internet address and the hostname of the appropriate hosts, press PF3 to return to the Communications panel.



```
CMH                      Communications                      System:  RALYAS4B

Select one of the following:

  1. Communication status
  2. Messages
  3. Access a remote system
  4. Configure communications and remote hardware
  5. Network management
  6. Network configuration
  7. Verify communications
  8. Send or receive files
  9. Jobs

 70. Related commands

Selection or command
====> 5

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel  F13=Information Assistant
F16=AS/400 Main menu
C COPYRIGHT IBM CORP. 1980, 1993.
```

*Figure 294. Communications*

On the Communications panel type **5** to reach the Network Management panel.

```
NETWORK                  Network Management                  System:  RALYAS4B

Select one of the following:

  1. Display network attributes
  2. Change network attributes
  3. Display sphere of control SOC status
  4. Work with sphere of control SOC
  5. Network problem handling
  6. Display APPN information
  7. Work with distribution queues
  8. Display distribution services
  9. Display distribution services log
 10. TCP/IP administration

 70. Related commands

Bottom

Selection or command
====> 10

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel  F13=Information Assistant
F16=AS/400 Main menu
C COPYRIGHT IBM CORP. 1980, 1993.
```

*Figure 295. Network Management*

On the Network Management panel type **10**, and the TCP/IP Administration panel appears.

```
TCPADM                TCP/IP Administration                System:  RALYAS4B

Select one of the following:

    1. Configure TCP/IP
    2. Start TCP/IP subsystem
    3. End TCP/IP subsystem
    4. Start TCP/IP FTP session
    5. Verify TCP/IP connection
    6. Work with names for SMTP
    7. Start TCP/IP TELNET session
    8. Work with TCP/IP network status
    9. Send TCP/IP spooled file

Selection or command
====> 2

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel
C  COPYRIGHT IBM CORP. 1987, 1993.
```

*Figure 296. TCP/IP Administration*

Type **2** to activate the TCP/IP subsystem on the AS/400.

```
TCPADM                TCP/IP Administration                System:  RALYAS4B

Select one of the following:

    1. Configure TCP/IP
    2. Start TCP/IP subsystem
    3. End TCP/IP subsystem
    4. Start TCP/IP FTP session
    5. Verify TCP/IP connection
    6. Work with names for SMTP
    7. Start TCP/IP TELNET session
    8. Work with TCP/IP network status
    9. Send TCP/IP spooled file

Selection or command
====> 2

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel
Subsystem name QTCP active.
C  COPYRIGHT IBM CORP. 1987, 1993.
```

*Figure 297. TCP/IP Administration*

If the TCP/IP subsystem is active, the following message is displayed on the lower screen line: **Subsystem name QTCP active**

Now the AS/400 is configured and prepared for printing a job with the 3174 Line Printer Daemon (LPD).

### 9.11.11 Printing with the 3174 Line Printer Daemon on AS/400

To start an LPD print job from the AS/400, the TCP/IP Administration panel should be displayed.




Figure 298. TCP/IP Administration

Type **9** on this panel, and you get the Send TCP/IP Spooled File panel.




Figure 299. Send TCP/IP Spooled File SNDTCPSPLF

On this panel you type in the desired data. Remote system is the host name of the 3174 which is customized for LPD. In our example this is **TCP3174L**. The Printer queue name is **3174PRTQ**, the same name as used in the 3174 LPD customization.

The entries in the other fields are AS/400 specific. For more details see *AS/400 Transmission Control Protocol/Internet Protocol Guide Version 2, SC41-9875-02*.

Press Enter to start the print job.

```
TCPADM                      TCP/IP Administration                      System:  RALYAS4B

Select one of the following:

    1. Configure TCP/IP
    2. Start TCP/IP subsystem
    3. End TCP/IP subsystem
    4. Start TCP/IP FTP session
    5. Verify TCP/IP connection
    6. Work with names for SMTP
    7. Start TCP/IP TELNET session
    8. Work with TCP/IP network status
    9. Send TCP/IP spooled file

Selection or command
===>

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel
Spooled file QPDSPJOB sent.
```

Figure 300. TCP/IP Administration

After the job is started and the LPD printer is printing, the following is displayed on the lower screen line:  
**Spooled file QPDSPJOB sent.**

### 9.11.12 3174 Line Printer Daemon Configuration for RS/6000

This section describes how to configure the 3174 Line Printer Daemon on the RS/6000.

The following steps are required to configure the printer system on the RS/6000.

- Manage Local Printer Subsystem
  - Add a Local Printer Queue
  - Add a Local Queue Device
  - Start a Queue
- Manage Remote Printer Subsystem
  - Add a Remote Printer Queue
  - Add a Remote Queue Device
- Server Services
  - Start LPD Remote Printer Subsystem
  - Start a Print Job

After you login to your RS/6000 workstation you get the Login screen.

```

IBM AIX Version 3 for RISC System/6000
C Copyrights by IBM and by others 1982, 1991.
login: root
root's Password:
*****
*
*
* This is RISC System/6000 RS60001, in the lab at ITS0 Raleigh
*
*
* This system is at AIX level 3.2.5. If you have any questions about it
* call Rob Macgregor on 1-2325
*****

Last unsuccessful login: Mon Apr 25 13:58:18 1994 on pts/2 from TCP3174L
Last login: Tue Apr 26 09:54:49 1994 on pts/2 from 9.24.104.73
%YOU HAVE NEW MAIL'
swcons: console output redirected to: /log/26Apr94
%root:rs60001' / > smit

```

Figure 301. RISC System/6000

On this screen you invoke the System Management panel by entering smit on the command line.

SMIT is a menu-driven, command-building facility. SMIT menus, submenus, and dialog screens present complex system management tasks in an organized manner and prompt you for parameters when necessary. As you make menu selections, SMIT builds or runs the appropriate command.

The SMIT text interface uses cursor keys to navigate through the panels.

```

                                System Management

Move cursor to desired item and press Enter.

Software Installation & Maintenance
Devices
Physical & Logical Storage
Security & Users
Diskless Workstation Management & Installation
Communications Applications and Services
Spooler Print Jobs
Problem Determination
Performance & Resource Scheduling
System Environments
Processes & Subsystems
Applications
Using SMIT information only

F1=Help           F2=Refresh       F3=Cancel       Esc+8=Image
Esc+9=Shell      Esc+0=Exit      Enter=Do

```

Figure 302. System Management (SMIT Text Interface)

Select **Spooler Print Jobs** with the cursor to get the Spooler Print Jobs panel.

### 9.11.13 Manage Local Printer Subsystem




Figure 303. Spooler Print Jobs

Here, select **Manage Local Printer Subsystem**, and the following panel is shown.




Figure 304. Manage Local Printer Subsystem

Here select **Local Printer Queues** and the following panel appears, which allows you to add the local printer queue.




Figure 305. Add a Local Queue

The **NAME of queue to add** is the predefined printer name of the 3174 Line Printer Daemon customization.

The **NAME of device to add** is the predefined printer device name as specified during the 3174 Line Printer Daemon customization.




Figure 306. Queue to Change / Show

Select **Change / Show Characteristics of a Queue** to display or to change the characteristics of the local printer queue.

Select **3174PRTQ** and press Enter.




Figure 307. Change / Show Characteristics of a Queue

The **Name of queue** is the predefined printer name of the 3174 Line Printer Daemon customization. The **Name of Queue on remote printer** is identical to this customized printer name. The **DESTINATION HOST for remote jobs** is the name of the 3174, which has been customized for 3174 Line Printer Daemon.

**Note:** When creating a queue on the RS/6000, you should use **attshort** for the SHORT FORM FILTER, and **attlong** for the LONG FORM FILTER. The other filters have commands in their respective control file defaults that the 3174 will reject and will cause the job to be aborted.

Press Enter, and the local printer queue is defined. The Local Printer Queues panel appears again.




Figure 308. Local Printer Queues

To make sure the local printer queue is active, select **Start a Queue**. The following panels allow you to select the predefined local printer queue.




Figure 309. QUEUE Name

Select **3174PRTQ:COAXPRT** and press Enter.




Figure 310. Start a Queue



Press Enter on this screen, and the Command Status is displayed on the next panel.




Figure 311. Command Status Panel

Now the local printer queue is active.

### 9.11.14 Manage Remote Printer Subsystem

To manage the remote printer subsystem select **Manage Remote Printer Subsystem** on the Spooler Print Jobs panel.




Figure 312. Spooler Print Jobs




Figure 313. Manage Remote Printer Subsystem

Here, select **Client Services**, and the following screen will be shown.




Figure 314. Client Services

Select **Remote Printer Queues**, and you get the following screen which allows you to display the characteristics of the 3174PRTQ remote printer queue.




Figure 315. Queue to Change / Show

Select **3174PRTQ** and press Enter.

```

Change / Show Characteristics of a Queue

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

Name of queue          (Entry Fields)
3174PRTQ
Queuing DISCIPLINE    shortest job next    +
ACTIVATE the queue?   yes                  +
ACCOUNTING FILE pathname (FALSE)
DESTINATION HOST for remote jobs (TCP3174L)
Pathname of the SHORT FORM FILTER for queue (/usr/lpd/attshort)  +/
status output
Pathname of the LONG FORM FILTER for queue (/usr/lpd/attlong)  +/
status output
Name of QUEUE on remote printer (3174PRTQ)

F1=Help      F2=Refresh    F3=Cancel     F4=List
Esc+5=Reset  Esc+6=Command Esc+7=Edit    Esc+8=Image
Esc+9=Shell  Esc+0=Exit    Enter=Do

```

Figure 316. Change / Show Characteristics of a Queue

The **Name of queue** is the predefined printer name of the 3174 Line Printer Daemon customization. The **Name of Queue on remote printer** is identical to this customized printer name. Press Enter, and the Manage Remote Printer Subsystem panel is displayed.

### 9.11.15 Server Services

```

Manage Remote Printer Subsystem

Move cursor to desired item and press Enter.

Client Services
Server Services

F1=Help      F2=Refresh    F3=Cancel     Esc+8=Image
Esc+9=Shell  Esc+0=Exit    Enter=Do

```

Figure 317. Manage Remote Printer Subsystem

Select **Server Services**, and the Server Services panel is displayed.

```

Server Services

Move cursor to desired item and press Enter.

Host Access for Printing
lpd Remote Printer Subsystem
Manage Local Printer Subsystem

F1=Help      F2=Refresh    F3=Cancel     Esc+8=Image
Esc+9=Shell  Esc+0=Exit    Enter=Do

```

Figure 318. Server Services

Select **lpd Remote Printer Subsystem**, and the following panel appears.




Figure 319. lpd Remote Printer Subsystem

Select **Start Using the lpd Subsystem**.




Figure 320. Start Using the lpd Subsystem

Press Enter, and the lpd Remote Printer Subsystem is started.

The RS/6000 remote printer system is configured now for printing a print job on the 3174 Line Printer Daemon (LPD).

### 9.11.16 Printing with the 3174 Line Printer Daemon from RS/6000

To start an LPD print job from the RS/6000, invoke from the System Management panel the function Spooler Print Jobs, and you will get the following panel.




Figure 321. Spooler Print Jobs

Select **Start a Print Job** and press Enter.

On the following panel you see all print job definitions.

```

                                Start a Print Job

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

* FILE to print                    print.test
PRINT QUEUE:(Queue Device)        3174PRQ:COAXPRT +
NUMBER of copies                    (1) #
Make a COPY of the file on the local host? no +
    Applicable to local print jobs only.
ERASE the file from the system after printing? no +
Send notification of job status?    no +
* BURST Status                      no burst pages +
USER NAME for 'Delivery to' output label ()
CONSOLE acknowledgement message for remote print ()
FILE acknowledgement message for remote print ()
ERASE the file from the system after printing? no +
Send notification of job status?    no +
* BURST Status                      no burst pages +
USER NAME for 'Delivery to' output label ()
CONSOLE acknowledgement message for remote print ()
FILE acknowledgement message for remote print ()
Priority LEVEL.                      (15) #
    Enter a number between 0 and 20. A user with
    administrative privileges for the qpri
    command may enter a number between 0 and 30.
    Larger numbers indicate higher priorities.

F1=Help      F2=Refresh      F3=Cancel      F4=List
Esc+5=Reset  Esc+6=Command  Esc+7=Edit    Esc+8=Image
Esc+9=Shell  Esc+0=Exit    Enter=Do

```

Figure 322. Start a Print Job

Press Enter, and start the print job.

```

                                COMMAND STATUS

Command: OK          stdout: no          stderr: no

Before command completion, additional instructions may appear below.

F1=Help      F2=Refresh      F3=Cancel      Esc+6=Command
Esc+8=Image  Esc+9=Shell    Esc+0=Exit

```

Figure 323. Command Status Panel

After the print job is successfully started, **OK** is displayed on the Command line.

### 9.11.17 3174 Line Printer Daemon Configuration for HP-UX Workstation

This section describes how to configure the 3174 Line Printer Daemon on the HP-UX workstation.

The following steps are required to configure the remote printer on the HP-UX system:

- Add remote printer/plotter.
- Enable printer/plotter.
- Start up print spooler.

**Note:** These are the 3174 hostname entries in the /etc/hosts file.

```
9.67.212.250 MNFLAB # Proteon Router to site 9.67.194.31
9.67.212.210 RTB17AS4 AS4TR # HP 9000 Series 800 mdl G40
9.24.104.74 mvs18
9.24.104.58 317412L
```

After you login to the HP workstation, the following screen is shown.

```
c Copyright 1985, 1986, 1988 Massachusetts Institute of Technology
c Copyright 1986 Digital Equipment Corp.
c Copyright 1990 Motorola, Inc.
c Copyright 1990-1992 Cornell University
c Copyright 1988 Carnegie Mellon

                RESTRICTED RIGHTS LEGEND
Use, duplication, or disclosure by the U.S. Government is subject to
restrictions as set forth in sub-paragraph c 1 ii of the Rights in
Technical Data and Computer Software clause in DFARS 252.227-7013.

                Hewlett-Packard Company
                3000 Hanover Street
                Palo Alto, CA 94304 U.S.A.

Rights for non-DOD U.S. Government Departments and Agencies are as set
forth in FAR 52.227-19 c 1,2 .

WARNING: YOU ARE SUPERUSER

# sam
```

*Figure 324. Login at HP Host*

After login as superuser **root** you are able to call the System Management panel by entering **sam** on the command line.

SAM is a menu-driven, command-building facility. It is comparable to the RS/6000 SMIT facility. SAM menus, submenus, and dialog screens present complex system management tasks in an organized manner and prompt you for parameters when necessary. As you make menu selections, SAM builds or runs the appropriate command.

The following screen shows you the System Administrations Manager (SAM) panel.

## System Administrations Manager (SAM)




Figure 325. System Administrations Manager (SAM) Panel

Select **Printers and Plotters**, press Enter, and the Printer/Plotter menu bar will be displayed.




Figure 326. Printer/Plotter Menu Bar

On this panel, the line **Printers and Plotters** is highlighted. Press Enter and you get the following panel.

## Printer/Plotter Manager

```

| X:Printer/Plotter Manager (RTB17AS4) |
+-----+
File List View Options Actions Help
+-----+
Print Spooler: STOPPED                      Default Printer: NOT DEFINED
+-----+
Printer/Plotters                                0 of 2 selected
+-----+
Name      Status      Fence      Type      Location
Priority
+-----+
| beehive  disabled    0          local    /dev/null
| rejects  disabled    0          local    /dev/null
+-----+

```

Figure 327. Printer/Plotter Manager

Select **Actions** with the Tab key on the upper menu bar, press Enter, and the following panel is shown.

```

| X:Printer/Plotter Manager (RTB17AS4) |
+-----+
File List View Options Actions Help
+-----+
Print Spooler: STOPPE | Add Local Printer/Plotter -> | er: NOT DEFINED
+-----+ | Add Remote Printer/Plotter... |
Printer/Plotters | Add Network Based Printer/Plotter -> | 0 of 2 selected
+-----+ | Remove Printer/Plotter |
| Name      Status      | Enable Printer/Plotter |
+-----+ | Disable Printer/Plotter |
| beehive  disabled | Modify Fence Priority... |
| rejects  disabled | Set as System Default Printer/Plotter |
+-----+ |
| Start Up Print Spooler |
| Shut Down Print Spooler |
| Show Common Problems |
+-----+

```

Figure 328. Add Remote Printer/Plotter

Here, use the Arrow key to select **Add Remote Printer/Plotter** and press Enter. On the following panel you are able to specify the remote printer.



## Add Remote Printer

```

| X:Add Remote Printer (RTB17AS4) |
+-----+
File List View Options Actions Help
+-----+
+ Add Remote Printer (RTB17AS4) +
Print Spooler: S | Printer Name:COAXPRT | inter: NOT DEFINED
Printer/Plotters | Remote System Name:317412L | 0 of 2 selected
Name Stat | Remote Printer Name:3174PRTQ |
+-----+
| beehive disa | ( Remote Cancel Model ... ) rcmodel |
| rejects disa | ( Remote Status Model ... ) rsmodel |
| | ( ) Make This the System Default Printer |
| | ( ) Allow Anyone to Cancel a Request |
| | ( ) Remote Printer is on a BSD System |
+-----+
| ( OK ) ( Cancel ) ( Help ) |
+-----+

```

Figure 329. Add Remote Printer/Plotter

Enter on the **Printer Name** field the predefined printer device name of the 3174 LPD customization. In our case, we used **COAXPRT**. Type in the field **Remote System Name** the hostname of the 3174, which is used instead of the 3174 IP address. In our example, the 3174 hostname is **317412L**. In the **Remote Printer Name** field, we typed in **3174PRTQ**; this is the printer name, as predefined in the 3174 LPD customization.

With the Tab key select **OK** and press Enter; the remote printer is added now. The Printer/Plotter panel with the action menu bar is displayed again.

The next action, which is required, is enabling the newly defined remote printer.

## Enable Printer

```

| X:Enable Printer/Plotter (RTB17AS4) |
+-----+
File List View Options Actions Help
+-----+
Print Spooler: STOPPED | Add Local Printer/Plotter -> | r: NOT DEFINED
+-----+ | Add Remote Printer/Plotter... |
Printer/Plotters | Add Network Based Printer/Plotter -> | 0 of 2 selected
+-----+ | Remove Printer/Plotter |
| Name | Status | Enable Printer/Plotter |
| beehive | disabled | Disable Printer/Plotter |
| rejects | disabled | Modify Fence Priority... |
+-----+ | Set as System Default Printer/Plotter |
| | | Start Up Print Spooler |
| | | Shut Down Print Spooler |
+-----+ | Show Common Problems |
+-----+
  
```

Figure 330. Enable Printer/Plotter

On the Printer/Plotter panel do the following. Select with the Arrow key **Enable Printer/Plotter** and press Enter. Press PF8, and the next panel shows you the status of the remote printer.

```

| X:Printer/Plotter Manager (RTB17AS4) |
+-----+
File List View Options Actions Help
+-----+
Print Spooler: STOPPED | Default Printer: NOT DEFINED
+-----+
Printer/Plotters | 0 of 2 selected
+-----+
| Name | Status | Fence | Type | Location |
| 3174PRTQ | enabled, idle | 0 | remote | COAXPRT on 317412L |
| beehive | disabled | 0 | local | /dev/null |
| rejects | disabled | 0 | local | /dev/null |
+-----+
  
```

Figure 331. Printer/Plotter Status

Here, in the status field, you see 3174PRTQ (remote printer name), is enabled. Press PF8, and you get again the Printer/Plotter panel with the action menu bar.

## Start Up Print Spooler




Figure 332. Start Up Print Spooler

With the Arrow key, select **Start Up Print Spooler** on the menu bar, and press Enter. Press PF8, and the following panel appears.




Figure 333. Print Spooler Running

The print spooler is running now. At this point the remote printer on the HP workstation is defined, enabled and ready to do a print job.

If you want to leave SAM, press PF key **Exit SAM** which is not shown on the panel.

## Printing with the 3174 Line Printer Daemon on HP-UX System

In our scenario we start the LPD print job on the HP-UX system from our 3174 coax-attached terminal. From the 3174 Connection Menu we select the desired TELNET emulation. The TELNET Local Mode screen will appear.

```
3174 TELNET> open hp
Finding address ...
Attempting connection to 9.67.212.210
Connected to 9.67.212.210

HP-UX RTB17AS4 A.09.04 E 9000/867 ttyp1

login: hpuser
```

Figure 334. TELNET with HP Workstation

At the TELNET prompt type **open hp** as the desired destination name of the HP-UX host. After the connection to the HP host is established, you are able to login. Type in the user ID and the corresponding password. The HP-UX login screen will be displayed.

```
Hewlett-Packard Company
3000 Hanover Street
Palo Alto, CA 94304 U.S.A.

Rights for non-DOD U.S. Government Departments and Agencies are as set
forth in FAR 52.227-19 c 1,2 .

# lp -d317412L /etc/hosts.
```

Figure 335. Login at HP Host

After the successful login, the command prompt is displayed on the lower line. Here you type in:

```
# lp -d3174PRTQ /etc/hosts
```

The lp command enables you to transfer the contents of the file (/etc/hosts) from the HP-UX workstation to the 3174 Line Printer Daemon that provides print services.

For detailed information of the lp command refer to *HP-UX System Administration Manual, Release 9.0*.

## 9.11.18 3174 Line Printer Daemon Configuration for SunOS Workstation

The following section describes the configuration and setup considerations that are necessary to print with the 3174 Line Printer Daemon on the SunOS host.

In our scenario we defined the remote printer on the SunOS host with a TELNET session from the 3174.

First do a verification of TCP/IP connectivity between 3174 coax-attached terminal and the SunOS system.

### Verification

Verification of TCP/IP connectivity to the Sun workstation, which is connected to Ethernet can be done with a ping.

Invoke the TELNET Local Mode screen by selecting a TELNET emulation.

```
3174 TELNET> ping sun

Finding address ...
00064 characters to 9.67.212.9
Received reply to packet 00000, delay ms = 00185
Received reply to packet 00001, delay ms = 00209
Received reply to packet 00002, delay ms = 00173
Received reply to packet 00003, delay ms = 00184
Received reply to packet 00004, delay ms = 00169
Received reply to packet 00005, delay ms = 00209
Received reply to packet 00006, delay ms = 00200
Received reply to packet 00007, delay ms = 00190
Received reply to packet 00008, delay ms = 00222
Received reply to packet 00009, delay ms = 00225

Summary for PING to 9.67.212.9

Packets sent: 00010 Packets received: 00010
Round-trip ms   min avg max   = 00169 00196 00225

3174 TELNET>
```

Figure 336. Ping Command to SunOS Host

### TELNET Session to SunOS Host

```
3174 TELNET> open sun
```

Figure 337. TELNET with SunOS Host

At the TELNET prompt, type **open sun**. **Sun** is the destination name of the Sun host; you get the following panel. We entered **Sun** as the alias for the Sun's IP address in the 3174 customization.

```

3174 TELNET> open sun
Finding address ...
Attempting connection to 9.67.212.9
Connected to 9.67.212.9

SunOS UNIX SPSUN009

login: root
Password:
Last login: Wed May 11 13:52:03 on console
SunOS Release 4.1.3 GENERIC #3: Mon Jul 27 16:43:54 PDT 1992
You have new mail.
Type dec-vt100 unknown
SPSUN009#
After the connection to the SunOS host is build up, you can login to
to the foreign host, and you get the SunOS login screen with
the hostid as the command prompt.

```

Figure 338. Login to SunOS Host

After the successful login, the command prompt is displayed on the lower line.

Now you are able to define the remote printer daemon on the SunOS station.

**LPD Definition on SunOS**

**/etc/printcap:** Printcap is a simplified version of a database for describing printers. The spooling system accesses the printcap file every time it is used, allowing dynamic addition and deletion of printers.

Each entry in the data base describes one printer. The first entry for each printer gives the names which are known for the printer. The second name given is the most common abbreviation for the printer, and the last name given should be a long name fully identifying the printer.

For detailed description how to set up the database refer to *sun microsystems System and Network Administration, Part Number:800-3805-10*.

The following line shows our entry in the /etc/printcap:

```

#
# Printer Caption Entry for remote 3174 ITS0 B657
lp|3174PRTQ:\
    :lp=:rm=3174PRTQ:rp=COAXPRT:sd=/var/spool/lpd:

```

**/etc/hosts:** The following entry has to be made in the /etc/hosts file before printing. In the /etc/hosts file is the name of the 3174 Line Printer Daemon.

```

SPSUN009# vi /etc/hosts
/etc/hosts 14 lines, 322 characters
#
# Sun Host Database
#
# If the NIS is running, this file is only consulted when booting
#
127.0.0.1      localhost
#
9.67.212.9    SPSUN009 loghost
45.119.151.153 8260DMM_A
45.119.151.154 8260DMM_B
45.119.151.155 8260_HMP

```

```
45.119.151.158      8260DMM_D
45.119.151.157      8260DMM_C
9.24.104.58         3174PRTQ
```

### User Commands on SunOS

**LPR Command:** The `lpr` command creates a printer job in a spooling area for subsequent printing as facilities become available. Each printer job consists of a control file and one or more data files. The data files are copies of each filename you specify. The spool area is managed by the line printer daemon, `lpd`. Jobs that specify a printer on a remote machine are forwarded by `lpd`.

```
SPSUN009# lpr -P3174PRTQ etc/hosts
```

This command send the print job to our 3174 Line Printer Daemon, named 3174PRTQ. In our example we try to print the `/etc/hosts` file.

**LPQ Command:** The `lpq` command displays the contents of a printer queue. It reports the status of the specified jobs, or all jobs owned by the user specified by username.

```
SPSUN009# lpq -P3174PRTQ etc/hosts
```

**LPSTAT Command:** The `lpstat` prints information about the current status of the printer spooling system.

```
SPSUN009# lpstat
```

### Line Printer Administration

The `lpc` program lets you control the operations of those printers which are described in the `/etc/printcap` database. `Lpc` can be used to start or stop a printer daemon, enable or disable the print queue for a printer, rearrange the order of jobs in a printer queue, or display the status of a printer, the printer daemon, and its spooling queue.

The following panels shows the `LPC status` command.

```
Last login: Thu May 12 18:15:58 from 3174PRTQ
SunOS Release 4.1.3 GENERIC #3: Mon Jul 27 16:43:54 PDT 1992
You have new mail.
SPSUN009# lpc
lpc> status
lp:
    queuing is enabled
    printing is enabled
    1 entry in spool area
    waiting for queue to be enabled on 3174PRTQ
lpc>
```


Figure 339. `lpc` Program

This example shows the status of an attempt to start a spooling daemon for our 3174PRTQ printer.

## 9.12 Scenario 2 - TN3270 to MVS Host

The purpose of this connectivity scenario is to describe how terminal attached to a 3174 Ethernet Controller

LAN-attached workstation can use the TCP/IP protocol to communicate with MVS host applications through an IBM 3172 Interconnect Controller as shown in Figure 340.



4172/417205

Figure 340. TN3270 to MVS Host



### 9.12.1 Scenario Description

This section describes the distinctive steps to establish a TN3270 TELNET session to the MVS host.

The composite network has the following components:

- MVS host with the destination address 9.67.32.65
- 3172-1 with IP-address 9.67.32.1
- 3174-14R with the Ethernet adapter address 9.67.32.91

### 9.12.2 TN3270 Customization

This section describes the entries to the customization that are needed to support the TN3270. If you are not familiar with customizing the 3174 for TCP/IP operation refer to *3174 Planning Guide*.




Figure 341. AEA and TCP/IP Station Set Panel

To define the station set for TN3270 access, respond to the following questions:

- Q721** Enter **TN3270**; this is the station set name that you wish displayed on the Connection Menu.
- Q722** Enter **TH** as the station type for the TCP/IP host.
- Q751** Specify **6** for the data stream supported by the TCP/IP host.

Press Enter and PF8 to continue with the customization.

### 9.12.3 Defining Default Destinations

___ AEA and TCP/IP Default Destination ___							
Station Set	Station Set Name	Session Limit	Session				
			LT1	LT2	LT3	LT4	LT5
1	3270 HOST	0	---	---	---	---	---
2	TELNET VT100	0	---	---	---	---	---
3	TELNET IBM3101	0	---	---	---	---	---
4	TELNET VT220 7 BIT	0	---	---	---	---	---
5	TELNET VT220 8 BIT	0	---	---	---	---	---
1	<b>TN3270</b>	0	---	---	---	---	---
7		0	---	---	---	---	---
8		0	---	---	---	---	---

PF: 3=Quit    4=Default    7=Back    8=Fwd    10=Page Back    11=Page Fwd

Figure 342. AEA and TCP/IP Default Destination Panel

This panel determines what the terminal user will see on each LT when it is first accessed. Press PF8 and the next panel appears.

### 9.12.4 Defining TCP/IP Options

___ TCP/IP Options Menu ___		
3174 IP Address	052 - 009 . 067 . 032 . 091	
Subnet Mask	054 - 255 . 255 . 255 . 192	
Maximum TELNET Connections	058 - 020	(001 - 250)
Maximum Printer Connections	059 - 005	(001 - 099)
TCP/IP Buffer Space	060 - 0256 K	(K = 1024 bytes)
Routing Field Support	062 - Y	(Y,N)
All Routes Broadcast	064 - Y	(Y,N)

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 343. TCP/IP Options Menu

On this panel you define a 3174 IP address and the corresponding subnet mask. After defining press Enter followed by PF8 and the following panel is displayed.

## 9.12.5 Defining TCP/IP Routing Information

TCP/IP Routing Information		
Destination IP Address	Type (N,S,H,D)	Router IP Address
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX
XXX . XXX . XXX . XXX	X	XXX . XXX . XXX . XXX

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 344. TCP/IP Routing Information

In our scenario we do not use router. Therefore, just press PF8 to continue with the next panel.

## 9.12.6 Defining Domain Name Services

TCP/IP Domain Name Services	
3174 Hostname	3174TCP1 <b>1</b> _____
3174 Domain Name	ITSO RALEIGH IBM COM <b>2</b> _____
	_____
	_____
Domain Nameserver IP Addresses <b>3</b>	
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX
	XXX . XXX . XXX . XXX

PF: 3=Quit    4=Default    7=Back    8=Fwd

Figure 345. TCP/IP Domain Name Services

**1** Is the name assigned to your 3174.

**2** Is the domain in which your 3174 is in.

**3** In our example, we have not defined a nameserver.

Press Enter and PF8, and the following panel will allow you to create a host nickname. In our scenario we do not define a host nickname; therefore, walk-through the following panel by pressing Enter and PF8 to finish TN3270 customization.

After you have completed the 3174 TCP/IP customization for TN3270 you have to reIML the 3174.

### 9.12.7 Connection Menu

The following panel shows you the Connection Menu after the 3174 becomes active. This menu represents the different TELNET emulations which are customized on the 3174.

```

                                     Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME          STATUS    NUM NAME          STATUS
 1 3270 HOST      ?
 2 TELNET VT100   Down
 3 TELNET IBM3101 Down
 4 TELNET VT220 7 BIT Down
 5 TELNET VT220 8 BIT Down
 6 TN3270         Down

PF: 3=End        6=Terminal Disconnect    12=Host Disconnect

=====>To:
```

Figure 346. Connection Menu Immediately after 3174 IMLed

When the 3270 host attachment becomes active, the status changes without user intervention. When you press the Enter key, the status shows all TCP/IP hosts active.

```

                                     Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME          STATUS    NUM NAME          STATUS
 1 3270 HOST      Up
 2 TELNET VT100   UP
 3 TELNET IBM3101 Up
 4 TELNET VT220 7 BIT Up
 5 TELNET VT220 8 BIT Up
 6 TN3270         Up

PF: 3=End        6=Terminal Disconnect    12=Host Disconnect

=====>To: 6
```

Figure 347. Connection Menu after 3174 Becomes Active and Enter Pressed

Select **TN2370** by typing **6** on the command line and then press Enter.



```

Application Selection          Help: 17-6666 Term: RAKAE001
                              Date: 04/29/94 Time: 09:43:21
                              Broadcast:
Select application or enter command. Return to this panel using Escape key PA2
Issue commands in applications using Command key PF01 and Prefix #

  ID Name      Status M  B Jump Key Application Description
  1 NETV20    07:44      PA2  NPDA/NLDM NetView SA20 - RAKAN
  2 TS020    07:44      PA2  TSO on SA20 - RAKAT
  3 NRFAS4A                      PA2  NRF application on as/400
  4 NRFTEST                      PA2
  5 CICS1                      PA2  CICS V2.1 on SA20 - RAKAC001
  6 HONE                      PA2
  7 NETOPS03                      PA2  AUTO OPS NetView SA03 - RA3AO
  8 NETOPS18 07:44      PA2  AUTO OPS NetView SA18 - RAIAO
  9 NETOPS20 07:44      PA2  AUTO OPS NetView SA20 - RAKAO
 10 NETOPS25                      PA2  AUTO OPS NetView SA25 - RAIAO

To terminate all sessions use the LOGOFF command.

COMMAND ==> 2 _____
PF 1=Help  2=Language  3=Disconnect  4=Redefine Keys  7=Backward  8=Forward

```

Figure 350. Application Selection

On the Application Selection panel you select the application which you want work with. In our example we decided to work with TSO.

Type in **2** on the command line and press Enter; the TSO logon process is started.

```

ICH70001I FRAN      LAST ACCESS AT 09:45:43 ON FRIDAY, APRIL 29, 1994
IKJ56455I FRAN LOGON IN PROGRESS AT 09:45:56 ON APRIL 29, 1994
IKJ56951I NO BROADCAST MESSAGES
***

```

Figure 351. TSO Logon

After a successful TSO logon process, the ISPF/PDF PRIMARY OPTION MENU will appear.

```

                                ISPF/PDF PRIMARY OPTION MENU
OPTION  ==>>>
                                USERID   FRAN
0  ISPF PARMS  Specify terminal and user parameters  TIME   09:46
1  BROWSE      Display source data or output listings  ISPF   V3R5
2  EDIT        Create or change source data
3  UTILITIES   Perform utility functions
6  COMMAND     Enter TSO Command, CLIST, or REXX exec
8  SDSF        System Display and Search Facility
T  TUTORIAL    Display information about ISPF/PDF
D  DITTO       MVS DITTO
J  XMIT        Transmit / Receive
U  USER Util  NCP GEN, ACFTAP, Language foreground and batch
R  RACF        Resource Access Control Facility
H  HCD         Hardware Configuration Definition
S  SMP/E       SMP/E
X  EXIT        Terminate ISPF using log and list defaults

Enter END command to terminate ISPF.

F1=HELP      F2=SPLIT    F3=END      F4=RETURN   F5=RFIND    F6=RCHANGE
F7=UP        F8=DOWN     F9=SWAP    F10=LEFT   F11=RIGHT   F12=RETRIEVE

```

Figure 352. ISPF/PDF Primary Option Menu

```

                                ISPF/PDF PRIMARY OPTION MENU
OPTION  ==>>> 6
                                USERID   FRAN
0  ISPF PARMS  Specify terminal and user parameters  TIME   09:50
1  BROWSE      Display source data or output listings  ISPF   V3R5
2  EDIT        Create or change source data
3  UTILITIES   Perform utility functions
6  COMMAND     Enter TSO Command, CLIST, or REXX exec
8  SDSF        System Display and Search Facility
T  TUTORIAL    Display information about ISPF/PDF
D  DITTO       MVS DITTO
J  XMIT        Transmit / Receive
U  USER Util  NCP GEN, ACFTAP, Language foreground and batch
R  RACF        Resource Access Control Facility
H  HCD         Hardware Configuration Definition
S  SMP/E       SMP/E
X  EXIT        Terminate ISPF using log and list defaults

Enter END command to terminate ISPF.

F1=HELP      F2=SPLIT    F3=END      F4=RETURN   F5=RFIND    F6=RCHANGE
F7=UP        F8=DOWN     F9=SWAP    F10=LEFT   F11=RIGHT   F12=RETRIEVE

```

Figure 353. ISPF/PDF Primary Option Menu

To work with the TSO COMMAND PROCESSOR, type in **6** on the OPTION line and press Enter; the following panel appears.

```

----- TSO COMMAND PROCESSOR -----
ENTER TSO COMMAND, CLIST, OR REXX EXEC BELOW:

===>

F1=HELP    F2=SPLIT    F3=END      F4=RETURN   F5=RFIND    F6=RCHANGE
F7=UP      F8=DOWN     F9=SWAP    F10=LEFT   F11=RIGHT   F12=RETRIEVE

```

Figure 354. TSO Command Processor

```

----- TSO COMMAND PROCESSOR -----
ENTER TSO COMMAND, CLIST, OR REXX EXEC BELOW:

===> netstat devlinks

F1=HELP    F2=SPLIT    F3=END      F4=RETURN   F5=RFIND    F6=RCHANGE
F7=UP      F8=DOWN     F9=SWAP    F10=LEFT   F11=RIGHT   F12=RETRIEVE

```

Figure 355. TSO Command Processor

On this panel you are able to work with TSO commands. In our scenario we want to show what kind of information is available with the command **netstat devlinks**

On the arrow line type in **netstat devlinks** and press Enter. In our case, the result of this command is shown on the following panel.

```

----- TSO COMMAND PROCESSOR -----
ENTER TSO COMMAND, CLIST, OR REXX EXEC BELOW:

===> netstat devlinks

TCPNET267I MVS TCP/IP Netstat V2R2.1
TCPNET245I
TCPNET246I Device CH2EN2          Type: LCS           Status: Ready
TCPNET252I Queue size: 0          Address: 0EC0
TCPNET120I Link EN2              Type: ETHER|802.3  Net number: 1
TCPNET245I
TCPNET246I Device CH2TR2          Type: LCS           Status: Inactive
TCPNET252I Queue size: 0          Address: 0EC2
TCPNET120I Link TR2              Type: IBMTR        Net number: 1
TCPNET245I
TCPNET246I Device CTCD2025        Type: CTC           Status: Inactive
TCPNET252I Queue size: 0          Address: 0C04
TCPNET120I Link CTCL2025         Type: CTC           Net number: 1

```

Figure 356. netstat devlinks

On this panel the TCPNET status information is displayed.



## 9.13 Scenario 3 - TN3270 to CICS/6000

The purpose of this connectivity scenario is to describe how a 3174 coax-attached or ASCII terminal can communicate over an Ethernet-LAN to CICS/6000 as shown in Figure 357.




Figure 357. TN3270 to RS/6000 Host

### 9.13.1 Scenario Description

The test configuration consists of the following components:

- RS/6000 with AIX 3.2.3 and IP-address 9.67.32.73
- 3174-14R with an Ethernet adapter address 9.67.32.91
- PS/2s running DOS and OS/2 are not being used in this scenario.

### 9.13.2 TN3270 Customization

This section describes the entries to the customization that are needed to support the TN3270. If you are not familiar with customizing the 3174 for TCP/IP operation refer to *3174 Planning Guide*.

```

_____ AEA and TCP/IP Station Set _____

  721 - TN3270 _____ 722 - TH 723 - TN3270 725 - 1
731 - 1 732 - 1 733 - 0 734 - 735 - 0 736 - 1 737 -
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 6 752 -
761 - 1 762 - 1 763 - 0 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000 791 - 00000

  721 - _____ 722 - _____ 723 - _____ 725 - 1
731 - 1 732 - 1 733 - 0 734 - 735 - 0 736 - 1 737 -
741 - 000 742 - 015 743 - 1 744 - 0 745 - 0 746 - 0 0
751 - 2 752 -
761 - 1 762 - 1 763 - 1 764 - 1 765 - 0
771 - 1 772 - 1 773 - 1 774 - 1 775 - 1 776 - 1
781 - 0 782 - 0 783 - 066 784 - 1 785 - 11111000 786 - 132 787 - 0
790 - 000 . 000 . 000 . 000 791 - 00000

All responses are correct
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

```

Figure 358. AEA and TCP/IP Station Set Panel

To define the station set for TN3270 access, respond to the following questions:

- Q721** Enter **TN3270**, as this is the station set name that you wish displayed on the Connection Menu.
- Q722** Enter **TH** as the station type for the TCP/IP host.
- Q751** Specify **6** for the data stream supported by the TCP/IP host.

Press Enter and the PF8 key to continue with the customization.

### 9.13.3 Defining Default Destinations

```

_____ AEA and TCP/IP Default Destination _____

Station Set      Station Set Name      Session Limit      Session
                  Name                  LT1 LT2 LT3 LT4 LT5
1  3270 HOST          0      -- -- -- --
2  TELNET VT100      0      -- -- -- --
3  TELNET IBM3101    0      -- -- -- --
4  TELNET VT220 7 BIT 0      -- -- -- --
5  TELNET VT220 8 BIT 0      -- -- -- --
1  TN3270            0      -- -- -- --
7                                0      -- -- -- --
8                                0      -- -- -- --

PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd

```

Figure 359. AEA and TCP/IP Default Destination Panel

This panel determines what the terminal user will see on each LT when it is first accessed. Press the PF8 key, and the next panel appears.

### 9.13.4 Defining TCP/IP Options

```
_____ TCP/IP Options Menu _____  
  
3174 IP Address          052 - 009 . 067 . 032 . 091  
Subnet Mask             054 - 255 . 255 . 255 . 192  
  
Maximum TELNET Connections 058 - 020          (001 - 250)  
Maximum Printer Connections 059 - 005          (001 - 099)  
TCP/IP Buffer Space       060 - 0256 K      (K = 1024 bytes)  
  
Routing Field Support     062 - Y          (Y,N)  
All Routes Broadcast     064 - Y          (Y,N)  
  
PF: 3=Quit  4=Default  7=Back  8=Fwd
```

Figure 360. TCP/IP Options Menu

On this panel you define 3174 IP address and the corresponding Subnet Mask. After defining, press Enter and the PF8 key, the following panel is displayed.

### 9.13.5 Defining TCP/IP Routing Information

```
_____ TCP/IP Routing Information _____  
  
Destination IP Address   Type      Router IP Address  
                        (N, S, H, D)  
  
XXX . XXX . XXX . XXX   X         XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX   X         XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX   X         XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX   X         XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX   X         XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX   X         XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX   X         XXX . XXX . XXX . XXX  
XXX . XXX . XXX . XXX   X         XXX . XXX . XXX . XXX  
  
PF: 3=Quit  4=Default  7=Back  8=Fwd
```

Figure 361. TCP/IP Routing Information

In our scenario we do not use routers. Therefore, just press PF8 to continue to the next panel.

## 9.13.6 Defining Domain Name Services

```

_____ TCP/IP Domain Name Services _____

3174 Hostname
3174TCP1 1 _____

3174 Domain Name
ITSO RALEIGH IBM COM 2 _____
_____
_____

Domain Nameserver IP Addresses 3

XXX . XXX . XXX . XXX

XXX . XXX . XXX . XXX

XXX . XXX . XXX . XXX

XXX . XXX . XXX . XXX

PF: 3=Quit  4=Default  7=Back  8=Fwd

```

Figure 362. TCP/IP Domain Name Services

- 1 Is the name assigned to your 3174.
- 2 Is the domain in which your 3174 is in.
- 3 In our example, we have not defined a nameserver.

Press Enter and PF8, and the following panel appears.

## 9.13.7 Defining TCP/IP Nicknames

```

_____ TCP/IP 3174 Defined Nicknames _____

Nickname                IP Address

DOS _____          009 . 067 . 032 . 093
OS2 _____           009 . 067 . 032 . 094
AS400B _____        009 . 067 . 032 . 095
RS60001 _____       009 . 067 . 032 . 085
RS6KICIS _____    009 . 067 . 032 . 073
3174L _____         009 . 067 . 032 . 091
_____                 XXX . XXX . XXX . XXX
_____                 XXX . XXX . XXX . XXX
_____                 XXX . XXX . XXX . XXX
_____                 XXX . XXX . XXX . XXX
_____                 XXX . XXX . XXX . XXX
_____                 XXX . XXX . XXX . XXX
_____                 XXX . XXX . XXX . XXX

PF: 3=Quit  4=Default  7=Back  8=Fwd

```

Figure 363. TCP/IP 3174 Defined Nicknames

Since users remember names better than numeric IP addresses, this panel allows you to define up to 16 host nicknames and their associated IP addresses. In our scenario we defined **RS6KCICS** as the nickname. After defining the nickname, press Enter and PF8.

After you have completed the 3174 TCP/IP customization for TN3270, you have to reIML the 3174.

### 9.13.8 CICS/6000 Overview

CICS/6000 is the latest member of the CICS product family. It extends the distributed processing capabilities of CICS to the AIX environment. Like existing CICS products that run on the MVS, VSE, OS/2, and OS/400 platforms, CICS/6000 requires prerequisite products in order for it to function. In the case of CICS/6000 the prerequisite products are Distributed Computing Environment (DCE) and Encina. The name Encina is derived from Enterprise Computing in a New Age.

DCE is prerequisite to both CICS/6000 and Encina, because it provides a common infrastructure for distributed processing. CICS/6000 is the transaction monitor that enables transaction processing, resource management, and communication with other CICS family members.

For detailed information about the CICS/6000 environment refer to *AIX CICS/6000 Installation and Configuration: A Guide to Implementation, GG24-4091-00*.

### 9.13.9 CICS/6000 Environment

Before you are able to communicate with TN3270 from a 3174 CUT or ASCII terminal to CICS/6000 be sure that the following steps have been taken on the CICS/6000 system:

- Install the CICS/6000 products.
- Configure a region.
- Create users.
- Customize the environment.
- Define a separate CICS/6000 client machine.
- Enable access from remote machines through a TCP/IP LAN.

For a detailed description about this procedures refer to Chapter 4 of *AIX CICS/6000 Installation and Configuration: A Guide to Implementation, GG24-4091-00*.

### 9.13.10 CICS/6000 TELNET Server

CICS/6000 supplies a component called `cicsteld` (CICS telnet daemon). This component provides the telnet server services to telnet clients and communicates with CICS/6000 regions.




Figure 364. *cicsteld* Protocol

In our the scenario the telnet client is a 3270 coax-attached terminal.

### 9.13.11 TCP/IP Port Number

When the telnet client wants to attach to a telnet server, it must supply the hostname of the machine on which that server resides. It must also supply a port number, which distinguishes one TCP/IP service from another; see Figure 365 on page 346.

The TCP/IP protocol architects a set of **well-known** port numbers that are reserved for specific applications and services. When using a telnet client to contact a standard telnet server, you only need to supply the hostname of the server, as the telnet service port number is defined as **well-known** (port23).

The majority of telnet clients provide a mechanism to specify an alternative port number when connecting to a remote telnet server. This mechanism allows alternative servers to coexist on the same TCP/IP host without interfering with each other. This mechanism is used by `cicsteld`.




Figure 365. TCP/IP Port Number

You must select a port number for `cicsteld` registration, in our example we use 5001, that incoming telnet client requests will use to reach the `cicsteld` server.

After the configuration of `cicsteld` is finished, we are able to access the CICS/6000 region from the 3174 connection menu, using the `TN3270` command. For detailed information refer to Chapter 6 of *AIX CICS/6000 Installation and Configuration: A Guide to Implementation, GG24-4091-00*.

### 9.13.12 Connection Menu

The following panel shows you the Connection Menu after the 3174 becomes active. This menu represents the different TELNET emulations which are customized on the 3174.

```

Connection Menu
Enter a number (NUM) or a name on the Command Line, then press ENTER

NUM NAME                STATUS  NUM NAME                STATUS
1 TN3270                 Up      2 TELNET VT100           UP
3 TELNET IBM3101         Up      4 TELNET VT220 7 BIT     Up
5 TELNET VT220 8 BIT     Up      6 TN3270                 Up

PF: 3=End      6=Terminal Disconnect    12=Host Disconnect

=====>>To: 6

```

Figure 366. Connection Menu after 3174 Becomes Active and Enter pressed

Select TN2370 by typing `6` on the command line and press Enter.

```
3174 TELNET> open rs6kcics 5001
Attempting connection to 9.67.32.73
Connected to 9.67.32.73
```

*Figure 367. TELNET Local Mode*

At the TELNET prompt type **open rs6kcics 5001** and press Enter. Instead of the IP-destination address, we use the RS/6000 nickname, which was customized.

While attempting to establish a connection to a CICS/6000 region, the following messages will appear, one after another, on the upper line of your screen.

```
ERZ1824T/0031: Checking supplied user identify 'telduser'.
```

```
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd
```

*Figure 368. Checking User*

```
ERZ1814I/0011: Searching for available regions.
```

```
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd
```

*Figure 369. Searching Available Regions*

Available CICS Regions

Move cursor to desired item and press <ENTER>

REGION	Description
<b>itso</b>	Region Definition

PF3=Exit

*Figure 370. Available CICS Regions*

On this screen, the available CICS regions are displayed. Move the cursor to the desired region and press Enter. In our example, we have defined only the region **itso**



```
ERZ18151/0013: Connect to region 'itso'.  
  
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd
```

Figure 371. Connect to Region

After the successful connection to the selected region, you are able to run different commands to start CICS-supplied transactions.

For detailed information about these commands refer to *AIX CICS/6000 Customization and Operation, Release 1, SC33-0931-01*.

**CESN Command**

This is a CICS-supplied transaction that enables users to sign on to the CICS system.

Run the following command:

CESN

the CICS Signon Screen is displayed.

**9.13.13 CICS Signon Screen**

```
CESN - CICS SIGNON - ENTER USERID AND PASSWORD  
  
USERID:  
  
PASSWORD:  
  
PF: 3=Quit 4=Default 7=Back 8=Fwd 10=Page Back 11=Page Fwd
```

Figure 372. CESN - CICS Signon Screen

On this screen, Enter your CICS user ID and password to sign on to a CICS/6000 session.

## CEMT Command

This is a CICS-supplied transaction that invokes all the master terminal functions. These functions include inquiring and changing the value of parameters used by CICS, altering the status of system resources, and terminating tasks.

Run the following command:

```
CEMT INQUIRE TASK
```

The following panel appears.

```
INQUIRE TASK
STATUS: RESULTS - OVERTYPE TO MODIFY

Tas(      14) Tc1(001) Tra(CEMT) Fac(RT00) Run Inf Ter
User(te\duser)

APPLID=itso

RESPONSE: NORMAL
PF 1 HELP      3 END

7 SBH 8 SFH 9 MSG 10 SB 11 SF
```

Figure 373. Inquire Task

### 9.13.14 Working with Your CICS/6000 Region

Now that your CICS/6000 region is running, you may want to customize your environment to better support the existing terminals in your system configuration.

The following customization steps should be done on your CICS/6000 system:

- Specify a 3270 configuration.
- Modify a 3270 configuration.
- Access CICS/6000 from a remote machine.
- Use the screen design aid tool.

For a detailed description about these topics go to Chapter 7 of *AIX CICS/6000 Installation and Configuration: A Guide to Implementation*, GG24-4091-00.

### Configuring a Client for a TCP/IP Network

The first step in configuring a client for a TCP/IP network is to ensure that the client has a network interface card (NIC) installed and configured correctly. The NIC must be compatible with the network hardware and software being used.

#### Configuring the Network Interface Card (NIC)

There are several steps to configuring a NIC. First, you must identify the NIC's hardware address (MAC address). This address is unique to each NIC and is used to identify the device on the network. Next, you must configure the IP address and subnet mask for the NIC. This information is used to route traffic to and from the device. Finally, you must configure the default gateway, which is the IP address of the router that connects the local network to the Internet.

#### Configuring the Operating System

Once the NIC is configured, you must configure the operating system to use the network. This involves installing and configuring the TCP/IP stack. The TCP/IP stack is a set of protocols that allow devices to communicate over a network. It consists of several layers, including the application layer, the transport layer, the network layer, and the link layer. Each layer has its own set of protocols and functions.

#### Configuring the Network Software

Finally, you must configure the network software on the client. This includes installing and configuring the network client software, such as the Network Manager or the Network Configuration Utility. This software allows you to manage the network configuration and troubleshoot any problems that may arise.

#### Configuring the Network Services

Once the network is configured, you must configure the network services that you want to use. This includes configuring the DNS, DHCP, and other services. The DNS is used to resolve domain names into IP addresses. DHCP is used to automatically assign IP addresses to devices on the network. Other services, such as FTP and Telnet, are used to access remote resources.

#### Configuring the Network Security

Finally, you must configure the network security. This includes configuring firewalls, intrusion detection systems, and other security measures. These measures help to protect the network from unauthorized access and data theft. It is important to regularly update and maintain these security measures to ensure the network remains secure.

## Chapter 10. 3174 Configuration Support C, Release 5

The new functions added in Release C5 fall into four categories:

- Enhancements to APPN
- Addition of the Frame Relay Communication Feature
- The inclusion of several RPQs as base function
- Miscellaneous enhancements

This chapter describes mainly the 3174 TCP/IP traffic function over the Frame Relay Communications feature.




Figure 374. 3174 Frame Relay Communications Feature

With the addition of the Frame Relay interface, the 3174 expands the networking opportunities for interconnecting multiple protocols at speeds up to 256 Kbps. 3174 protocols, such as SNA PU2.0, APPN, LAN Gateway, and TCP/IP, are supported by the Frame Relay Communications feature.

A major application of 3174 Frame Relay support is the interconnection of token-ring LANs across a WAN that requires higher speed access. With source-route remote bridge support, the 3174 can communicate over private or public Frame Relay networks, bridging a token-ring workstation attached to the 3174 across a Frame Relay network to another token-ring workstation.

**Note:**

Frame relay remote bridge is not available in Configuration Support-C Release 5. The frame relay remote bridge function is planned for late 1994.

You can create hybrid networks where private and public networks are used (as available) with a single network interface. This will allow you to efficiently and economically expand your business network across town, or across country, while using higher communication speeds.

---

## 10.1 Multiprotocol Frame Relay

The 3174 Frame Relay Communications feature, along with other IBM products, such as the 6611, 3745, 3172, RouteXpander/2, and AS/400, support RFC 1490 (updated 1294 RFC), a multiprotocol interconnect standard for Frame Relay. This standard establishes a format for transport across a Frame Relay network, so that any other device that meets this standard can read all traffic sent into the network.

---

## 10.2 DLCI

The 3174 can support up to 250 Data Link Connection Identifiers (DLCIs) with a single access to a private or public Frame Relay network. Multiple DLCIs are allowed for each protocol type supported, as well as multiple protocols via one DLCI. The Local Management Interface (LMI), which provides status inquiries between the 3174 and the Frame Relay network, is supported for LMI Rev1, Annex D, and CCITT formats.

---

## 10.3 IP Support

The IP support of Frame Relay allows coax and ASCII terminal users to log on to TCP/IP hosts as TELNET clients over a WAN. The TELNET sessions can co-exist with existing 3270 or ASCII host sessions using the Multiple Logical Terminal function. Other basic protocols such as ICMP, UDP and SNMP, are also supported. For IP traffic, the 3174 uses InARP (Inverse ARP) when each DLCI becomes active to determine the remote device's IP address. The 3174 requires its remote partners to reply to InARP requests if they want to talk with the 3174 over Frame Relay.

---

## 10.4 Interoperability

TCP/IP on the 3174 can use a Frame Relay network to a TCP/IP host or IP router, such as a 6611 or a 3745 using the Frame Relay Handler support in NCP.

---

## 10.5 Migration - Coexistence

All functions in the previous C releases can coexist with the C5 functions. You can upgrade an existing 3174 to C5 and not lose any current function given you have installed the memory required to handle all the desired function.

Although C4 allowed Ethernet configurations, but not token-ring configurations, C5 allows either one to be configured.





## 10.6.4 Frame Relay Description Panel Layout

This is what the panel looks like that describes the connection parameters to a Frame Relay network.

```

                                Frame Relay
          IA = PRIMARY FR HOST LINK                                00/FR

300 - _ Enable Frame Relay (0-No, 1-Yes)
313 - 0 NRZI (0-NRZ, 1-NRZI)

552 - 050 Maximum Number of DLCIs (001-254)                    - 0 0

554 - _ Committed Information Rate (002048-256000)

558 - 0 Congestion control (0-No Support/1-Support)
560 - 0 DE Bit Support (0-No Support/1-Support)
562 - 3 LMI Type (2-LMI Rev-1, 3-Annex-D, 5-CCITT)
563 - 10 LMI Transmit Polling Interval (1-30)
563 - 10 LMI Receive Polling Interval (5-30)
566 - 0000 Additional Receive Buffer Space (0000-1024)

PF: 3=Quit 4=Default 7=Back 8=Fwd 9=RtnH
```

Figure 378. Frame Relay Description

### Question 300: Enable Frame Relay (over communication adapter)

This is a flag to indicate if Frame Relay should be enabled over the communication adapter.

Response:

\_ = do not enable

0 = do not enable

1 = enable

Default:

underscore

### Question 552: Maximum Number of DLCIs

This is the maximum number of DLCIs that will be allowed for particular physical connection to an FR network.

Response:

1-254 (decimal) for programmable communication adapter

Default:

050

### Question 554: Committed Information Rate

This is the maximum bits per second that an FR service provider agrees to carry for a DLCI. This number is determined at the time of subscription to the network.

Response:

2048-256000 decimal.



**Question 558: Frame Relay Congestion Control**

This is a 1 digit field to indicate if you want the 3174 to employ congestion control procedures when there is congestion in the network.

Response:

0 = Continue to transmit frames even if network is congested  
1 = Discard frames queued for transmission if the network is congested

Default:

0

**Question 560: Discard Eligibility (DE) Bit Support**

The DE bit is used to indicate if frames are eligible to be discarded when the network becomes congested.

Response:

0 = DE bit is never turned on in frames transmitted by the 3174.  
1 = DE bit is on in data frames transmitted by the 3174.

Default:

0 = DE off

**Question 562: Local Management Interface (LMI) Type**

This is the type of LMI that is active in the Frame Relay network. It should be determined when you subscribe to a Frame Relay service.

Response:

2 = LMI Rev 1 (DLCI 1023)  
3 = Annex D (DLCI 0)  
5 = CCITT (DLCI 0)

Default:

3 = Annex D

**Question 563: LMI Transmit Polling Interval**

This is the interval (in seconds) between LMI STATUS ENQUIRY message transmission. This is also known as the T391 timer value parameter, and should be set according to the recommendations of the Frame Relay service provider.

Response:

1 - 29 seconds (decimal)  
This should be determined when you subscribe to Frame Relay service provider.

Default:

10

**Question 564: LMI Receive Polling Interval**

The number of seconds between STATUS ENQUIRY messages expected from the network. If no STATUS ENQUIRY messages are received in the number of seconds specified, then an error is logged. This is also known as the T392 parameter.

Response:

5 - 30 seconds (decimal)

This should be determined when you subscribe to Frame Relay service provider.

Default:

15

#### Question 566: Additional Receive Buffer Space

The number of additional bytes of storage allocated for receiving frames.

Response:

0 - 1024 KB of storage (decimal)

Default:

00

#### Note:

Increase the amount of buffer space when:

- You have a large amount of Frame Relay frame fragmentation.
- You see an excessive number of Generic Alerts being issued for buffer pool empty conditions.

### 10.6.5 Customization Error Messages

SSC	Description	Action
7670	Maximum Number of DLCIs must be greater than or equal to the total number of DLCIs defined on the 3174.	Correct total or individual counts and retry.
7666	Q554 must be non-zero when Q300 is 1.	Correct Q554 or Q300 and retry.
7667	Q564 must be greater than Q563.	Correct Q564 and/or Q563 and retry.
7668	Q300 must be 1 when host attach is Frame Relay	Correct Q300 or Host Attach (Q101) and retry.
7669	DLCI number/SAP combination must be unique across all hosts.	Correct duplicate addresses in Q090 and retry.



## Appendix A. Address Bit Order for Ethernet Addresses

This appendix provides information about Ethernet addresses and address bit conversions. An Ethernet address is characterized by a value of 0 for the universal/local bit. Figure B-1 shows the structure of an Ethernet address.




Figure 379. B-1. Ethernet Address

### Hexadecimal Representation of Addresses

For any universally administered LAN address, there are two possible hexadecimal representations: non-canonical, in which octet contains the most significant bit first, or canonical, in which each byte contains the least significant bit first. If the representation type being used is not specified, the address can easily be misinterpreted.

Figure B-2 shows an example of an address, displayed in bit form as it would be transmitted, with the leftmost bit (individual/group bit) transmitted first.




Figure 380. B-2. Example of Address with the Leftmost Bit Transmitted First

Using this example, the non-canonical hexadecimal representation (most significant bit first) is:

10 00 5A 0F 74 A8

Using the same example, the canonical hexadecimal representation (least significant bit first) is:

08 00 5A F0 2E 15

**Note:** These two examples are different representations of the same address. The major difference is the order of the bits within bytes. The byte order does not vary.

Non-canonical hexadecimal representation is the form that must be used when you specify LAN address during the customization of the 3174.

Canonical hexadecimal representation is the form typically used for Ethernet and is usually written with a hyphen (-) separating each byte. Ethernet addresses using the canonical representation need to be converted to a non-canonical form

before customizing the 3174. For more information about converting addresses from a canonical to a non-canonical form of hexadecimal representation, see "Address Conversion" on page 360.

### Address Conversion

Because the 3174 requires LAN addresses to be customized in a non-canonical form, addresses written in canonical form must be converted to non-canonical form before customization.

Use the following procedure, the Address Conversion Worksheet, and Table 1 to convert an address. For an example of how to convert an address, see "Example of Converting an Address" on page B-3.


1. Write the 12-digit address on the Address Conversion Worksheet.
2. Separate the 12-digit into pairs. Use the first digit of each pair as the row coordinate and the second digit as the column coordinate.
3. Locate a bit order inverted pair in Table 1 for each pair you wrote on the worksheet.
4. Combine the six pairs from the table into the converted 12-digit address.

*Table 14. Address Conversion Table*

2nd Char. (Col.) → 1st Char. ↓ (Row)	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	00	80	40	C0	20	A0	60	E0	10	90	05	D0	30	B0	70	F0
1	08	88	48	C8	28	A8	68	E8	18	98	58	D8	38	B8	78	F8
2	04	84	44	C4	24	A4	64	E4	14	94	54	D4	34	B4	74	F4
3	0C	8C	4C	CC	2C	AC	6C	EC	1C	9C	5C	DC	3C	BC	7C	FC
4	02	82	42	C2	22	A2	62	E2	12	92	52	D2	32	B2	72	F2
5	0A	8A	4A	CA	2A	AA	6A	EA	1A	9A	5A	DA	3A	BA	7A	FA
6	06	86	46	C6	26	A6	66	E6	16	96	56	D6	36	B6	76	F6
7	0E	8E	4E	CE	2E	AE	6E	EE	1E	9E	5E	DE	3E	BE	7E	FE
8	01	81	41	C1	21	A1	61	E1	11	91	51	D1	31	B1	71	F1
9	09	89	49	C9	29	A9	69	E9	19	99	59	D9	39	B9	79	F9
A	05	85	45	C5	25	A5	65	E5	15	95	55	D5	35	B5	75	F5
B	0D	8D	4D	CD	2D	AD	6D	ED	1D	9D	5D	DD	3D	BD	7D	FD
C	03	83	43	C3	23	A3	63	E3	13	93	53	D3	33	B3	73	F3
D	0B	8B	4B	CB	2B	AB	6B	EB	1B	9B	5B	DB	3B	BB	7B	FB
E	07	87	47	C7	27	A7	67	E7	17	97	57	D7	37	B7	77	F7
F	0F	8F	4F	CF	2F	AF	6F	EF	1F	9F	5F	DF	3F	BF	7F	FF

### Address Conversion Worksheet

The following sheet can be used for converting addresses.



### Example of converting an Address

Figure B-3 shows how a bit-inverted Ethernet address of 10-00-5A-4D-BC-96 is converted into a non-canonical hexadecimal representation.

The same process is used to convert a non-canonical address to a canonical address hexadecimal representation.




Figure 381. B-3. An Example of How an Ethernet Address is Converted



## Appendix B. SNMP Variables

The 3174 supports the MIB-II variables shown in the following table. In the notes, "Qxxx" refers to customization question xxx.

Variable Name	ASN1 Notation	Notes about the 3174's version of the variable
system	1.3.6.1.2.1.1	Only accepted on a GET_NEXT request.
sysDescr.0	1.3.6.1.2.1.1.1.0	"3174-mmm, ID cccccc, LIC nnnnn-ddddd" <b>mmm</b> 3174 model -- for example, 13R <b>ccccc</b> the controller ID from Q108 <b>nnnnn</b> The microcode configuration, level and suffix -- for example C0300 <b>dddd</b> The maintenance level -- for example 92340
sysObjectID.0	1.3.6.1.2.1.1.2.0	The 3174's ID is 1.3.6.1.4.1.2.6.13
sysUpTime.0	1.3.6.1.2.1.1.3.0	
sysContact.0	1.3.6.1.2.1.1.4.0	Response to Q099.
sysName.0	1.3.6.1.2.1.1.5.0	3174's host name, appended to the domain name, from Domain Name Services panel.
sysLocation.0	1.3.6.1.2.1.1.6.0	Data entered via online test, (/5,2)
sysServices.0	1.3.6.1.2.1.1.7.0	8
interfaces	1.3.6.1.2.1.2	Only accepted on a GET_NEXT request.
ifNumber.0	1.3.6.1.2.1.2.1.0	This is 1 for the 3174, as TCP/IP is supported on only one interface.
ifTable	1.3.6.1.2.1.2.2	Only accepted on a GET_NEXT request.
ifEntry	1.3.6.1.2.1.2.2.1	Only accepted on a GET_NEXT request.
ifIndex.1	1.3.6.1.2.1.2.2.1.1.1	This is 1.
ifDescr.1	1.3.6.1.2.1.2.2.1.2.1	"IBM 3174 Token-Ring Network Adapter" or "IBM 3174 Ethernet LAN Adapter"
ifType.1	1.3.6.1.2.1.2.2.1.3.1	<ul style="list-style-type: none"> <li>• 9 - for Token/Ring,</li> <li>• 6 - Ethernet V2</li> <li>• 7 - 802.3 or both 802.3 and V2</li> </ul>
ifMtu.1	1.3.6.1.2.1.2.2.1.4.1	1492
ifSpeed.1	1.3.6.1.2.1.2.2.1.5.1	4M or 16M, for T/R 10M for Ethernet



Variable Name	ASN1 Notation	Notes about the 3174's version of the variable
ifPhysAddress.1	1.3.6.1.2.1.2.2.1.6.1	This is the reply to Q080 (token-ring) or Q084 (Ethernet)
ifAdminStatus.1	1.3.6.1.2.1.2.2.1.7.1	
ifOperStatus.1	1.3.6.1.2.1.2.2.1.8.1	
ifLastChange.1	1.3.6.1.2.1.2.2.1.9.1	
ifInOctets.1	1.3.6.1.2.1.2.2.1.10.1	
ifInUcastPkts.1	1.3.6.1.2.1.2.2.1.11.1	
ifInNUcastPkts.1	1.3.6.1.2.1.2.2.1.12.1	
ifInDiscards.1	1.3.6.1.2.1.2.2.1.13.1	
ifInErrors.1	1.3.6.1.2.1.2.2.1.14.1	
ifInUnknownProtos.1	1.3.6.1.2.1.2.2.1.15.1	
ifOutOctets.1	1.3.6.1.2.1.2.2.1.16.1	
ifOutUcastPkts.1	1.3.6.1.2.1.2.2.1.17.1	
ifOutNUcastPkts.1	1.3.6.1.2.1.2.2.1.18.1	
ifOutDiscards.1	1.3.6.1.2.1.2.2.1.19.1	
ifOutErrors.1	1.3.6.1.2.1.2.2.1.20.1	
ifOutQLen.1	1.3.6.1.2.1.2.2.1.21.1	
ifSpecific.1	1.3.6.1.2.1.2.2.1.22.1	1.3.6.1.2.1.10.9 for Token-Ring 1.3.6.1.2.1.10.7 for Ethernet
at	1.3.6.1.2.1.3	Only accepted on a GET_NEXT request.
atTable	1.3.6.1.2.1.3.1	Only accepted on a GET_NEXT request.
atEntry	1.3.6.1.2.1.3.1.1	Only accepted on a GET_NEXT request.
atIfIndex.1.1.IPAddr	1.3.6.1.2.1.3.1.1.1.1.n.n.n.n	"n.n.n.n" = IP address
atPhysAddress.1.1.IPAddr	1.3.6.1.2.1.3.1.1.2.1.1.n.n.n.n	
atNetAddress.1.1.IPAddr	1.3.6.1.2.1.3.1.1.3.1.1.n.n.n.n	
ip	1.3.6.1.2.1.4	Only accepted on a GET_NEXT request.
ipForwarding.0	1.3.6.1.2.1.4.1.0	3174 does not operate as a Gateway, so this variable is 2.
ipDefaultTTL.0	1.3.6.1.2.1.4.2.0	30
ipInReceives.0	1.3.6.1.2.1.4.3.0	
ipInHdrErrors.0	1.3.6.1.2.1.4.4.0	
ipInAddrErrors.0	1.3.6.1.2.1.4.5.0	
ipForwDatagrams.0	1.3.6.1.2.1.4.6.0	Since the 3174 does not operate as a gateway, this is 0.
ipInUnknownProtos.0	1.3.6.1.2.1.4.7.0	
ipInDiscards.0	1.3.6.1.2.1.4.8.0	
ipInDelivers.0	1.3.6.1.2.1.4.9.0	
ipOutRequests.0	1.3.6.1.2.1.4.10.0	

Variable Name	ASN1 Notation	Notes about the 3174's version of the variable
ipOutDiscards.0	1.3.6.1.2.1.4.11.0	
ipOutNoRoutes.0	1.3.6.1.2.1.4.12.0	
ipReasmTimeout.0	1.3.6.1.2.1.4.13.0	
ipReasmReqds.0	1.3.6.1.2.1.4.14.0	
ipReasmOKs.0	1.3.6.1.2.1.4.15.0	
ipReasmFails.0	1.3.6.1.2.1.4.16.0	
ipFragOKs.0	1.3.6.1.2.1.4.17.0	
ipFragFails.0	1.3.6.1.2.1.4.18.0	
ipFragCreates.0	1.3.6.1.2.1.4.19.0	
ipAddrTable	1.3.6.1.2.1.4.20	Only accepted on a GET_NEXT request.
ipAddrEntry	1.3.6.1.2.1.4.20.1	Only accepted on a GET_NEXT request.
ipAdEntAddr.IPAddr	1.3.6.1.2.1.4.20.1.1.n.n.n.n	
ipAdEntIfIndex.IPAddr	1.3.6.1.2.1.4.20.1.2.n.n.n.n	
ipAdEntNetMask.IPAddr	1.3.6.1.2.1.4.20.1.3.n.n.n.n	
ipAdEntBcastAddr.IPAddr	1.3.6.1.2.1.4.20.1.4.n.n.n.n	1
ipAdEntReasmMaxSize.IPAddr	1.3.6.1.2.1.4.20.1.5.n.n.n.n	65535
ipRoutingTable	1.3.6.1.2.1.4.21	Only accepted on a GET_NEXT request.
ipRouteEntry	1.3.6.1.2.1.4.21.1	Only accepted on a GET_NEXT request.
ipRouteDest.IPAddr	1.3.6.1.2.1.4.21.1.1.n.n.n.n	
ipRouteIfIndex.IPAddr	1.3.6.1.2.1.4.21.1.2.n.n.n.n	
ipRouteMetric1.IPAddr	1.3.6.1.2.1.4.21.1.3.n.n.n.n	-1
ipRouteMetric2.IPAddr	1.3.6.1.2.1.4.21.1.4.n.n.n.n	-1
ipRouteMetric3.IPAddr	1.3.6.1.2.1.4.21.1.5.n.n.n.n	-1
ipRouteMetric4.IPAddr	1.3.6.1.2.1.4.21.1.6.n.n.n.n	-1
ipRouteNextHop.IPAddr	1.3.6.1.2.1.4.21.1.7.n.n.n.n	
ipRouteType.IPAddr	1.3.6.1.2.1.4.21.1.8.n.n.n.n	1
ipRouteProto.IPAddr	1.3.6.1.2.1.4.21.1.9.n.n.n.n	2 customized routes 4 routes determined from ICMP redirects
ipRouteAge.IPAddr	1.3.6.1.2.1.4.21.1.10.n.n.n.n	0 (The 3174 does not track the age of Route table entries.)

Variable Name	ASN1 Notation	Notes about the 3174's version of the variable
ipRouteMask.IPAddr	1.3.6.1.2.1.4.21.1.11.n.n.n.n	<b>0.0.0.0</b> Host routes <b>Customized Subnet Mask</b> Destinations on the 3174's network <b>255.0.0.0</b> Destinations on class A networks <b>255.255.0.0</b> Destinations on class B networks <b>255.255.255.0</b> Destinations on class C networks
ipRouteMetric5.IPAddr	1.3.6.1.2.1.4.21.1.12.n.n.n.n	-1
ipRouteInfo.IPAddr	1.3.6.1.2.1.4.21.1.13.n.n.n.n	0.0
ipNetToMediaTable	1.3.6.1.2.1.4.22	Only accepted on a GET_NEXT request.
ipNetToMediaEntry	1.3.6.1.2.1.4.22.1	Only accepted on a GET_NEXT request.
ipNetToMediaIflIndex.1.1.IPAddr	1.3.6.1.2.1.4.22.1.1.1.1.n.n.n.n	"n.n.n.n" = IP address
ipNetToMediaPhysAddress.1.1.IPAddr	1.3.6.1.2.1.4.22.1.2.1.1.n.n.n.n	
ipNetToMediaNetAddress.1.1.IPAddr	1.3.6.1.2.1.4.22.1.3.1.1.n.n.n.n	
ipNetToMediaType.1.1.IPAddr	1.3.6.1.2.1.4.22.1.4.1.1.n.n.n.n	
ipRoutingDiscards.0	1.3.6.1.2.1.4.23.0	
icmp	1.3.6.1.2.1.5	Only accepted on a GET_NEXT request.
icmpInMsgs.0	1.3.6.1.2.1.5.1.0	
icmpInErrors.0	1.3.6.1.2.1.5.2.0	
icmpInDestUnreachs.0	1.3.6.1.2.1.5.3.0	
icmpInTimeExcds.0	1.3.6.1.2.1.5.4.0	
icmpInParmProbs.0	1.3.6.1.2.1.5.5.0	
icmpInSrcQuenchs.0	1.3.6.1.2.1.5.6.0	
icmpInRedirects.0	1.3.6.1.2.1.5.7.0	
icmpInEchos.0	1.3.6.1.2.1.5.8.0	
icmpInEchoReps.0	1.3.6.1.2.1.5.9.0	
icmpInTimestamps.0	1.3.6.1.2.1.5.10.0	
icmpInTimestampReps.0	1.3.6.1.2.1.5.11.0	
icmpInAddrMasks.0	1.3.6.1.2.1.5.12.0	
icmpInAddrMaskReps.0	1.3.6.1.2.1.5.13.0	
icmpOutMsgs.0	1.3.6.1.2.1.5.14.0	
icmpOutErrors.0	1.3.6.1.2.1.5.15.0	
icmpOutDestUnreachs.0	1.3.6.1.2.1.5.16.0	
icmpOutTimeExcds.0	1.3.6.1.2.1.5.17.0	
icmpOutParmProbs.0	1.3.6.1.2.1.5.18.0	

Variable Name	ASN1 Notation	Notes about the 3174's version of the variable
icmpOutSrcQuenchs.0	1.3.6.1.2.1.5.19.0	
icmpOutRedirects.0	1.3.6.1.2.1.5.20.0	
icmpOutEchos.0	1.3.6.1.2.1.5.21.0	
icmpOutEchoReps.0	1.3.6.1.2.1.5.22.0	
icmpOutTimestamps.0	1.3.6.1.2.1.5.23.0	
icmpOutTimestampReps.0	1.3.6.1.2.1.5.24.0	
icmpOutAddrMasks.0	1.3.6.1.2.1.5.25.0	
icmpOutAddrMaskReps.0	1.3.6.1.2.1.5.26.0	
tcp	1.3.6.1.2.1.6	Only accepted on a GET_NEXT request.
tcpRtoAlgorithm.0	1.3.6.1.2.1.6.1.0	4 (Van Jacobson's algorithm)
tcpRtoMin.0	1.3.6.1.2.1.6.2.0	2000
tcpRtoMax.0	1.3.6.1.2.1.6.3.0	128000
tcpMaxConn.0	1.3.6.1.2.1.6.4.0	Sum of responses to Q058 and Q059
tcpActiveOpens.0	1.3.6.1.2.1.6.5.0	
tcpPassiveOpens.0	1.3.6.1.2.1.6.6.0	
tcpAttemptFails.0	1.3.6.1.2.1.6.7.0	
tcpEstabResets.0	1.3.6.1.2.1.6.8.0	
tcpCurrEstab.0	1.3.6.1.2.1.6.9.0	
tcpInSegs.0	1.3.6.1.2.1.6.10.0	
tcpOutSegs.0	1.3.6.1.2.1.6.11.0	
tcpRetransSegs.0	1.3.6.1.2.1.6.12.0	
tcpConnTable	1.3.6.1.2.1.6.13	Only accepted on a GET_NEXT request.
tcpConnEntry	1.3.6.1.2.1.6.13.1	Only accepted on a GET_NEXT request.
tcpConnState.connid	1.3.6.1.2.1.6.13.1.1.connid	"connid" = local_IPaddr. local_port. remote_IPaddr. remote_port
tcpConnLocalAddress.connid	1.3.6.1.2.1.6.13.1.2.connid	
tcpConnLocalPort.connid	1.3.6.1.2.1.6.13.1.3.connid	
tcpConnRemAddress.connid	1.3.6.1.2.1.6.13.1.4.connid	
tcpConnRemPort.connid	1.3.6.1.2.1.6.13.1.5.connid	
tcpInErrs.0	1.3.6.1.2.1.6.14.0	
tcpOutRsts.0	1.3.6.1.2.1.6.15.0	
udp	1.3.6.1.2.1.7	Only accepted on a GET_NEXT request.
udpInDatagrams.0	1.3.6.1.2.1.7.1.0	
udpNoPorts.0	1.3.6.1.2.1.7.2.0	
udpInErrors.0	1.3.6.1.2.1.7.3.0	

Variable Name	ASN1 Notation	Notes about the 3174's version of the variable
udpOutDatagrams.0	1.3.6.1.2.1.7.4.0	
udpTable	1.3.6.1.2.1.7.5	Only accepted on a GET_NEXT request.
udpEntry	1.3.6.1.2.1.7.5.1	Only accepted on a GET_NEXT request.
udpLocalAddress.connid	1.3.6.1.2.1.7.5.1.1.connid	"connid" = local_IPaddr. local_port.
udpLocalPort.connid	1.3.6.1.2.1.7.5.1.2.connid	"connid" = local_IPaddr. local_port.
transmission	1.3.6.1.2.1.10	Only accepted on a GET_NEXT request
dot3	1.3.6.1.2.1.10.7	Only accepted on a GET_NEXT request
dot3StatsTable	1.3.6.1.2.1.10.7.2	Only accepted on a GET_NEXT request
dot3StatsEntry	1.3.6.1.2.1.10.7.2.1	Only accepted on a GET_NEXT request
dot3StatsIndex	1.3.6.1.2.1.10.7.2.1.1.ifindex	"ifindex" = the index of the interface. This is 1.
dot3StatsAlignmentErrors	1.3.6.1.2.1.10.7.2.1.2.ifindex	
dot3StatsFCSErrors	1.3.6.1.2.1.10.7.2.1.3.ifindex	
dot3StatsSingleCollisionFrames	1.3.6.1.2.1.10.7.2.1.4.ifindex	
dot3StatsMultipleCollisionFrames	1.3.6.1.2.1.10.7.2.1.5.ifindex	
dot3StatsSQETestErrors	1.3.6.1.2.1.10.7.2.1.6.ifindex	
dot3StatsDeferredTransmissions	1.3.6.1.2.1.10.7.2.1.7.ifindex	Not supported
dot3StatsLateCollisions	1.3.6.1.2.1.10.7.2.1.8.ifindex	
dot3StatsExcessiveCollisions	1.3.6.1.2.1.10.7.2.1.9.ifindex	
dot3StatsInternalMacTransmit-Errors	1.3.6.1.2.1.10.7.2.1.10.ifindex	
dot3StatsCarrierSenseErrors	1.3.6.1.2.1.10.7.2.1.11.ifindex	
dot3StatsFrameTooLongs	1.3.6.1.2.1.10.7.2.1.13.ifindex	
dot3StatsInternalMacReceive-Errors	1.3.6.1.2.1.10.7.2.1.16.ifindex	
dot5	1.3.6.1.2.1.10.9	Only accepted on a GET_NEXT request
dot5Table	1.3.6.1.2.1.10.9.1	Only accepted on a GET_NEXT request
dot5Entry	1.3.6.1.2.1.10.9.1.1	Only accepted on a GET_NEXT request
dot5IfIndex	1.3.6.1.2.1.10.9.1.1.1.ifindex	"ifindex" = the index of the interface. This is 1.
dot5Commands	1.3.6.1.2.1.10.9.1.1.2.ifindex	1 (no-op)
dot5RingStatus	1.3.6.1.2.1.10.9.1.1.3.ifindex	

Variable Name	ASN1 Notation	Notes about the 3174's version of the variable
dot5RingState	1.3.6.1.2.1.10.9.1.1.4.ifindex	
dot5OpenStatus	1.3.6.1.2.1.10.9.1.1.5.ifindex	
dot5RingSpeed	1.3.6.1.2.1.10.9.1.1.6.ifindex	3 if customized for 4M, or 4 if customized for 16M
dot5Upstream	1.3.6.1.2.1.10.9.1.1.7.ifindex	
dot5ActMonParticipate	1.3.6.1.2.1.10.9.1.1.8.ifindex	2 (false)
dot5Functional	1.3.6.1.2.1.10.9.1.1.9.ifindex	
dot5StatsTable	1.3.6.1.2.1.10.9.2	
dot5StatsEntry	1.3.6.1.2.1.10.9.2.1	
dot5StatsIfIndex	1.3.6.1.2.1.10.9.2.1.1.ifindex	"ifindex" = the index of the interface. This is 1.
dot5StatsLineErrors	1.3.6.1.2.1.10.9.2.1.2.ifindex	
dot5StatsBurstErrors	1.3.6.1.2.1.10.9.2.1.3.ifindex	
dot5StatsACErrors	1.3.6.1.2.1.10.9.2.1.4.ifindex	
dot5StatsAbortTransErrors	1.3.6.1.2.1.10.9.2.1.5.ifindex	
dot5StatsInternalErrors	1.3.6.1.2.1.10.9.2.1.6.ifindex	
dot5StatsLostFrameErrors	1.3.6.1.2.1.10.9.2.1.7.ifindex	
dot5StatsReceiveCongestions	1.3.6.1.2.1.10.9.2.1.8.ifindex	
dot5StatsFrameCopiedErrors	1.3.6.1.2.1.10.9.2.1.9.ifindex	
dot5StatsTokenErrors	1.3.6.1.2.1.10.9.2.1.10.ifindex	
dot5StatsSoftErrors	1.3.6.1.2.1.10.9.2.1.11.ifindex	
dot5StatsHardErrors	1.3.6.1.2.1.10.9.2.1.12.ifindex	
dot5StatsSignalLoss	1.3.6.1.2.1.10.9.2.1.13.ifindex	
dot5StatsTransmitBeacons	1.3.6.1.2.1.10.9.2.1.14.ifindex	
dot5StatsRecoverys	1.3.6.1.2.1.10.9.2.1.15.ifindex	
dot5StatsLobeWires	1.3.6.1.2.1.10.9.2.1.16.ifindex	
dot5StatsRemoves	1.3.6.1.2.1.10.9.2.1.17.ifindex	
dot5StatsSingles	1.3.6.1.2.1.10.9.2.1.18.ifindex	
dot5StatsFreqErrors	1.3.6.1.2.1.10.9.2.1.19.ifindex	
snmp	1.3.6.1.2.1.11	
snmplnPkts	1.3.6.1.2.1.11.1.0	
snmpOutPkts	1.3.6.1.2.1.11.2.0	
snmplnBadVersions	1.3.6.1.2.1.11.3.0	
snmplnBadCommunityNames	1.3.6.1.2.1.11.4.0	
snmplnBadCommunityUses	1.3.6.1.2.1.11.5.0	
snmplnASNParseErrs	1.3.6.1.2.1.11.6.0	
snmplnTooBigs	1.3.6.1.2.1.11.8.0	
snmplnNoSuchNames	1.3.6.1.2.1.11.9.0	
snmplnBadValues	1.3.6.1.2.1.11.10.0	
snmplnReadOnlys	1.3.6.1.2.1.11.11.0	
snmplnGenErrs	1.3.6.1.2.1.11.12.0	

<b>Variable Name</b>	<b>ASN1 Notation</b>	<b>Notes about the 3174's version of the variable</b>
snmpInTotalReqVars	1.3.6.1.2.1.11.13.0	
snmpInTotalSetVars	1.3.6.1.2.1.11.14.0	
snmpInGetRequests	1.3.6.1.2.1.11.15.0	
snmpInGetNexts	1.3.6.1.2.1.11.16.0	
snmpInSetRequests	1.3.6.1.2.1.11.17.0	
snmpInGetResponses	1.3.6.1.2.1.11.18.0	
snmpInTraps	1.3.6.1.2.1.11.19.0	
snmpOutTooBig	1.3.6.1.2.1.11.20.0	
snmpOutNoSuchNames	1.3.6.1.2.1.11.21.0	
snmpOutBadValues	1.3.6.1.2.1.11.22.0	
snmpOutGenErrs	1.3.6.1.2.1.11.24.0	
snmpOutGetRequests	1.3.6.1.2.1.11.25.0	
snmpOutGetNexts	1.3.6.1.2.1.11.26.0	
snmpOutSetRequests	1.3.6.1.2.1.11.27.0	
snmpOutGetResponses	1.3.6.1.2.1.11.28.0	
snmpOutTraps	1.3.6.1.2.1.11.29.0	
snmpEnableAuthenTraps	1.3.6.1.2.1.11.30.0	2 (disabled)

## Abbreviations

ABBREVIATION	MEANING		
<b>ACFIVTAM</b>	Advanced Communications Function/Virtual Telecommunications Access Method	<b>IP</b>	Internet Protocol
<b>AEA</b>	Asynchronous Emulation Adapter	<b>IPDS</b>	Intelligent Printer Data Stream
<b>APAR</b>	Authorized Program Analysis Report	<b>ISDN</b>	Integrated Services Digital Network
<b>APPN</b>	Advanced Peer-to-Peer Networking	<b>JCL</b>	Job Control Language
<b>ARP</b>	Address Resolution Protocol	<b>KDU</b>	Keyboard Definition Utility
<b>ASCII</b>	American National Standard Code for Information Interchange	<b>LAP</b>	Link Access Protocol
<b>BRI</b>	Basic Rate Interface	<b>LEN</b>	Low Entry Networking
<b>CCA</b>	Concurrent Communication Adapter	<b>LFS</b>	Local Format Storage
<b>CECP</b>	Country Extended Code Page	<b>LFU</b>	Limited Function Utility
<b>CICS</b>	Customer Information Control System	<b>LIC</b>	Licensed Internal Code
<b>CID</b>	Connection Identifier	<b>LT</b>	Line Termination
<b>CMEP</b>	Change Management Entry Point	<b>MLT</b>	Multiple Logical Terminal
<b>CMFP</b>	Change Management Focal Point	<b>MVS</b>	Multiple Virtual Storage
<b>COPT</b>	Connection Options	<b>MVS/ESA</b>	Multiple Virtual Storage/Enterprise System Architecture
<b>COS</b>	Class Of Service	<b>MVS/IXA</b>	Multiple Virtual Storage/Extended Architecture
<b>CP</b>	Control Point	<b>NAM</b>	Network Asset Management
<b>CSCF</b>	Central Site Control Facility	<b>NCP</b>	Network Control Program
<b>CSCM</b>	Central Site Change Management	<b>NDIS</b>	Network Device Interface Specification
<b>CSCU</b>	Central Site Control Unit	<b>NIA</b>	Network Interface Adapter
<b>CSU</b>	Customer Setup	<b>NLDM</b>	Network Logical Data Manager
<b>CUG</b>	Closed User Group	<b>NMVT</b>	Network Management Vector Transport
<b>CUT</b>	Control Unit Terminal	<b>NN</b>	Network Node (APPN)
<b>DATE</b>	Dedicated Access to X.25 Transport Extension	<b>NPDA</b>	Network Problem Determination Application
<b>DDDLU</b>	Dynamic Definition of Dependent LU	<b>NPKT</b>	Negotiated Packet Size
<b>DFT</b>	Distributed Function Terminal	<b>NPSI</b>	NCP Packet Switching Interface
<b>DNS</b>	Domain Name System	<b>NSCU</b>	Network Site Control Unit
<b>DPC</b>	Dual Purpose Connector	<b>NTRI</b>	NCP Token-Ring Interconnection
<b>DRD</b>	Distributed Resource Directory	<b>NT1</b>	Network Termination 1
<b>DSL</b>	Downstream Load	<b>NT2</b>	Network Termination 2
<b>DSPU</b>	Downstream Physical Unit	<b>NVDM</b>	NetView Distribution Manager
<b>EAB</b>	Extended Attribute Buffer	<b>OEM</b>	Other Equipment Manufacturer
<b>EN</b>	End Node (APPN)	<b>OOPT</b>	Outgoing Call Options
<b>ES</b>	Extended Services	<b>OSI</b>	Open Systems Interconnection
<b>ESCON</b>	Enterprise Systems Connection	<b>PABX</b>	Private Automated Branch Exchange
<b>ET</b>	Exchange Termination	<b>PAM</b>	Printer Authorization Matrix
<b>FTA</b>	Fiber Optic Terminal Adapter	<b>PIM</b>	Plug In Module
<b>FTTERM</b>	File Transfer and Terminal Emulation program	<b>PING</b>	Packet Internet Groper
<b>GIX</b>	Generalized Interactive Executive	<b>PRI</b>	Primary Rate Interface
<b>GW</b>	Gateway	<b>PS</b>	Programmed Symbols
<b>HNAD</b>	Host Network (DTE) Address	<b>PSDN</b>	Packet Switched Data Network
<b>ICA</b>	Integrated Communication Adapter	<b>PSH</b>	Physical Services Header
<b>ICMP</b>	Internet Control Message Protocol	<b>PUID</b>	Physical Unit ID
<b>IDLC</b>	ISDN Data Link Control	<b>PVC</b>	Permanent Virtual Circuit
<b>IML</b>	Initial Microprogram Load	<b>QLLC</b>	Qualified Logical Link Control
<b>IOF</b>	Interactive Operator Facility	<b>RARP</b>	Reverse Address Resolution Protocol
<b>IOPT</b>	Incoming Call Options	<b>RPOA</b>	Recognized Private Operating Authority
		<b>RPQ</b>	Request for Price Quotation
		<b>RR</b>	Resource Repository
		<b>RTM</b>	Response Time Monitor
		<b>SAP</b>	Service Access Point



<b>SDDL</b>	Selection of Definitions for Dependent LU	<b>TCP</b>	Transmission Control Program
<b>SDLC</b>	Synchronous Data Link Control	<b>TCPIIP</b>	Transmission Control Protocol/Internet Protocol
<b>SHM</b>	Short Hold Mode	<b>TEI</b>	Terminal Endpoint Identifier
<b>SID</b>	Short Identifier	<b>TE1</b>	Terminal Equipment with ISDN Interface
<b>SLMH</b>	Single Link Multi-Host	<b>TE2</b>	Terminal Equipment with non-ISDN Interface
<b>SNA</b>	Systems Network Architecture	<b>TG</b>	Transmission Group
<b>SNAIDS</b>	Systems Network Architecture/Distribution Services	<b>TMA</b>	Terminal Multiplexer Adapter
<b>SNAIFS</b>	Systems Network Architecture/File Services	<b>TTP</b>	Telephone Twisted-Pair
<b>SNAIMS</b>	Systems Network Architecture/Management Services	<b>T2.0</b>	Type 2.0
<b>SNMP</b>	Simple Network Management Protocol	<b>T2.1</b>	Type 2.1
<b>SOEMI</b>	Serial Original Equipment Manufacturer Interface	<b>UDP</b>	User Datagram Protocol
<b>SVC</b>	Switched Virtual Circuit	<b>UDT</b>	User-Defined Terminal Table
<b>TA</b>	Terminal Adapter	<b>UDX</b>	User-Defined Translate Table
<b>TCF</b>	Transmission Control File	<b>VPD</b>	Vital Product Data
<b>TCLS</b>	Throughput Class Negotiation	<b>VTAM</b>	Virtual Telecommunications Access Method
		<b>WCC</b>	Write Control Character

---

# Index

## Numerics

- 3174 Ethernet Adapter
  - Configuration Support-C Release 4 227
- 3174 TCP/IP Enhancements RPQ 8Q1041
- 3174-11r customization 107

## A

- abbreviations 371
- acronyms 371
- address bit order Ethernet addresses 359
- AS/400 definitions 178

## P

- packaging - RPQ 8Q0935 16

## R

- RISC system/6000 definitions 105, 146

## S

- scenario 1: TCP/IP using 3174 peer communication only
  - 3174-peer definition panel 110
  - 3174-peer status 118
  - CM/2 definitions 69
  - common network 108
  - common SNA 108
  - configuration description 68
  - configuration diagram 67
  - configuration using icat 76
  - defining DSPU address limit 107
  - defining network ID 108
  - defining RU Size 107
  - defining SDLC address 107
  - enabling token-ring gateway 107
  - installation/configuration automation tool (icat) 75
  - minimum configuration and setup 106
  - model attach 107
  - NDIS interface and protocol manager configuration 94
  - NDIS interfaces 94
  - open session 104
  - panel: 3270 emulation through token-ring 73
  - panel: CM/2 installation and setup 69
  - panel: CM/2 setup 70
  - panel: configuration definition - 3270TCP 72, 74
  - panel: icat introduction 75
  - panel: open configuration 71
  - PC/3270 advanced options for 3174 network stations 85
  - PC/3270 advanced options for 3174 peer communication 84

- scenario 1: TCP/IP using 3174 peer communication only (*continued*)
  - PC/3270 attachment types 84
  - PC/3270 choose configuration 83
  - PC/3270 configuration in Windows mode 89
  - PC/3270 configuration program 82
  - PC/3270 create configuration file 83
  - PC/3270 definitions 82
  - PC/3270 end of configuration 87, 88
  - PC/3270 end of link options 87
  - PC/3270 keyboard and code pages 85
  - PC/3270 panel sizes 85
  - PC/3270 startup options 86
  - ping 100
  - question 650: 3174-peer support 110
  - question 651: bridge support 110
  - question 652: LAN manager support 111
  - question 653: 3174-peer online test updates 111
  - question 660: 3174-peer port address range 112
  - question 661: percentage of discard threshold 113
  - read TCP/IP configuration 93, 95
  - ring address assignment 109
  - SDLC 107
  - SMIT TCP/IP 105
  - system files 96
  - TCP/IP for DOS configuration 92
  - TCP/IP for DOS installation 91
  - TCP/IP for DOS installation tool 91
  - TCP/IP for OS/2 installation/configuration 75
  - TCP/IP LAN adapter and protocol support (TCPlaps) 78
  - telnet 101
  - telnet session establishment 104
  - token-ring address 108
  - using TCP/IP for panels 99
  - write TCP/IP configuration 96
- scenario 2: concurrent access to SNA and TCP/IP
  - 3174 domain name 141
  - 3174 hostname 141
  - 3174 multi-host customization 121
  - 3174 TCP/IP customization 131
  - add an HCON session 156
  - add SNA display session 157
  - advanced SNA configuration 149
  - AIX 3270 host communication program/6000 (HCON) 155
  - change/show SNA token ring attachment profile 151
  - command status 148, 154, 157
  - common network 124, 127
  - common SNA 124
  - configuration description 120
  - configuration diagram 119
  - configure complete 130

scenario 2: concurrent access to SNA and TCP/IP

(continued)

- configure SNA profiles 147
- customizing panel flow 131
- defining 3270 host and display station sets 134
- defining controller address 123, 127
- defining default destinations 138
- defining domain name services 141
- defining nicknames 142
- defining port set 132
- defining RU size 123
- defining TCP/IP options 139
- defining TCP/IP routing information 140
- defining TCP/IP station sets 135
- defining upper limit address 123, 127
- display SNA resources 153
- domain nameserver ip addresses 141
- enabling AEA and TCP/IP option 131
- enabling token-ring gateway 123
- HCON session 158
- HCON user functions 156
- local (SNA) 123, 127
- manage SNA services 152
- mapping port to port set 133
- model attach 121
- multi-host definition 122
- physical units 150
- port address 126, 129
- port assignment 126, 129
- Question 052: 3174 IP address 139
- Question 054: subnet mask 139
- Question 058: maximum telnet connections 139
- Question 060: TCP/IP buffer space 139
- Question 062: routing field support 139
- Question 064: all routes broadcast 140
- Question 700: configure AEA and TCP/IP feature 131
- quick configuration 147
- quick configuration for a 3270 communication connection 148
- ring address assignment 125, 128
- ring transmission definition 125, 128
- SNA services 146
- SNA token ring attachment profile name 151
- start an SNA link station 153
- start SNA resources 152
- telnet to RS/6000 143
- token ring 150
- token-ring address 124, 127

scenario 3: APPN and TCP/IP via 3174 to AS/400 and VTAM

- 3174 hostname 204
- 3174-peer bridge profile panel 177
- 3174-peer definition panel 176
- 3174-peer status 208
- 5250 emulation 187
- AEA and TCP/IP configure 198
- APPN customizing 161

scenario 3: APPN and TCP/IP via 3174 to AS/400 and

VTAM (continued)

- APPN network node feature 161
- APPN node definition 169
- as/400 device description 181
- as/400 network attributes 178
- associated LU 172
- CM/2 definitions for 5250 emulation 182
- CM/2 installation and setup 182
- CM/2 manager setup 183
- CM/2 profile list sheet 185
- common network 168
- common SNA panel 164
- configuration definition 184
- configuration description 160
- configuration diagram 159
- configuration status 178
- configure LAN transports 188
- configure workstation 189
- controller description 179
- COS definition 172
- customize control disk menu 161
- defining 3270 host and display station sets 200
- defining control point name 178
- defining COS 172
- defining default destinations 202
- defining domain name services 204
- defining DSPU address limit 164
- defining local LU name 178
- defining mode/COS correlation 174
- defining network name 178
- defining nicknames 205
- defining node type 178
- defining port set 198
- defining RU size 164
- defining SDLC address 164
- defining TCP/IP options 202
- defining TCP/IP routing information 203
- defining TCP/IP station sets 201
- dependent LU 165
- device description 181
- disabled wildcard 169
- display adjacent nodes 191
- enabling token-ring gateway 164
- independent LU 165
- LAN adapter and protocol support 188, 190
- local node characteristics 186
- mapping port to port set 200
- network adapter address 189
- network attributes 178
- network resources 171
- open configuration 183
- overview panel flow 163
- peer communication customizing 161
- question 500: CSCM unique 164
- question 501: network ID 165
- question 502: logical unit name 164
- question 510: APPN network controller 166

scenario 3: APPN and TCP/IP via 3174 to AS/400 and VTAM (continued)

question 511: APPN control point name 166  
question 512: APPN virtual node name 166  
question 610: APPN sessions 169  
question 611: APPN nodes/links 169  
question 612: APPN wildcard option 170  
question 613: APPN wildcard host link 170  
ring address Assignment 168  
SNA features list 186  
TCP/IP customizing 161  
TCP/IP definitions 198  
telnet to AS/400 206  
token-ring address 168  
token-ring or other LAN types DLC adapter parameters 185  
VTAM definition list 192

scenario 4

3174 hostname 219  
3174-Peer definition panel 212  
AEA and TCP/IP configure 213  
customize control disk menu 211  
defining 3270 host and display station sets 215  
defining default destinations 217  
defining domain name services 219  
defining nicknames 220  
defining port set 214  
defining TCP/IP options 217  
defining TCP/IP routing information 218  
defining TCP/IP station sets 216  
mapping port to port set 215  
router definition on vax host 223  
scenario 4 configuration 209  
scenario 4 description 210  
TCP/IP and peer support customizing 211  
TCP/IP definitions 213  
telnet to VAX host 224

SNMP variables 363

subnet masks 20

## T

### TCP/IP

3174 domain name 42  
3174 hostname 42  
3174 models supported 12  
3174 support before RPQ 8Q0935 9  
3174 support with RPQ 8Q0935 9  
adding 3174 to TCP/IP network 19  
address resolution protocol (ARP) 6  
architecture 3  
codes and messages - telnet 63  
configure AEA and TCP/IP option 26  
Customizing 3174 TCP/IP Telnet Support 24  
customizing panel flow 26  
data buffers 15  
data flows 64  
defining 3270 host and display station sets 32  
defining default destinations 38

### TCP/IP (continued)

defining domain name services 41  
defining nicknames 43  
defining port set 29  
defining TCP/IP options 39  
defining TCP/IP routing information 40  
defining TCP/IP station sets 33  
devices supported 14  
domain name system 7  
domain nameserver IP addresses 42  
enabling AEA and TCP/IP option 28  
escaping to local mode 47  
establishing a TCP connection 4  
example scenario 24  
gateways 7  
hosts supported 15  
how the 3174 TCP/IP Telnet Support looks at names 22  
how to use the RPQ 45  
if things go wrong... 61  
internet control messaging protocol (ICMP) 6  
internet protocol (IP) 5  
IP addresses 19, 21  
local mode command - ? 59  
local mode command - CLOSE 55  
local mode command - DISPLAY 57  
local mode command - HELP 59  
local mode command - NAMES 51  
local mode command - OPEN 54  
local mode command - PING 52  
local mode command - QUIT 55  
local mode command - SEND 58  
local mode command - SET 58  
local mode command - STATUS 56  
local mode command - TOGGLE 58  
mapping port to port set 30  
name servers 21  
names 21  
nicknames 21  
opening a connection 46  
operation: 3270 terminal 61  
operation: ASCII terminal 60  
operation: telnet to MVS host 51  
operation: telnet to RS/6000 host 49  
overview 3  
packaging - Configuration Support-C Release 3 16  
packaging - RPQ 8Q0935 16  
packet internet groper (PING) 7  
question 052: 3174 IP address 39  
question 054: subnet mask 39  
question 058: maximum telnet connections 39  
question 060: TCP/IP buffer space 40  
question 062: routing field support 40  
question 064: all routes broadcast 40  
question 168: Additional Extension Mode Key 61  
question 700: configure AEA and TCP/IP feature 28  
question 702: control key assignment 28

TCP/IP (continued)

question 703: request MLT for AEA 29  
questions 710 through 713: miscellaneous ASCII  
options 29  
returning to the connection menu 48  
returning to the telnet session 48  
routes 23  
simple network management protocol (SNMP) 7  
special considerations for 3270 emulation 61  
special considerations for 3270 terminals 60  
special considerations for ASCII terminals 59  
storage requirements 15  
subnet masks 20  
support with Configuration Support-C Release  
3 10  
support with RPQ 8Q1041 10  
supported configuration - DSPU 3174 13  
supported configuration - gateway 3174 12  
telnet 5  
telnet session resources 48  
telnet sessions 15  
terminal operation 46  
terminal types 59  
token-ring considerations 44  
transmission control protocol (TCP) 3  
user datagram protocol (UDP) 6

GG24-4172-00



Printed in the United States of America  
on recycled paper containing 10%  
recovered post-consumer fiber

Using 3174 in TCP/IP Networks

GG24-4172-00

PRINTED IN THE U.S.A.

**IBM**<sup>®</sup>

GG24-4172-00

