

19JAN79 1120

PG-001

ORG=R01-WENDY GILLESPIE LOC=HVNT BLDG=1510 DEPT=0426 REQUESTOR= PROC NO=000001652162-A05

PROCESS RETRIEVAL - CHANGE IDENTIFICATION-

ITEM-ID	RTG	D/P	PRIME	PROC	CHG	PC	SPEC	LEAD	VAR	LT	YIELD							
ALT	IND	PROC	COMP	CHANGE-NO	EF-DATE	CST	CH	ANA	RESP-ENG	SO	SUPP	TIME	DAY/100	FACTOR				
00	1652162	A05	MFG	YES	YES	INSR	10	745961	01DEC78	E	J	036	M69	G	MCCORMACK	F	902	100

BASIC NAME	DESCRIPTION	LAB-CTL	PROC	B/M	LVL	DISP	SHIP-MODE	CERT	DATE	U/M	MAX-QTY	MIN-QTY	OPTM	QTY	OUT-SEQ
GROUP	BM	954	10	745961						01					NO

BILL LEVEL	DRAWING LVL	INSTR LVL	SPEC LVL	DIAGNOST LVL	ITEM HDR LVL	MDF LVL	
10	745961	NONE	NONE	NONE	10	745961	NONE

OPER NO	CONTENT NO	CMP SEQ	BASIC NAME	CONT	SP	QTY	ENG	MFG	ALT	DESCRIPTION	SPEC	PC	DSB	FALL	CMP	REFERENCE			
NO	NO	SEQ	BASIC NAME	QTY	QY	U/M	MDR	PLN	CH	PLN	CH	SO	SUPP	ANA	CD	OUT	USE	TIC	ITEM-ID

AAAA																			
00	2222222	1	FORM	1	01	U	R	S		GA23-0001-0	A	992	007						99
00	2222222	2	FORM	1	01	U	R	S		GA23-0002-0	A	992	007						99
00	2222222	3	FORM	1	01	U	R	S		GX27-0010-0	A	992	007						99

SHPG DEPT=0176																			

0080 DEPT=0744																			
00	1652157	1	3601ENG SP	1	01	U	R	R			R	902	036						99
00	1652160	3	PRD SHEET	1	01	U	R	S		EC 745961	R	902	036						99
00	2222222	2	FORM	1	01	U	R	S		SX27-2957	A	992	007						99
00	2222222	4	FORM	1	01	U	R	S		GX27-0002-0	A	992	007						99
00	2222222	7	FORM	1	01	U	R	S		GA27-2898-0	A	992	007						99

LAST PAGE

IBM INTERNAL USE ONLY

23MAR79 1006

PG-001

ORG=A78-MIKE FREE LOC=HVNT BLDG=1512 DEPT=0607 REQUESTOR=SALLY PROC NO=000001747487-K05

PROCESS RETRIEVAL - CHANGE IDENTIFICATION- 10000745949

ITEM-ID	RTG	D/P	PRIME	PROC	IEC	CHG	PC	SPEC	LEAD	VAR	LT	YIELD			
00	1747487	K05	MFG	YES	YES	INSR	10	745949	22SEP78	E	J	M72	F	902	100

BASIC NAME	DESCRIPTION	LAB-CTL	PROC	B/M	LVL	DISP	SHIP-MODE	CERT	DATE	U/M	MAX-QTY	MIN-QTY	OPTM	QTY	OUT-SEQ
PUB GRP BM		954	10	745949						01					NO

BILL LEVEL	DRAWING LVL	INSTR LVL	SPEC LVL	DIAGNOST LVL	ITEM HDR LVL	MDF LVL
10	745949	NONE	NONE	NONE	10	745948

3631-PROCESS IS A FINAL

OPER	CMP	CONT	QTY	ENG	MFG	ALT	SPEC	PC	DSB	FALL	CMP	REFERENCE							
NO	CONTENT NO	SEQ	BASIC NAME	QTY	U/M	MDR	PLN	CH	PLN	CH	DESCRIPTION	SO	SUPP	ANA	CD	OUT	USE	TIC	ITEM-ID
0080	DEPT=0744																		
00	222837	1	BINDER	1	01	U		D				A	Z90	32			99		1652141
00	1652141	1	INSTR	1	01	U	R	R				R	902	PCA			99		
00	1747488	1	PRD SHEET	1	01	U	R	S			EC 745949	R	902				99		
00	1747489	1	TAB	1	01	U		D				A	Z93	PCA			99	00	1652141
00	222222	1	FORM	1	01	U	R	S			SY27-2519-0	A	992	007			99		
00	222222	2	FORM	1	01	U	R	S			S126-013-2	A	992	007			99		
00	222222	3	FORM	1	01	U	R	S			SN31-0864	A	992	007			99		

LAST PAGE

IBM INTERNAL USE ONLY

FIELD ENGINEERING BILL-5117491

EC LEVEL-960447

LOC-HVNT

ORG LUC BLDG DEPT ADDRESSEE
A78 HVNT 1512 0607 MIKE FREE

REQUESTOR

PAGE 1

MACHINE TYPE-NONE

SECTION NO 000

TITLE- INDUSTRY SYSTEMS INSTALLATION REPORT

MAINTENANCE REFERENCE MATERIAL

NONE

PARTS AND ASSEMBLIES

CHECK	PART NUMBER	QUANTITY	U/M	NAME	DESCRIPTION	REFERENCE/EC
	5116787	1	1	BAG	10X14	
	5117493	1	1	LETTER	CE INSTN.	
	5117494	1	1	INREP	INST.REPORT	
	5117495	1	1	ENVELOPE	ENVELOPE(0024)	

COMMENTS- NONE

*** LAST PAGE ***

MACH LIST FOR-3601 MOD- A SER-57054041 PLT-57 COL 26 SHIP 28 20JUN79

CTRY-724 CUST-W000001- SER BR- SYS #- IQ564- - TYP-

FCT ORDER-IV1870 SALES MODEL- PLT SEQ #-

TYPE OF PRODUCTION - LOCATION CODE - F

SHIPPED-06JUL79 SHP SEQ- FCT SEQ-0002 WD- MODE- MACH STA-FACTORY

SEQ # EC # STATUS MASTER COMMENT PICK-UP EC DATE

B0002 FCT 000743984 FACT LVL

Y0001 OPT 000393674 INSTALED 08JUN79
Y0002 OPT 000335233 INSTALED 08JUN79

FEATURE RM QTY FEATURE NAME MES # K M DEV STAT DATE ACC SHP-LVL-FCT

0001563243 0001 MODEM CABLE 5500 INT 08JUN79 0001
***** COMMENTS

E0001 FCT 000739341 FACT LVL

***** THE FOLLOWING IS AN RPQ FEATURE *****

0001651191 0001 ADD ATT RPQ SUPT 9492 INT 08JUN79 0003
***** COMMENTS

D0006 000742978 PRES LVL

E0003 FCT 000742972 FACT LVL

***** THE FOLLOWING IS AN RPQ FEATURE *****

0001651369 0001 * RPQ SUPP DISC 9589 INT 08JUN79 0001
***** COMMENTS

D0005 000742979 PRES LVL

E0001 FCT 000742956 FACT LVL

0001739382 0001 PUBS GROUP INT 08JUN79 0007
***** COMMENTS

E0007 FCT 000745961 FACT LVL

0001831755 0001 COVER GROUP INT 08JUN79 0003
***** COMMENTS

E0003 FCT 000745183 FACT LVL

0004406037 0001 1200 BPS 2 WIRE 5500 INT 08JUN79 0001
***** COMMENTS

E0001 FCT 000747313 FACT LVL
E0002 FCT 000748506 INQUIRY

0004406053 0001 SHP GP A2/A3/C00 0000 INT 08JUN79 0001
***** COMMENTS

D0001 000745949 PRES LVL

E0001 FCT 000747313 FACT LVL
E0002 FCT 000748506 INQUIRY

0004406072 0001 220V 50HZ 2813 INT 08JUN79 0001
***** COMMENTS

MACH LIST FOR-3601 MOD- A SER-57054041 PLT-57 COL 26 SHIP 28 20JUN79

SEQ #	EC #	STATUS	MASTER COMMENT	PICK-UP EC	DATE
E0001	FCT 000746738	FACT LVL			
***** THE FOLLOWING IS AN RPQ FEATURE *****					
0004940972	0001 GERM.LAN MOD A02		2929 INT	08JUN79	0001
*****		COMMENTS			
E0001	FCT 000111111	FACT LVL			
0004941012	0001 33FD 50HZ HI VLT		INT	08JUN79	0002
*****		COMMENTS			
E0002	FCT 000745228	FACT LVL			
R0001	REA 0005709061	INSTALED		000111111	
Y0001	OPT 000746202	INQUIRY			
0004946036	0001 LOGIC GRP		INT	08JUN79	0004
*****		COMMENTS			
D0001	000748503	INQUIRY			
D0002	000355419	INQUIRY			
E0004	FCT 000747306	FACT LVL			
Y0001	OPT 000747545	INSTALED			08JUN79
0004946045	0001 CCA W.CLK		6301 INT	08JUN79	0002
*****		COMMENTS			
E0002	FCT 000389181	FACT LVL			
0004946047	0001 USER STORAGE NO1		9592 INT	08JUN79	0002
*****		COMMENTS			
E0002	FCT 000748080	FACT LVL			
E0003	FCT 000748490	INQUIRY			
0004946048	0001 USER STORAGE NO2		9592 INT	08JUN79	0002
*****		COMMENTS			
E0002	FCT 000748080	FACT LVL			
E0003	FCT 000748490	INQUIRY			
0004946051	0001 LOOP ADAPT 1		4735 INT	08JUN79	0002
*****		COMMENTS			
E0002	FCT 000748080	FACT LVL			
0004946052	0001 LOOP ADAPT 2		4735 INT	08JUN79	0002
*****		COMMENTS			
E0002	FCT 000748080	FACT LVL			
0004946080	0001 FRAME ASM		INT	08JUN79	0005
*****		COMMENTS			
E0005	FCT 000748132	FACT LVL			
E0006	FCT 000748362	INQUIRY			

MACH LIST FOR-3601 MOD- A SER-57054041 PLT-57 COL 26 SHIP 28 20JUN79
 CTRY-724 CUST-W000001- SER BR- SYS #- IQ564- - TYP-
 FCT ORDER-IV1870 SALES MODEL- PLT SEQ #-
 TYPE OF PRODUCTION - LOCATION CODE - F
 SHIPPED-06JUL79 SHP SEQ- FCT SEQ-0002 WD- MODE- MACH STA-FACTORY

FEATURE SUMMARY LIST

PAGE 01

FEATURE BM	SOP	QTY	STAT	FEATURE NAME	MES	DEV	DATE	CCL	RPQ
0001563243		0001	INT	MODEM CABLE		5500	08JUN79		
0001651191		0001	INT	ADD ATT RPQ SUPT		9492	08JUN79		£
0001651369		0001	INT	* RPQ SUPP DISC		9589	08JUN79		£
0001739382		0001	INT	PUBS GROUP			08JUN79		
0001831755		0001	INT	COVER GROUP			08JUN79		
0004406037		0001	INT	1200 BPS 2 WIRE		5500	08JUN79		
0004406053		0001	INT	SHP GP A2/A3/C00		0000	08JUN79		
0004406072		0001	INT	220V 50HZ		2813	08JUN79		
0004940972		0001	INT	GERM.LAN MOD A02		2929	08JUN79		£
0004941012		0001	INT	33FD 50HZ HI VLT			08JUN79		
0004946036		0001	INT	LOGIC GRP			08JUN79		
0004946045		0001	INT	CCA W.CLK		6301	08JUN79		
0004946047		0001	INT	USER STORAGE NO1		9592	08JUN79		
0004946048		0001	INT	USER STORAGE NO2		9592	08JUN79		
0004946051		0001	INT	LOOP ADAPT 1		4735	08JUN79		
0004946052		0001	INT	LOOP ADAPT 2		4735	08JUN79		
0004946080		0001	INT	FRAME ASM			08JUN79		
0005240403		0001	INT	RFI FILTER		2759	08JUN79		
0007373861		0001	INT	PACKING BM - HVT			08JUN79		

TABLE OF CONTENTS

REPORT NUMBER 000000

REPORT DATE 20JUN79

VOL BD M/T 3601 A SERIAL 57054041

COL 26 SHIP 28

LOGIC NUMBER DESCRIPTION
SLT BOARDS

PART NUMBER EC NUMBER FEATURE BM

01AA1 CUSTMZ BD MODS 2A2B3A3B STGE 2

0006813046 000747306 0004946036

PAGE NO. 0001

TABLE OF CONTENTS

REPORT NUMBER 000000

REPORT DATE 20JUN79

VOL RS M/T 3601 A SERIAL 57054041

COL 26 SHIP 28

LOGIC REFERENCE DATA	NUMBER	DESCRIPTION	PART NUMBER	EC NUMBER	FEATURE BM
128		SHIP GRP BM (M.I.MANUAL)	0001747487	000745949	0004406053
140		SHIP GRP BM (OPS.GUIDE)	0001652162	000745961	0001739382
300		INSTALLATION REPORT BM	0005117491	000111111	
305		CE INSTR FORM IN FIVE LANGUAGES	0005117493	000111111	
310		INSTALLATION REPORT SHEET	0005117494	000111111	
315		WINDOW ENVELOPE	0005117495	000111111	
320		POLYTHENE BAG	0005116787	000111111	

PAGE NO. 0002

TABLE OF CONTENTS

REPORT NUMBER 000000

REPORT DATE 20JUN79

VOL 001 M/T 3601 A SERIAL 57054041

COL 26 SHIP 28

LOGIC NUMBER DESCRIPTION
REFERENCE DATA
PRD 01 OPS GUIDE
PRD 02 M I MANUAL

PART NUMBER EC NUMBER FEATURE BM
0001652160 000745961 0001739382
0001747488 000745949 0004406053

PAGE NO. 0003

MACH LIST FOR-3601 MOD- A SER-57054041 PLT-57 COL 26 SHIP 28

20JUN79

SEQ #	EC #	STATUS	MASTER COMMENT	PICK-UP EC	DATE
E0007	FCT 000748379	INSTALED			08JUN79
E0008	FCT 000749176	INSTALED			08JUN79

0005240403	0001 RFI FILTER		2759 INT	08JUN79	0002
*****		COMMENTS			

E0002	FCT 000745183	FACT LVL			
E0003	FCT 000748756	INQUIRY			
E0004	FCT 000749176	INSTALED			08JUN79

0007373861	0001 PACKING BM - HVT		INT	08JUN79	0001
*****		COMMENTS			

E0001	FCT 000960248	FACT LVL			
-------	---------------	----------	--	--	--

END

TABLE OF CONTENTS

REPORT NUMBER 000000

REPORT DATE 20JUN79

VOL 999 M/T 360I A SERIAL 57054041

COL 26 SHIP 28

LOGIC NUMBER DESCRIPTION
MINNOW PROGRAM
01 2 3619 SUPPORT DISKETTE

PART NUMBER EC NUMBER FEATURE BM
0001651369 000742979 0001651369

PAGE NO. 0004



3601

**Models 2A, 2B, 3A, 3B, and
Models C and D**

3602

**Models 1A and 1B
Finance Communication Controllers
Maintenance Information**

Preface

This manual contains maintenance information necessary to service the IBM 3601 Models, 2A, 2B, 3A, 3B, and Models C and D Finance Communication Controller and the 3602 Models 1A and 1B Finance Communication Controller. It contains the following chapters and appendixes:

- Chapter 1 (Left) Maintenance Analysis Procedures (MAPs)
- Chapter 1 (Right) Maintenance Procedures
- Chapter 2 Maintenance Approach, Aids, and Special Tools
- Chapter 3 Reference Data
- Chapter 4 Component Locations
- Chapter 5 Parts Catalog
- Chapter 6 Installation Instructions
- Appendix A List of Abbreviations
- Appendix B Glossary
- Appendix C Index
- Appendix D List of Pages

Each chapter has its own Contents table where feasible.

First Edition (April 1978)

This manual, written at EC level 745948 will be subject to change from time to time. Any such change will be reported in subsequent revisions or Technical Newsletters.

A form is provided at the back of this publication for reader's comments. If the form has been removed, comments may be addressed to: IBM Corporation, Dept. 63T, Neighborhood Road, Kingston, N.Y., 12401

© International Business Machines Corporation 1976, 1977, 1978

Use of the MAPs

The starting point for each call is the error indication index, MAP 1. This index directs the Customer Engineer (CE) to MAPs which will isolate the trouble indicated by the error indication. Each MAP contains step by step procedures to locate the failing part. Where necessary, the MAPs refer to operating procedures and maintenance procedures (check, adjustment, removal, and replacement) located in Chapter 1, right half.

When the CE gets to a point in the MAPs that indicates "call for aid", the error indications should be checked again before calling for aid. If other error indications are present, the MAPs pointed to by MAP 1 should be used. If no other error indications are present, MAP 2 should be used. This MAP provides a systematic approach to finding error indications. Additionally, MAP 2 leads to use of the starter diskette in the attempt to identify the problem. (Refer to 3.3.3 for details on starter diskette operation.) A more detailed description of the maintenance approach is contained in Chapter 2.

Safety Notices

The following DANGER notices are also located in the applicable procedures:

DANGER

Motor case can get hot.

DANGER

When replacing a 60-Hz drive motor, position two large holes in motor frame (4 on 1.26) to top and under bracket.

DANGER

As the first step in removing and replacing the power supply, disconnect the 3601 power cord from the ac outlet.

CE Safety Practices

All Customer Engineers are expected to take every safety precaution possible and observe the following safety practices while maintaining IBM equipment:

1. You should not work alone under hazardous conditions or around equipment with dangerous voltage. Always advise your manager if you MUST work alone.
2. Remove all power AC and DC when removing or assembling major components, working in immediate area of power supplies, performing mechanical inspection of power supplies and installing changes in machine circuitry.
3. Wall box power switch when turned off should be locked or tagged in off position. "Do not Operate" tags, form 229-1266, affixed when applicable. Pull power supply cord whenever possible.
4. When it is absolutely necessary to work on equipment having exposed operating mechanical parts or exposed live electrical circuitry anywhere in the machine, the following precautions must be followed:
 - a. Another person familiar with power off controls must be in immediate vicinity.
 - b. Rings, wrist watches, chains, bracelets, metal cuff links, shall not be worn.
 - c. Only insulated pliers and screwdrivers shall be used.
 - d. Keep one hand in pocket.
 - e. When using test instruments be certain controls are set correctly and proper capacity, insulated probes are used.
 - f. Avoid contacting ground potential (metal floor strips, machine frames, etc. — use suitable rubber mats purchased locally if necessary).
5. Safety Glasses must be worn when:
 - a. Using a hammer to drive pins, riveting, staking, etc.
 - b. Power hand drilling, reaming, grinding, etc.
 - c. Using spring hooks, attaching springs.
 - d. Soldering, wire cutting, removing steel bands.
 - e. Parts cleaning, using solvents, sprays, cleaners, chemicals, etc.
 - f. All other conditions that may be hazardous to your eyes. REMEMBER, THEY ARE YOUR EYES.
6. Special safety instructions such as handling Cathode Ray Tubes and extreme high voltages, must be followed as outlined in CEM's and Safety Section of the Maintenance Manuals.
7. Do not use solvents, chemicals, greases or oils that have not been approved by IBM.
8. Avoid using tools or test equipment that have not been approved by IBM.
9. Replace worn or broken tools and test equipment.

10. The maximum load to be lifted is that which in the opinion of you and management does not jeopardize your own health or well-being or that of other employees.
11. All safety devices such as guards, shields, signs, ground wires, etc. shall be restored after maintenance.
12. Each Customer Engineer is responsible to be certain that no action on his part renders product unsafe or exposes hazards to customer personnel.
13. Place removed machine covers in a safe out-of-the-way place where no one can trip over them.
14. All machine covers must be in place before machine is returned to customer.
15. Always place CE tool kit away from walk areas where no one can trip over it (i.e., under desk or table).
16. Avoid touching mechanical moving parts (i.e., when lubricating, checking for play, etc.).
17. When using stroboscope — do not touch ANYTHING — it may be moving.
18. Avoid wearing loose clothing that may be caught in machinery. Shirt sleeves must be left buttoned or rolled above the elbow.
19. Ties must be tucked in shirt or have a tie clasp (preferably nonconductive) approximately 3 inches from end. Tie chains are not recommended.
20. Before starting equipment, make certain fellow CE's and customer personnel are not in a hazardous position.
21. Maintain good housekeeping in area of machines while performing and after completing maintenance.

Artificial Respiration

General Considerations

1. Start Immediately, Seconds Count
Do not move victim unless absolutely necessary to remove from danger. Do not wait or look for help or stop to loosen clothing, warm the victim or apply stimulants.
2. Check Mouth for Obstructions
Remove foreign objects — Pull tongue forward.
3. Loosen Clothing — Keep Warm
Take care of these items after victim is breathing by himself or when help is available.
4. Remain in Position
After victim revives, be ready to resume respiration if necessary.
5. Call a Doctor
Have someone summon medical aid.
6. Don't Give Up
Continue without interruption until victim is breathing without help or is certainly dead.

Rescue Breathing for Adults

Victim on His Back Immediately

1. Clear throat of water, food, or foreign matter.
2. Tilt head back to open air passage.
3. Lift jaw up to keep tongue out of air passage.
4. Pinch nostrils to prevent air leakage when you blow.
5. Blow until you see chest rise.
6. Remove your lips and allow lungs to empty.
7. Listen for snoring and gurglings, signs of throat obstruction.
8. Repeat mouth to mouth breathings 10-20 times a minute.

Continue rescue breathing until he breathes for himself.



Reprint Courtesy Mine Safety Appliances Co.

B

PART NO

1747488

LOGIC PG NO

360IBB

1747488

PUBLICATIONS REFERENCE DRAWING

MACHINE TYPE / MODEL NO. 3601 MODELS A02,A03,B02,B03,C,D

MACHINE NAME CONTROLLER

FORM NO.	E C NO.	DESCRIPTION / COMMENTS	QUANTITY	B/M NO.
SY27-2519-0	745948	MAINT. INFO.,BASE MANUAL (NOTE 1)	1	1747487
SN31-0864	745949	TNL TO SY27-2519-0	1	1747487
SI26-0013-2	745948	PARTS CATALOG (NOTE 2)	1	1747487

NOTES,

- 1** ASSEMBLE MAINTENANCE INFORMATION MANUAL WITH BINDER AND SPINE TAB PER ASSEMBLY INSTRUCTIONS P/N 1652141
- 2** INSERT PARTS CATALOG AFTER MAINTENANCE MANUAL, CHAPTER 4

EDM			DATE	CHANGE NO	DATE	CHANGE NO	1747488	
NAME	PUB REF DWG (PRD)		REL	MAR 76	742712	NOV 77		745948
3601 CONTROLLER				SEP76	743984	AUG 78		745949
DESIGN	LR	MAR76	SHT 1 OF 1	APR77	745946			
DETAIL	C2	11/5/4		JUN 77	745947			
CHECK			CLASSIFICATION	MUST CONFORM TO ENG SPEC		DEVELOPMENT NO	LOGIC PG NO	
APPRO	JLM	MAR76					360IBB	

B

Chapter 1. Maintenance Procedures

Contents

Procedure No.		Page
Operations		
1.1	Startup (Reset)	1-5R
1.2	Logon/Logoff Procedures for CE.	1-7R
1.3	Assigning the Component to Be Tested	1-9R
1.4	Assigning a Component to Be the Output Printer	1-10R
1.5	Display/Print Statistic Counters	1-11R
1.6	Display/Print Controller Log	1-12R
1.7	Loop Error Log Message	1-12R
1.8-1.19	Not Used	
Diskette Drive, One Read/Write Head		
1.20	Diskette Drive Assembly Removal and Replacement	1-12R
1.21	Latch Assembly Removal and Replacement	1-13R
1.22	Cover Assembly Removal and Replacement	1-13R
1.23	Collet Removal and Replacement	1-13R
1.24	Track Indicator Adjustment	1-14R
1.25	Drive Motor Removal	1-15R
1.26	Drive Motor Replacement	1-15R
1.27	Belt Tracking Adjustment	1-15R
1.28	Idler Assembly Removal and Replacement	1-16R
1.29	Hub Assembly Removal and Replacement	1-16R
1.30	Drive Pulley Removal	1-16R
1.31	Drive Pulley Replacement	1-16R
1.32	Pressure Pad Actuator Removal and Replacement	1-17R
1.33	Pressure Pad Actuator Adjustment	1-17R
1.34	Leadscrew and Head Carriage Assembly Removal	1-18R
1.35	Leadscrew and Head Carriage Assembly Replacement	1-18R
1.36	Read/Write Head Adjustment	1-20R
1.37	Head and Pressure Pad Cleaning	1-20R
1.38	Leadscrew Wheel Removal and Replacement	1-21R
1.39	Not Used	
1.40	Lower Limit Stop Adjustment	1-22R
1.41	Upper Limit Stop Adjustment	1-22R
1.42	Stepper Motor Removal and Replacement	1-24R
1.43	Stepper Motor Adjustment	1-24R
1.44	Phototransistor Service Check	1-26R
1.45	Phototransistor Adjustment	1-26R
1.46	Phototransistor Removal and Replacement	1-26R
1.47	Light Emitting Diode (LED) Service Check	1-28R
1.48	LED Removal and Replacement	1-28R
1.49	Diskette Drive Control Card Pin Assignment	1-29R
1.50	Diskette Drive Control Card Removal and Replacement	1-30R
1.51	Diskette Drive Control Card Test Points	1-30R
1.52-1.59	Not Used	
Diskette Drive, Two Read/Write Heads		
1.60	Diskette Drive Assembly Removal and Replacement	1-32R
1.61	Latch Assembly Removal and Replacement	1-33R
1.62	Cover Assembly Removal and Replacement	1-33R
1.63	Collet Removal and Replacement	1-33R
1.64	Head/Carriage Position Service Check and Adjustment	1-34R
1.65	Head/Carriage Assembly Removal	1-38R

Contents (Cont)

Procedure No.	Page
1.66 Head/Carriage Assembly Replacement	1-38R
1.67 Head Load Solenoid/Bail Assembly Service Check and Adjustment	1-40R
1.68 Head Load Solenoid/Bail Assembly Removal and Replacement	1-44R
1.69 Drive Belt Service Check and Adjustment	1-46R
1.70 Drive Motor Removal	1-46R
1.71 Drive Motor Replacement	1-46R
1.72 Drive Pulley Removal	1-46R
1.73 Drive Pulley Replacement	1-46R
1.74 Idler Assembly Removal and Replacement	1-46R
1.75 Stepper Motor Removal	1-48R
1.76 Stepper Motor Replacement	1-48R
1.77 Pulley/Clamp Removal	1-50R
1.78 Pulley/Clamp Replacement	1-50R
1.79 Wiper Replacement	1-50R
1.80 Drive Band Service Check and Adjustment	1-52R
1.81 Drive Band Removal	1-54R
1.82 Drive Band Replacement	1-54R
1.83 Stepper Drive Idler Assembly Removal	1-56R
1.84 Stepper Drive Idler Assembly Replacement	1-56R
1.85 LED/PTX Alignment	1-57R
1.86 LED Service Check	1-57R
1.87 PTX/Amplifier Service Check	1-57R
1.88 LED Removal	1-58R
1.89 LED Replacement	1-58R
1.90 PTX Removal	1-58R
1.91 PTX Replacement	1-58R
1.92 Diskette Drive Control Card Pin Assignments	1-60R
1.93 Diskette Drive Control Card Removal and Replacement	1-61R
1.94 Diskette Drive Control Card Test Points	1-61R
1.95 Index Test Point	1-63R
1.96-1.99 Not Used	
Disk	
1.100 Disk Enclosure (DE) Removal	1-64R
1.101 Disk Enclosure (DE) Replacement	1-66R
1.102 Disk Motor Removal	1-68R
1.103 Disk Motor Replacement	1-68R
1.104 Motor Brake Service Check	1-70R
1.105 Motor Brake Adjustment	1-70R
1.106 Motor Brake Assembly Removal	1-72R
1.107 Motor Brake Assembly Replacement	1-72R
1.108 Speed-sensing Transducer Service Check	1-74R
1.109 Speed-sensing Transducer Adjustment	1-74R
1.110 Anti-static Brush Service Check	1-74R
1.111 Disk Storage Card Jumpers	1-76R
1.112 DE Cables	1-77R
1.113 DE Brake Circuit	1-79R
1.114 Disk Storage Diagnostic Run	1-80R
1.115 Disk Storage Error Codes	1-80R
1.116-1.119 Not Used	

Contents (Cont)

Procedure No.		Page
Electrical Devices		
1.120	Supply Voltage Test Points	1-95R
1.121	External Modem Wrap Card	1-95R
1.122	External Modem Signal Cable	1-95R
1.123	Transmit Level Adjustment for 1200-bps Integrated Modem	1-96R
1.124	Transmit Level Adjustment for 600-bps Integrated Modem	1-97R
1.125	Receive-level Check for 1200 bps and 600-bps Integrated Modem	1-100R
1.126	Power Supply Removal and Replacement	1-101R
1.127	Logic Board Removal and Replacement	1-101R
1.128	Card Names - Boards where Used (ALL Controllers)	1-102R
1.129	Card Names - Boards where Used (3602 Disk Storage only)	1-105R
1.130	Board Locations	1-107R
1.131	Card Locations	1-108R

BLANK PAGE

Note: The MAPs and the procedures refer to the following 3604 keyboard display terminals: the 3604 at address 1 on loop 1; the control operator's 3604; and the 3604 at which the CE is logged on. With an operating diskette, the 3604 at address 1 on loop 1 may or may not be physically the same 3604 as the control operator's 3604. With a starter diskette, the 3604 at address 1 on loop 1 is also the control operator's 3604.

1.1 STARTUP (RESET)

The following text (1.1.1, 1.1.2 and 1.1.3) applies to the operating diskette and the starter diskette.

1.1.1 Startup (Reset) Sequence

The startup sequence is as follows:

1. The CE activates the power switch or the reset switch on the controller.
2. The 3604 at address 1 on loop 1 displays a series of messages in the upper left corner of the gas panel to indicate the progress of the startup diagnostic tests. (This 3604 may require a power off/on reset.) The first message of this series is IDL (initial diagnostic load) and the final message is DTC (diagnostic test complete). Each message is displayed for a number of seconds and then is replaced by the succeeding one.
3. The control operator's 3604 displays a message on the top two lines of the gas panel. (This message indicates that the configuration image and the application programs have been successfully loaded from the diskette.) The top line contains seven groups of characters. From left to right, the groups give the following information:
 - a. The control code supplemental version ID.
 - b. Diskette identification (Volume ID).
 - c. Configuration identification.
 - d. The EC level of the controller data.
 - e. Control unit (controller) address (CUA). The CUA is used by the host to address this controller.
 - f. Relocate count (a count of the diskette records moved to the error track because of diskette surface defects).
 - g. Session identification. As used here, a session is one or more periods of time that the customer thinks of as one continuous period of time for record keeping.

The second line of the gas panel contains a five-digit message, 00001. This message requests the CE to key and enter one digit to specify the type of start wanted.

The type of start specified by each valid digit is as follows:

- 0 XX = Load utility, where 70 = diskette format.*
- 1 = Cold start.
- 2 = Warm start.
- 3 = Diagnostic loop.
- 4 = Prompt mode.
- 5 = Prompt mode for optional operations.
- 6 X = Describe the 3604 model number, where X = model number.
- 7 XX = Load link module, where
 - 01 = CCA TAM
 - 02 = HPCA TAM
 - 03 = CCA CREDIT LYONNAIS
 - 04 = HPCA CREDIT LYONNAIS
 - 05 = BSC
- 8 = Cold start with no start link issued.
- 9 = Warm start with no start link issued.

*Starter diskette only.

Note: Use the Universal Translate Table keyboard locations when entering the required digit. See keyboard chart in 1.2.

Special Note: When using an operating diskette, never specify a cold start (digit 1 or digit 8) unless the customer allows you to do so.

4. The CE keys and enters the correct digit. If 1, 2, 8, or 9 are entered, go to step 5 in this sequence. If 4 is entered, go to step 6. If 5 is entered, go to step 7. If 3 is entered, the controller will loop on the startup diagnostic sequence (IDL to DTC).
5. After entering 1, 2, 8 or 9, the gas panel goes blank and the customer's application program takes control!
6. If the CE requests a prompt mode start by keying and entering 4, the control operator's 3604 displays a sequence of five-digit messages (00002 through 00004) in the position where 00001 was displayed. After each message is displayed, the CE enters a response as shown in the chart on the next page, and the next message then appears. After the response to message 00004 has been completed, the screen again displays 00001. The CE now enters a 1, 2, 3, 4, 5, 8, or 9 to specify the startup, as in step 4.

7. If the CE requests a prompt mode start by keying and entering 5, the control operator's 3604 displays the message 00005 in place of 00001. The CE keys and enters responses to this message as shown in the chart below. After the responses to 00005 have been completed, the screen again displays 00001. The CE now enters 1, 2, 3, 4, 5, 8, or 9 to specify the start-up, as in step 4.
8. The CE may describe the 3604 by entering 6 X where X is the 3604 model number.

Prompt Mode Message Sequence*

Displayed Message	CE Response
00002	Enter a one- or two-character control unit address (CUA) in hex. This CUA replaces the one on the diskette.**
00003	Enter a 1 to request dump option. Enter a 0 to request no dump option.** <i>Note: The dump is taken only after a system failure. See 82060.</i>
00004	Enter a 1- to 16-character control operator identification code, supplied by the customer. Valid characters are 0-9, A-F, X, and blank.** If 90000 is displayed after entering a new identification (ID) code, the earlier ID code must be entered. If it is not entered correctly, 00004 will again display; if it is entered correctly, the ID code will be changed and 00001 will display.
00005	Enter the ID codes for as many as 16 optional modules of controller data. (Press enter after each ID code of one or two hex characters.) The 00005 message will remain after each entry unless the CE has responded by entering 00 or FF, or by pressing the EM (enter) key or the RE (reset) key. If 00 is entered, no optional modules will be loaded. If FF is entered, all optional modules will be loaded. For optional module ID codes on starter diskette, see 3.3.3.**
00006	Enter a 5-character XID.**

*Refer to the IBM 3600 system FE MIM, SY27-2520.

**If only the EM (enter) key is pressed, this input is bypassed and the operation continues. If the RE (reset) key is pressed twice, the prompt mode sequence is terminated.

1.1.2 Startup (Reset) Errors

1. If the startup diagnostics detect an error, the startup terminates with no message displayed or with one of the following messages displayed on the 3604 at address 1 on loop 1. (See MAP 1, Error Indication Index.)

IDL	MV0 XXX	MV3 0
HSH	ROS	MV1 XXX
LDI	PCK	MV2 XXX
IRT	LSW	MV3 XXX
HSH	HSH	ESA
LDC	LEC	INV
INS	MV2 0	DTC

MV2 and MV3 messages will only appear with the expanded memory. HSH will only appear if there is a diskette read error.

2. If the controller detects an error during the remainder of the startup:
 - a. 82XXX error messages* are displayed on the 3604 at address 1 on loop 1.
 - b. 9XXXX error messages* are displayed at the control operator's 3604.

1.1.3 Error-Free Startup (Reset)

If the startup was error-free, the startup message sequence will reach DTC, blank the display, then display a startup message ending with 00001 on the second line of the gas panel, and accept the startup request.

1.2 LOGON/LOGOFF PROCEDURES FOR CE

1.2.1 Operating Diskette

The following procedure assumes that there has been a good startup (1.1.1):

1. At an idle 3604, press the RE (reset) key three times. If reset is not marked, ask the customer to identify the reset key.
2. Message 90000 should be displayed. When 90000 is displayed, the layout of the keyboard keys is as assigned by the Universal Translate Table (UTT). The keyboard layout for the different 3604 keyboards is shown on the next page.

Note: *If 90000 is not displayed and the CHECK indicator lights, another 3604 is already logged on.*

3. Obtain the control operator identification (ID) code from the customer and enter this code at the 3604, using the 3604 UTT keyboard layout.

Note: *The control operator ID is not displayed.*

4. Message 91111 should be displayed, indicating a successful logon. If 91111 is not displayed, go to step 1.
Note: *After 91111 is displayed, the CE is able to give the keyboard commands, described in the IBM 3600 System FE MIM, SY27-2520.*

5. Logoff Procedure: To log off, key in 000 and then press the enter (EM) key.

1.2.2 Starter Diskette

As soon as the CE completes the startup by responding to the 00001 message, the gas panel on the control operator's 3604 (address 1 on loop 1) goes blank and the message 92222 appears. This message indicates that the CE is automatically logged on that 3604 and may run exerciser tests by using its keyboard. The CE can log off that 3604 and can then manually log on and log off at another 3604 in the same way as with an operating diskette (1.2.1). Note, however, that the control operator ID code for the starter diskette is 12345.

1.3 ASSIGNING THE COMPONENT TO BE TESTED

1.3.1 Operating Diskette

1. Log on at any idle 3604 (1.2.1).
2. Key in: 007 LSSD X

where:

L = Loop number.

SS = Terminal address (01 through 16).

D = Component address, as follows:

- 1 = Keyboard
- 2 = Display
- 3 = Encoder
- 4 = 3610, 3612 document printer or 3618 printer
- 5 = 3611 or 3612 Passbook Printer
- 6 = 3606/3608 keyboard/display
- 7 = 3608 printer
- 8 = 3614 Consumer Transaction Facility

X = 1 for side B.

X = 0 for side A.

If X is not entered, the default is the A side. If only 007 is entered, the component is reassigned to its work station.

1.3.2 Starter Diskette

Refer to starter diskette configuration information (3.3.3) to determine how to prepare for use of the starter diskette and also see command code 973. (Refer to the IBM 3600 System FE MIM, SY27-2520.)

Test Component on Loop 1

1. Set address switches of the terminal that contains the component to be tested (3.3.3).
2. Log on (1.2.2).
3. Key and enter: 007 LSSD X
The letters LSSD X have the same meaning as with the operating diskette.

Test Component on Loop 2

1. Set address switches of the terminal that contains the component to be tested (3.3.3).
2. Log on (1.2.2).

3. With the starter diskette, loop 2 is named as having a wrappable modem. If loop 2 actually has a wrappable modem (1200 bps), go now to step 4. If loop 2 has no modem or has a modem that is not wrappable (600 bps), then key and enter:

```
040 0 02 00 02
040 0
```

4. Key and enter: 007 LSSD X
The letters LSSD X have the same meanings as with the operating diskette.

Test Component on Loop Other Than 1 or 2

1. Set address switches of the terminal that contains the component to be tested (3.3.3).
2. Log on (1.2.2).
3. Determine whether the loop has a wrappable modem (1200 bps), a modem that is not wrappable, or no modem (local loop).
4. Key and enter:

```
040 0 0X00 0Y
040 0
```

where:

X is set to 2 if there is no wrappable modem on the loop (local loop or World Trade 600 bps remote loop).

X is set to 3 if there is a wrappable modem (1200 bps remote loop).

Y is set to the loop number of the loop to be tested.

The first of the above commands stops all loops except loop 1, and specifies the loop to be tested. The 040 0 command starts the loop to be tested.

5. Key and enter : 007 LSSD X
The letters LSSD X have the same meanings as with the operating diskette.

1.4 ASSIGNING A COMPONENT TO BE THE OUTPUT PRINTER

1.4.1 Operating Diskette

1. Log on at any idle 3604 (1.2.1).
2. Key in: 006 LSSD X

where:

- L = Loop number.
- SS = Terminal address (01 through 16).
- D = Component address, as follows:
 - 1 = Keyboard
 - *2 = Display
 - 3 = Encoder
 - *4 = 3610, 3612 document printer, or 3618 printer
 - 5 = 3611 or 3612 passbook printer
 - 6 = 3606/3608 keyboard/display
 - 7 = 3608 printer
 - 8 = 3614 Consumer Transaction Facility
- X = 1 for side B
- X = 0 for side A

*Only components that can be assigned as an output printer (continuous form printers only).

1.4.2 Starter Diskette

Refer to starter diskette configuration information (3.3.3) to determine how to prepare for use of the starter diskette and also see command code 973. (Refer to the IBM 3600 System FE MIM, SY27-2520.)

Output Printer on Loop 1

1. Set the address switches of the terminal that contains the component that is to be the output printer (3.3.3).
2. Log on (1.2.2).
3. Key and enter 006 LSSD X
The letters LSSD X have the same meanings as with the operating diskette.

Output Printer on Loop 2

1. Set the address switches of the terminal that contains the component that is to be the output printer (3.3.3).

2. Log on (1.2.2).
3. With the starter diskette, loop 2 is named as having a wrappable modem. If loop 2 actually has a wrappable modem (1200 bps), go now to step 4. If loop 2 has no modem or has a modem that is not wrappable (600 bps), then key and enter:

```
040 0 02 00 02
040 0
```

4. Key and enter 006 LSSD X
The letters LSSD X have the same meanings as with the operating diskette.

Output Printer on Loop Other Than 1 or 2

1. Set the address switches of the terminal that contains the component that is to be the output printer.
2. Log on (1.2.2).
3. Determine whether the loop has a wrappable modem (1200 bps), a modem that is not wrappable (600 bps), or no modem (local loop).
4. Key and enter:

```
040 0 0X 00 0Y
040 0
```

where:

- X is set to 2 if there is no wrappable modem on the loop (local loop or World Trade 600 bps remote loop).
- X is set to 3 if there is a wrappable modem (1200 bps remote loop).
- Y is set to the number of the loop to be tested.

The first of the above commands stops all loops except loop 1, and specifies the loop to be tested. The 040 0 command starts the loop to be tested.

5. Key and enter 006 LSSD X
The letters LSSD X have the same meanings as with the operating diskette.

1.5 DISPLAY/PRINT STATISTIC COUNTERS

Note: *Statistic counts are located in functional storage and are lost each time there is a reset (warm start or cold start). In contrast, the log is located on the diskette. Thus, the log is lost only on a cold start.*

1.5.1 Operating Diskette

After logging on at a 3604 (1.2), the CE can key in either of two commands to obtain statistic counters:

1. 010 LSSD is keyed to display the statistic counters of a specified component,

where:

L = Loop number.

SS = Terminal address (01 through 16)

D = Component address, as follows:

- 1 = Keyboard
- 2 = Display
- 3 = Encoder
- 4 = 3610, 3612 document printer, or 3618 printer
- 5 = 3611 or 3612 passbook printer
- 6 = 3606/3608 keyboard/display
- 7 = 3608 printer
- 8 = 3614 Consumer Transaction Facility

LSSD = 9001 for host link

LSSD = 9002 for diskette

LSSD = 903X for ALA line

LSSD = X000 for loop control, where X is the number of the loop.

2. 012 X is keyed to print statistic counters for all components on the assigned output printer. X is the number of loops attached to the controller.

The output format is:

LSDM TT SS XXX XXX XXX... ..

L = Loop number.

S = Terminal address in hexadecimal

D = Component address, same as input above

M = Modulus value for a terminal component, or speed of a loop (see below)

TT = Component type (see below)

SS = Work station identification

XXX = error count in decimal

LSDM = 9010 = Host link

LSDM = 9020 = Diskette

LSDM = 93X0 = ALA line

LSDM = X000 for loop control where X is the number of the loop.

If M = loop speed, values are as follows:

01 = 4800 bps

02 = 2400 bps

04 = 1200 bps

08 = 600 bps

8X = clocking loop

Component types (TT) are as follows:

80 = Loops

01 = Host link

81 = Keyboard

02 = Diskette

82 = Display

03 = ALA line

83 = 3610, 3611 or 3612 printer

85 = 3618 printer

86 = Magnetic Stripe Encoder

87 = 3614 Consumer Transaction Facility

88 = 3606/3608 keyboard/display

89 = 3608 printer

1.5.2 Starter Diskette

1. Refer to starter diskette configuration information (3.3.3) to determine how to prepare for using the starter diskette by:
 - a. Setting the address switches of some terminals or by simply turning off power on other terminals.
 - b. For loops other than loop 1, using the 040 command to set up the loop that is to be the working loop.
2. Obtain statistic counters in the same way as with an operating diskette (1.5.1).

1.6 DISPLAY/PRINT CONTROLLER LOG

Note: Refer to 3.3.5 for more information on the controller log.

1. Log on (1.2).
2. Key in one of the following commands:

<u>Command</u>	<u>Function</u>
001	Display the first part of each of the last five messages in the log. Each display line will contain a four-digit message number and as many as 36 characters of the message. After the first time you press the enter key, you can go back five additional messages each time you press the enter key again.
002 XXXX	Display full text of log message XXXX (maximum 240 characters).
002 9999	Display the last X1-XXX type message in the log. (Display full text of the message; maximum of 240 characters.)
046 XXXX YYYY	Print log messages numbered XXXX through YYYY on the printer assigned to be the output printer by command code 006.
046 0001 9999	Print all log messages on the assigned output printer.

1.7 LOOP ERROR LOG MESSAGE

The loop error message is:

11 005 Loop X Error, Code = Y - Z

Where:

- X = Loop Number
- Y = Loop Status
 - 0 - Loop Failed (Wrap Good)
 - 1 - Modem Check
 - 2 - Loop Check
 - 4 - Machine Check
 - 8 - User Requested Stop Loop
- Z = Data Set (Modem) Status
 - 0 - Transmit and Receive Not Ready
 - 1 - Receive Ready (Carrier Detect)
 - 2 - Transmit Ready (Clear to Send)
 - 3 - Combination of 1 and 2

1.8—1.19 NOT USED

1.20 3601 DISKETTE DRIVE ASSEMBLY REMOVAL AND REPLACEMENT

1. Turn off power.
2. Remove the smaller front end cover by raising it from its pivot pins.
3. Remove the side cover by raising up and tilting the top outwards.
4. Remove the diskette drive control card access cover by removing one holding screw.
5. Unplug the diskette drive motor connector.
6. Unplug the cable from the diskette drive control card and remove the ground wire. (The other end of this cable plugs into 01A1Z3.)
7. Remove the holding screw from the diskette drive assembly base plate. The base plate is exposed by the front end cover removal (step 2).
8. Loosen the Zeus* fastener on the inside top of the diskette drive assembly.
9. Remove the diskette drive assembly by sliding it out from the front end of the controller.

Replace the diskette drive assembly by reversing the above procedure.**

*Titan Tool Supply Co., Inc.

**Jumper assembly PN 4409828 for low voltage (100 – 123.5) or PN 4409829 for high voltage (200 – 240) may be required in order to use the latest style diskette drive motor.

1.21 LATCH ASSEMBLY REMOVAL AND REPLACEMENT

1. Open diskette drive assembly cover **3**.
2. Remove the two latch mounting screws **1**.
3. Pull latch **11** away from cover.
4. To replace, reverse above procedure.


1.22 COVER ASSEMBLY REMOVAL AND REPLACEMENT

CAUTION: Do not allow pressure pad arm **40** to snap against head.

1. Remove diskette drive assembly (1.20).
2. Remove two screws **8** while holding cover.
3. Remove cover carefully to avoid damage to wires.
4. Remove wires from LED **2** and pressure pad actuator **9**.
5. Remove wires from clip on cover.
6. To replace cover, reverse above procedure.

1.23 COLLET REMOVAL AND REPLACEMENT

1. Remove diskette drive assembly (1.20).
2. Remove cover (1.22).
3. Remove mounting screw **10**.
4. Remove collet assembly **5** and spring and washer **4**.
5. Remove collet **7** by removing clip **6**.
6. To replace collet, reverse above procedure.




1.24 TRACK INDICATOR ADJUSTMENT

1. Log on (1.2).
2. Key in 034 0001 0001 and press the enter (EM) key. This causes the read/write head assembly to seek and read record 1 on track 0 continuously.
3. Loosen two screws.
4. Adjust track indicator so that zero line is centered on pressure pad arm pointer.
5. Tighten screws.
6. Press reset (RE) key twice.
7. Check for gap between pressure pad arm and track indicator bracket at all tracks by keying:

034 0001 7501

8. Press reset (RE) key twice to end the test.



1.25 DRIVE MOTOR REMOVAL

DANGER
Motor case can get hot.

1. Remove diskette drive assembly (1.20).
2. Remove drive belt.
3. Loosen two motor mounting clamps and remove drive motor **3**.
4. Loosen setscrew **2** and remove drive pulley **1**.

1.26 DRIVE MOTOR REPLACEMENT

1. Replace drive pulley **1**. (Align setscrew **2** with flat surface on shaft.)

DANGER:
When replacing a 60-HZ drive motor, position two large holes **4** in motor frame to top and under bracket.


2. Clamp motor to mounting bracket.
3. Replace belt.
4. Inspect belt tracking and adjust if necessary (1.27).
5. Replace diskette drive assembly (1.20).

1.27 BELT TRACKING ADJUSTMENT

Belt must ride in center of drive pulley **1** and hub pulley **12** when drive pulley is rotated counterclockwise viewed from the pulley side.

CAUTION: Drive pulley setscrew must be aligned with flat surface on motor shaft.

1. Remove diskette drive assembly (1.20).
2. Adjust drive pulley **1** and idler position so that belt rides on center of drive pulley and hub pulley. To adjust drive pulley, loosen setscrew **2**. To adjust idler position, loosen screw **6** and slide idler in or out.



* Jumper assembly PN 4409828 for low voltage (100 – 123.5) or PN 4409829 for high voltage (200 – 240) may be required in order to use the latest style diskette drive motor.

1.28 IDLER ASSEMBLY REMOVAL AND REPLACEMENT

1. Remove diskette drive assembly (1.20).
2. Remove belt and spring **15**.
3. Remove screw **6** and remove idler assembly.
4. To replace idler, reverse above procedure and inspect belt tracking (1.27).

1.29 HUB ASSEMBLY REMOVAL AND REPLACEMENT

1. Remove diskette drive assembly (1.20).
2. Remove cover from diskette drive assembly (1.22).
3. Remove drive belt.
4. Remove screw **13** and remove hub pulley **12**.
5. Remove hub **7**.
6. Remove bearing retaining screws, retaining plate **8**, and bearing **9**.
7. Remove bearing retaining screws, retaining plate **11**, bearing, and spacers **10**.

8. To replace, reverse above procedure. Inspect belt tracking and adjust if necessary (1.27).


CAUTION: The front bearing **9** must be flush with front surface of baseplate. To do this, tighten front bearing retaining screws first. Seal on bearings should face outside.

1.30 DRIVE PULLEY REMOVAL


1. Remove diskette drive assembly (1.20).
2. Remove belt.
3. Loosen setscrew **2** and remove drive pulley **1**.

1.31 DRIVE PULLEY REPLACEMENT

1. Position drive pulley **1** on shaft.
2. Align setscrew **2** with flat surface of shaft, and tighten.
3. Replace belt.
4. Inspect belt tracking and adjust if necessary (1.27).




CAUTION: Before replacing cover screws, position actuator **39** bail under pressure pad arm. **40**




1.32 PRESSURE PAD ACTUATOR REMOVAL AND REPLACEMENT

1. Remove diskette drive assembly (1.20).
2. Remove cover from diskette drive assembly (1.22).
3. Remove two screws **2**.
4. Remove leads and remove pressure pad actuator **1**.
5. To replace, reverse above procedure and adjust (1.33).




1.33 PRESSURE PAD ACTUATOR ADJUSTMENT

1. Load diskette into the diskette drive assembly.
2. Energize the coil by installing a jumper between the "–Head Load" and "Ground" test points on the diskette drive control card (1.51).
3. Adjust screw **3** until the pressure pad arm **40** and bail **39** just touch.
4. Rotate adjusting screw **3** clockwise 1/2 to 3/4 turn and check for gap between arm and bail at all tracks. If condition cannot be met within 1/2 to 3/4 turn, look for mechanical defect.




CAUTION: Before replacing cover screws, position actuator **39** bail under pressure pad arm. **40**



1.34 LEADSCREW AND HEAD CARRIAGE ASSEMBLY REMOVAL

1. Remove diskette drive assembly (1.20).
2. Note routing of head cable.
3. Remove wires from connector by pushing down with small screwdriver, as shown.



4. Center carriage on leadscrew by turning stepper motor wheel.
5. Remove stepper motor **3** per procedure 1.42, and remove leadscrew wheel **2**.
6. Remove diskette drive assembly cover (1.22).
7. Loosen clamping screws on upper and lower stops **5** **6**.
8. Remove bottom bearing **4**.

CAUTION: Watch for preload spring **1** when removing shaft.

9. Slide leadscrew assembly down until top clears baseplate, then slide assembly out.

CAUTION: Do not allow pressure pad arm to snap against head.

10. Remove top bearing, preload spring, and both stops from leadscrew.

1.35 LEADSCREW AND HEAD CARRIAGE ASSEMBLY REPLACEMENT


Note: If the leadscrew and carriage are disassembled, reassemble by threading the leadscrew into the bottom portion of the carriage assembly and into the carriage nut and spring. At **7** there should be a movement of approximately 0.202 inch (0.51 mm) against spring tension.

1. Center carriage assembly on leadscrew and install upper and lower limit stops.
2. Replace top bearing and preload spring **1** (depression side up).
3. Replace assembly into baseplate, bottom end first.
4. Replace bottom bearing and check for about 0.030-inch (0.76 mm) up and down movement of leadscrew against preload spring.
5. Replace leadscrew wheel, leadscrew wheel clamp, and stepper motor.


Note: Reroute head cable as noted under step 2 of the removal procedure (1.34).

6. Connect wires (see 1.34 for wire locations).

Note: Make sure that the locking tabs on the terminals engage in the connector slot to prevent the leads from pushing out when plugged in.



7. Adjust stepper motor (1.43) and read/write head (1.36).
8. Replace diskette drive assembly cover (1.22).



1.36 READ/WRITE HEAD ADJUSTMENT

To properly make the head adjustment, you must obtain three simultaneous conditions:

- Correct head-to-CE tool clearance.
- Correct relationship between the stepper motor and leadscrew wheels.
- Correct clearance between the stepper motor and leadscrew wheels.


1. Remove diskette drive assembly (1.20).
2. Access head to track 0. Leadscrew wheel **12** and stepper motor wheel **13** should line up as in view **S**.
3. Remove diskette drive assembly cover (1.22).
4. Loosen mounting screw and move phototransistor assembly **1** to the left.

Note: If phototransistor assembly is not moved, the accuracy of the head adjustment may be affected.

5. Loosen clamping screws on lower limit stop **8** and leadscrew wheel **9**.

Note: Steps 6 and 7 provide maximum stepper motor-to-leadscrew wheel pin penetration with no binds.

6. Determine type of stepper assembly, below:



7. With stepper motor wheel **13** and leadscrew wheel **12** positioned as in view **S**, insert feeler gauge between these wheels. (see **11** in view **S**.) The feeler gauge should correspond to the gap setting for **X** or **Y** in step 6. Gauge may be left in place.
8. Locate the white dot label or other mark on the outer circumference of diskette drive hub. If hub has both, always use white dot. Rotate hub so that this mark is in the up position.

Note: Step 8 makes sure that any hub eccentricity is located in the same spot and that all head adjustments use the same reference point.

CAUTION: Avoid any contact of CE tool with highly polished face of head.

9. Install CE tool **2** on hub. Clamp into place with thumbscrew.

10. Rotate CE tool so that it contacts surface **4**.
11. Rotate leadscrew by gripping upper limit stop **3** and adjust for gap **5**. This gap is a number found on the front of the read head assembly **6**. This number represents thousandths. Example: 3 equals 0.003" (0.076 mm). Adjust for a very light drag on a 0.003" (0.076 mm) gauge. A 0.002" gauge (0.051 mm) must be free.

Note: When doing step 12, be sure that stepper motor wheel and leadscrew wheel remain positioned as in view **S**.

12. Tighten leadscrew wheel clamping screw **9**. The top of the clamping collar should be nearly even with the top of the metal clamping surface of leadscrew wheel.

Note: If clamping collar is not fastened tightly, machine operation can cause head to go out of adjustment.

13. Adjust phototransistor **1** so that raised edge is in contact with CE tool, and tighten mounting screw.
14. Remove CE tool and adjust lower limit stop (1.40).
15. Recheck gap setting **5**.
16. Rotate stepper motor at least one full revolution and check for binds.
17. Adjust upper limit stop (1.41).
18. If leadscrew wheel is type **Y** in step 6, the slot should be 25–40 percent full with IBM #23 grease.
19. Replace cover (1.22) and adjust track indicator (1.24).

1.37 HEAD AND PRESSURE PAD CLEANING

1. Open the smaller front cover of the controller and remove it by raising it from its pivot pins.
2. Turn off power.
3. Open the cover of the disk drive assembly, and manually rotate the stepper motor wheel until the carriage assembly is at the upper limit stop.

CAUTION: Do not allow pressure pad arm to snap against head. Also, use only the materials mentioned in steps 4 and 5 to clean head and pressure pad.

4. Pivot pressure pad arm **7** away from head and check pad for contamination. If contaminated, use dry brush (PN 2200106) to remove caked deposits and to fluff pad.




CAUTION: Fluid treated cloth should not contact pressure pad.

5. While holding pressure pad arm out, clean polished head surface with isopropyl alcohol (PN 2200200) applied to a clean cloth (PN 2108930).

1.38 LEADSCREW WHEEL REMOVAL AND REPLACEMENT

1.39 NOT USED

1. Remove diskette drive assembly (1.20).
2. Remove stepper motor (1.42).
3. Loosen clamping screw **9** and remove leadscrew wheel **12**.
4. Replace leadscrew wheel. (Don't tighten clamping screw **9** in this step. This screw is tightened during the read/write head adjustment.)
5. Replace stepper motor (1.42).
6. Adjust stepper motor (1.43).
7. Adjust read/write head (1.36).



Machine Front (Cover Side)

Note: *The lower and upper limit stops are adjusted (1.40, 1.41) to make sure that the carriage can always be accessed to tracks 0 and 76 and will not overtravel, damaging this mechanism.*


1.40 LOWER LIMIT STOP ADJUSTMENT

1. Remove diskette drive assembly (1.20).
2. Loosen clampscrew **1**. Make sure that leadscrew is $45^\circ \pm 15^\circ$ beyond track 0 in downward direction. Leadscrew wheel **6** and stepper motor wheel **7** must be in position shown in Detail A.
3. Position limit stop **5** so that projection on limit stop is in front of and against the projection on carriage.
4. Adjust distance **4** between top of projection on limit stop and bottom of carriage for 0.012 to 0.018 inch (0.31 to 0.46 mm).

1.41 UPPER LIMIT STOP ADJUSTMENT


1. Remove diskette drive assembly (1.20).
2. Loosen clamp screw **3** and slide stop up as far as possible.
3. Starting at track 0, rotate stepper motor wheel to move carriage assembly up to track 76.
4. Adjust stop so that distance **2** is 0.025 to 0.035 inch (0.64 to 0.89 mm).
5. Tighten clamp screw **3**.

CAUTION: Do not overtighten clampscrew.



1.42 STEPPER MOTOR REMOVAL AND REPLACEMENT


1. Remove diskette drive assembly (1.20).
2. Remove five leads from the connector (black, white, yellow, red, and blue).



3. Remove two screws **1** and remove motor.
4. To replace stepper motor, reverse the above procedure and then adjust the stepper motor (1.43).


CAUTION: To avoid breaking parts when replacing the stepper motor, make sure that pins **5** of stepper motor wheel **4** are in slots of leadscrew wheel **3**.

Make sure that the locking tabs on the terminals engage in the connector slot to prevent the leads from pushing out when plugged in.




1.43 STEPPER MOTOR ADJUSTMENT


1. Remove diskette drive assembly (1.20).
2. Loosen two screws **1**.
3. Move stepper motor away from leadscrew.
4. Loosen clamping screw **2** and move leadscrew wheel **3** up so that it rotates freely.
5. Position leadscrew wheel as shown in Detail A.
6. Pull leadscrew wheel **3** down until pins **5** on stepper motor drive wheel **4** fit into notches on leadscrew wheel. See Detail A.
7. Slide stepper motor toward leadscrew until pins contact notches. No clearance is allowable. Do not force stepper motor into leadscrew wheel.
8. Tighten two stepper motor mounting screws **1**.
9. Move leadscrew wheel up until it rotates freely.
10. Rotate leadscrew wheel and slide down on drive pins in the position shown in Detail B.
11. Adjust head (1.36).



CAUTION: Before replacing cover screws, position actuator 39 bail under pressure pad arm. 40




Detail A



Top View

Front of Machine (Cover Side)

Detail B





Top View

Front of Machine (Cover Side)

1.44 PHOTOTRANSISTOR SERVICE CHECK


Note: Always perform the following procedure with the diskette loaded; otherwise ambient light will be present, causing a faulty reading on the VOM.

1. Unplug motor connector.
2. Attach positive probe of VOM (15V dc scale) to +5V dc test point on diskette drive control card (1.51).
3. Attach negative probe to "Phototransistor Current" test point on diskette drive control card (1.51).
4. Insert diskette and close cover.
5. With head unloaded, rotate hub until index hole causes phototransistor to switch on or off. (Rotating the hub back and forth causes a continuous switching in the transistor.)
6. A shift in excess of 3.5V dc should be noted on VOM under normal circumstances.
7. If scope is available, plug motor connector in and test for index pulse width of 1.7 to 8.0 ms.



1.45 PHOTOTRANSISTOR ADJUSTMENT




1. Access to track 0.
2. Remove diskette drive assembly (1.20).
3. Remove diskette drive assembly cover (1.22).
4. Loosen mounting screw **3**, and move phototransistor **2** to left.
5. Install CE tool **1** as shown below.



6. Adjust phototransistor **2** so that raised edge is in contact with tool.
7. Tighten mounting screw **3**.
8. Remove CE tool.
9. Replace diskette drive assembly cover (1.22).

1.46 PHOTOTRANSISTOR REMOVAL AND REPLACEMENT

1. Access to track 0.
2. Remove diskette drive assembly (1.20).
3. If necessary, remove diskette drive assembly cover (1.22).
4. Remove mounting screw **3** and washer.
5. Remove leads from phototransistor assembly.
6. Connect leads to the replacement phototransistor. (Yellow wire goes to terminal marked Y.)
7. Adjust starting at step 5 of 1.45.





1.47 LIGHT EMITTING DIODE (LED) SERVICE CHECK


1. Attach positive probe of VOM to "LED Current" test point on diskette drive control card (1.51) and attach negative lead to ground test point.
2. Voltage should be +1.0V dc to +1.6V dc.

1.48 LED REMOVAL AND REPLACEMENT

1. Remove diskette drive assembly (1.20).
2. Remove diskette drive assembly cover (1.22).
3. Remove two mounting screws **1**.
4. Remove leads from LED assembly **2**.
5. To replace, reverse the above procedure. (Yellow wire goes to terminal marked Y.)




CAUTION: Before replacing cover screws, position actuator **39** bail under pressure pad arm. **40**



1.49 DISKETTE DRIVE CONTROL CARD PIN ASSIGNMENT

Name	Color	FC Card	FC Cable End
Stepper Motor MC-0 (Phase 0)	White	B03	D03
Stepper Motor MC-1 (Phase 1)	Red	D02	B02
Stepper Motor MC-2 (Phase 2)	Yellow	B04	D04
Stepper Motor MC-3 (Phase 3)	Black	B02	D02
Stepper Common +24V dc	Blue	D05	B05
Head Magnet +24V dc	Yellow	D04	B04
- Head Load	Black	B05	D05
LED Return	Black	D06	B06
LED Current	Yellow	D07	B07
Phototransistor Return	Black	D09	B09
Phototransistor Current	Yellow	B08	D08
Head Input	Black	B12	D12
Head Input	White	B13	D13
Erase Current	Red	B10	D10
Head Ground and Shield	Green	B09	D09
Preamp TP1		D12	B12
Preamp TP2		D13	B13




				01A1Z Cable End	3601-2/3 Basic Ctrl Bd	3601-C Basic Ctrl Bd	01A1 TB1
Ground	Black	D08	B08				
+Access 0		G02	D02	D02	H6A04	D6E04	X
+Access 1		G03	D03	D03	H6B04	E6A04	X
+Access 2		G04	D04	D04	H6C04	E6B04	X
+Access 3		G05	D05	D05	H6D04	E6C04	X
+Diskette Data		G07	D07	D07	J6A04	E6E04	X
+Head Engage		G10	D10	D10	J6D04	F6C04	X
+Write Data		J02	B02	B02	H6A02	D6E02	X
+Erase Gate		J04	B04	B04	H6C02	E6B02	X
+Write Gate		J05	B05	B05	H6D02	E6C02	X
+Low Current		J06	B06	B06	H6E02	E6D02	X
+Index		G13	D13	D13	K6B04	K6B04	X
+24V dc		J10	B10	B10	J6D02	G6A04	X
+5V dc*		J03	B03	X	X	X	TB1-1
-5V dc*		J11	B11	X	X	X	TB1-4
Ground		J08	B08	B08	J6B02	F6C02	TB1-10

*Note: This cable wire is not point to point.

**1.50 DISKETTE DRIVE CONTROL CARD
REMOVAL AND REPLACEMENT**

The diskette drive control card is positioned with the components and test pins facing out. The card does not have to be moved for servicing.

1. Turn off power.
2. Loosen screw and turn bracket 90°. Tighten screw.
3. Remove card.
4. To replace, reverse above procedure. Be sure card is properly seated in socket and retaining bracket.



Diskette Drive Control Card


1.51 DISKETTE DRIVE CONTROL CARD TEST POINTS

2 X 3 Card Test Points

Note: 2 X 2 card test points are on the following page.

(Only the major components are shown as an aid in locating pins.)

PN 8524194




1.51 (Cont)

2 X 2 Card Test Points

Note: If you experience the problem of no index pulse or multiple index pulses because of shine-through, raise the threshold level of the index amplifier by moving the jumper to position 1. You can raise the threshold level again by moving the jumper to position 2. With the jumper in the high threshold position, more LED light is required to switch the PTX amplifier than when the jumper is in the medium or low threshold positions. Do not increase the threshold level more than necessary to ensure proper operation.

1.52–1.59 NOT USED



1.60 DISKETTE DRIVE ASSEMBLY REMOVAL AND REPLACEMENT

3601

1. Turn off power.
2. Remove the smaller front end cover by raising it from its pivot pins.
3. Remove the side cover by raising up and tilting the top outwards.
4. Remove the diskette drive control card access cover by removing one holding screw.
5. Unplug the diskette drive motor connector.
6. Unplug the cable from the diskette drive control card and remove the ground wire.
7. Remove the holding screw from the diskette drive assembly base plate. The base plate is exposed by the front end cover removal (step 2).
8. Loosen the Zeus* fastener on the inside top of the diskette drive assembly.
9. Remove the diskette drive assembly by sliding it out from the front end of the controller.

Replace the diskette drive assembly by reversing the above procedure.**

3602

1. Turn off power.
2. Swing open the right front cover.
3. Remove the right end cover by pulling out on the bottom and lifting off.
4. Remove the holding screw from the front of the diskette drive bottom base plate.
5. Loosen the two holding screws on the frame to the top rear of the assembly.
6. Lift the assembly up and off the screws loosened in step 5.
7. Tilt the assembly out the front.
8. Disconnect the cables if required.

Replace the diskette drive assembly by reversing the above procedure.**

*Titan Tool Supply Co., Inc.

**Jumper assembly PN 4409828 for low voltage (100–123.5) or PN 4409829 for high voltage (200–240) may be required in order to use the latest style diskette drive motor.

1.61 LATCH ASSEMBLY REMOVAL AND REPLACEMENT

1. Open diskette drive cover **3**.
2. Remove the two latch mounting screws **2**.
3. Pull latch **1** away from cover.
4. To replace, reverse above procedure.

1.62 COVER ASSEMBLY REMOVAL AND REPLACEMENT


1. Turn off power.
2. Open diskette drive cover **3**.
3. Remove both pivot screws **11** while holding cover.
4. Remove cover.
5. To replace cover, reverse above procedure.

Note: When replacing the cover be sure the two timing pins **12** have been returned to the special holder.

CAUTION: Allow power to remain off if removing the cover to start a diskette drive maintenance procedure. Do not turn on power unless a procedure instructs you to do so or is completed.

1.63 COLLET REMOVAL AND REPLACEMENT

1. Remove diskette drive cover (1.62).
2. Remove mounting screw **13**.
3. Remove collet assembly **6**, spring **4**, two washers **10** and shim **9**.
4. Remove collet **8** by removing clip **7**.
5. To replace collet, reverse above procedure.



1.64 HEAD/CARRIAGE POSITION SERVICE CHECK AND ADJUSTMENT

CAUTION: The head/carriage assembly is a factory-adjusted and tested assembly. Do not try to adjust or repair this internal component. Do not, for any reason, clean the read/write heads. To do so would cause severe damage to the head surfaces or head spring supports.

Service Check

1. Remove diskette drive cover (1.62).
2. Remove cover/wiper assembly **4**.

CAUTION: The read/write heads must not be allowed to come together without a piece of clean paper inserted between the head surfaces.

3. Insert a piece of clean paper between the head surfaces.
4. Rotate stepper motor pulley by hand to track 40 and insert timing pin **6** (located inside cover assembly) through pulley **5** and into timing slot **7** in casting.
5. Turn on power.
6. Electrically detent stepper motor to phase 0 by installing a jumper between the "Align Access" and "Ground" test points on diskette drive control card (1.94).

Note: The timing pin should now pass freely through the stepper motor pulley and the timing slot in the casting. If it does not, remove the timing pin and jumper, power off, and adjust the head/carriage position, starting at step 4.


7. Remove the timing pin and return it to its storage location inside cover assembly.
8. Remove jumper installed in step 6.
9. Rotate stepper motor pulley clockwise, by hand, one detent position.

Note: This moves the head/carriage assembly approximately 0.020 in (0.508 mm). Verify by looking for no gap between timing pointer **1** on carriage and timing block **2** on casting.

10. Replace jumper between the "Align Access" and "Ground" test points on diskette drive control card (1.94).
11. Verify 0.020-in. (0.508 mm) gap **3** between timing pointer **1** on carriage and timing block **2** on casting by looking for no motion of head/carriage assembly when a 0.0195-in. (0.495 mm) feeler gauge is inserted. Check for motion of head/carriage assembly when inserting a 0.021-in. (0.533 mm) feeler gauge.

Note: If there is motion with a 0.0195-in. (0.495 mm) gauge inserted, or no motion with a 0.021-in. (0.533 mm) gauge inserted, the head/carriage assembly requires adjustment. Adjust head/carriage position starting at step 10

12. If for some reason verification in step 11 is not positive, repeat steps 8 through 11. (Accuracy of this verification requires that the stepper motor be electrically detented from a point at least one detent away from track 40.)
13. If verification in step 11 is good, remove jumper installed in step 10.
14. Remove paper from between head surfaces.
15. Replace cover/wiper assembly.
16. Replace diskette drive cover (1.62).



1.64 HEAD/CARRIAGE POSITION SERVICE CHECK AND ADJUSTMENT (Cont)

CAUTION: The head/carriage assembly is a factory-adjusted and tested assembly. Do not try to adjust or repair this internal component. Do not, for any reason, clean the read/write heads. To do so would cause severe damage to the head surfaces or head spring supports.

Adjustment

1. Remove diskette drive cover (1.62).
2. Remove cover/wiper assembly **4**.

CAUTION: The read/write heads must not be allowed to come together without a piece of paper inserted between the head surfaces.

3. Insert a piece of clean paper between head surfaces.
4. Measure and record gap between stepper motor pulley and casting **10**.

Gap is:

5. Loosen clamp screw **7**.

Note: The stepper motor shaft should be free to rotate inside the stepper motor pulley.

6. Rotate stepper motor pulley by hand to track 40 and insert timing pin **6** (located inside cover assembly) through pulley **9** and into timing slot **5** in casting.
7. Turn on power.
8. Electrically detent stepper motor to phase 0 by installing a jumper between the "Align Access" and "Ground" test points on diskette drive control card (1.94).

CAUTION: Do not push clamp **8** against pulley **9** when tightening clamp screw **7**. Clamp must be positioned near the end of the pulley flanges for effective clamping.

9. Make the gap **10** recorded in step 4 and tighten pulley clamp screw **7**.

Note: The timing pin should now pass freely through the stepper motor pulley and the timing slot in the casting.

10. Remove the timing pin and return it to its storage location inside the cover assembly.
11. Loosen two band clamping screws **1** on head/carriage assembly.
12. Remove jumper installed in step 8.
13. Rotate stepper motor pulley clockwise, by hand, one detent position.

Note: This moves the head/carriage assembly approximately 0.020 in. (0.508 mm); verify by visually checking for no gap between timing pointer **2** and carriage and timing block **3** on casting.

14. Replace jumper between the "Align Access" and "Ground" test points on diskette drive control card (1.94).

Note: Verify that head/carriage assembly moved to track 40 by visually checking that timing hole in pulley lines up with timing slot in casting (do not use timing pin).


15. Insert 0.020-in. (0.508 mm) feeler gauge between timing pointer **2** on carriage and timing block **3** on casting.



Note: Apply light pressure to top of carriage to hold gauge in place.

16. With light pressure still applied to top of carriage, tighten band clamping screws **1**.
17. Remove jumper installed in step 14.
18. Rotate stepper motor pulley clockwise, by hand, one detent position.
19. Replace jumper between the "Align Access" and "Ground" test points on diskette drive control card (1.94) and verify alignment of timing holes at track 40.
20. Verify 0.020-in. (0.508 mm) gap between timing pointer and timing block by visually checking for no motion of head/carriage assembly when a 0.0195-in. (0.495 mm) feeler gauge is inserted. Check for motion of head/carriage assembly when inserting a 0.021-in. (0.533 mm) feeler gauge.

Note: If there is motion with a 0.0195-in. (0.495 mm) gauge inserted, or no motion with a 0.021-in. (0.533 mm) gauge inserted, repeat steps 11 through 20.

21. If adjustment is good, remove jumper installed in step 19.
22. Remove paper from between head surfaces.
23. Replace cover/wiper assembly **4**.
24. Replace diskette drive cover (1.62).






1.65 HEAD/CARRIAGE ASSEMBLY REMOVAL

1. Remove diskette drive cover (1.62).
2. With power off, remove cover/wiper assembly **7**.
3. Remove head cable from diskette drive control card.

CAUTION: The read/write heads must not be allowed to come together without a piece of clean paper inserted between the head surfaces.

Note: When removing cable assemblies, observe the original routing for replacement purposes.

4. Remove card retainer and diskette drive control card.
5. Position head/carrriage assembly to approximately track 40.
6. Remove two band clamping screws **2** and clamp **1**. Carefully place head/carrriage assembly at its lower limit (track 0).
7. Remove screw **12**, nylon washer **14**, and guide rod **13**.
8. Carefully lift and pivot head/carrriage assembly to remove it from guide rod **4**.



1.66 HEAD/CARRIAGE ASSEMBLY REPLACEMENT


CAUTION: When installing the head/carrriage assembly, make sure bail assembly **5** is under tab **6** of the carrriage arm with bail return spring **11** properly installed.

CAUTION: The read/write heads must not be allowed to come together without a piece of clean paper inserted between the head surfaces.


1. Insert a piece of clean paper between the head surfaces.
2. Carefully install head/carrriage assembly on guide rod **4** and place it at its lower limit.
3. Replace guide rod **13**, nylon washer **14**, and screw **12**.

Note: Ensure guide rod notch **15** is aligned with screw **12** and is properly seated in groove **3**.


4. Position head/carrriage assembly to approximately track 40.
5. Replace clamp **1** and two band clamping screws **2**, but do not tighten.
6. Replace diskette drive control card and card retainer.
7. Following original routing, carefully replace head cable onto diskette drive control card.
8. Rotate stepper motor pulley by hand to track 40 and insert timing pin **9** (located inside cover assembly) through pulley **10** and into timing slot **8** in casting.
9. Turn on power.
10. Electrically detent stepper motor to phase 0 by installing a jumper between the "Align Access" and "Ground" test points on diskette drive control card (1.94).
11. The timing pin should pass freely through the stepper motor pulley and the timing slot in the casting. If it does, adjust the head/carrriage position (1.64), starting at step 11. If it does not, remove the timing pin and adjust the head/carrriage position (1.64), starting at step 4.



Properly Seated
Guide Rod



Improperly Seated
Guide Rod



1.67 HEAD LOAD SOLENOID/BAIL ASSEMBLY SERVICE CHECK AND ADJUSTMENT

Service Check

1. Turn off power.
2. Disconnect drive motor power cable from socket **3**.
3. Remove diskette drive cover (1.62).


DANGER:

Voltage is still present at socket with the drive motor power cable disconnected and power on.

4. Turn on power.

CAUTION: The read/write heads must not be allowed to come together without a piece of clean paper inserted between the head surfaces.

5. Insert a piece of clean paper between the head surfaces.
6. Energize the head load solenoid by installing a jumper between the “-Head Load” and “Ground” test points on diskette drive control card (1.94).
7. Verify gap **5** of 0.015 ± 0.005 in. (0.381 ± 0.127 mm) between bail **1** and carriage arm **2** throughout carriage travel.




Note: If the gap is not within tolerance, adjust solenoid/bail assembly, starting at step 7.

8. Remove jumper installed in step 6.
9. Remove paper from between head surfaces.
10. Replace diskette drive cover (1.62).
11. With head load solenoid deenergized and cover closed, look for gap **4** of 0.93 to 0.108 in. (2.3 to 2.7 mm) between head surfaces.

Note: This gap cannot be measured and must be estimated.

12. If the gap checked for in step 11 is not within tolerance, adjust the head load solenoid (1.67), starting at step 14.
13. Turn off power.
14. Connect the drive motor power cable to socket **3**.
15. Turn on power.



1.67 HEAD LOAD SOLENOID/BAIL ASSEMBLY SERVICE CHECK AND ADJUSTMENT (Cont)

Adjustment

1. Turn off power.
2. Disconnect the drive motor power cable from socket **7**.
3. Remove diskette drive cover (1.62).

DANGER

Voltage is still present at socket with the drive motor power cable disconnected and power on.

4. Turn on power.

CAUTION: The read/write heads must not be allowed to come together without a piece of clean paper inserted between the head surfaces.

5. Insert a piece of clean paper between the head surfaces.
6. Energize the head load solenoid by installing a jumper between the "–Head Load" and "Ground" test points on diskette drive control card (1.94).

DANGER

Solenoid case can get hot.

7. Remove the holding screw from the disk drive assembly base plate.
8. Loosen the Zeus fastener on the inside top of the diskette drive assembly.
9. Slide out the diskette drive assembly so that the solenoid locking screw is accessible **6**.
10. Loosen solenoid locking screw **6**.
11. Rotate solenoid **4** in casting for gap **9** of 0.015 ± 0.005 in. (0.381 ± 0.127 mm) between bail **1** and carriage arm **2**.


Note: A clockwise rotation of the solenoid decreases the bail-to-carriage arm gap.


12. Verify this gap throughout carriage travel.
13. With pellet **5** still in place, tighten solenoid locking screw **6**.
14. Replace the holding screw removed in step 7.
15. Tighten the Zeus fastener.
16. Remove jumper installed in step 6.
17. Remove paper from between head surfaces.
18. Replace diskette drive cover (1.62).

19. With head load solenoid deenergized and cover closed, look for gap **8** of 0.093 to 0.108 in. (2.3 to 2.7 mm) between head surfaces.

Note: This gap cannot be measured and must be estimated. To obtain this gap, turn the backstop screw **3** clockwise until the heads just touch, then back open the heads by turning the backstop screw one turn counterclockwise.

20. Turn off power.
21. Connect the drive motor power cable to socket **7**.
22. Turn on power.





1.68 HEAD LOAD SOLENOID/BAIL ASSEMBLY REMOVAL AND REPLACEMENT

Removal

1. Turn off power.
2. Disconnect drive motor power cable from socket **9**.
3. Remove diskette drive cover (1.62).

CAUTION: The read/write heads must not be allowed to come together without a piece of clean paper inserted between the head surfaces.

4. Insert a piece of clean paper between the head surfaces.
5. Remove the solenoid leads **11** from taper pin terminal block **10**.

Note: When removing cable assemblies, observe the original routing for replacement purposes.

6. Remove bail return spring **4**.
7. Remove mounting screw **3** and bail **2**, pulling solenoid plunger **5** out of solenoid **6**.
8. Remove plunger from bail.
9. Loosen solenoid locking screw **8**.

Note: Be careful not to lose pellet **7**.

10. Remove head load solenoid by turning it counterclockwise.

Replacement

Note: When replacing the head load solenoid, replace both the solenoid **6** and plunger **5**.

1. Install solenoid approximately four turns into casting.
2. Install plunger to bail **2**.

CAUTION: When installing plunger into solenoid, be careful not to damage solenoid surface material.

3. While inserting plunger into solenoid, replace bail and mounting screw **3**.


Note: Be sure bail is under tab **1** of carriage arm.




4. Replace bail return spring **4**.
5. Replace solenoid leads **11** to taper pin terminal block **10**.

DANGER:

Voltage is still present at socket **9** with the drive motor power cable disconnected and power on.

6. Turn on power.
7. Adjust solenoid/bail assembly (1.67), starting at step 6.





1.69 DRIVE BELT SERVICE CHECK AND ADJUSTMENT

Service Check

1. With power on, check that belt **2** is riding on center of hub pulley **1** and drive pulley **6**.
2. If belt is not centered, adjust drive belt.

Adjustment

1. Turn off power.
2. Loosen idler locking screw **3** and drive pulley setscrew **7**.
3. Slide idler assembly **4** and drive pulley **6** in or out so belt is centered on hub pulley **1** and drive pulley when drive pulley is rotated counterclockwise.
4. Align drive pulley setscrew with flat surface **8** of the drive shaft and tighten.
5. Turn on power and do drive belt service check.

1.70 DRIVE MOTOR REMOVAL

DANGER:

Motor case can get hot.

1. Remove diskette drive cover (1.62).
2. With power off, disconnect drive motor power cable from socket **10**.
3. Remove drive belt.
4. Remove two motor bracket mounting screws **12** and remove drive motor and bracket as an assembly **11**.
5. Loosen setscrew **7** and remove drive pulley **6**.

1.71 DRIVE MOTOR REPLACEMENT

1. Install drive pulley **6** on new motor. (Align setscrew with flat surface of the drive shaft **8** and tighten.)

DANGER:

When replacing a 60-Hz drive motor, position two large holes in motor frame to top and under bracket.

2. Replace motor and bracket assembly **11** and two screws **12**.
3. Replace diskette drive cover (1.62).
4. Connect drive motor power cable to socket **10**.*
5. Turn on power and do drive belt service check (1.69).

1.72 DRIVE PULLEY REMOVAL

1. Turn off power.
2. Remove drive belt.
3. Loosen setscrew **7** and remove drive pulley **6**.

1.73 DRIVE PULLEY REPLACEMENT

1. Install pulley **6** on motor shaft aligning setscrew **7** with the flat surface **8** of the shaft.
2. Replace drive belt.
3. Turn on power and do drive belt service check (1.69).

1.74 IDLER ASSEMBLY REMOVAL AND REPLACEMENT


Removal

1. Turn off power.
2. Remove drive belt.
3. Remove idler spring **5**.
4. Remove idler assembly locking screw **3**.
5. Remove idler assembly **4**.

Replacement


1. Reverse above procedure and adjust drive belt (1.69).

*Jumper assembly PN 4409828 for low voltage (100–123.5) or PN 4409829 for high voltage (200–240) may be required in order to use the latest style diskette drive motor.



1.75 STEPPER MOTOR REMOVAL

1. Remove diskette drive cover (1.62).
2. With power off, remove head cable from diskette drive control card.
3. Remove card retainer and diskette drive control card.
4. Disconnect cable from position A2 **19** and remove two screws **1** and cover **2**.
5. Remove stepper motor leads **3** from cable connector by pushing down on terminal tabs with small screwdriver.



6. Remove cover/wiper assembly **8**.
7. Loosen two mounting screws **5**. Push idler assembly **7** against spring tension and tighten screws.
8. Remove clamp screw **17** on pulley **13**.
9. Remove clamp **16**.

CAUTION: During the following steps be careful not to damage the drive band **14**.

10. Carefully remove drive band ends from pulley pin **15**.
11. Measure and record gap between stepper motor pulley and casting **18**.

Gap is:

12. Loosen clamp screw **11** and remove stepper motor pulley.
13. Remove three stepper motor mounting screws **4** and remove motor.

1.76 STEPPER MOTOR REPLACEMENT

1. Install stepper motor into its mounting position and route motor cable toward diskette drive control card.
2. Replace and tighten three screws **4**.
3. Insert stepper motor leads **3** into cable connector.

Note: Make sure that the locking tabs on the terminals engage in the connector slot to prevent the leads from pushing out when plugged in.



4. Replace connector cover and two screws.
5. Connect cable to position A2 **19**.
6. Replace stepper motor pulley **13**, clamp **12**, and screw **11** (do not tighten screw).

Note: With the stepper motor pulley clamp screw loose, the motor shaft is free to rotate inside the pulley.

7. Replace drive band ends on pulley pin **15** with notches facing away from stepper motor. Install clamp **16** and screw **17**, but do not tighten screw.
8. Loosen two mounting screws **5** and allow spring tension to position idler **7**. Tighten mounting screws and center drive band on idler pulley as shown **6**.
9. Replace diskette drive control card and card retainer.
10. Replace head cable on diskette drive control card.
11. Position stepper motor pulley by hand to track 40 and insert timing pin **10** (located inside cover assembly) through pulley and into timing slot **9** in casting.
12. Turn on power.
13. Electrically detent stepper motor to phase 0 by installing a jumper between the “-Align Access” and “Ground” test points on diskette drive control card (1.94).
14. Make the gap between pulley and casting **18** equal the value recorded during stepper motor removal, step 11 (1.75).

CAUTION: Do not push clamp against pulley when tightening clamp screw. Clamp must be positioned near the end of the pulley flanges for effective clamping.

15. Tighten clamp screw **11**.
16. Tighten band clamp screw **17**.
17. Remove timing pin and return it to its storage location inside the cover assembly.
18. Remove jumper installed in step 13.
19. Do drive band service check (1.80).
20. Do head/carriage position service check (1.64).
21. Replace cover/wiper assembly **8**.
22. Replace diskette drive cover (1.62).



1.77 PULLEY/CLAMP REMOVAL

1. Remove diskette drive cover (1.62).
2. With power off, remove cover/wiper assembly **4**.
3. Disconnect head cable from diskette drive control card.
4. Remove card retainer and diskette drive control card.
5. Loosen two mounting screws **1**. Push idler assembly **3** against spring tension and tighten screws.

CAUTION: During the following steps be careful not to damage the drive band.

6. Remove clamp screw **14** and clamp **13** from pulley **10**.
7. Carefully remove drive band ends from pulley pin **12**.
8. Measure and record gap between stepper motor pulley and casting **15**.

Gap is:

9. Loosen clamp screw **8** and remove pulley **10** and clamp **9**.

1.78 PULLEY/CLAMP REPLACEMENT

1. Replace pulley **10**, clamp **9**, and clamp screw **8**. (Do not tighten screw.)

Note: With the stepper motor clamp screw loose, the motor shaft is free to rotate inside the pulley.

2. Replace drive band ends on pulley pin **12** and install clamp **13** and screw **14**. Do not tighten screw.
3. Loosen two mounting screws **1** and allow spring tension to position idler **3**. Tighten mounting screws and center drive band on idler pulley as shown **2**.
4. Replace diskette drive control card and card retainer.
5. Replace head cable on diskette drive control card.
6. Position stepper motor pulley by hand to track 40 and insert timing pin **7** (located inside cover assembly) through pulley and into timing slot **6** in casting.
7. Turn on power.
8. Electrically detent stepper motor to phase 0 by installing a jumper between the “–Align Access” and “Ground” test points on diskette drive control card (1.94).



9. Make the gap between pulley and casting equal the value recorded during pulley/clamp removal, step 8 (1.77).

CAUTION: Do not push clamp against pulley when tightening clamp screw. Clamp must be positioned near the end of the pulley flanges for effective clamping.

10. Tighten clamp screw **8**.
11. Tighten band clamp screw **14**.
12. Remove timing pin and return it to its storage location inside cover assembly.
13. Remove jumper installed in step 8.
14. Do drive band service check (1.80).
15. Do head/carriage position service check (1.64).
16. Replace cover/wiper **4**.
17. Replace diskette drive cover (1.62).

1.79 WIPER REPLACEMENT

1. Remove diskette drive cover (1.62).
2. Remove cover/wiper assembly **4**.
3. Exchange wiper **5**.
4. Replace cover/wiper assembly.
5. Replace diskette drive cover (1.62).



1.80 DRIVE BAND SERVICE CHECK AND ADJUSTMENT

Service Check

1. Remove diskette drive cover (1.62).
2. With power off, disconnect head cable from diskette drive control card.
3. Remove card retainer and diskette drive control card.
4. Loosen two mounting screws **3** and allow spring tension to position idler **5**. Tighten mounting screws.
5. Remove cover/wiper assembly **7**.
6. Rotate stepper motor pulley and check that drive band is centered **4** on idler pulley **5** throughout travel of head/carriage assembly.
7. If above check is not good, adjust drive band, starting at step 5.
8. Replace diskette drive control card and card retainer.
9. Connect head cable to diskette drive control card.
10. Replace cover/wiper assembly **7**.
11. Replace diskette drive cover (1.62).

Adjustment

1. Remove diskette drive cover (1.62).
2. With power off, remove cover/wiper assembly **7**.
3. Disconnect head cable from diskette drive control card.
4. Remove card retainer and diskette drive control card.
5. Position head/carriage assembly to approximately track 40.
6. Remove two band clamping screws **2** and clamp **1**.
7. Loosen two mounting screws **3** and allow spring tension to position idler **5**. Tighten mounting screws.
8. Rotate stepper motor pulley by hand a few turns to allow drive band to find its center **4** on idler pulley.
9. Position head/carriage by hand to approximately track 40 and check that band mounting slots **6** are centered (left to right) over mounting holes on carriage pad.
10. Repeat step 9 for approximately track 76. If both positions are centered, skip step 11.
11. Loosen clamp screw **10** and adjust stepper motor pulley **12** to position needed for steps 9 and 10.
12. Measure and record gap between stepper motor pulley and casting **15**.

Gap is:

13. Position head/carriage assembly to approximately track 40.

14. Replace clamp **1** and two clamp screws **2**, but do not tighten.
15. Position stepper motor pulley by hand to track 40 and insert timing pin **9** (located inside cover assembly) through pulley and into timing slot **8** in casting.
16. Loosen clamp screw **10**.
17. Replace diskette drive control card and card retainer.
18. Connect head cable to diskette drive control card.
19. Turn on power.

Note: *With clamp screw **10** loose, stepper motor shaft is free to turn inside pulley.*



20. Electrically detent stepper motor to phase 0 by installing a jumper between the "Align Access" and "Ground" test points on diskette drive control card (1.94).
21. Make the gap between pulley and casting **15** equal the value recorded during step 12.

CAUTION: Do not push clamp **11** against pulley **12** when tightening clamp screw **10**. Clamp must be positioned near the end of the pulley flanges for effective clamping.

22. Tighten clamp screw **10**.

Note: *The timing pin should pass freely through the stepper motor pulley and the timing slot in the casting.*

23. Remove timing pin and return it to its storage location inside cover assembly.
24. Remove jumper installed in step 20.
25. Adjust head/carriage position (1.64), starting at step 13.







1.81 DRIVE BAND REMOVAL

1. Remove diskette drive cover (1.62).
2. With power off, remove cover/wiper assembly **5**.
3. Disconnect head cable from diskette drive control card.
4. Remove card retainer and diskette drive control card.
5. Loosen two mounting screws **3**. Push idler assembly **4** against spring tension and tighten mounting screws.
6. Position head/carriage assembly to approximately track 40.
7. Remove two band clamping screws **2** and clamp **1**. Carefully lower head/carriage assembly to rest on casting.
8. Remove clamp screw **6** and clamp **7**.
9. Remove drive band ends from pulley pin **8**.
10. Remove drive band.

1.82 DRIVE BAND REPLACEMENT

1. Place drive band around idler assembly **4**.
2. Install drive band ends on pulley pin **8** with notches facing away from stepper motor.
3. Replace clamp **7** and clamp screw **6**, but do not tighten.
4. -Adjust drive band (1.80), starting at step 9.




1.83 STEPPER DRIVE IDLER ASSEMBLY REMOVAL

1. Remove drive band (1.81).
2. Loosen two mounting screws **2**.
3. Remove spring **1**.
4. Remove mounting screws and idler assembly **3**.

1.84 STEPPER DRIVE IDLER ASSEMBLY REPLACEMENT

1. Replace idler assembly **3** and two mounting screws **2**.
2. Replace spring **1**.
3. Push idler assembly against spring tension and tighten mounting screws.
4. Replace drive band (1.82).




1.85 LED/PTX ALIGNMENT

1. Remove diskette drive cover (1.62).
2. Loosen PTX mounting screw **2**.
3. Position PTX assembly **3** against casting stop **1** (away from leads) and tighten mounting screw.
4. Loosen two LED mounting screws **4**.
5. Insert two timing pins **7** (located inside cover assembly) through LED and into PTX assembly and tighten LED mounting screws.
6. Remove timing pins and return to storage location inside cover assembly.
7. Replace diskette drive cover (1.62).
8. Turn on power.

1.86 LED SERVICE CHECK

1. Turn on power.
2. Connect negative probe of volt/ohmmeter (VOM) to "Ground" test point on diskette drive control card (1.94).
3. Connect positive probe of VOM (5V dc scale) to "43FD LED Voltage" test point (1.94).
4. Check VOM for reading of 1V dc to 2V dc.
5. Move positive probe to "33FD LED Voltage" test point (1.94).
6. Check VOM for reading of 1V dc to 2V dc.
7. If either voltage level is not within limits, replace LED assembly **5**.



1.87 PTX/AMPLIFIER SERVICE CHECK


CAUTION: Perform this service check with a diskette inserted backward (with the label facing the hub pulley), or LED light will be present causing a wrong VOM reading.

1. Turn off power.
2. Insert a diskette backward and close cover.
3. Disconnect drive motor power cable from socket **6**

DANGER:

Voltage is still present at socket with the drive motor power cable disconnected and power on.

4. Turn on power.
5. Connect positive probe of VOM (15V dc scale) to "+Index" test point on diskette drive control card (1.94).
6. Connect negative probe of VOM to "Ground" test point (1.94).
7. Check VOM for reading of less than 1V dc.
8. Install one end of a jumper to "43FD PTX" test point (1.94).
9. While observing VOM, touch other end of jumper to diskette drive casting three times. VOM should read 2.5V dc or more for at least last two groundings.
10. Repeat steps 8 and 9 with jumper on "33FD PTX" test point (1.94).
11. If either condition fails to generate at least 2.5V dc output, replace diskette drive control card.
12. Remove diskette.
13. Insert the starter diskette normally.
14. Rotate the hub until the index hole causes the photo-transistor to switch on and off. There should be a shift of approximately 2.5V.
15. Repeat the process with a 2-sided diskette. This tests the other LED and phototransistor.



1.88 LED REMOVAL


1. Remove diskette drive cover (1.62).
2. Disconnect drive control cable from position A2 on the file control card.
3. Remove cable connector cover **1** and remove four LED leads **2** by pushing down on tabs with a small screwdriver.
4. Remove LED cable from retainers **11**.

Note: When removing cable assemblies, note the original routing for replacement purposes.

5. Remove four screws **10** and guide **9**.
6. Remove two LED mounting screws **13** and nuts **14** and remove LED assembly.

1.89 LED REPLACEMENT

1. Install LED assembly **12**, two mounting screws **13**, and nuts **14** into guide **9**.
2. Replace guide and four screws **10**.
3. Following original routing through three retainers **11**, insert the four LED leads **2** (33FD pair identified with tubing) into diskette drive control cable connector.
4. Replace the cable connector cover **1**.
5. Connect cable to position A2 on diskette drive control card socket.
6. Align LED/PTX (1.85), starting at step 2.



1.90 PTX REMOVAL

1. Remove diskette drive cover (1.62).
2. With power off, remove four screws **10** and guide **9**.


Note: Be careful not to damage the LED leads.


3. Disconnect the diskette drive control cable from position A2 on the file control card.
4. Remove connector cover **3** and remove four PTX leads **4** by pushing down on tabs with small screwdriver.
5. Remove PTX mounting screw **7** and washer **6**.
6. Remove PTX assembly **8**.

Note: When removing cable assemblies, note original routing for replacement purposes.

1.91 PTX REPLACEMENT

1. Install PTX assembly **8** against casting stop **5** (away from leads) and replace screw **7** and washer **6**.
2. Following original routing, insert four PTX leads **4** (33FD pair identified by tubing) into diskette drive control cable connector.
3. Replace connector cover **3** and plug connector into position A2 of diskette drive control card socket.
4. Replace guide **9** and four screws **10**.
5. Adjust LED/PTX (1.85), starting at step 4.






1.92 DISKETTE DRIVE CONTROL CARD PIN ASSIGNMENTS

Name	Color	Control Card	Cable, Drive End
Stepper Motor MC-0 (Phase 0)	Orange	G03	D03
Stepper Motor MC-1 (Phase 1)	Red	J02	B02
Stepper Motor MC-2 (Phase 2)	Yellow	G04	D04
Stepper Motor MC-3 (Phase 3)	Blue	G02	D02
Stepper Common +24V dc	Black	J05	B05
Head Magnet +24V dc	Yellow	J04	B04
- Head Load	Black	G05	D05
LED Return (Diskette 1)	Red	J06*	B06
LED Current (Diskette 1)	Black	J07*	B07
PTX Return (Diskette 1)	Yellow	J09*	B09
PTX Current (Diskette 1)	Black	G08*	D08
LED Return (Diskette 2)	Red	G06	D06
LED Current (Diskette 2)	Black	G07	D07
PTX Return (Diskette 2)	Yellow	G11	D11
PTX Current (Diskette 2)	Black	G10	D10
Preamp TP1		J12	B12
Preamp TP2		J13	B13

Cable to Basic Control Board. See Figure 3-3.



Diskette Drive Cable


				Cable End	3601-2/3 3602 Basic Ctrl Bd	3601-D Basic Ctrl Bd	3601 TBI	3602 TBI
Ground	Black	J08	B08					
+ Access 0		B02	D02	D02	H6A04	D6E04		
+ Access 1		B03	D03	D03	H6B04	E6A04		
+ Access 2		B04	D04	D04	H6C04	E6B04		
+ Access 3		B05	D05	D05	H6D04	E6C04		
+ Diskette Data		B07	D07	D07	J6A04	E6E04		
+ Head Engage		B10	D10	D10	J6D04	F6C04		
+ Write Data		D02	B02	B02	H6A02	D6E02		
+ Erase Gate		D04	B04	B04	H6C02	E6B02		
+ Write Gate		D05	B05	B05	H6D02	E6C02		
+ Inner Tracks		D06	B06	B06	H6E02	E6D02		
+ Index		B13	D13	D13	K6B04	G6A04		
+ Erase Current Sense		D09	B09	B09	J6C02	F6B02		
+ Select Head 1		D07	B07	B07	J6A02	E6E02		
+ Two-sided Diskette Sense		B08	D08	D08	J6B04	F6A04		
- Two-sided Drive Sense		B09	D09	D09	J6C04	F6B04		
+ 24V dc		D10	B10	B10	J6D02	F6C02		
+ 5V dc**		D03	B03				TB1-1	TB1-6
- 5V dc**		D11	B11				TB1-4	TB1-10
Ground		D08	B08	B08	J6B02	F6A02	TB1-10	TB1-3

*Tubing.


**This cable wire is not point to point.

1.93 DISKETTE DRIVE CONTROL CARD REMOVAL AND REPLACEMENT


1. Turn off power.
2. Disconnect head cable **2** from diskette drive control card **3**.
3. Remove card retainer **1** and card.
4. To replace, reverse above procedure.




1.94 DISKETTE DRIVE CONTROL CARD TEST POINTS



1.94 DISKETTE DRIVE CONTROL CARD TEST POINTS (Cont)





PN 8527124



1.95 INDEX TEST POINT

Check for index pulses every 166.6 ms at the "+Index" test point on the diskette drive control card (1.51 or 1.94). Pulse width should be 1.7 to 8.0 ms.



1.96–1.99 Not Used

1.100DISK ENCLOSURE (DE) REMOVAL

The following may eliminate the need for DE replacement; it clears as much of the customer data as possible for his security.

You should advise the customer that some information that was on the disk has been destroyed. You should ask the customer whether he wishes to attempt to salvage the remaining data using the utility programs or his own methods. If the customer does not or can not salvage data, the CE should run utility program routines 1 and 4 as follows:

- Load the diagnostic/utility diskette in the diskette drive and press reset on the controller.
- When the control program has been loaded, BC80 may display; respond with the model number of the 3604 that you are using, followed by enter (EM). BC80 should then display on this 3604.
- When BC80 is displayed, respond with 000001 EM (enter key); when 0012 is displayed, respond with F and EM (enter key).
- When 0014 is displayed, respond with C and EM (enter key).
- When the routine is complete, 0000 is displayed. Then respond with 000004 EM (enter key) to run routine 4.
- When 0045 is displayed, respond with C6 EM (enter key). This should write all sector IDs and zero all data fields. If a message of 0041,DDD is displayed, you have a permanent, unrecoverable disk defect, and the DE must be replaced.
- When the routine is complete (nearly 1 hour), there should be a normal completion message of 0044,DDD, where DDD is the decimal count of the sectors with alternates assigned (recoverable surface defects). Respond with C EM (enter key) to terminate.

Running these utilities clears and restores the DE IDs. All the data is now zeros.

Note: See your branch office for correct methods of returning a used DE to ensure security of customer data. Inform the customer of methods available.


CAUTION: Do not turn the motor spindle unless instructed to, and then in a clockwise direction only. See the direction arrow on the duct cover at the rear of the DE.

CAUTION: The DE weighs approximately 37 lb. (12.25 kg.); locate a space for it before removal.

1. Disconnect the controller from the ac power source.
2. Turn on the actuator lock **1**.
3. Remove the DE card socket cover.
4. Release the cable straps located at the side of the DE card sockets.
5. Remove the cards and cable ends from the DE card sockets.
6. Remove the drive belt guard **7** by loosening the two holding screws and lifting it off.
7. Lock the spindle by loosening the two screws holding the spindle lock/anti-static brush, and by engaging the spindle locking pin on the spindle pulley **9**. Tighten the two holding screws.
8. Remove the drive belt **5** after removing belt tension by pivoting the drive motor **6** upward.
9. Disconnect the speed-sensing transducer **3** wires from TB1 **2** terminals 7 (black wire) and 8 (white wire). Unfasten these wires from the holder **4**.
10. If present, disconnect the two wires from TB2 **11** terminals 1 (yellow wire) and 2 (black wire).
11. Disconnect DE ground wire from TB1 **2** terminal 4.
12. Disconnect DE ground strap **8** at the controller end.
13. Ensure that the DE holding clip at the top of the disk storage subframe is engaged. See Detail A.
14. Remove the three mounting nuts and washers **10**. See Detail B.

CAUTION: When lifting away the DE, use care to prevent loose wires from being damaged.

15. Release the DE holding clip, and lift away the DE. Always support the DE on its three mounting screws **10**.



1.101

1.101 DISK ENCLOSURE (DE) REPLACEMENT

Note: Instructions for packing and unpacking are supplied with each DE; one copy fastened outside the case, another inside the case. If both copies are missing, order PN 7373765.

CAUTION: Do not turn the motor spindle unless instructed to, and then in a clockwise direction only. See the direction arrow on the duct cover at the rear of the DE.

CAUTION: When installing the DE, use care to prevent loose wires from being damaged.

1. Lift the DE onto the disk storage subframe. Push the three mounting screws **10** firmly into the rubber mounts, and ensure that the holding clip, at the top of the disk storage subframe, is engaged. See Detail B.

Note: Alignment marks are provided on the disk storage subframe for positioning the top of the DE.

2. Install the three sets of DE mounting nuts and washers (see Detail C) on the mounting screws **10**. Tighten each nut until its two-coiled washer is depressed.
3. Connect the DE ground strap **8** at the controller end.
4. Connect the DE ground wire to TB1 **2** terminal 4.
5. Connect the speed-sensing transducer wires to TB1 **2** terminals 7 (black wire) and 8 (white wire). Fasten these wires in the holder **4**.
6. Measure the space between the speed-sensing transducer **3** and the spindle pulley **9** for 0.006 ± 0.002 -in. (0.1524 ± 0.0508 mm) gap. See Detail A. Adjust, if needed, by loosening the clamping screw.
7. If a yellow wire and a black wire are present near TB2 **11**, connect to terminals 1 (yellow wire) and 2 (black wire).
8. Install the drive belt **5**, smooth side against pulleys, after pivoting the drive motor **6** upward.





CAUTION: Ensure that the drive belt cannot touch the speed-sensing transducer.

9. Unlock the spindle by loosening the two screws holding the spindle lock/anti-static brush, and by disengaging the spindle locking pin on the spindle pulley **9**. Center the anti-static brush on the center pin of the spindle, and tighten the two holding screws.
10. Ensure that the anti-static brush has a pressure of approximately 60 grams on the center pin of the spindle. Adjust, if needed, by forming the brush.
11. Install the drive belt guard **7**.
12. Install the cards and cable ends in the DE card sockets. See DE cables (1.112).
13. Fasten the cable straps located at the side of the DE card sockets.
14. Install the DE card socket cover.
15. Turn off the actuator lock **1**.
16. Do the motor brake service check (1.104).

CAUTION: Before turning on power, allow 30 minutes for the DE to reach room temperature.

17. Run utility program routines 1 and 4 as follows to prepare the DE for 3602 use:
 - Load the diagnostic/utility diskette in the diskette drive and press reset on the controller.
 - When the control program has been loaded, BC80 may display; respond with the model number of the 3604 that you are using, followed by enter (EM). BC80 should then display on this 3604.
 - When BC80 is displayed, respond with 000001 EM (enter key); when 0012 is displayed, respond with F and EM (enter key).
 - When 0014 is displayed, respond with C and EM (enter key).
 - When the routine is complete, 0000 is displayed. Then respond with 000004 EM (enter key) to run routine.
 - When 0045 is displayed, respond with C6 EM (enter key). This should write all sector IDs and zero all data fields. If a message of 0041,DDD is displayed, you have a permanent, unrecoverable disk defect, and the DE must be replaced.
 - When the routine is complete (nearly 1 hour), there should be a normal completion message of 0044,DDD, where DDD is the decimal count of the sectors with alternates assigned (recoverable surface defects). Respond with C EM (enter key) to terminate.

Running these utilities clears and restores the DE IDs. All the data is now zeros.



1.102 DISK MOTOR REMOVAL

CAUTION: Do not turn the motor spindle unless instructed to, and then in a clockwise direction only. See the direction arrow on the duct cover at the rear of the DE.

1. Disconnect the controller from the ac power source.
2. Turn on the actuator lock **1**.
3. Remove the drive belt guard **5** by loosening the two holding screws and lifting it off.
4. Lock the spindle by loosening the two screws holding the spindle lock/anti-static brush, and by engaging the spindle locking pin on the spindle pulley **6**. Tighten the two holding screws.
5. Remove the drive belt **3** after removing belt tension by pivoting the drive motor **4** upward.
6. Disconnect the motor wires from TB1 **2**, terminal 1, terminal 2, and terminal 3.
7. Disconnect the motor-brake wires from TB1 **2**, terminals 5 and 6.
8. Remove the three reusable cable straps that hold these wires (disconnected in steps 6 and 7) to the disk storage subframe.
9. Insert the blade of a large screwdriver through the center of the motor tension spring, and lift the spring from the motor mounting bracket. See Detail A.
10. Remove the locking clip and holding ring from the motor pivot pin.
11. Slide the motor assembly away from the disk storage subframe, and lift upward to clear the pivot pin.
12. Remove the motor from the mounting bracket by removing the three screws at the front of the bracket.
13. If required, remove the brake assembly (1.106).


1.103 DISK MOTOR REPLACEMENT

CAUTION: Do not turn the motor spindle unless instructed to, and then in a clockwise direction only. See the direction arrow on the duct cover at the rear of the DE.

1. Install the motor on its mounting bracket, ensuring that the motor vents face upward and the motor cable exits at the bottom left. Fasten the motor, using the three mounting screws.
2. Replace the brake assembly if it was removed (1.107).
3. Put a small amount of grease on the pivot points of the motor assembly.
4. Lift the motor assembly into position, and insert the pin on the motor mount into the hole in the disk storage subframe.
5. Lift the brake end of the motor assembly onto the pivot pin.
6. Install the holding ring on the pivot pin. Then install the holding clip on the pivot pin, pushing it into the slot with a screwdriver.
7. Lift the tension spring into its position on the motor mounting bracket. See Detail A.
8. Pivot the drive motor upward to ensure correct seating of the tension spring.
9. Connect the motor wires to TB1 **2**, terminal 1, terminal 2, and terminal 3.
10. Connect the motor-brake wires to TB1 **2**, terminals 5 and 6, as indicated by wire labels.
11. Install the three reusable cable straps that hold these wires (connected in steps 8 and 9) to the disk storage subframe.
12. Install the drive belt **3**, smooth side against pulleys, after pivoting the drive motor **4** upward.


CAUTION: Ensure that the drive belt cannot touch the speed-sensing transducer.

13. Unlock the spindle by loosening the two screws holding the spindle lock/anti-static brush, and by disengaging the spindle locking pin on the spindle pulley **6**. Center the anti-static brush on the center pin of the spindle, and tighten the two holding screws.
14. Ensure that the spindle anti-static brush has a pressure of approximately 60 grams on the center pin of the spindle. Adjust, if needed, by forming the brush.
15. Install the drive belt guard **5**.
16. Turn off the actuator lock **1**.




1.104 MOTOR BRAKE SERVICE CHECK

1. Disconnect the controller from the ac power source.
2. Disconnect the disk motor power plug at the ac power box.
3. Connect the controller to ac power, and turn on power.
4. The brake is now energized, and the gap **1** between the brake pad **2** and the brake plate **3** should be 0.005 to 0.010-in. (0.127 to 0.254 mm) at all three openings in the brake mount.
5. Turn off power.
6. Disconnect the controller from the ac power source.
7. The brake is now de-energized, and the gap **8** between the brake pad **7** and the brake coil **6** should be 0.005 to 0.010-in. (0.127 to 0.254 mm) at all three openings in the brake mount.
8. Connect disk motor power plug removed in step 2.

**1.105 MOTOR BRAKE ADJUSTMENT**

1. Disconnect the controller from the ac power source.
2. Loosen the three brake adjustment locking screws **4**.
3. Turn the three adjusting screws **5** slowly for 0.008-in. (0.203 mm) gap as measured in service check step 7.
4. Tighten the locking screws **4**, and do service check.



BLANK PAGE

1.106 MOTOR BRAKE ASSEMBLY REMOVAL

1. Disconnect the controller from the ac power source.
2. Cut open the cable strap **6** holding the motor and brake cables together, and also the strap **5** holding the brake cable to the brake mount.
3. Remove the brake anti-static brush **3** by removing the screw holding it to the brake mount.
4. Remove the ground wire **2** by removing the brake adjustment locking screw **1**. Replace the locking screw.
5. Remove the three mounting screws **7** holding the brake assembly to the motor; also, remove ground wire **4**.
6. Remove the brake assembly, including the brake pad **13** and spring **12**.


1.107 MOTOR BRAKE ASSEMBLY REPLACEMENT

1. Loosen the three brake locking screws **8**.
2. Turn the brake adjusting studs out until the brake coil **11** touches the brake mount **10**.
3. Mount the brake assembly onto the rear of the motor. Ensure that the three slots in the brake pad **13** are aligned with the three pins on the brake coil **11**. When viewed from the rear of the motor, the hazard label should be on top and the cables from the motor and brake should run together at the bottom left.

4. Install the three screws **7** holding the brake assembly to the motor, connecting the ground wire **4** under one of the screws.

CAUTION: Ensure that the brake mount **10** touches the motor end on each of the three mounting surfaces. The surfaces must not be pressed together by the screws **7**, as this would damage the brake assembly. If the surfaces do not touch using hand pressure, ensure that earlier assembly has been done correctly.

5. Install the anti-static brush **3** and its ground cables **2** and **4**. Ensure that the brush has a pressure of approximately 60 grams on the center of the brake. Adjust, if needed, by forming the brush arm.
6. Install the remaining ground wire **2** under one of the brake adjustment screws **1**.
7. Tie the motor and brake cables with cable straps **5** and **6**.
8. Do the motor brake service check (1.104).



1.108 SPEED-SENSING TRANSDUCER SERVICE CHECK

1. Turn off power.
2. Measure for approximately 300 ohms resistance between points 01A1A5D10 and 01A1A5D11. If measurement is incorrect, replace the transducer **2** and do the adjustment (1.109).
3. Connect a CE Probe to the transducer signal, as follows:

<i>Switch</i>	<i>Position</i>
TECHNOLOGY	MULTI
LATCH	NONE
GATE	OFF

Connect probe signal lead to 01A1A5D11, and probe reference lead to 01A1A5D10.

Power leads

- + (red) to any card socket D03 pin (+5V).
- (black) to any card socket D08 pin (Ground).

4. Turn on power.
5. With the disk turning, both probe lights should be on. If not, do the adjustment (1.109). If adjustment was correct, replace transducer.



1.109 SPEED-SENSING TRANSDUCER ADJUSTMENT

CAUTION: Do not turn the spindle **4** during the following procedure.


1. Disconnect the controller from the ac power source.
2. Turn on the actuator lock **1**.
3. Remove the drive belt guard **3**.
4. Measure the space between the transducer **2** and the spindle pulley **4** for 0.006 ± 0.002 -in. (0.1524 ± 0.0508 mm); see Detail A. Adjust, if needed, by loosening the transducer clamping screw.
5. Install the drive belt guard **3**.
6. Turn off the actuator lock **1**.

1.110 ANTI-STATIC BRUSH SERVICE CHECK

1. Disconnect the controller from ac power.
2. Remove the drive belt guard **3**.
3. Ensure that the anti-static brush for the spindle **4**, has a pressure of approximately 60 grams on the center of the spindle. Adjust, if needed, by forming the brush arm.
4. Ensure that the anti-static brush for the brake has a pressure of approximately 60 grams on the center of the brake. Adjust, if needed, by forming the brush arm.
5. Install the drive belt guard **3**.



**1.111 DISK STORAGE CARD JUMPERS
(PN 1794401)**





Notes: 01-B1 board requires back panel connection from H2B09 to F6C04. 01-A1 board requires back panel connections defining installed disk storage size:

Model 1A (5.2 Meg.)

W/O Fixed Heads	D3D09 to C4B10 J3D11 to J3D10 A3D02 to A3D10
With Fixed Heads	D3D09 to C4B10 J3D11 to J3D10 M5D13 to M5D08


Model 1B (9.3 Meg.)

W/O Fixed Heads	B5D09 to D2D09 B5D10 to D4D07 J3D10 to J3D08 D4D05 to K3D10 D4D06 to K3B13 M5D11 to M5D08 A3D02 to A3D10
With Fixed Heads	B5D09 to D2D09 B5D10 to D4D07 J3D10 to J3D08 D4D05 to K3D10 D4D06 to K3B13 M5D11 to M5D08 M5D13 to M5D08



CAUTION: To avoid plugging card in backwards, note the location of the capacitors and plug in the card with the capacitors towards the socket.


1.112 DE CABLES



Cable 1 (Disk Drive Motor)

	Disk TB1	Wire Number	208, 230, 220, 235V ac	115V ac
Disk Drive Motor	1	1	Line	Neutral
	2	2	Ground	Ground
	3	3	Line	Line

Disk TB2 (Not present on Mod 1A)



Cable 2 01X-W1A1 to 01A1A5


	Disk TB1	W1 Logic Board Plugging Position and Pin Number	01A1A5 Cable Connector Contact Number
Motor Brake Speed Transducer	5		B07
	6		B05
	7		D11
	8		D10
1B Only	Disk TB2	A1B02	B02
		A1B03	B03
		A1B04	B04
		A1B07	B08
		A1D02	D02
		A1D07	D07
		A1D09	D08
			D12
			D13

Cable 3 01X-W1B1 to 01A1A2 (Servo Amp)


W1 Board Plugging Position and Pin Number	01A1 Board Plugging Position and Pin Number
B1D04	A2D04
B1D05	A2D05

1.112 DE CABLES (Cont)


**Cable Connector
Contact Numbers**




Cable 6 01X-W1B2 to 01A1A3




Cable 4 01X-W1B5 to 01A1A4



Cable 5 01X-W1B6 to 01A1Y1



1.113 DE BRAKE CIRCUIT



- Measure 24V at 01ATB1-16
- To test continuity, turn off power and remove cards A1C4 and A1H2.
- Measure between TB1-16 and 01A1C4D02 for approximately 100 ohms.
- Between TB1-16 and 01A1H2J10, an ohmmeter should read approximately 25 ohms in one direction and 250 ohms in the other.
- Ensure that cabling is not shorted to anything else.
- Correct any problem found or, if continuity is good, replace the two cards.

1.114 DISK STORAGE DIAGNOSTIC RUN

Note: *The results of this diagnostic are valid only if the complete procedure is followed from power on or reset. The diagnostic expects to start from a reset condition.*

1. Power off all terminals other than the 3604 at address 1 on loop 1, to prevent interference.
2. Insert the diagnostic diskette and activate the controller power-on or reset switch.
3. When the control program has been loaded, BCBO may display; respond with the model number of the 3604 that you are using, followed by enter (EM). BC80 should then display on this 3604.
4. Key in 1010 and press enter (EM). This command selects and runs all disk storage tests that do not require manual intervention.*
5. Messages will be displayed defining machine status:

1000	= Tests completed successfully.
1080	= Temporarily unable to do input/output. This is normal for short periods of time during the tests. A stop (1 minute or more) at this point indicates a controller problem; see MAP2.
10EE X-X	= Machine failure where X-X is error code data. The first two digits are the number of the failing routine. See the Disk Diagnostic Error Codes.
10F0	= Test is running.
BCXX	= Procedure error; see Chapter 3, section 3.12.4.

Note: *The diagnostic run can be ended at any time by pressing the free (FR) key on the 3604 (refer to 1.2 for keyboard locations).*

CAUTION: Do not use reset to end. This could terminate an incomplete write operation. Use the free (FR) key.

*For more information on command codes and test routines, see Chapter 3, section 3.12.

1.115 DISK DIAGNOSTIC ERROR CODES

The following error codes are displayed following error message 10EE. These codes direct you to replace the FRUs in the most likely sequence to solve the failure. Return each FRU that does not solve the problem.

CAUTION: Turn power off when changing cards.

The first two digits of the error code are the number of the failing routine. Generally, error code stops on routines that read can be caused by the disk data having been destroyed. Refer to the routine description in 3.12.3 to determine if a routine or utility program should be run to try to correct or eliminate this as a cause of the error code stop. Refer to the example on the following page.

Try to find a completely matching code. Ignore the "X" character if it appears in the list. The "X" has the following meaning per the jumpering in 1.111:

- | | |
|---|---------------------------|
| 0 | = 5 Meg, no fixed heads. |
| 1 | = 10 Meg, no fixed heads. |
| 4 | = 5 Meg, fixed heads. |
| 5 | = 10 Meg, fixed heads. |

If you cannot find a complete match, try to match only the first 4 characters to the codes in the list with the "***". All cards are located on 01A1 board, except B3, A2 and A5, which are located on the DE. Any other exceptions will be noted. If the error code stop changes when you replace a card, consider the following:

1. Any change in the error code stop may mean that the replacement card was defective or there is more than one problem on the machine.
2. A higher error code stop probably indicates that the replacement card was good, but that there is a second problem. The second problem may be another card or the contents of the disk may have been destroyed by the first defective card. You can try to correct the disk data by running a write routine or one of the utility programs as described in Chapter 3.
3. A lower error code stop probably indicates that the replacement card was defective. If you could not find a match, or if card replacement did not correct the problem, return to the MAP step that you came from.

Note: *Be sure to check jumpers on cards 01A1G2, J2, and K2 (1.111).*

Example:

An example of the sequence of steps that may be required to resolve a customer problem is as follows:

Customer reports problem — probably by an 11 007 error log message.

CE runs diagnostic — error stop 421A 0083 1001 X013 0268 9700

1. The CE determines that the first two digits are 42, which is the failing routine. By referring to 3.12.3, the CE determines that routine 42 is a write-then-read sector ID on the CE cylinder; therefore, the problem is not because of bad data on the disk. Error code list 1.115 directs the CE to replace cards. When the diagnostic is run the second time, there is a 4191 message. By looking at 3.12.3, the CE determines that routine 41 reads the IDs on the CE cylinder; therefore, this error stop can be caused by bad data on the disk.
2. The CE should run only routine 42 as he is trying to correct the original error stop by changing the FRUs listed. In this case the third card corrects the problem.
3. The CE then runs the whole diagnostic again. This time he gets a 4993 error message. Again, by looking at 3.12.3, he could determine that this is a read of the fixed head IDs.
4. The CE should then run routine 50 to write the fixed head IDs.
5. The CE should then run the whole diagnostic again. This time it runs error free.
6. The CE then returns the system to the customer.
7. The customer may then get another 11 007 message indicating disk data is still bad per MAP 11-2.
8. The CE should then advise the customer that some information that was on the disk has been destroyed.
9. The CE should ask if the customer wishes to attempt to salvage the remaining data using the utility programs or his own methods.
10. If the customer does not or can not salvage data, the CE should run utility program routines 1 and 4 as follows:
Load the diagnostic/utility diskette in the diskette drive and press reset on the controller. When the control program has been loaded, BC80 may display; respond with the model number of the 3604 that you are using, followed by enter (EM). When BC80 is displayed, respond with 000001 EM (enter key); when 0012 is displayed, respond with F and EM (enter key). When 0014 is displayed, respond with C and EM (enter key). When the routine is complete, 0000 will display. Then respond with 000004 EM (enter key) to run routine 4. When 0045 is displayed, respond with C6 EM (enter key). This should write all sector IDs and zero all data fields. If a message of 0041,DDD is displayed, you have a permanent, unrecoverable disk defect, and the DE must be replaced. When the routine is complete (nearly 1 hour), there should be a normal completion message of 0044,DDD where DDD is the decimal count of the sectors with alternates assigned (recoverable surface defects). Respond with C EM (enter key) to terminate.
11. Running these utilities clears and restores the DE IDs. All the data is now zeros.

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

(These codes follow the "10EE" message.)

Code	FRUs
* 0000	F2 L2
* 0168	F2 G2 H2 J2
For Error Code 0181, check that 01A1 has power (Fig. 3-8) and that it is cabled to 01A2 (1.112).	
* 0181	* F2 01A2M2
* 0183	F2 K2 J2
0183 525C	F2 J2
* 0185	C2 K2 H2 F2 D2 B3 G2 L2
0185 0210	G2 K2
0185 0410	G2 K2
0185 0411	G2
0185 0810	H2 K2
0185 1010	D2 K2 C2 F2 G2 B3
0185 2010	G2 K2
0185 4010	F2 K2
0185 8010	F2 K2 L2
* 0187	G2
* 0189	F2 G2 H2 J2 K2 L2
0189 0011	H2 F2 G2 J2
0189 0012	F2 J2
0189 0014	F2 J2
0189 0017	F2 J2 L2
0189 0018	F2 J2
0189 0020	J2 H2
0189 0030	J2 F2 G2 H2
0189 0050	G2 H2 J2
0189 0051	L2 G2 H2
0189 0080	F2 H2
0189 0090	K2 J2 H2
* 0191	G2 F2 J2 L2
0191 0010 0010	F2 G2 L2
0191 8014 0010	J2 G2
* 0193	F2 J2 K2 L2 M2 H2 G2
* 0195	F2 J2 K2 L2 M2 H2 G2
* 0197	F2 J2 K2 L2 M2 H2 G2
* 0199	F2 J2 H2 G2 K2
* 019B	F2 J2 K2 L2 M2 H2 G2
* 019D	F2 J2 K2 L2 M2 H2 G2
* 019F	F2 J2 K2 L2 M2 H2 G2
* 01A0	F2 J2 K2 L2 M2 H2 G2
* 01A1	F2 G2
* 01A2	F2 J2 K2 L2 M2 H2 G2

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code	FRUs
* 0283	J2 K2 L2 F2
* 0285	F2 J2 K2 L2 M2 H2 G2
* 0287	F2 J2 K2 L2 M2 H2 G2
* 0289	K2 F2 J2
* 028B	F2 J2 K2 L2 M2 H2 G2
* 028D	F2 J2 K2 L2 M2 H2 G2
* 028F	F2 J2 K2 L2 M2 H2 G2
* 0291	F2 J2 K2 L2 M2 H2 G2
* 0293	M2 J2 F2 K2 L2
0293 0010 0000	F2 M2 K2 J2 L2
0293 0010 0070	F2
0293 0010 0080	F2
0293 0010 00C3	K2
0293 0010 00D1	J2
* 0295	F2 J2 K2 L2 M2 H2 G2
* 0297	F2 J2 K2 L2 M2 H2 G2
* 0299	F2 J2 K2 L2 M2 H2 G2
* 029B	F2 J2 K2 L2 M2 H2 G2
* 029D	M2 J2 F2 D2
029D 0010 0002	M2 J2 D2
029D 0010 00FF	J2 K2
029D 0010 F270	M2 F2

For error codes beginning with 03XX, perform the transducer service checks first (1.108).

* 0391	* C4 B4 D2 H2 M2
* 0393	* C4 F2 L2 M2
* 0395	* F2 J2 K2 L2 M2 H2 G2
* 0397	* F2 J2 K2 L2 M2 H2 G2
* 0399	* C4 H2 B2 D2 M2
* 039B	* F2 J2 K2 L2 M2 H2 G2

For error codes beginning with 04XX, ensure that the actuator lock is off. Run routine 56 first. If it does not isolate the failure, return to this list.

* 0471	* L2 M2 G2
* 0475	* L2
* 0491	* D2 G2
0491 1010 1005 X000 0450	* G2
0491 1010 1005 X000 0650	* G2
* 0493	* D2 C4 M2
* 0495	* D2 B2 B4 C4 C2 F2 G2 H2 M2 J2
0495 0000 1001 X000 0278 0400	* D2 M2
0495 0000 1001 X000 02E8 0400	* C4 D2
0495 0000 1001 X000 03D8 0400	* D2 M2 G2
0495 0000 1001 X000 0648 0400	* C4 D2 M2
0495 0000 1001 X000 0668 0400	* D2 C4
0495 0010 1000 X000 B050 0410	* D2 C2
0495 0010 1000 X000 B070 0410	* D2 B4
0495 0010 1000 X000 F270 0410	* F2 G2 H2 J2 L2
0495 0010 1001 X000 0050 0410	* C4 D2
0495 0010 1001 X000 0250 0410	* C4 B4
0495 0010 1001 X000 0258 0410	* C4 D2
0495 0010 1001 X000 0278 0410	* B4 D2 B2 C4 M2

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code						FRUs
0495	0010	1001	X000	0450	0410	* D2 B4 B2
0495	0010	1001	X000	0650	0410	* B4 D2
0495	0010	1001	X000	1258	0410	* D2 M2
0495	0010	1001	X000	2A40	0410	* D2 C4
0495	0010	1001	X000	2C50	0410	* C4 B2 B4 D2 M2
0495	0010	1001	X000	2E50	0410	* C4 D2 C2 M2
0495	0010	1001	X000	3050	0410	* G2 D2 C4 B4
0495	0010	1001	X000	3250	0410	* D2 M2
0495	0010	1001	X000	3270	0410	* B4 B2 C4
0495	0010	1001	X000	8A50	0410	* D2 B4 G2 M2
0495	0010	1001	X000	A270	0410	* D2 C4 M2 B4
0495	0010	1001	X000	AA40	0410	* D2 G2 J2 M2
0495	0010	1001	X000	AA50	0410	* D2 G2 C4
0495	0010	1001	X000	AC50	0410	* D2 C4 B4 B2 M2
0495	0010	1001	X000	AE50	0410	* C4 D2 M2
0495	0010	1001	X000	AE70	0410	* D2 C4 M2 B4
0495	0010	1001	X000	B050	0410	* D2 B4 B2 C4
0495	0010	1001	X000	B250	0410	* B4 D2 J2 M2
0495	0010	1001	X000	B270	0410	* D2 B4
0495	0010	1001	X000	B450	0410	* B2 B4 C4 D2
0495	0010	1001	X000	EE50	0410	* B4 C4
0495	0010	1001	X000	EE70	0410	* B4 B2 C4
0495	0010	1001	X000	F250	0410	* B2 B4 D2
0495	0010	1001	X000	F270	0410	* B2 D2 B4 C4 K2 F2
0495	0010	1401	X000	2C50	0410	* G2
0495	0010	1401	X000	3250	0410	* G2
* 0497						* M2
* 0499						* M2 F2 D2 G2 J2
0499	0000	1001	X000	02F0	0400	* D2
0499	0020	9141	X001	02F8	0420	* F2
* 049B						* D2 C4 F2 G2 J2
* 1075						F2 L2 J2 K2
1075	0000	1001	X004	02E8	0380	L2 F2
1075	0049	1001	X071	02E8	0140	J2 K2
* 1078						F2 J2 K2 G2 H2 L2
1078	0000	0000	X000	02E8		F2 K2 J2
1078	0000	1001	X000	02E8		F2 J2 G2 H2 L2
* 107A						G2
* 107B						L2 G2 K2 H2 F2
107B	0020	1041	X008	02E8		L2
107B	0020	1141	X000	02E8		G2 H2 K2
107B	0020	1141	X008	02E8		L2 F2 G2
107B	0020	9141	X000	02E8		F2 K2 L2
* 107C						F2 H2
* 107F						F2 J2 K2 G2 H2 L2
* 1081						F2 G2 H2 J2 L2
1081	0000	0000				F2 J2 G2 H2
1081	0801	0000				G2 F2 H2 L2
* 1083						L2 F2 M2 G2 H2 K2
1083	X000	0000				F2 L2 M2 K2
1083	X008	0000				L2 F2 G2 H2

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code			FRUs						
* 1084			G2	J2	F2	D2	H2	K2	M2
1084	0011	0000	K2						
1084	00F9	0000	F2						
1084	1111	0000	K2						
1084	8011	0000	F2	G2	H2				
* 1086			H2	M2	F2	K2	L2	G2	
1086	X089		M2						
1086	X08C		L2	M2					
1086	X0A8		L2	F2	G2	H2	K2	M2	
1086	X0C8		M2						
1086	X0C9		H2	K2					
* 1087			J2	H2	K2	G2			
1087	9113	0000	K2	J2					
1087	9115	0000	K2	J2	G2	H2			
1087	9119	0000	H2	J2					
1087	9151	0000	H2	J2					
1087	9191	0000	H2	J2					
* 1088			H2	J2	C2				
* 1091			H2	J2	K2	M2	G2	F2	L2
1091	X040	0003	H2	G2	J2	K2			
1091	X088	0003	M2	F2	L2				
1091	X089	0003	M2	K2					
* 1093			L2	M2	H2	J2	K2	F2	G2
* 1094			L2	M2	H2	J2	K2	F2	G2
* 1096			H2	G2	F2	K2	L2	J2	
1096	9110	0005	H2	K2					
1096	9111	0005	H2	G2	F2	L2	J2		
* 1097			L2	H2	M2	G2	K2		
1097	XFFF	0005	L2	M2					
* 1098			L2	M2	H2	J2	K2	F2	G2
* 1099			H2	J2		G2			
1099	9111	000A	H2	G2	J2				
1099	9151	000A	J2	H2					
* 109B			L2	M2	H2	J2	K2	F2	G2
* 109D			J2	K2	H2	F2			
109D	8191	000E	J2	H2					
109D	9110	000E	H2	J2					
* 109E			L2	M2	H2	J2	K2	F2	G2
* 10A0			K2	J2	H2	G2	F2	C2	L2
10A0	1011	0015	K2	J2	G2				
* 10A2			L2	M2	H2	J2	K2	F2	G2
* 10A4			L2	M2	H2	J2	K2	F2	G2
* 10A6			L2	M2	H2	J2	K2	F2	G2
* 10A7			H2	F2					

1.115 DISK DIAGNOSTIC ERROR CODES (cont)

Code				FRUs									
* 10B0				L2	M2	H2	J2	K2	F2	G2			
* 10B2				L2	M2	H2	J2	K2	F2	G2			
* 10B3				H2	L2								
10B3	X008	0000		L2									
* 10B4				L2	M2	H2	J2	K2	F2	G2			
* 10B6				L2	M2	H2	J2	K2	F2	G2			
* 10B8				L2	M2	H2	J2	K2	F2	G2			
* 10BA				H2	K2	G2	F2						
* 10BC				L2	M2	H2	F2	G2	C2				
* 10BE				L2	M2	H2	J2	K2	F2	G2			
* 10BF				H2	K2								
* 10C0				H2	G2								
* 10C2				L2	H2	M2	F2	G2					
10C2	X044			L2	F2								
10C2	X060			L2	M2	F2							
10C2	X040	0129		L2	G2	M2							
10C2	X0CA	0129		H2	F2								
* 10C3				L2	M2	H2	J2	K2	F2	G2			
* 10C4				L2	M2	H2	J2	K2	F2	G2			
* 10C6				H2	G2	K2							
10C6	5011	0129		K2	H2								
* 10C7				L2	F2								
* 10C8				L2	M2	H2	J2	K2	F2	G2			
* 10C9				L2	M2	H2	J2	K2	F2	G2			
* 10CA				L2	M2	H2	J2	K2	F2	G2			
* 10CB				G2	J2	H2							
* 10D0				M2	K2	J2	L2	H2	F2	G2	B3	D2	
10D0	0000	0001	0007	J2	K2								
10D0	0000	0010	0007	K2	M2								
10D0	0000	0030	0007	M2	F2								
10D0	0000	0080	0007	L2	M2								
10D0	0000	0200	0007	K2	M2								
10D0	0000	0400	0007	K2	M2								
10D0	0000	0800	0007	K2	M2								
10D0	0000	1000	0007	K2	M2								
10D0	0000	2000	0007	K2	M2								
10D0	0000	4000	0007	K2	M2								
10D0	0001	0000	0011	K2									
10D0	C2C3	0000	0072	L2									
10D0	FFFF	0000	0001	L2	M2	K2	F2						
10D0	FFFF	0000	0005	L2	M2								
10D0	FFFF	0000	000F	M2	L2								
10D0	FFFF	0001	0001	L2	M2								
10D0	FFFF	000F	0001	L2	M2								
10D0	FFFF	00FF	0001	M2	J2	K2							
10D0	FFFF	1FFF	0001	K2									

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code					FRUs									
10D0	FFFF	2101	0001		L2	M2								
10D0	FFFF	3183	0001		L2									
10D0	FFFF	7FFF	0001		K2	M2								
10D0	FFFF	8CEB	0001		L2	M2								
10D0	FFFF	BFFF	0001		K2	M2								
10D0	FFFF	DEDF	0001		L2									
10D0	FFFF	EEEE	0001		K2	M2								
10D0	FFFF	F0FF	0001		J2	K2								
10D0	FFFF	F1FF	0001		D2	B3								
10D0	FFFF	F7FF	0001		K2	M2								
10D0	FFFF	FAFB	0001		L2	F2	H2							
10D0	FFFF	FBFF	0001		K2	M2	G2							
10D0	FFFF	FDFF	0001		K2	M2	G2							
10D0	FFFF	FEFF	0001		K2	M2								
10D0	FFFF	FFFE	0001		M2	L2	H2							
* 10D2					L2	M2	H2	J2	K2	F2	G2			
* 10D5					L2	M2	H2	J2	K2	F2	G2			
* 10D6					L2									
* 10D8					L2	M2	H2	J2	K2	F2	G2			
* 10DA					L2	M2	H2	J2	K2	F2	G2			
* 10DC					L2	M2	H2	J2	K2	F2	G2			
* 117B					L2	M2	H2	J2	K2	F2	G2			
117B	0041	1001	X055	02E8	G2	F2								
* 11A0					F2									
* 11C3					B3									
* 127B					J2	K2	H2							
* 1281					G2									
* 1282					L2	M2	H2	J2	K2	F2	G2			
* 1283					L2	J2	K2	F2	G2	H2	M2			
1283	X008	0000			L2	F2	G2	H2						
* 1284					F2	G2	L2	H2						
* 1286					L2	M2	H2	J2	K2	F2	G2			
* 128A					K2	F2								
* 128D					L2	J2	K2	F2	G2	H2	M2			
* 128E					L2	J2	K2	F2	G2	H2	M2			
* 1290					L2	J2	K2	F2	G2	H2	M2			
* 1292					H2									
* 1294					M2	L2								
1294	X060	0003			L2	J2	H2							
* 1296					H2									
* 1299					L2	J2	K2	F2	G2	H2	M2			
* 129A					L2									
* 129A					L2	J2	K2	F2	G2	H2	M2			
* 129B					L2	J2	K2	F2	G2	H2	M2			
* 129C					L2	J2	K2	F2	G2	H2	M2			
* 129D					L2	J2	K2	F2	G2	H2	M2			
129D	9115	0001			L2	J2	K2	F2	G2	H2	M2			
* 129E					H2									
* 129E					L2	J2	K2	F2	G2	H2	M2			

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code					FRUs								
* 12A0					L2	J2	K2	F2	G2	H2	M2		
* 12A1					L2	J2	K2	F2	G2	H2	M2		
* 12A2					L2	J2	K2	F2	G2	H2	M2		
* 12A4					L2	J2	K2	F2	G2	H2	M2		
* 12A6					L2	J2	K2	F2	G2	H2	M2		
* 12A8					L2	J2	K2	F2	G2	H2	M2		
* 12A9					L2	J2	K2	F2	G2	H2	M2		
* 12AA					L2	J2	K2	F2	G2	H2	M2		
* 12AB					L2	J2	K2	F2	G2	H2	M2		
* 12AC					K2	G2							
* 12AD					G2	H2	F2	K2	J2				
12AD	9111	X0F8	02E8	0016	G2	K2	H2	J2					
12AD	9150	X0F8	02E8	0016	H2	F2							
* 12AE					L2	J2	K2	F2	G2	H2	M2		
* 12AF					H2	F2							
* 12D0					H2								
* 12D2					L2	J2	K2	F2	G2	H2	M2		
* 12D4					L2	F2							
12D4	00C9	1011	X022	02E8	F2								
* 12D5					K2	J2	C2						
12D5	0001	1011	X022	02E8	K2	C2							
* 137E					J2	K2							
* 1383					G2	K2	D2						
* 1385					D2	G2	C4	M2					
* 1387					G2	D2							
* 1389					F2	J2	K2	G2					
* 138B					G2	K2	F2	D2					
138B	8211				K2	G2	F2	D2					
138B	9111				F2	G2							
* 138D					J2	G2	F2	K2					
* 1391					L2	J2	K2	F2	G2	H2	M2		
* 1393					L2	J2	K2	F2	G2	H2	M2		
* 1395					G2	J2							
1395	1011	0005			J2	G2							
* 1397					K2	G2							
* 1399				See Note at end of list.	G2	J2	F2	H2					
1399	9611	0003		See Note at end of list.	J2	H2	F2						
* 139B					G2	J2	F2						
139B	9011	0002			J2	G2							
139B	9011	0003			J2	G2	F2						
139B	9411	0004			J2								
* 139D					G2	J2	K2	H2					
* 139E					G2	J2	K2	H2					
* 139F					G2	J2	K2						
139F	9611	0007			G2	K2							
* 13A1					G2	H2	F2	J2	K2				
13A1	9011	0009			G2	F2	H2	K2					
13A1	9611	0009			J2	G2							
* 13A3					L2	J2	K2	F2	G2	H2	M2		
* 13A5					G2	K2	J2	D2	F2	H2	L2	M2	
* 13A7					G2	K2	J2	D2	F2	H2	L2	M2	
* 13A9					G2	K2	J2	D2	F2	H2	L2	M2	
* 14C7					L2								
* 14D5					L2								
* 14E1					G2	K2	J2	D2	F2	H2	L2	M2	
* 14E2					L2	M2	F2	G2					

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code							FRUs
14E2	0008	X008					L2 F2 G2
14E2	0041	X020					M2 L2
* 14E3							L2 G2 H2
* 14E4							F2 G2 L2
* 1503							F2 K2
* 1582							D2 G2 C4 F2 J2 M2
1582	0003						F2 J2
1582	002A						F2 G2
* 1606							F2
* 1801							J2 F2 K2 L2 M2
* 2003							G2
* 200F							D2 G2 J2 M2 L2
200F	0008	0001	0079	02E8	0000		M2 L2
200F	000B	0001	0077	02E8	0000		M2 L2
* 2101							C4 D2 B4
2101	000A	8001	0008	3660			B4 C4
* 2103							G2
* 2105							C4 D2
* 2180							L2
* 2181							F2 J2 K2 L2 H2
* 220F							G2 H2 L2 J2 M2 C2 F2
220F	000A	8141	X0C9				H2
220F	000A	8181	X0C9				C2 H2 J2
220F	000B	0001	X007				L2
220F	000B	0001	X057				L2
220F	000B	0001	X063	0000			L2 M2
220F	002A	8141	X0CB	0000			F2 G2 H2 L2
220F	004B	0001	X061	0000			L2
* 2211							L2 F2 H2 G2 J2 K2 C2
2211	0023	0001	X057	02E0	0000	0000	K2
2211	0023	0001	X057	02E0	0000	1FC0	C2 H2
2211	0023	0001	X057	02E8	0000		H2
2211	0043	0001	X057	02E0	0000	0000	J2 G2 H2
2211	0043	0001	X057	02E8	0000		J2 H2 G2
* 2213							K2 J2 L2 F2 M2
2213	0003	0001	X057	02E8	0000	0040	K2 J2 F2 M2
2213	0003	0001	X057	02E8	0000	FFC0	L2
* 2281							K2 L2 C2 M2 B3 A5 F2 J2 H2 D2
2281	0003	488C	4886				F2 H2 L2
2281	0003	E0E1	4888				M2 L2
2281	0003	E0E1	83FA				F2 L2 M2 H2 D2
2281	0003	E0E1	8400				H2 F2
2281	0003	E0E1	8404				L2
2281	0803	866A	4886				B3 C2 J2 B2 K2 D2
2281	0803	E0E1	83F8				C2 B3 A5 J2 K2
2281	0803	E0E1	8400				K2 J2 H2
* 230F							F2 G2
* 2311							B3 K2 C2 H2
2311	0023	0001	X016	02E8	0040	0000	K2
2311	0023	0001	X016	02E8	0040	0040	B3
2311	0023	0001	X057	02E8	0040		C2 H2

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code							FRUs
* 2313							K2 F2 B3 H2
2313	0003	0001	X016	02E8	0040	0000	K2 F2 H2
2313	0803	0001	X016	02E8	0040	0000	B3 K2
* 2381							G2 K2 J2 D2 F2 H2 L2 M2
* 2481							F2 G2 H2 D2 C2 L2 M2 J2
* 2482							F2 G2 H2 D2 M2
2482	0803						H2 G2 D2 M2
* 2483							L2 F2 C2 H2 J2
2483	0023						C2
2483	0043						H2 J2
* 2484							F2 G2 H2 D2 C2 L2 M2 J2
* 2485							D2 G2 F2 J2 M2
* 2487							F2 G2 H2 D2 C2 L2 M2 J2
* 2489							D2
* 2520							J2 K2 D2
* 2522							J2 G2
* 2524							J2 F2 D2 K2
2524	0003	0001	X016	02E8	0001	0000	J2 D2 F2
2524	0003	0001	X016	02E8	0005	0105	J2 K2
2524	0003	0001	X016	02E8	0032	1032	J2 K2
* 2622							J2
* 3207							D2 G2
* 3209							G2 D2 K2 C4 J2 M2
3209	2003	0001	X000	02F8	C001		D2 G2 K2
3209	2003	1001	X000	0040	00A8		D2
3209	2003	1001	X000	0640	0002		G2 F2
3209	2003	1001	X000	0660	C001		K2
3209	2003	1001	X000	2E60	0002		C4 D2
3209	2003	1001	X000	3260	0002		D2 G2 M2
3209	2003	1001	X000	3260	00A8		J2
* 3213							G2 J2 K2 D2
3213	0003	1001	X016	0268	5400	1400	J2
3213	0003	1801	X016	0268	0080	0180	G2 K2 D2
* 3219	0423	1001	X013	0269	5400		J2 H2 K2
* 328F							D2 M2
* 3290							M2 D2 C4 G2
3290	0268						G2 D2
3290	1060						M2 C4
3290	1660						M2 C4
3290	5260						D2 M2
* 3292							M2 D2
* 3293							L2 M2
* 3294							M2 D2 L2 C4 K2 J2 H2 C2
* 3295							K2 H2 C2 J2
* 3296							M2 D2 L2 C4 K2 J2 H2 C2
* 32A0							M2 D2 L2 C4 K2 J2 H2 C2

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code	FRUs
* 3301	G2
* 3309	G2 D2
* 3383	G2 D2 K2 M2 C4 J2 F2 L2
* 3384	G2 K2
* 3385	G2 D2 K2 M2 C4 J2 F2 L2
* 3387	G2 D2 K2 M2 C4 J2 F2 L2
* 3389	M2
* 338B	G2 D2 K2 M2 C4 J2 F2 L2
* 3393	G2 D2 K2 M2 C4 J2 F2 L2
* 3395	G2 D2 K2 M2 C4 J2 F2 L2
* 3397	G2 D2 K2 M2 C4 J2 F2 L2
* 3399	G2 D2 K2 M2 C4 J2 F2 L2
* 339B	G2 D2 K2 M2 C4 J2 F2 L2
* 3413	C4 D2 B4 C2 B2
* 3490	G2 D2 K2 M2 C4 J2 F2 L2
* 3492	G2 D2 K2 M2 C4 J2 F2 L2
* 3494	G2 J2
* 3496	See Note at end of list. G2 D2 K2 M2 C4 J2 F2 L2
* 3498	See Note at end of list. G2 D2 K2 M2 C4 J2 F2 L2
* 349A	G2 D2 K2 M2 C4 J2 F2 L2
* 3509	D2 C4
* 3513	D2
* 3607	D2 C4
* 3609	D2
* 360F	H2 J2 K2 F2 L2 M2 G2
* 4127	H2 J2 K2

For error code 4191, run routine 51 first. The CE Track Data may have been destroyed. If it does not isolate the failure, return to this list.

* 4191		*	K2	J2	H2	F2	G2		
* 4193			K2	J2	H2	F2	G2	B3	C2 L2
* 4214			B2	F2	G2	C2			
* 4217			H2	L2	F2	J2			
* 4219			D2	K2	J2	H2	B3	A5	C2 G2 F2
4219	0403	1001	X013	0269	5400	K2	G2		
4219	0423	1001	X013	0268	5400	G2	F2	H2	
4219	0803	1001	X011	0269	5400	H2			
4219	0803	1001	X013	0269	5400	K2	J2		
4219	1013	1001	X011	0268	5400	D2	B3		
4219	1013	1001	X011	0269	5400	D2	B3	A5	C2
4219	1013	1001	X011	0269	9700	B2	A5	D2	
* 421A						K2	H2	J2	B3 F2 G2 C2
421A	0083	1001	X013	0268	9700	D2	F2	G2	
421A	0083	1001	X013	0269	9700	K2	H2	C2	J2
* 4225						H2			
* 4293						K2	J2	H2	F2 G2 B3 C2 L2

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code	FRUs							
* 433D	H2							
* 4392	K2	J2	H2	F2	G2	B3	C2	L2
4392 0003 9702	H2	G2						
* 4393	G2	H2	F2	K2				
* 4395	K2	J2	H2	F2	G2	B3	C2	L2
* 4397	K2	J2	H2	F2	G2	B3	C2	L2
* 439A	K2	J2	H2	F2	G2	B3	C2	L2
* 439E	G2							
* 439F	G2	F2						
* 43A0	H2							
* 43A6	K2	J2	H2	F2	G2	B3	C2	L2
* 43A9	K2	J2	H2	F2	G2	B3	C2	L2
* 43AA	K2	J2	H2	F2	G2	B3	C2	L2
* 43AB	H2	F2						

For error code 4446, run Routine 51 first. The CE Track Data may have been destroyed. If it does not isolate the failure, return to this list.

* 4446	K2	H2	J2	L2	B3	F2	G2	C2
* 4601	F2	H2	G2	J2	K2	L2	M2	
* 4628	H2	F2	G2	K2	L2			
4628 002A X008 0268 5440	F2	G2	H2	K2	L2			
* 4630	G2	F2	H2					
4630 000A 9100 X088 0268 5440	H2	G2						
4630 000A 9101 X008 0268 5440	G2	H2						
4630 002A 9141 X008 0268 5440	F2	G2						
* 4633	H2	F2	G2	L2				
* 464B	F2	H2						
* 4689	J2	K2	G2	H2				
* 4783	F2							
* 4784	F2							
* 4785	F2	K2						
* 4787	F2	K2	H2	L2				
* 4788	K2	H2	L2	F2				
* 4789	G2							
* 478A	K2							
* 478B	M2							
* 483B	G2	B4	H2	F2	J2	K2	L2	M2

For error code 4891, run Routine 51 first. The CE Track Data may have been destroyed. If it does not isolate the failure, return to this list.

* 4891	*	K2	J2	H2	F2	G2	B3	C2	L2
* 4892	F2	G2	B3	C2	L2				

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code							FRUs									
* 4989							K2	J2	A2	H2	F2	G2	B3	C2	L2	
* 4990							B2	A5	A2							
* 4991	See Note at end of list.						F2	D2	A2	G2	B4	L2	M2	C4		
* 4992	See Note at end of list.						F2	D2	A2	G2	B4	L2	M2	C4		
* 4993							F2	D2	A2	G2	B4	L2	M2	C4		
* 5090							A2	B3	D2	G2						
* 5092							A2	B3	D2	G2						
* 5093							A2	B3	D2	G2						
* 5094							A2	B3	D2	G2						
* 5222							J2	K2								
* 5381							F2	D2			G2	B4	L2	M2	C4	
* 5383							F2	D2			G2	H2	B4	L2	M2	C4
* 5668							F2	L2								
* 5681							F2	D2			G2	H2	B4	L2	M2	C4
* 5682							F2	D2			G2	B4	L2			
5682	0000	0001	X000	02E8			F2	B4								
5682	0010	0010	X000	0000			F2	L2								
5682	0010	1010	X000	8450			D2									
5682	0010	1011	X000	AC70			D2									
5682	0010	1011	X000	B250			D2									
5682	0010	1011	X000	B270			D2	M2								
* 5691							D2	C4			G2	J2	M2			
5691	0010	1011	X000	42E8			C4	D2			M2					
* 5693							F2	D2			G2	J2	K2			
5693	0000	0011	X000	F270			F2	K2								
5693	0000	1011	X000	F270			D2	F2			G2	J2	K2			
* 5695							F2	D2			G2	H2	B4	L2	M2	C4
* 5697							D2	C4								
* 5699							D2	C4			B4	B2	G2	F2	M2	J2
5699	0000	1001	X000	0278	0100		D2	M2								
5699	0000	1001	X000	02D8	0100		D2	C4			C2	M2	G2			
5699	0010	1000	X000	AC50	1C00		D2	C2								
5699	0010	1000	X000	B070	1C00		D2	C2								
5699	0010	1001	X000	0250	AB00		C4	D2			M2					
5699	0010	1001	X000	0258	0100		C4									
5699	0010	1001	X000	0270	0100		C4	D2								
5699	0010	1001	X000	0278	0100		B4	B2			D2	C4				
5699	0010	1001	X000	0450	BF00		D2	B4								
5699	0010	1001	X000	0450	B700		D2	B4			M2					
5699	0010	1001	X000	1258	0100		D2	B4			M2					
5699	0010	1001	X000	2C50	1D00		C4	B2			M2					
5699	0010	1001	X000	3050	1D00		B2	C4			B4	D2				
5699	0010	1001	X000	3270	0100		D2	B4			C4	M2	G2			
5699	0010	1001	X000	3070	0100		C4	D2			M2					
5699	0010	1001	X000	3250	1D00		C4									
5699	0010	1001	X000	3270	1D00		B2	B4			C4					
5699	0010	1001	X000	7270	0100		D2	B2								
5699	0010	1001	X000	8A50	0000		D2	B4			M2					

1.115 DISK DIAGNOSTIC ERROR CODES (Cont)

Code	FRUs
5699 0010 1001 X000 A270 0000	D2 C4 B4 M2
5699 0010 1001 X000 A850 1C00	B2 B4 C4
5699 0010 1001 X000 AA50 0000	D2 G2 C4 B4
5699 0010 1001 X000 AC70 1C00	D2 B4
5699 0010 1001 X000 AE50 0000	C4 D2 M2
5699 0010 1001 X000 B074 1C00	D2 B4
5699 0010 1001 X000 B250 0000	B4 D2
5699 0010 1001 X000 B270 0000	D2 B4
5699 0010 1001 X000 B270 0100	D2 C4 J2 M2
5699 0010 1001 X000 EA70 0000	B2 B4
5699 0010 1001 X000 EE50 0000	B4
5699 0010 1001 X000 F250 0000	D2 B2
5699 0010 1001 X000 F270 0000	B2 D2 B4 F2
5699 0010 1001 X000 F650 0000	B4
5699 0010 1001 X000 F670 0000	B2 B4 C4
5699 0010 1011 X000 4668 0100	C4 C2
5699 0010 1401 X000 2C50 1F00	G2
5699 0010 1401 X000 3050 1F00	G2
* 569B	F2 D2 G2 H2 B4 L2 M2 C4
* 569D	D2 C4 F2 G2 J2
* 5781	F2 D2 G2 H2 B4 L2 M2 C4
* 5791	F2 D2 G2 H2 B4 L2 M2 C4
* 5792	F2 L2 J2 K2 M2
5792 0010	M2
* 5793	F2 D2 G2 H2 B4 L2 M2 C4
* 5794	L2 F2
* 5795	F2 D2 G2 H2 B4 L2 M2 C4
* 5796	M2 L2 C4 F2 D2
5796 7270	M2 C4
5796 D270	M2 D2
5796 F250	F2
5796 F274	L2

Note: These error codes may be caused by configuration errors on the diagnostic diskette. Check the continuity of the configuration jumpers on 1.111 and ensure that they correctly match the hardware you have. Then start utility routine 5 by entering 000005 when BC80 is displayed. This should dynamically configure your diskette. When it displays 0055 terminate it by depressing the Free Key, and rerun the diagnostic. This time, follow the FRU replacement listed for these error codes.

1.116 – 1.119 Not Used

1.120 SUPPLY VOLTAGE TEST POINTS

Logic Board	Card and Pin*	Limits
Basic	H2U03	+4.5 to +5.5
Controller	H2S11	+7.7 to +9.3
and Adapter	H2S06	-4.5 to -5.5





*Ground = any D08, J08, P08, or U08

Note: If the axe circuit forces all supply voltages to 0 volt, all voltages should be looked upon as failing.

1.121 EXTERNAL MODEM WRAP CARD

Line Name	PN 8523344		PN 1747496	
	Modem	Jumper*	Modem	Jumper
Request to Send	600 1200 GND 4800	A to B A to B Open	All	A to B
Data Signal Rate Selector	600 1200 GND 4800	D to E C to D Open	1200 2400	D to E C to D

*Use jumper, PN 816645.





PN 5864363
5864660 (A)

PN 4409769 (B)

Note: See the chart on the end of the logic gate for card locations.

**Optional EC747541, added capacitor assembly PN 4405002 from B09 and D09 to ground D08 to eliminate noise on Xmit data and Xmit clock.

1.122 EXTERNAL MODEM SIGNAL CABLE



PN 4944498 * (Used with card PN 8523344)

Signal	Y Pin	Connector
Received Data	1	3
Ground	2	7
Transmitted Data	3	2
Spare	4	Tied back
Clear to Send	5	5
Carrier Detect	6	8
Request to Send	7	4
Data Signal Rate Sel	8	23

PN 4944499 (Used with card PN 1747496) **


Signal	Y Pin	Connector
Received Data	1	3
Ground	2	7
Transmitted Data	3	2
Spare	4	Tied back
Transmit Clock	5	24*
Data Term. Ready	6	20
Request to Send	7	4
Data Signal Rate Sel	8	23

*15 for some WT modems.

PN 4409768 (Used with card A or B)

Signal	Card Pin	Connector
Received Data	G04	3
Ground	J08	7
Transmitted Data	G07	2
Spare		Tied back
Transmit Clock	G12	24*
Data Term. Ready	J02	20
Request to Send	G03	4
Data Signal Rate Sel	J06	23


*15 for some WT modems.



1.123 TRANSMIT LEVEL ADJUSTMENT

38LS Modems

The US Domestic version is not adjustable. It is factory set and sealed at 0 db. The World Trade version is adjusted by setting the switches as shown.



*WT only; switches AA-DD are for line equalization (3.9.4).

I=On

Switch DBM	A	B	C	D	E	F	G	H
0								
-1								
-2								
-3								
-4								
-5								
-6								
-7								
-8								
-9								
-10								
-11								
-12								
-13								
-14								
-15								
-16								
-17								
-18								

1200-BPS Integrated Modem

Setting Transmit Level Without a DB Meter (Remote Loop)

Turn the transmit level potentiometer counterclockwise at least 15 turns (for PN 5864365, counterclockwise 15 turns, then clockwise 8 turns) to set the level to approximately -2db to 0db. This potentiometer is the topmost on the card when the card is plugged in. (No jumpers on card).

Setting Transmit Level Without a DB Meter (Host Link)

Turn the transmit level potentiometer clockwise at least 15 turns. With the jumper on the transmit card, the level will be approximately 0db to +2db; without the jumper, approximately -2db to 0db. This potentiometer is topmost on the card when the card is plugged in.

Transmit Level Adjustment With a DB Meter

This procedure requires DB meter PN453545:

1. Set the 2W-4W TRANS/REC switch to TRANS.
2. Set the WRAP switch to the down position (not in wrap).
3. Connect the DB meter in one of the following ways:
 - a. Connect the plug end of the communications cable to the TRANS/REC jack on the cover of the DB meter. Jumper the cover LINE terminals to the DB meter LINE terminals. Set the BRDG/600/324 switch to 600. See Wiring A.
 - b. Jumper the transmit lines (B02 and D05 of the modem transmit card) to the LINE terminals of the DB meter. Set the BRDG/600/324 switch to 600 and disconnect the cable to the communication channel. See Wiring B.
 - c. 4-wire only:
Jumper the transmit lines (B02 and D05 of the modem transmit card) to the LINE terminals of the DB meter. Set the BRDG/600/324 switch to BRDG. See Wiring C.
4. Set the RANGE switch (0 to -45) to the value to be added to the meter reading.
5. Set the POWER switch to on.
6. Press the BATT TEST switch. The meter should read in the GOOD range if the batteries are good. Release the BATT TEST switch.
7. Adjust the transmit level potentiometer (at the top of the transmit card when the card is plugged in) until the meter value plus the RANGE switch value equals the required DB level. (You may have to jumper J07 to ground to force the modem to transmit.) You may have to install the transmit level jumper on the card to reach 0db level.


1.124 TRANSMIT LEVEL ADJUSTMENT FOR 600-BPS INTEGRATED MODEM



This procedure requires DB meter PN 453545:


1. Set the 2W-4W TRANS/REC switch to TRANS.
2. Set the WRAP switch to the down position (not in wrap).
3. Connect the DB meter as stated in (a) below if the communication cable of the controller is terminated by a plug, or as stated in (b) below if terminated by other than a plug.
 - a. Connect the plug end of the communications cable to the TRANS/REC jack on the cover of the DB meter. Jumper the cover LINE terminals to the DB meter Line terminals. Set the BRDG/600/324 switch to 600. See Wiring A.
 - b. Jumper the transmit lines (B02 and D05 of the modem transmit card) to the LINE terminals of the DB meter. Set the BRDG/600/324 switch to 600 and disconnect the cable to the communication channel. See Wiring B.
4. Set the RANGE switch (0 to -45) to the value to be added to the meter reading.
5. Set the POWER switch to on.
6. Press the BATT TEST switch. The meter should read in the GOOD range if the batteries are good. Release the BATT TEST switch.
7. Read the meter and add it to the value of the RANGE switch.

CAUTION: Turn off power before removing or inserting a card.

8. If transmit level adjustment is required, refer to the adjacent sketch. Two straps are required, one on each side of the dashed line between the two 0 DB pairs of pins. Add the values assigned to the two strapped pairs of pins.







Wiring C


(Procedure 1.123)

1.125 RECEIVE-LEVEL CHECK FOR 1200-BPS AND 600-BPS INTEGRATED MODEMS

To verify that an adequate signal level is being received, you may monitor the receive signal at the controller with the DB meter, as follows:

1. **CAUTION: Turn off power.**
2. Remove the transmit and receive card, cards.
3. Turn on power.
4. Connect the DB meter LINE terminals as explained in Note 1.
5. Set the BRDG/600/324 switch to 600.
6. Set the power switch to on.
7. Press the BATT test switch. The meter should read in the good range if the batteries are good. Release the BATT test switch.

8. Set the range switch to obtain a meter reading and add its value to the meter reading. (Two-wire 1200 bps operation requires that the other end be forced to transmit by jumpering J07 of its transmit card to ground.)
9. In countries that permit transmission at 0 db, the received signal should be about -16 db. In these countries, the signal-to-noise ratio at the receiver should allow normal operation between extreme limits of 0 and -27 db. Usually, lower transmit limits allow the receiver to operate to a lower extreme. The carrier detect threshold can be lowered from -33 db to -43 db by jumpering D11 to D12 on the receive card (2-card modem).



Note 1:

- 1200 bps: Connect LINE terminals to G09 and J11 of receiver card.
- 600 bps: Connect LINE terminals to B02 and D05 of the transmit card.
- 38LS M/D: Connect LINE terminals to B02 and D05.

1.126 POWER SUPPLY REMOVAL AND REPLACEMENT

DANGER

Be sure to disconnect the controller power cord from the ac outlet.

1. Unplug power input cable from the power supply assembly.
2. Unplug the slip-on connectors from the output of the power supply. Note wire number sequence. Refer to Power Distribution Wiring Diagram, Figure 3-10.
3. Loosen two bottom holding screws.
4. Remove two top holding screws.
5. Lift power supply mounting plate off two lower holding screws.
6. Remove screws holding power supply to mounting plate.

To replace the power supply, reverse the above procedure.

DANGER

Be sure to disconnect controller power cord from ac outlet.

1. Remove diskette access cover.
2. Remove front cover (two screws).
3. Remove side cover and open gate.
4. Remove top cover (four nuts, one in each corner).
5. Remove fan air duct.
6. Loosen bottom 2 screws on power supply mounting plate.
7. Remove top two screws.
8. Lift power supply mounting plate from bottom two screws. Turn power supply 90° to expose cabling through top of machine.

To replace the power supply, reverse the above procedure.

1.127 LOGIC BOARD REMOVAL AND REPLACEMENT

CAUTION: Turn off power.

1. Unplug all cards from board.
2. Unplug all cables from board. Note the location of cables and jumpers.
3. Remove four screws that hold the logic board to the gate.
4. Remove the logic board.

To replace the logic board, reverse the above procedure. Use 1.131 for card locations. Be sure to connect jumpers on board, as on the original board. For jumper information, refer to 3.9, 3.11, and 1.111.

1.128 CARD NAMES – BOARDS WHERE USED (ALL CONTROLLERS)

Note: For disk storage cards, see 1.129.

Term	Name	Use	Board Name	Part Number
ALA	Alternative line attachment (to down line equipment from the controller)	ALA	Basic controller, adapter	
CA	Communication Adapter; see CCA and HPCA.			
CCA	Common communication adapter (with clock)	ALA Host	Basic controller, adapter	8526485
	Common communication adapter (without clock)	ALA Host	Basic controller, adapter	8523016
CTRL	Control			
CTLR 1	Controller card 1	Basic	Basic controller	2411872
CTLR 2	Controller card 2	Basic	Basic controller	2411851
CTLR 3	Controller card 3	Basic	Basic controller	2411869 2411893*
Diskette Adapter	Diskette adapter	Basic	Basic controller	1590652 1590648* 5619736*
EIA	Electronic Industries Association (converter for external modem)	Host	Basic controller	8523023
EIA/ PTT	Electronic Industries Association (converter for external modem)/ public telephone, telegraph (with clock)	Remote loop	Basic controller, adapter	1747496 4409769**
	Electronic Industries Association (converter for external modem)/ public telephone, telegraph (without clock)	Remote loop	Basic controller, adapter	8523344 4409769**
ESA 1	Extended storage address (card 1)	Basic	Basic controller	2411855 1588028* 1588030* 1588096* 1588098*
		Expanded memory	Basic controller	1588075 1588090*
ESA 2	Extended storage address (card 2) Heavy lands identify D and J connector pins to board.	Basic	Basic controller	8514516
		Expanded memory	Basic controller	2411890

*Indicates this PN has a later EC level than the PN listed above it. To ensure card is available, order the part number on the card being replaced. It is possible that later level cards have been used

** See 1.121 and 1.122.

since the publication of this document. If a card with a part number that is not listed is found in the machine, consult your support structure for more information.

1.128 (cont)

Term	Name	Use	Board Name	Part Number
FSU Type A	Functional storage unit; first and second 8K blocks of Volume 0	Basic	Basic controller	1744832 4941120* 6815146*
FSU Type B	Functional storage unit; first, second, third, and fourth 8K blocks of Volume 0	Basic	Basic controller	4406044 6815147*
FSU Type C	Functional storage unit; first and second 8K blocks of Volume 1	Basic	Basic controller	8527159
FSU Type D	Functional storage unit; first, second, third, and fourth 8K blocks of Volume 1	Basic	Basic controller	1588051
FSU Type E	Functional storage unit; first, second, third, and fourth 8K blocks of Volume 1	Basic	Basic controller	1588052
FSU Type F	Functional storage unit; two 8K blocks	Basic	Basic controller	8527158
HOST	Line attachment to up-line equipment from the controller			
HPCA	High performance communication adapter (with clock)	Host	Basic controller	8526519
		ALA	Basic controller, Adapter	
	High performance communication adapter (without clock)	Host	Basic controller	8526518
		ALA	Adapter	
LOOP CTRL	Loop control	Loop	Basic controller, Adapter	1744811 1741520* 4404468*
M/D RCVR	Modulator/demodulator (modem) receiver	Host	Basic controller	5864331
		ALA	Basic controller, Adapter	
M/D XMIT	Modulator/demodulator (modem) transmitter	Host	Basic controller	5864353 5864374*
		ALA	Adapter	
M/D WRAP	Modulator/demodulator (modem) wrap (test card)	Host	Basic controller	5862864
		ALA	Adapter	
M/D RCVR/ XMIT	Modulator/demodulator (modem) receiver transmitter (single card remote loop modem)	Remote loop	Adapter	5864365 5864376*

*Indicates this PN has a later EC level than the PN listed above it. To ensure card is available, order the part number on the card being replaced. It is possible that later level cards have been used

since the publication of this document. If a card with a part number that is not listed is found in the machine, consult your support structure for more information.

1.128 (cont)

Term	Name	Use	Board Name	Part Number
RE-DRIVE	Redrive card. Amplifies and redrives signals on the input/output bus to disk storage, loop 7, 8 and ALA ports 81, 82, and 83	Disk loop ALA	Adapter	8525771
RESET	Reset	Basic	Basic controller	8524554
38LS M/D	38-low speed (up to 1200 bps) Modulator/Demodulator	Host	Basic controller	1644769
		ALA	Basic controller, Adapter	1756005* 8564510*
		Remote loop	Adapter	1755945 1756011* 8564481* World Trade
38LS EIA	38 low-speed (up to 1200 bps) Compatible Electronic Industries Association (converter for external modem)	Host	Basic controller	5864363
		ALA	Basic controller Adapter	5864660*

* Indicates this PN has a later EC level than the PN listed above it. To ensure card is available, order the part number on the card being replaced. It is possible that later level cards have been used since the publication of this document. If a card with a part number that is not listed is found in the machine, consult your support structure for more information.

**1.129 CARD NAMES – BOARDS
WHERE USED
(3602 Disk Storage Only)**

Term	Name	Use	Board Name	Part Number
Buffer	Disk storage adapter buffer	Disk storage	Disk storage	1745550 6815150*
Bus Byte 0	Disk storage adapter bus, byte 0	Disk storage	Disk storage	8524620
Bus Byte 1	Disk storage adapter bus, byte 1	Disk storage	Disk storage	8524652
Byte Ctrl	Disk storage adapter byte control	Disk storage	Disk storage	8526006
Coil Drivers	Disk storage control coil drivers, 5.2 meg	Disk storage	Disk storage	5861346 5861352*
	Disk storage control coil drivers, 9.3 meg	Disk storage	Disk storage	5861350
Ctrl Disk	Disk storage adapter control	Disk storage	Disk storage	8525774 8526618* 8526620**
Data Separator	Disk storage adapter data separator	Disk storage	Disk storage	8219247 8219259*
Data AGC	Disk enclosure data and automatic gain control	Disk storage	DE	5850850 8250197* 8219258*† 8219260*† 8219264*†
Decode	Disk storage adapter decode	Disk storage	Disk storage	8524609
Fixed Head	Disk enclosure fixed head	Disk storage	DE	5861336 8250195*†
Interface	Disk storage adapter interface, 5.2 meg	Disk storage	Disk storage	8522402 8522701* 8522693*
	Disk storage adapter interface, 9.3 meg	Disk storage	Disk storage	8522616 8522694* 8522702*

Note: For footnotes, refer to the following page.

1.129 (cont)

Term	Name	Use	Board Name	Part Number
Position Detect	Disk storage access arm position detector, 5.2 meg	Disk storage	Disk storage	5850867 8219249* 8219265*
	Disk storage access arm position detector, 9.3 meg	Disk storage	Disk storage	5850973 8219251* 8219266*
Preamp	Disk storage data preamplifier	Disk storage	DE	8230292 8219253* 8219255*†
Seek Ctrl	Disk storage seek control	Disk storage	Disk storage	8526496 8528055*
Velocity Ctrl	Disk storage access arm velocity control 5.2 meg	Disk storage	Disk storage	5850875 8219257*
	Disk storage access arm velocity control 9.3 meg	Disk storage	Disk storage	5850968


*Indicates this PN has a later EC level than the PN listed above it. To ensure card is available, order the part number on the card being replaced. It is possible that later level cards have been used since the publication of this document. If a card with a part number that is not listed is found in the machine, consult your support structure for more information.

- † • Fixed head card PN 8250195 must be used with a choice of Data AGC cards PNs 8219258 or 8219260 or 8219264 and preamplifier card 8N 8219255.
- Data AGC cards PNs 8219258 or 8219260 or 8219264 must use preamplifier card PN 8219255.
- Preamplifier card PN 8219255 can only be used with Data AGC cards PNs 8219258 or 8219260 or 8219264.


**Buffer card PN 6815150 and the following wires are prerequisite for this card:

K4D08 to L4D13
G4B05 to L5B11
M4B09 to L4B02
L4B13 to G3D02
J3B06 to L3B06
J3B09 to L4B05
L2B06 to J5D04
H3D09 to L3B11
L4B11 to H2D02
L4D05 to D5B10
K3B02 to L3D10


1.130 BOARD LOCATIONS




3601 Models 2A, 2B, 3A, 3B
Prior to Mid 1978



3601 Models 2A, 2B, 3A, 3B
After Mid 1978




3601 Models C, D




3602 Models 1A, 1B

1.131 CARD LOCATIONS


Note: Compare Board Locations (1.130) with your controller to determine your board PN.




Disk Storage Card Side PN 1744816



1.131 (cont)




Basic Controller, Card Slide PN 4944490



Adapter, Card Side PN 4944496


1.131 (cont)



Basic Controller Card Set PN 6813046

Legend

- Ctrl = Controller card
- EIA = Electronic Industries Association converter for external modem.
- ESA = Extended storage addressing.
- FSU = Functional storage unit.
- M/D = Modem
- SDLC = Synchronous data link control.
- ① = Number 1.
- ⑧ = Number 8.
- = Crossover, PN 2633938



Basic Controller Card Side PN 6813048

BLANK PAGE

Chapter 2. Maintenance Approach, Aids, and Special Tools

Contents

Heading	Page
2.1 Functional Parts of the Controller	2-1
2.2 Maintenance Approach	2-1
2.3 Maintenance Facilities	2-1
2.3.1 Startup (Reset) Diagnostic Messages	2-1
2.3.2 Keyed Input Commands	2-1
2.3.3 Controller Log	2-2
2.3.4 Statistic Counters	2-2
2.3.5 Displayed Messages and Status	2-2
2.3.6 Starter Diskette	2-2
2.3.7 Diagnostic Diskette (3602 Only)	2-2
2.4 Special Tools	2-2
2.5 Use of MAPs	2-2
2.5.1 Entering the MAPs	2-2
2.5.2 MAP Format	2-2
2.5.3 Information That Supports the MAPs	2-2
2.6 Maintenance Aids	2-2

This chapter introduces the Customer Engineer (CE) to maintenance of the Finance Communication Controllers by outlining:

- Functional parts of the controllers
- Maintenance approach.
- Maintenance facilities.
- Special tools.
- Use of the Maintenance Analysis Procedures (MAPs) and the supporting information in this manual.
- Maintenance aids.

2.1 FUNCTIONAL PARTS OF THE CONTROLLERS

The functional parts of the controllers are:

1. The basic controller.
2. Functional storage.
3. Diskette storage.
4. Disk storage (3602 only).
5. Control of local and remote loops and the terminals connected to the loops. (A terminal may include one or more separately addressable parts. Each addressable part is called a terminal component.)
6. Host communication link control.
7. Operator controls (a power switch and a reset switch).

For a functional description of the controller, refer to 3.2 in this manual.

2.2 MAINTENANCE APPROACH

Maintenance of the controller and connected terminals is based upon:

- The availability to the CE of the maintenance information manuals for the controller and each of the connected terminals. Each manual includes Maintenance Analysis Procedures (MAPs) to isolate troubles.
- CE use of the MAPs.
- CE use of the maintenance facilities, outlined in 2.3, to aid in use of the MAPs.
- The availability of replacement Field Replacement Units (FRUs) at the Branch Office.

Customer engineers (CEs) are directed by the customer to the branch experiencing the trouble. (The customer normally determines that a branch or particular unit is causing trouble when he tries to recover from an error condition.)

If the CE knows that a particular unit is not functioning correctly, he will go directly to the manual for that unit (for example, the 3604). Otherwise, he will select the controller, 3604, or 3614 manual depending upon the nature of the problem. For example, a local branch problem not yet defined will cause the CE to select the controller manual; a remote branch problem not yet defined will cause the CE to select the manual for the unit that contains the modem (3604 or 3614). Further, the Error Indication Index in each manual directs the CE to a particular MAP.

Replacement FRUs are available at the Branch Office; at the option of the Branch Office, the FRUs may be available to the CE when he makes the call or after the CE has performed initial troubleshooting.

Note: *When a call has been completed, any good FRUs that were originally removed from a unit while troubleshooting should be returned to the unit.*

If the trouble is not found, the CE follows Branch Office procedures to call for aid.

2.3 MAINTENANCE FACILITIES

The facilities for maintenance of the controller and connected terminals are outlined in the following text.

2.3.1 Startup (Reset) Diagnostic Messages

A sequence of diagnostic messages is displayed on the 3604 at address 1 on loop 1 at startup (reset). As shown in the Error Indication Index (MAP 1), termination of the startup in one of these messages is an error indication that leads to a MAP. Also, individual controller MAPs refer to these diagnostic messages. These messages are listed under "Startup Errors" in 1.1.2.

2.3.2 Keyed Input Commands

These commands enable the CE to:

1. Examine the controller log.
2. Examine the statistic counters.
3. Exercise the components of the controller and the components of terminals connected to the controller.

2.3.3 Controller Log

The controller log is data that is located on the diskette. Into this log, the controller places messages that contain maintenance information and engineering data. (Refer to 3.3.5 for details on the controller log.) The user's programs also have the ability to place messages in this log. For those messages that require immediate action, the controller turns on the CHECK light of the control operator's 3604. (Refer to 3.3.1 for the definition of this 3604.)

Note: *The log messages are lost only on a cold start. They are not lost on a warm start. (Refer to "Error-Free Startup" under 3.3.2 to see how the different types of starts are selected.)*

2.3.4 Statistic Counters

In addition to recording errors in the log, the controller maintains statistic counters for each of the components of the system listed in 3.3.6. As described in 3.3.6, keyboard commands are available to display or print the contents of statistic counters.

Note: *Statistic counts are located in functional storage and are lost each time there is a startup (reset), regardless of whether it is a warm start or a cold start.*

2.3.5 Displayed Messages and Status

To communicate with the CE, the controller displays five-digit (8XXXX and 9XXXX) error messages and informational messages on the gas panel of one of the following 3604s: the 3604 at address 1 on loop 1, the control operator's 3604, or the 3604 at which the CE is logged on. Table 3-3 lists the 3604 display the controller uses when it must communicate with the CE.

Some of the displayed error messages are followed by two status bytes, described in 3.3.8.

2.3.6 Starter Diskette

The IBM-controlled starter diskette is used to separate or identify problems connected with application programs. The procedures given in 3.3.3 *must* be followed to obtain correct operation of the system while using the starter diskette.

2.3.7 Diagnostic Diskette (3602 Only)

This diagnostic diskette is used to identify failures in the disk storage. Its use is described in paragraphs 1.114 and 1.115.

2.4 SPECIAL TOOLS

The following tools are required to maintain the diskette drive assembly with one read/write head:

- CE alignment tool, PN 2200698. This tool is used to: (1) align the read/write head by adjusting it to track 0, and (2) adjust the phototransistor assembly by mechanical alignment. Refer to procedures 1.36 and 1.45 for a sketch of this tool.
- Head-cleaning tools:
 - Brush, PN 2200106.
 - Isopropyl alcohol, PN 2200200.
 - Cloth, PN 2108930.

CAUTION: If the diskette drive has two read/write heads, do not clean the read/write heads for any reason. The two read/write head assembly contains parts that are easily damaged by solvents, including isopropyl alcohol and IBM cleaning fluid.

To maintain the diskette drive assembly with two read/write heads, use two timing pins (PN 1611189), located inside the diskette drive cover assembly. These pins are used to: (1) align the stepper motor and (2) align the LED assembly.

IBM DB meter PN 453545 is required if it becomes necessary to check the transmit level of a modem.

2.5 USE OF MAPS

The MAPs have been developed to provide a systematic logical approach to identifying and correcting problems in the 3600 system. They are the primary maintenance tool for the CE. In this controller manual, the MAPs are on 8-1/2 x 11 pages that should be inserted in the left half of an 11 x 17 binder. (The maintenance procedures, also on 8-1/2 x 11 pages, should be inserted in the right half of the binder.)

2.5.1 Entering the MAPs

The starting point for each call is the Error Indication Index, MAP 1. This index directs the CE to MAPs which will isolate the trouble indicated by the error indication. Each MAP contains step-by-step procedures to locate the failing part. Where necessary, the MAPs refer to operating procedures and maintenance procedures located in Chapter 1, right half.

When the CE gets to a point in the MAPs that indicates "Call for aid", the error indications should be checked again before calling for aid. If other indications are present, the MAPs pointed to by MAP 1 should be used. If no other error indications are present, MAP 2 should be used. This MAP provides a systematic approach for finding error indications. Additionally, MAP 2 leads to use of the starter diskette in the attempt to identify the problem. (Refer to 3.3.3 for details on starter diskette operation.)

Note: *As you become familiar with the system, you may choose to enter the MAPs at any point based upon your observation, the customer's description of the trouble, and your experience. If, however, you do not correct a problem on your first pass through the MAPs, you should use MAP 2. This will make sure that you observe error indications which you may not have observed before, or which you may have observed but believed to be not connected with the problem.*

2.5.2 MAP Format

- Each MAP is identified by a number and title, most MAPs being more than one page long.
- MAP pages contain two columns. The left column is the "command" column, which contains step-by-step procedures for isolating and repairing a failure. The right column may also be a "command" column or, when necessary, a "supplemental" column, containing notes, reference material, and figures.
- Statements such as "Replace drive motor (1.64)" are referring you to a procedure in the right-hand group of 8-1/2 by 11 pages.
- Entry and exit points may be used to direct the CE to some other MAP or another part of the same MAP. Example: Go to MAP 12, Entry Point A.
- At the top of Part 1 of each MAP are tables of Entry Points leading to this MAP and Exit Points leaving this MAP.
- At the bottom of each path on a MAP page are statements such as $\frac{3}{A}$. This means go to A on page 3 of the MAP and continue on the path.
- At the top of each MAP page, except page 1, are statements such as $\frac{A}{1}$. This means that the path is a continuation of the path that left page 1 of that MAP with an A designation.
- Logic cards are called by name; refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

- At the end of most paths you will find a statement "Verify Fix". It is intended that you make sure that the reported problem has been corrected. You may have repaired another problem. The method of verifying the fix will depend on the problem; it may require the customer to perform the operation with which he had a problem.
- If you do not correct the problem, it may have disappeared or you will be instructed to call for aid. Your management will have its own procedures for obtaining aid.

2.5.3 Information That Supports the MAPs

In addition to the introductory information here in Chapter 2, this manual contains the following chapters to support the MAPs:

- Chapter 1, Maintenance Procedures. Contains the following kinds of maintenance help: system operation, check, adjustment, removal, replacement, board layouts, and card part numbers. These procedures are on 8-1/2 x 11 pages that should be inserted in the right half of an 11 x 17 binder next to the MAPs.
- Chapter 3, Reference Data, on 11 x 17 pages. This chapter includes tables of information on keyed commands and displayed messages. Also, it includes internal and external cabling information and power distribution wiring diagrams.
- Chapter 4, Component Locations. This chapter describes the designation system for logic boards and cards, and the pins on the logic boards.
- Chapter 5, Parts Catalog.
- Chapter 6, Installation Instructions; self-explanatory.

2.6 MAINTENANCE AIDS

The following service aids are provided as helpful hints:

1. Loop cable problems may not fail in a logical manner. A check may be performed by powering off all terminals on the suspect loop, powering off the controller, removing the loop card, and measuring for continuity at the logic board cable connectors. Maximum ring-to-ring, tip-to-tip resistance must be less than 40 ohms per 2000 feet. Refer to Figure 3-7.
2. Intermittent power failures may be identified by causing some vibration in the area of the power supply.
3. Some logic failures have been traced to the clear board coating getting on the card socket pins.
4. When the MAPs direct you to replace a logic card, you may wish to measure the voltages at the card socket first. The voltages are listed in Chapter 3.

5. Problems during installation are quite often caused by improper setting of the terminal address switches or failure to have the speed switches for each terminal in agreement with the controller speed jumpering.
6. Before calling for aid, you should always use the starter diskette to separate or identify problems connected with application programs.
7. You *must* follow the procedure in 3.3.3 to obtain correct operation of the system while using the starter diskette.
8. A more complete wrap test of 4-wire, integrated 1200-bps modems, both in host links and remote loops, may be performed by removing the wrap card, unplugging the communication cable at the communication facility end, and connecting the transmit pair of lines to the receive pair of lines preferably with a 16-db attenuator jack, PN 1760940. If a start loop command (040) or a start link command (041) is issued and an error is detected, the controller will perform wrap tests and place the results in the controller log.
9. When working on an intermittent problem, try to select the correct MAP by using visual error indications and/or the controller log and error counter data. Refer to MAP 1 for the most probable FRU to repair/replace. Also, you may swap storage volume 0 cards with storage volume 1 cards in an attempt to identify the failure by changing the symptoms. Some of these cards are optional features; check part numbers before swapping cards.
If you are unable to identify the failure, try a systematic adjustment/card replacement, or call for aid.
10. Some problems can be caused by shorts that occur when feature jumpers are pushed too far on the back-panel pins and cut through the clear insulation.
11. If you know how to add in hexadecimal,* following procedure for determining the current host link parameters may be of value to you. After logging on, the procedure, in general, is: (1) enter debug mode,** (2) display location X'1C', and (3) display the location at the address equal to X'15' plus the address found at X'1C'. Details of the procedure are as follows:
 - (1) Keyboard entry:
123 1
 - (2) Keyboard entry:
11 1 X1C
 - (2) Observe display:
001C - AAAA BBBB CCCC DDDD
 - (3) On scratch paper:
X'15' + AAAA = YYYY

- (3) Keyboard entry:
11 1 XYYYY
- (3) Observe display:
YYYY - PPMM MMMM MMMM MMMM

The meaning of each bit in hexadecimal PP is as follows:

Bit	Meaning
0 off	Data terminal ready
0 on	Connect modem to line
1 off	Non NRZI
1 on	NRZI
2 off	Switched line
2 on	Leased line
3 off	Disconnect response mode
3 on	Normal response
4 off	No select standby
4 on	Select standby
5 off	High-speed line
5 on	Low-speed line
6 off	Control request to send
6 on	Permanent request to send
7 off	Tone generation
7 on	Omit tone generation

To determine if a wrappable modem is configured, add X'35' to the address found at 1C and display that location. If bit 2 of the first character at that location is on, a wrappable modem is configured. To leave debug mode, enter 00.

*Refer to Appendix C in the 3600 System FE MIM for the hexadecimal add-subtract table.
**Refer to Chapter 10 in the 3600 System FE MIM.

12. Some additional suggestions for unresolved problems include:
 - a. Exchange storage volume 0 cards with volume 1 cards to try to change the trouble symptoms. Some of these cards are optional features; check part numbers before swapping cards.
 - b. Test the logic cards from this machine in another known good machine, if one is available.
 - c. Replace a group of cards at one time to provide for the possibility of two cards failing at one time.
 - d. Systematically replace each card in the machine.
 - e. Bypass loop devices by turning them off or changing the loop cabling.
 - f. Exchange major components (such as boards, power supply, cables, diskette drive assembly) with those of another machine if one is available and the component EC levels are the same.
13. If you are required to transmit diskette data to the host site or the design support center using TDAT, the following information will be helpful. Any other necessary information should be provided by the requesting group.
 - a. The system must be started using a starter diskette at EC level 741848 or higher.
 - b. Communication must be made, either normal host link or TDAT as instructed.
 - c. Log on and enter command code 888.
 - d. Respond to the displayed messages as follows (press EM (enter) after each entry):
00091 = Mount the diskette containing the data to be transmitted. No entry is required.

- 00092 = Enter a code to define data to be transmitted as follows:
- | | |
|-----------------|--|
| Enter key only | = Dump data |
| 0 | = Full diskette |
| TTRR TTRR | = From/to track and record (decimal) |
| X'TTRR' X'TTRR' | = From/to track and record (hexadecimal) |
- 00093 = Waiting for start:
0 = Host will start
1 = Controller start
- 00099 = Transmission complete
- e. To interrupt the transmission, press reset on the 3604. 00090 will display. Respond as follows:
0 = Continue
1 = Terminate
 14. Actual loop speeds must match the loop speed specified on the diskette, or difficult timing failures may occur. Examples are device timeouts or link timeouts.
 15. On some systems, when the 3604 at address 1 on loop 1 is not physically the first terminal on the loop, there exists a possibility that the startup diagnostic messages may not be displayed correctly. (Normal operation after startup is not affected by this incorrect display and the problem will be corrected in the future.) If it is required that you see these messages, turn off power on the terminals that physically precede the 3604.
 16. If you find a feature jumper missing, or if you change feature jumpering, be sure there is no conflict with existing jumpers; i.e., 2 speeds, 2 echo clamp delays, 4 wire and 2 wire, etc.

BLANK PAGE

Chapter 3. Reference Data

Contents

Heading	Page	
3.1	3600 Finance Communication System	3-2
3.2	Finance Communication Controllers	3-2
3.2.1	Basic Controller	3-2
3.2.2	Functional Storage	3-2
3.2.3	Diskette Storage	3-2
3.2.4	Disk Storage	3-2
3.2.5	Local and Remote Loops	3-2
3.2.6	Address and Speed Switches on Terminals	3-2
3.2.7	Alternative Line Attachment	3-2
3.2.8	Host Communication Link	3-2
3.2.9	Operator Controls	3-4
3.3	Communications Between Controller and Control Operator or CE	3-4
3.3.1	3604 Keyboard Display Terminals	3-4
3.3.2	Operating Diskette	3-4
3.3.3	Starter Diskette	3-6
3.3.4	Keyed Input Commands	3-6
3.3.5	Controller Log	3-7
3.3.6	Statistic Counters	3-7
3.3.7	Displayed Messages	3-7
3.3.8	Displayed Status	3-7
3.4	Disk Storage	3-8
3.4.1	Locations	3-8
3.4.2	Component Description	3-9
3.5	Diskette Drive Assembly (Single Side)	3-10
3.5.1	General Description	3-10
3.5.2	Operating Sequence	3-11
3.5.3	Read/Write Circuit Principles	3-12
3.6	Diskette Drive Assembly (Two-Sided)	3-13
3.6.1	General Description	3-13
3.6.2	Operating Sequence	3-14
3.6.3	Read/Write Circuit Principles	3-15
3.7	Diskette	3-16
3.8	Interconnect Diagrams	3-17
3.9	Communication Connections	3-36
3.9.1	Selection at Controller/Communication Connections	3-36
3.9.2	Communication Connections 3601-2A, 2B, 3A, 3B (Single TSR-3 Power Supply)	3-36
3.9.3	Communication Connections 3601-2A, 2B, 3A, 3B (One or Two TSR-2 Power Supplies)	3-38
3.9.4	Communication Connections (3601 C, D)	3-40
3.9.5	Communication Connections 3602-1A, 1B (TSR-3 Power Supply, More Than 2 Wires on B1Y4)	3-42
3.9.6	Communication Connections 3602-1A, 1B (TSR-3 Power Supply, Only 2 Wires on B1Y4)	3-44
3.10	Supply Voltages on Logic Boards and Cards	3-46
3.11	Back Panel Connections	3-46
3.11.1	Loop Control Cards	3-46
3.11.2	Modem Compatibility (Internal Modem)	3-46
3.11.3	External Modems	3-46

Contents

Contents

Heading	Page	
3.11.4	Communications Link Connections	3-46
3.11.5	Storage Connections (Basic Controller Board)	3-46
3.12	Disk Storage Diagnostics	3-47
3.12.1	General Description	3-47
3.12.2	Operating Procedure	3-47
3.12.3	Test Routines	3-47
3.12.4	Procedure Errors	3-48
3.12.5	Disk Storage Utility Programs	3-49

List of Figures

Figure	Title	Page
3-1	3600 Finance Communication System Example	3-3
3-2	3604 Universal Translate Table Keyboard Locations	3-5
3-3	Internal Cable PN 4943638/1741686, Basic Controller Board Connector/Diskette File Control Card	3-17
3-4	Internal Cable PN 4943641/1652549/1747295/4409516/Modem/EIA Connector for Communication Link	3-17
3-5	Internal Modem Cables, Board/Cable Panel	3-18
3-6	Internal Loop Cables, Board/Cable Panel	3-19
3-7	Controller Internal Cable to Operator's Panel	3-20
3-8	Selection of Power Distribution Wiring Diagram and Cable Assemblies	3-21
3-9	Power Distribution, 3601-2A, 2B, 3A, 3B (Single TSR-3 Power Supply), 2 Parts	3-22
3-10	Power Distribution, 3601-2A, 2B, 3A, 3B (One or Two TSR-2 Power Supplies), 2 Parts	3-24
3-11	Power Distribution, 3601 C, D, 2 Parts	3-26
3-12	Power Distribution, 3602-1A, 1B (TSR-3 Power Supply-More Than 2 Wires on B1Y4), 2 Parts	3-28
3-13	Power Distribution, 3602-1A, 1B (TSR-3 Power Supply, Only 2 Wires on B1Y4), 2 Parts	3-30
3-14	External Cables, Controller/Communication Link	3-32
3-15	External Cables, Controller/Communication Line for a Remote Loop	3-33
3-16	Japanese Connection of External Cables to Communication Line (Loop or Host Link)	3-34
3-17	Adapter Cable PN 1741656	3-34
3-18	Japanese Wrap Test Cable PN 2722052	3-35

List of Tables

Table	Title	Page
3-1	Terminal Address Switches (Switch Group 1)	3-2
3-2	Terminal Speed Switches (Switch Group 2)	3-2
3-3	Controller/CE Communication	3-4
3-4	Prompt Mode Message Sequence	3-5
3-5	Starter Diskette Configuration	3-6
3-6	First Status Byte	3-7

3.1 3600 FINANCE COMMUNICATION SYSTEM

The IBM 3600 Finance Communication System brings online system processing, with quick response, to a financial institution's central and branch office locations. In this system, IBM terminals located in branch offices are under the immediate control of a Finance Communication Controller.

Branch office terminals are connected to a controller in loop-type arrangements. As shown in Figure 3-1, there are local loops and remote loops. A controller may have a maximum of eight loops connected to it. One loop must be the basic local loop, each remaining loop being local or remote. The number of terminals connected to a controller is dependent on the terminal configuration.

Terminals that are within the same location as the controller will normally be connected to a local loop. Terminals located farther away must be connected to a controller by a communication line. In this case, the communication line and the terminals are said to form a remote loop. (It is possible for the terminals in several small branch offices to be part of one remote loop.) A loop of terminals on a remote loop is termed a remote subloop. The maximum recommended length of the cabling, between powered on terminals, is not more than 2000 feet (610 m).

As indicated on Figure 3-1, features can be ordered that enable the 3614 Consumer Transaction Facility (Models 1 and 2) to be connected to the central processing site through a communication link without going through a controller. These features provide a wider choice of physical locations for these terminals.

3.2 FINANCE COMMUNICATIONS CONTROLLERS

Normal operation of a controller is *online*. That is, it communicates with the institution's host computer via communication lines, and has access to the customer files for information inquiry and for updating. However, should a failure occur in the communication link between branch location and host computer, the controller can operate *offline*.

When the controller is offline, branch operations can continue, but without access to the host computer. Transactions that require information not available in the controller must wait until communications are restored. However, many routine transactions may be performed by using the controller's diskette for information storage. Offline transaction data can be collected and stored temporarily, so that when communications are reestablished, this data is sent to the host computer and the affected files are updated.

For introduction purposes, the following text briefly describes some functional areas and components of the controller.

Note: *This introduction gives the number of logic cards required for some functional areas, but does not go into detail. For detailed information on logic boards and logic cards, refer to Chapter 4, Component Locations.*

3.2.1 Basic Controller

The basic controller has three logic cards. At startup time, the basic controller directs the loading of the configuration image and the customer's application programs into functional storage from the diskette storage. After startup, as directed by the application program(s), the basic controller:

1. Performs the arithmetic and logical operations required to process transactions.
2. Controls the operation of the terminal components attached to the loops.

Note: *A terminal component is a separately addressable part of a terminal. The component performs an input or output function, but usually not both.*

3. Controls the transfer of data between functional storage and the customer's permanent and temporary files located on the diskette.
4. Controls the flow of messages between the host computer and the branch location.

3.2.2 Functional Storage

The basic functional storage consists of control storage and programmable storage. Additional control storage and programmable storage are available as features. For storage sizes, check the plug chart for your controller.

3.2.3 Diskette Storage

The diskette storage is a direct access, read/write data storage device designed to provide low-cost data entry and data storage. It does this by using removable, magnetic diskettes.

Each controller has one of two different diskette drive assemblies, one with a single read/write head that uses only diskettes with one magnetic surface, the other with two read/write heads that use diskettes with either one or two magnetic surfaces.

Connected with the diskette storage are two logic cards and a diskette drive assembly. One logic card, the diskette drive control card, is located on the diskette drive assembly; the other, the diskette adapter card, is located on the logic board containing the basic controller cards.

The customer's operating diskette is used for normal operation. The IBM-controlled starter and diagnostic (3602 only) diskettes are available to assist in maintenance. Also, the starter diskette must be used by the customer in the procedure for creating operating diskettes.

The customer creates (generates) operating diskettes from formatted diskettes. The operating diskettes provide a storage area for:

1. The configuration image. (See Glossary.)
2. The application programs that enable the controller and the connected terminals to perform the required transactions.
3. The customer's permanent and temporary files.

After the operating diskette has been generated, items 1 and 2 are read-only storage areas.

3.2.4 Disk Storage (3602 Only)

The disk storage is a direct access storage device that stores information on a magnetic disk by use of two movable heads and, if installed, eight fixed heads.

The 3602 Model 1A has approximately 5.2 million bytes of disk storage, the Model 1B approximately 9.3 million. As an option, eight fixed heads can be installed on either model to provide an additional 122K bytes.

Connected with the disk storage are up to 15 logic cards. Two of the cards (three if fixed heads are installed) are located on the disk enclosure (DE), a sealed assembly containing the recording disk and the movable and fixed heads. The other 12 logic cards are located on the disk storage logic board O1A1. Refer to section 3.4 for more detailed information on the disk enclosure.

3.2.5 Local and Remote Loops

Some controllers may have up to eight loops, with loop 1, the basic loop, being local, and the remaining loops being local or remote. Local loops operate at 600 bps, 1200 bps, 2400 bps, and 4800 bps, but only one 4800-bps local loop is allowed.

Connected with each loop, local or remote, is one loop card. Although all loop cards are identical, the sockets are jumpered to select speed and for remote loop operation. Jumpering instructions are on a label located on the logic gate in the controller.

Each remote loop requires an integrated modem, an external modem, or a 3603 Terminal Attachment Unit. Integrated modems consist of one logic card.

In the event of a 1200-bps remote loop problem, the controller wrap-tests the loop card. If the loop card passes the wrap-test, and an integrated modem is used, the controller wrap-tests the modem. The wrap-test results are entered in the controller log. (Refer to 3.3.5 for controller log details.)

3.2.6 Address and Speed Switches on Terminals

Each 3600 terminal has two groups of switches. Group 1 is used to set the terminal address, and Group 2 is used to set the terminal speed. Each group has four individual switches labeled 1, 2, 3, and 4; and each switch has an ON and an OFF position. Tables 3-1 and 3-2 show how to set these switches.

When the operating diskette is being used, the address and speed switches on the individual terminals must agree with the configuration information on that diskette. The customer will have configuration documentation for reference.

Note: *When a loop is functioning correctly, the READY lights on all powered terminals will be on continuously.*

Table 3-1. Terminal Address Switches (Switch Group 1)

Terminal Address	Switches			
	1	2	3	4
1	*			
2		*		
3	*	*		
4			*	
5	*		*	
6		*	*	
7	*	*	*	
8				*
9	*			*
10		*		*
11	*	*		*
12			*	*
13	*		*	*
14		*	*	*
15	*	*	*	*
16				

* = ON
blank = OFF

Table 3-2. Terminal Speed Switches (Switch Group 2)

Speed bps	Switches			
	1	2	3	4
600	*			
1200		*		
2400			*	
4800				*

* = ON
blank = OFF

3.2.7 Alternative Line Attachment


The Alternative Line Attachment permits the controller to attach nonloop discipline control units and terminals.

3.2.8 Host Communication Link

For communicating with the host computer, the controller requires one CA card (communication adapter card) and one modem. The modem may be a 1200-bps integrated modem or an external modem. For an external modem, the controller must have one EIA (Electronic Industries Associated) card.

There are two types of CA cards, one with clocking and one without clocking. The 1200-bps integrated modem requires a CA card with clocking.

The 1200-bps integrated modem consists of three cards: transmit, receive, and wrap.



Legend:

- ≡ = Communication lines
- T = any of 3600 system terminals, including the 3614 Consumer Transaction Facility.
- T† = a 3604 Keyboard Display at address 1 on loop 1. This 3604 displays diagnostic messages during startup (reset). This 3604 need not be physically the first terminal on the loop, although it is shown as such on this diagram. For other 3604 functions relating to the CE, refer to 3.3.1.
- T* = a 3604 Keyboard Display Model 2, 3, or 4, or a 3614 Consumer Transaction Facility Model 1 or 2. If both are on one remote subloop, the 3614 must interface the communication link.
- Modem = modulation/demodulation.
- Work Station = a group of one or more terminals that are recognized by the controller as being grouped. Operators use a work station to perform a set of operations under control of an application program.
- Remote loop = combination of the subloops within remote branch offices and the communication lines that connect the subloops to the controller.

Notes:

1. The modem (modulation/demodulation device) for the communication link may be a standalone modem or it may be contained within the controller or 3614 (an integrated modem).
2. Remote loops require an integrated modem, an external modem, or a 3603 Terminal Attachment Unit at each site.
3. Some controllers may have up to eight loops. Loop one must be the basic local loop, each remaining loop being local or remote.
4. Each interconnecting cable segment used for wiring local loops or remote subloops is limited in length by the driving or redriving capability of each unit. Each unit that has its power on is capable of driving a maximum of 2000 feet (610 meters) of cable. When its power is off, the terminal is automatically bypassed to maintain the loop integrity. However, the result is to connect the two cable segments together. If it is desired to keep the loop operational for other units (local or remote) on the loop, the sum of the cable segment lengths between the units with power on must not exceed 2000 feet (610 meters).

Figure 3-1. 3600 Finance Communication System Example Using a 3602 Controller

In the event of a host communication link problem, the controller wrap-tests the CA card. If the CA card passes this test, the controller wrap-tests the modem if it is an integrated modem. An external modem may or may not be wrap-tested by the controller. Wrap-test results are entered in the controller log. (Refer to 3.3.5 for controller log details.)

Note: MAP 6 gives information to help determine whether the controller is automatically wrap-testing the external modem.

3.2.9 Operator Controls

The controller operator controls are two switches: a power on-off switch and a reset switch. Turning on the power switch not only applies power to the controller, but also causes a system reset (startup). Activating the reset switch causes a system reset (startup).

Note: A reset (startup) always causes the diskette head carriage assembly to 'access' (move from one track position to the next) 80 times in the direction of track 0. The diskette has 77 tracks, and the head carriage assembly may be at any track when reset begins. Thus, shortly after you activate the power switch or the reset switch, you can see and hear the head carriage assembly striking against the lower stop a number of times.

3.3 COMMUNICATIONS BETWEEN CONTROLLER AND CONTROL OPERATOR OR CE

Note: In order to log on, the CE must obtain the identification code that is assigned by the customer and used by the customer's control operator. Thus, the control operator and the CE have the same capability for communicating with the controller. However, the following text, in most cases, mentions only the CE as the person communicating with the controller.

3.3.1 3604 Keyboard Display Terminals

The controller and the CE communicate through a 3604 Keyboard Display. Functionally, three 3604s can be identified in this person/machine communication process:

(1) the 3604 address 1 on loop 1, (2) the control operator's 3604, and (3) the 3604 at which the CE is logged on.

(Physically, these functions may be done at one, two, or three 3604s.) The immediately following text defines these 3604s, and Table 3-3 shows which 3604 is used at the various times that the controller and the CE must communicate. Also shown in Table 3-3 are the various levels of diskettes as indicated by the EC number displayed to the CE by the 3604.

Table 3-3. Controller/CE Communication

Time	3604 Components Used
The diagnostic part of startup. This time begins when the CE activates the power switch or the reset switch on the controller. It ends when the diagnostic test complete (DTC) message is displayed.	The display of the 3604 at address 1 on loop 1.
The part of startup after DTC: 1. 82XXX error messages, if any. 2. Two-line message, ending 00001. This message identifies the diskette used and requests a response to select the type of start wanted. If there is no response within 2 minutes, a warm start is done automatically. 3. The keyboard responses to the above message. 4. 9XXXX error messages, if any.	1. Display of 3604 at address 1, loop 1. 2. Display of control operator's 3604. 3. Keyboard of control operator's 3604. 4. Display of control operator's 3604.
When the CE is not logged on, and the controller wishes to inform the CE about a controller log message that requires attention.	The CHECK light of the control operator's 3604.
After startup has been completed and the CE is logged on.	The keyboard and display of 3604 at which the CE is logged on.

Diskette EC Levels

Starter Diskette PN 1652106	Operational Diskette	Level
EC 741883	EC 741883	4.8
EC 741181	EC 741181	4.9
EC 741846	EC 741847	5.0
EC 741848	EC 741849	5.1
EC 741850	EC 741851	5.2
EC 741852	EC 741853	5.3
EC 741854	EC 741855	5.4
EC 745120	EC 745121	5.5
EC 745122	EC 745123	5.6
EC 745124	EC 745125	5.7

- The 3604 at address 1 on loop 1. This is the 3604 on loop 1 whose address switches are set to 1. Physically, this may or may not be the 3604 that is nearest to the controller.
- The control operator's 3604. This is the first 3604 in a table that is set up in the configuration process. If this 3604 is not working at a time when the controller wishes to communicate with it, the controller searches the table, from top to bottom, until it finds a 3604 that is operating. With an operating diskette, the control operator's 3604 may be any 3604 on any loop. With a starter diskette, the control operator's 3604 is the 3604 at address 1 on loop 1.
- The 3604 at which the CE is logged on.
 - With an operating diskette, the CE is automatically logged on the control operator's 3604 during startup time to enable the CE to enter the keyboard responses that complete the startup. After startup is complete, the CE may manually log on at any 3604 that is idle.
 - With a starter diskette, the CE is automatically logged on the 3604 at address 1 on loop 1 during startup and after startup is complete. (A good logon of this type is indicated when message 92222 is displayed.) If desired, the CE may manually log off this 3604 and log on at another 3604.

At startup time and after the CE is logged on, the specified 3604 keyboard operates with the Universal Translate Table (Figure 3-2). After being logged on, the CE has the option of keying a command that returns the keyboard to the original translate table. (See the 045 X command in the IBM 3600 System FE MIM, SY27-2520.)

Note: After the keying of any command or response has been completed, this information is entered into the controller by pressing the EM key shown on Figure 3-2. To avoid much repetition, this step is usually omitted in the following text.

3.3.2 Operating Diskette

Error-Free Startup (Reset)

The startup sequence is as follows:

- The CE activates the power switch or the reset switch on the controller.
- The 3604 at address 1 on loop 1 displays a series of messages in the upper left corner of the gas panel to indicate the progress of the startup diagnostic tests. (This 3604 may require a power off/on reset). The first message of this series is IDL (initial diagnostic load) and the final message is DTC (diagnostic test complete). Each message is displayed for a number of seconds and is then replaced by the succeeding one.

- The control operator's 3604 displays a message on the top two lines of the gas panel. (This message indicates that the configuration image and the application programs have been successfully loaded from the diskette.) The top line contains seven groups of characters. From left to right, the groups give the following information:
 - The control code supplemental version ID.
 - Diskette identification (Volume ID).
 - Configuration identification (GEN ID).
 - The EC level of the controller data.
 - Control unit (controller) address (CUA). The CUA is used by the host to address this controller.
 - Relocate count. A count of the diskette records moved to the error track because of diskette surface defects.
 - Session identification. As used here, a session is one or more periods of time that the customer thinks of as one continuous period of time for the purpose or record keeping

The second line of the gas panel contains a five-digit message, 00001. This message requests the CE to key and enter one digit to specify the type of start wanted. The type of start specified by each valid digit is as follows:

- 0 XX = Load utility, where 70 = diskette format*
- 1 = Cold start
- 2 = Warm start
- 3 = Diagnostic loop
- 4 = Prompt mode
- 5 = Prompt mode for optional operations
- 6 X = Describe the 3604 model number, where X = model number
- 7 XX = Load link module, where,
 - 01 = CCA TAM
 - 02 = HPCA TAM
 - 03 = CCA CREDIT LYONNAIS
 - 04 = HPCA CREDIT LYONNAIS
 - 05 = BSC
- 8 = Cold start with no start link issued
- 9 = Warm start with no start link issued

*Starter diskette only.

Note: Use the Universal Translate Table Keyboard Locations when entering the required digit. See keyboard chart in Figure 3-2.

Special Note: When using an operating diskette, never specify a cold start (digit 1 or digit 8) unless the customer allows you to do so.

- The CE keys and enters the correct digit. If 1, 2, 8, or 9 are entered, go to step 5 in this sequence. If 4 is entered, go to step 6. If 5 is entered, go to step 7. If 3 is entered, the controller will loop on the startup diagnostic sequence (IDL to DTC).
- After entering 1, 2, 8, or 9, the gas panel goes blank and the customer's application program takes control.
- If the CE requests a prompt mode start by keying and entering 4, the control operator's 3604 displays a sequence of five-digit messages (00002 through 00004) in the position where 00001 was displayed. After each message is displayed, the CE enters a response as shown in Table 3-4, and the next message then appears. After the response to message 00004 has been completed, the screen again displays 00001. The CE now enters a 1, 2, 3, 4, 5, 8, or 9 to specify the startup, as in step 4.
- If the CE requests a prompt mode start by keying and entering 5, the control operator's 3604 displays the message 00005 in place of 00001. The CE keys and enters responses to this message as shown in Table 3-4. After the responses to 00005 have been completed, the screen again displays 00001. The CE now enters 1, 2, 3, 4, 5, 8, or 9 to specify the startup, as in step 4.
- The CE may describe the 3604 by entering 6 X, where X is the 3604 model number.

Startup Errors

- If the startup diagnostics detect an error, the startup terminates with no message displayed, or one of the following messages displayed on the 3604 at address 1 on loop 1. (See MAP 1, Error Indication Index.)

IDL	INS	HSH	MV2 XXX
HSH	MV0 XXX	LEC	MV3 XXX
LDI	ROS	MV2 0	ESA
IRT	PCK	MV3 0	INV
HSH	LSW	MV1 XXX	DTC
LDC			

MV2 and MV3 messages will only appear with the extended memory. HSH will only appear if there is a diskette read error.
- If the controller detects an error during the remainder of the startup: 82XXX error messages are displayed on the 3604 at address 1 on loop 1, and 9XXXX error messages are displayed at the control operator's 3604. (Refer to the IBM 3600 System FE MIM, SY27-2520.)

Manual Logon/Logoff Procedure

- At an idle 3604, press the RE (reset) key three times. If reset is not marked, ask the customer to identify the reset key.
- Message 90000 should be displayed. When 90000 is displayed, the layout of the keyboard keys is as

assigned by the Universal Translate Table (UTT). Refer to Figure 3-2 for the keyboard layout for the different 3604 keyboards.

Note: If 90000 is not displayed and the CHECK indicator lights, another 3604 is already logged on.

- Obtain the control operator identification (ID) code from the customer and enter this code at the 3604, using the 3604 UTT keyboard layout.

Note: The control operator ID is not displayed.


- Message 91111 should be displayed, indicating a successful logon. If 91111 is not displayed, go to step 1.
- Logoff Procedure: To log off, key in 000 and then press the EM (enter) key.

Table 3-4. Prompt Mode Message Sequence*


Displayed Message	CE Response
00002	Enter a one- or two-character control unit address (CUA) in hex. This CUA replaces the one on the diskette.**
00003	Enter a 1 to request dump option. Enter a 0 to request no dump option.** Note: The dump is taken only after a system failure. See 82060.
00004	Enter a 1- to 16-character control operator identification code, supplied by the customer. Valid characters are: 0-9, A-F, X, and blank.** If 90000 is displayed after entering a new identification (ID) code, the earlier ID code must be entered. If it is not entered correctly, 00004 will again display; if it is entered correctly, the ID code will be changed and 00001 will display.
00005	Enter the ID codes for as many as 16 optional modules of controller data. (Press the EM (enter) key after each ID code of one or two hex characters.) The 00005 message will remain after each entry unless the CE has responded by entering 00 or FF, or by pressing the EM (enter) key or the RE (reset) key. If 00 is entered, no optional modules will be loaded. If FF is entered, all optional modules will be loaded. For optional module ID codes on starter diskette, see 3.3.3.**
00006	Enter a 5-character XID.**

*See 3600 System FE MIM, SY27-2520, for Prompt Mode Startup.


** If only the EM (enter) key is pressed, this input is bypassed and the operation continues. If the RE (reset) key is pressed twice, the prompt mode sequence is terminated.




A. 30-Key Keyboard




B. 45-Key Keyboard




C. 74-Key Keyboard




D. 77-Key Keyboard



E. 92-Key Keyboard




F. 94-Key Keyboard



G. 99-Key Keyboard

Legend:

- BS = backspace
- RE = reset
- EM = end of message
- NK = return to normal keyboard = 045
- SP = space
- AV = advance/clear*
- FR = free*



* Used only for large disk storage utilities and error code diagnostics.

Figure 3-2. 3604 Universal Translate Table Keyboard Locations

3.3.3 Starter Diskette

An IBM-controlled starter diskette is shipped with each controller. All the exerciser tests that can be performed with an operating diskette are available on the starter diskette. (Refer to the IBM System 3600 FE MIM, SY27-2520. for the list of keyboard commands that control these tests.) Also, the starter diskette includes the create diskette function (capability) that is not available on the operating diskette. This function is used by the customer to create (generate) operating diskettes. For CE reference, a general description of this function is given in the IBM System 3600 FE MIM.

Preparing to Use the Starter Diskette

The starter diskette supplied to the customer has been configured for one terminal of each type on each of two loops, loops 1 and 2. (Loop 1 contains the control operator's 3604 at address 1.) After startup is complete, loops 1 and 2 are both running. Keyboard commands are available to stop loop 2, specify another loop to take loop 2's place, and start the other loop.

For all loops, the starter diskette is configured as shown in Table 3-5. Thus, if a terminal is being used in the testing, its address switches must be set as shown in Table 3-5. For terminals that are on the loop being tested but are not being used in the testing, configuration requirements may be met by turning off their power switches rather than changing the normal setting of their address switches.

There is no need to change the address switches or the power switches of terminals on loops not being tested.

Table 3-5. Starter Diskette Configuration

For starter diskettes at EC 745122 and above, see command code 973 in the IBM 3600 FE MIM, SY27-2520. Only addresses 01, 02, and 03 are valid on these diskettes.

Terminal	Address	Slots Used	Components
3604	01	1,9	Keyboard (magnetic stripe reader), and display.
3618	02	2,10	132 print positions, dual forms feed.
3604	03	3,11	Keyboard (magnetic stripe reader), display, and magnetic stripe encoder.
3610	04	4,12	Continuous form/cut form.
3611, 3612	05	5,13	Document: Continuous form/cut form. Passbook: 28 lines, centerfold starts on line 14, and ends on line 17.
3614	08	8,16	Cash issuer.

Startup

With the starter diskette, the startup is the same as with the operating diskette. Note that the control operator's 3604 is the 3604 at address 1 on loop 1.

Logon/Logoff Procedure

As soon as the CE completes the startup by responding to the 00001 message, the gas panel on the operator's 3604 (address 1 on loop 1) goes blank and the message 92222 appears. This message indicates that the CE is automatically logged on that 3604 and may run exerciser tests by using its keyboard. The CE can log off that 3604 by keying 000 and the enter (EM) key; he can then manually log on at another 3604 in the same way as with an operating diskette.

Testing a Component

After being logged on, the CE can test a component by using the commands described in the IBM 3600 System FE MIM.

If the component to be tested is on loop 1, it is assigned as the test component with command code 007, just as with an operating diskette.

With the starter diskette, loop 2 is named as having a wrappable modem. If loop 2 actually has a wrappable modem, it is only necessary to use the 007 command to assign the component to be tested, just as with an operating diskette. If loop 2 has no modem or has a modem that is not wrappable, the following commands should be given before giving the 007 command:

```
040 0 02 00 02
040 0
```

If the component to be tested is on a loop other than 1 or 2, it is necessary to enter the following commands, before using the 007 command:

```
040 0 0X 00 0Y
040 0
```

X is set to 2 if there is no wrappable modem on the loop (local loop or World Trade 600-bps remote loop).

X is set to 3 if there is a wrappable modem (1200-bps remote loop).

Y is set to the loop number of the loop to be tested. This same number is also used to specify the loop when using the 007 command to assign the component to be tested.

The first of the above commands (040 0 0X 00 0Y) stops all loops except loop 1 and specifies the loop to be tested. The 040 0 command starts the loop to be tested.

The host link is configured for a nonwrappable modem. If your modem is capable of an automatic wrap test, you must set this parameter with the 041 command. See Table 3-6.

Note: You must use a prompt mode startup to specify the component to be tested. (See 3.3.2.) The starter diskette optional module ID codes are:

<u>ID</u>	<u>Component</u>
0A	Address Sharing
0B	PIN Keyboard
5E	Optional module required for use of command code 063.
6A	ALA/Host Communication Link Test
83	3610, 3611, or 3612
85	3618
86	3604 magnetic stripe encoder
87	3614
88	3606/3608 keyboard/display
89	3608 printer

3.3.4 Keyed Input Commands*

After logging on the system at a 3604, the CE can use the keyboard at that 3604 to issue commands to the system. These commands enable the CE to perform the following functions:

1. Examine the controller log. For example, see command code 001. Controller log details are in 3.3.5.
2. Examine the statistic counters. For example, see command code 010. Statistic counter details are in paragraph 3.3.6.
3. Exercise a controller or terminal component.

*Refer to the IBM 3600 FE MIM, SY27-2520.

Note the following points concerning the use of these commands: *

1. As soon as the CE presses the RE (reset) key three times, the Universal Translate Table (Figure 3-2) is in effect. While logged on, the CE can use command code 045 or the NK key to return to the original translate table.
Note: When the Universal Translate Table is in effect, some of the other keys may still be active.
2. The fields of a command are to be entered in decimal unless the field representation is preceded by X. In that case, the field may be entered in decimal or hexadecimal. If the field is entered in hexadecimal, the first character of the field should be immediately preceded by X. For an example, see command code 031.
3. Leading zeros are not required in any input field except for the command codes, and the SS portion of the LSSD field in commands 006 through 010.
4. Before exercising a component, the CE must assign that component as the test component. See command code 007.
5. The CE has the option of assigning a component as the output printer. (See command code 006.) The output printer may be used to provide a hard copy of log messages (command code 046) and statistic counters (command code 012). Also, it may be used for a hard-copy record of all keyboard commands and display messages (command code 061).
6. If the controller detects an error while the CE is logged on, it displays a five-digit error message that begins with digit 9. These five digits are followed by four hexadecimal characters that are the two status bytes of the component associated with the error. *

3.3.5 Controller Log

The controller log is a file located on the diskette. The system monitor places messages in this log that relate to maintenance and engineering data. The user's programs also have the ability to place messages in this log. The first two digits of any log message are significant. The meanings of these digits are as follows:

- First digit = 1: System written log message.
- First digit = Not 1: User-written log message. User should not begin the message with a 1.
- Second digit = 1: The log message requires immediate attention. To alert the CE to the presence of such a message, the controller turns on the CHECK, 1, 2, or 3 indicator light of the control operator's 3604. (The configuration process at generation time determines which light will be used for this purpose. Usually, it is the CHECK light.) If the control operator's 3604 is not operating, the controller turns on the corresponding light of the first available 3604 that is operating.
- Second digit = Not 1: This message does not require immediate attention and does not turn on the CHECK light at a 3604.

Note: *The controller log is lost through a cold start. It is not lost through a warm start.*

The CE can examine a display or a printout of the controller log by logging on at any operating 3604, and then giving a 001, 002, or 046 command as described in the IBM 3600 System FE MIM, SY27-2520.

Log Usage Notes

1. When displaying and paging down the log by repeatedly pressing the enter (EM) key after entering the 001 command, the controller will cause message 90001 to be displayed if the enter key is pressed after message number one has been displayed.
2. If an attempt is made to write a log message while you are logged on and the log area is full, the controller will cause message 90012 4000 to be displayed.

Detailed log messages are in the IBM 3600 System FE MIM, SY27-2520.

3.3.6 Statistic Counters

In addition to recording errors in the system log, the controller maintains statistic counters for each of the following components of the system:

- Controller Diskette
- Controller Loop control (for each loop)
- Controller Host communication link
- 3602 Disk Storage
- 3604 Keyboard
- 3604 Display
- 3604 Encoder
- 3606 Keyboard/Display
- 3608 Keyboard/Display
- 3608 Printer
- 3610 Document Printer
- 3612 Document Printer
- 3612 Passbook Printer
- 3614 Consumer Transaction Facility
- 3618 Administrative Line Printer

Alternative line attachment information is contained in *Alternative Line Attachment General Information* manual, GA27-2856.

Note: *Statistic counts are located in functional storage and are lost each time there is a startup (warm or cold). In contrast, the controller log is located on the diskette. Thus, this log is lost only on a cold start.*

After logging on at a 3604, the CE can key in either of two commands to obtain statistic counts.

1. 010 LSSD is keyed to display the statistic counters of a specified component.
2. 012 X is keyed to print statistic counters for all components on the assigned output printer. X is the number of loops attached to the controller.

Refer to the IBM 3600 System FE MIM, SY27-2520 for details on the 010 and 012 commands and on the format of the printed/displayed statistic counter messages.

Concerning the displayed or printed counts, note that:

1. Each three-digit count represents the decimal count in one counter. The counters are designated as counter 1, counter 2, etc., from left to right.
2. If a count reaches 256, additional counts of that type will cause the count to return to 128 and continue from there. Thus, counts of 128 or over, are not definitive.
3. Counts represent the number of operation failures, not the number of retries per operation.

Tables in the IBM 3600 System FE MIM, SY27-2520, explain the counts for the controller components.


3.3.7 Displayed Messages

The controller communicates with the CE by displaying the messages described in the IBM 3600 System FE MIM, SY27-2520. Note that:

- All 82XXX messages are displayed only on the 3604 at address 1 on loop 1.
- 900NN error messages may be accompanied by four hexadecimal characters (two bytes) that give the status of the terminal component connected with the error. Tables in the IBM 3600 System FE MIM, SY27-2520, describe status information.

3.3.8 Displayed Status

Some of the 900NN messages explained in the IBM 3600 System FE MIM, SY27-2520, are accompanied by two status bytes, displayed as four hexadecimal characters. These bytes and characters are identified, as follows:



Byte 1 has general meaning not specific to any component. The specific information is contained in byte 2. The meaning of the individual bits of byte 1 is given in Table 3-6. Note that more than one bit of a status character can be activated at the same time. If this occurs, the displayed character is the sum of the activated bits. For example, a displayed first status byte of 63 indicates that bits 4 and 2 of the first status character and bits 2 and 1 of the second status character are activated. Similarly, more than one bit of status characters 3 and 4 can be activated simultaneously.

The IBM 3600 System FE MIM, SY27-2520 presents a list of status messages that assume no more than one bit activated in each character at any one time. From this you can determine the meaning of status messages that include characters with more than one activated bit.



Alternative line attachment information is contained in *Alternative Line Attachment General Information* Manual, GA27-2856.

Table 3-6. First Status Byte

	Bit Meaning
First Character (Byte 1)	8 = Intervention Required 4 = Unit Exception. 2 = Data Check. 1 = Status is for prior write operation combined with any residual status. The current write status is lost.
Second Character (Byte 1)	8 = Operation terminated by attention (pressing 3604 reset key twice). 4 = Command Reject. 2 = Unit Check. 1 = Wrong length record.

3.4 Disk Storage

3.4.1 Locations



3.4.2 Component Description

Disk Enclosure

The Disk Enclosure (DE) is a factory-sealed unit that houses the disk, spindle access arm, actuator, and fixed heads (where installed). These components may be visible through the clear cover, but are not accessible by the customer or CE.

The card sockets for data channel, head selection cards, and the connecting cables are mounted on the DE casting; they are not enclosed with the sealed cover. Two cards are used on a DE (three, if fixed head is installed).

Fixed Heads (Optional)

The fixed heads are on the servo side of the disk and may not be visible. Because the heads touch the disk surface during power up/down, the data and IDs on the fixed head tracks cannot be guaranteed after the power cycle and must be recreated following power-up.

Disk

The disk is one permanently mounted, 14-inch, magnetic-coated disk. It is driven by an ac motor at a nominal speed of 2964 rpm.

Data can be recorded on 304 concentric tracks per moving head. The pair of tracks, 0 and 1, equal one cylinder; this format is used because all of the customer data that is written with the moving heads is on the same side of the disk. The other side of the disk is prewritten with patterns (corresponding to each data track location) on the outer half of the disk (area A). This is used by the servo head to perform a seek operation.

Note: Two tracks (one available to each movable head) are reserved for read and write tests. The two tracks at cylinder position 303 are reserved for this purpose.

Disk Spindle

The disk spindle assembly is mounted in a housing (which contains two bearings) in the back of the DE. The housing is sealed to prevent contamination from being drawn into the DE through the bearings.

The disk spindle has a mounting hub to which the disk is clamped. A pulley is attached to the other end of the spindle; the pulley is belt-driven by an ac induction motor that is mounted on the subframe.

Belt tension is maintained by a spring acting on the pivot-mounted motor/brake assembly. The spindle and belt are grounded to the DE casting through an antistatic brush. An electromagnetic transducer, mounted on the DE, senses a slot in the spindle pulley to give an indication of speed.

Access Arm Actuator

The actuator arm is pivoted beside the disk and carries the heads across the disk to the track that is specified by the Disk Control. The movable data heads and the servo head are attached to one end of the actuator arm, and a rectangular coil is attached to the other end. The coil, which is located in a two-gap magnet, moves when current passes through it. This causes the heads to be moved in an arc across the disk surface. Track crossing information is obtained from the servo tracks to position the heads over the required track. A preamplifier for the servo is mounted on the actuator arm, close to the head element. The actuator has no mechanical detent when it completes a seek, but constantly servos. When the heads are over the landing zones, however, a magnetic catch on the actuator makes sure they do not move in a normal power-off state. During removal, installation, and in transit of the DE, the mechanical actuator and spindle locks must be set.

Motor

The disk is driven by a 1/6-Hp, ac-induction motor that is mounted on the subframe. The motor has a thermal cut-out switch with manual reset to prevent overheating. The motor has a fail-safe brake that is applied immediately following power off. The disk speed during start and stop operations is important because the time the heads touch the disk while it is rotating must be kept to a minimum. The fail-safe brake releases a spring-loaded plate that pushes the brake on when controller power turns off.

Data Recording

Data is transferred by heads that fly above the disk when the disk is spinning at 2964 rpm. When the disk is stationary, the heads are in contact with it. To minimize head wear, the stop/start times of the disk are controlled.

During a normal start or stop cycle, the data and servo heads are positioned over the landing zones. The landing zones are not used for recording. An actuator retract circuit ensures that the heads are moved over the landing zone if ac power fails.



Servo

The servo head follows prewritten patterns at the cylinder locations to ensure that the moving data heads maintain track alignment. The servo tracks provide information that is used by the servo circuitry to detect track crossing.

A seek error occurs when a read/write head is incorrectly positioned over the desired track after a seek operation. The disk maintains track alignment through the servo error signal, but cannot detect or recover from a seek error unless the heads enter the guard band area (that is, the area between the data tracks and the landing zone). If the read/write heads do enter the guard band, the servo head detects it and sends a signal to the Disk Control, which ends the seek operation.

Diagrammatic cross-section of disk

LZ : Landing Zone
G : Guard Band



3.5 DISKETTE DRIVE ASSEMBLY (SINGLE SIDE)

3.5.1 General Description

3 Diskette Drive Cover

The diskette drive cover permits insertion and removal of the diskette

2 Diskette Collet Assembly

When the diskette drive cover is closed, the spring-loaded collet centers and clamps the diskette to the diskette drive hub.

1 Head Load Actuator Assembly

The head load actuator assembly consists of a magnet and an armature. During a read or write operation, the head load actuator is energized and allows the pressure pad arm to push the diskette against the read/write head. At the same time, the head load actuator armature forces the diskette package against the flexible disk for cleaning. While not reading or writing, the head load actuator is deenergized and holds the pressure pad assembly away from the diskette to reduce diskette and head wear.

11 Preload Spring

The preload spring loads the leadscrew to maintain head alignment with the diskette.

10 Limit Stops


The upper limit stop prevents the head from being driven beyond track 77. The lower limit stop prevents the head from being driven lower than track 00.

9 Read/Write Head

The read/write head provides the read, write, and erase functions.

8 Leadscrew Nut and Spring

The leadscrew nut and spring load the head and carriage assembly to maintain head alignment with the diskette.



4 Light Emitting Diode (LED) and Phototransistor

When the diskette drive cover is closed, the continuous light emitted from the LED is directed toward the phototransistor. Once every revolution, the index hole in the diskette allows light from the LED to reach the phototransistor. The phototransistor sends index pulses to the diskette adapter card via the diskette drive control card.

5 Diskette Drive Control Card

The diskette drive control card provides drive circuits for the stepper motor, head load actuator, and write and erase heads. It also provides the amplifiers for the phototransistor and read head.

The card is mounted with the components and test pins facing out for service.

6 Motor and Drive

The motor turns the diskette at a speed of 360 rpm $\pm 2.5\%$.


7 Stepper Motor Assembly

The stepper motor wheel is permanently mounted on the end of the stepper motor shaft. The stepper motor shaft turns in increments of 90 degrees in either direction under the control of access pulses. The stepper motor wheel engages the leadscrew wheel. When the stepper motor rotates 90 degrees, it causes the leadscrew to rotate 90 degrees. The head carriage assembly then moves up or down one track on the diskette.

3.5.2 Operating Sequence



1. The controller activates motor power. Diskette can be inserted or removed with power up.
2. Insert diskette and close cover. Closing the cover engages the diskette clamp **9** in the drive hub **8**, clamping the diskette in place. With power up, the diskette is now turning.
3. After a 10-second delay from power on, index pulses **1** every 166.6 ms nominal are read.
4. 'Head engage' line **2** is activated. This causes the pressure pad **11** to push the flexible diskette against the read head **10**. After 80-ms settle time **5**, data is valid for the system. Head location is determined by reading track **3** or by returning the read head to track 0.
5. For each access command, the stepper motor **13** rotates the leadscrew **12** 90 degrees clockwise or counterclockwise. This moves the read head one track position. (Clockwise rotation of leadscrew, looking down on unit, moves the carriage up.) Two adjacent signal lines must be energized at the same time when accessing **8**. Overlapping must be no less than 50 ms **6**. Prior to read or write operations, the two lines for the selected track must be energized for 150 ms minimum **7** (50 ms for travel and 100 ms to stabilize).
6. Full track read occurs **4**.
7. Pressure pad is lifted as soon as possible after completion of last read, write, or access operation to reduce diskette and head wear **2**.

Typical Timing Sequence



Track	0	1	2	3	4	5	6	74	75	76
Access 0	X			X	X				X	X
Access 1	X	X		X	X	X			X	X
Access 2		X	X	X		X	X	X		
Access 3			X	X		X	X	X	X	

Motor is at phase 0 when read head is at track 0 and every track divisible by 4.



3.5.3 Read/Write Circuit Principles

Write Data


For each transition in the 'write data' line, current is switched in the read/write head causing a flux change on the diskette.

Raw Read Data

- Sine wave signal:
125 kHz (all 0's)
250 kHz (all 1's)
- Higher voltage at outer track because of higher diskette speed and lower bit density.
- All 0's pattern gives higher voltage amplitude than all 1's.


Limit Amplifier

- High-gain differential amplifier increases signal so one of amplifier transistors is cut off. Outputs of limiter are two out-of-phase square waves.
- Differential rectifier RC network differentiates square waves. Resulting positive- and negative-going pulses (180° out of phase) are input to an OR circuit. Output is a train of positive pulses. Positive leading edges of output pulses correspond to peaks in read signal delayed by a constant amount.
- Data is a string of 150-ns pulses (+Diskette Data) which are fed to the VFO in the diskette adapter card.




Erase

The edges of the data track are erased to prevent reading of adjacent tracks.



Full Track Differential Read Signal at CE Test Points



3.6 DISKETTE DRIVE ASSEMBLY (TWO-SIDED)

3.6.1 General Description

Cover Assembly

- 1 Latch assembly
- 2 Collet




The diskette drive cover assembly **3** pivots to accept the diskette **5**. The diskette is automatically centered and clamped to the drive hub **18** by the collet.

Two timing pins **4** are stored in a holder located inside the cover assembly.

AC Drive Components

- 13 Belt
- 8 Drive motor
- 16 Drive pulley
- 14 Idler assembly
- 15 Idler spring

These components drive the hub. The motor rotates the diskettes clockwise (viewed from the front) at a speed of 360 rpm with the heads loaded.



Stepper Drive Components

- 9 Stepper motor
- 23 Stepper motor pulley
- 24 Stepper motor pulley clamp
- 21 Wiper
- 22 Stepper drive band
- 10 Stepper idler assembly

The stepper motor shaft turns in increments of 1.8° in either direction under control of access pulses. This motion causes the head/carryage assembly to move the heads across the diskette surface a distance equal to one track.

Head/Carriage Assembly

The head/carryage assembly **19** consists of two read/write heads mounted on a common carriage. The assembly moves under control of the stepper motor. The read/write heads provide the read, write, and erase functions required to record and retrieve data from either side of the diskette.

CAUTION: The head/carryage assembly is a factory-adjusted and tested assembly. Any attempt to adjust, repair, or clean any part of this internal component is likely to cause serious damage to the read/write heads or carriage assembly.

Head Load Solenoid/Bail Assembly

The head load solenoid **7** is energized, causing the bail assembly **20** to load the heads. The heads are loaded before a read or write operation. The heads are unloaded after no more than one revolution if another read or write operation is not to be executed. This reduces wear to the diskette and read/write heads.

LED/PTX Assemblies

The LED (light emitting diode) **17** and PTX (phototransistor) **6** assemblies provide a means of detecting the diskette index and identifying the type of diskette inserted (one-sided or two-sided).



Diskette Drive Control Card

The diskette drive control card **12** provides the drive circuits for the stepper motor, head load solenoid, and the write and erase functions. It also provides the amplifiers for the read heads and the LED/PTX circuitry. The diskette drive control card is supported by a card retainer **11** located between it and the stepper motor.

3.6.2 Operating Sequence

1. The controller activates motor power and the diskette motor starts turning.
2. Insert a one-sided or two-sided diskette. The type of diskette is identified by the diskette sense line. An up level indicates a two-sided diskette.
3. Close the cover assembly. This causes the collet to engage the drive hub, clamping the diskette in place. The diskette starts turning.
4. After a 10-second delay from power on, index pulses **1** are sensed every 166.7 ms (nominal).
5. Head Engage **2** is activated causing the heads to load. After 80-ms head settle time **5**, data is valid for the controller, and head location is determined by reading **3** the track address.
6. Access to the desired track is done by sequencing the four access lines to move the head/carriage assembly in (toward the hub) or out (away from the hub). Energizing adjacent access lines **7** rotates the stepper motor 1.8°, a distance of one track. The two access lines for the last track accessed remain energized.
7. Reading occurs **4** 35 ms after the last track access **6**.
8. The heads are lifted after the last read, write, or access operation to reduce diskette and head wear.

Typical Timing Sequence



3.6.3 Read/Write Circuit Principles

Write Data


For each transition in the 'write data' line, current is switched in the read/write head, causing a flux change on the diskette surface.

Raw Read Data

- Sine wave signal:
 - 125 kHz (all 0's)
 - 250 kHz (all 1's)
- Higher voltage at outer tracks because of higher track speed and lower bit density.
- All 0's pattern gives higher voltage amplitude than all 1's.

Limit Amplifier



- High-gain differential amplifier increases signal so one of amplifier transistors is cut off. Outputs of limiter are two out-of-phase square waves.
- Differential rectifier RC network differentiates square waves. Resulting positive- and negative-going pulses (180° out of phase) are input to an OR circuit. Output is a train of positive pulses. Positive leading edges of output pulses correspond to peaks in read signal delayed by a constant amount.
- File data is a string of pulses (+Diskette Data), 150 ns to 500 ns long, which are fed to the VFO in the diskette adapter card.




3.7 DISKETTE

Characteristics


Diskette




- Do not use clips. Never write on diskette with erasable pencil.




- Do not touch or clean the flexible disk surface. Contaminated diskettes must be discarded.



- Keep diskette away from magnetic fields and from ferromagnetic materials which might be magnetized. Any diskette exposed to a magnetic field may lose information.



- Do not expose diskette to excessive heat (125°F or 51.5°C) or direct sunlight.



Long Term Storage

Place diskettes in their envelopes and store in the following environment:

- Temperature: 50° to 125°F (10.0° to 51.5°C)
- Relative humidity: 8% to 80%
- Maximum wet bulb: 85°F (29.4°C)

If a diskette has been exposed to temperatures outside of the machine's environmental range, allow five minutes acclimation time before use. The diskette should be removed from its shipping container during this time, but should be kept in its envelope.

Shipping and Receiving


CAUTION: Ship diskette inside the original shipping container. An ordinary mailing envelope does not provide sufficient protection.

Be sure to label the package: **DO NOT EXPOSE TO EXCESSIVE HEAT (125°F or 51.5°C) OR DIRECT SUNLIGHT.**


Upon receiving diskettes, check for container and diskette damage. Save the container for storing the diskette and for shipment later.

Insertion

- Open cover.




- Remove diskette from envelope. Grasp diskette by upper edge.



- Lower diskette squarely into the file. **CAUTION:** Do not insert damaged diskettes.

- Close cover after diskette is fully inserted.




- Place the empty envelope in a clean storage area.

Removal

Reverse above procedure.

Flexible Disk



Handling

CAUTION: Observe the following cautions:

- Do not insert damaged diskettes into diskette drive. Diskettes which are physically damaged (torn, creased, warped) or contaminated with foreign materials (eraser dust, fingerprints, cleaning fluid, etc.) may cause operation errors, equipment errors, or head damage.
- Placing heavy objects on diskettes may damage diskette.
- Return diskette to envelope whenever it is not being used. Storage space for diskettes enclosed in envelopes is provided inside front cover of the controller. When diskettes are stored outside of the controller, additional protection is provided by returning the diskettes to their shipping containers.

3.8 INTERCONNECT DIAGRAMS

Figures 3-3 through 3-18 illustrate the internal and external cables and power distribution wiring diagrams essential to controller maintenance. For a listing of these diagrams, refer to page 3-1.

Volts	Wire No.	3601 Location	3602 01B1 End	Diskette Drive End
+5*	1	01A/TB-1	TB1-6	B03
	T1	01A/TB1-9	TB1-3	Bus
+24	2	01A/A1Z-B10	Z3B10	B10
	T2	01A/A1Z-BUS	Z3 Bus	Bus
-5*	3	01A/TB1-4	TB1-10	B11
	T3	01A/TB1-10	TB1-3	Bus
Ground	Bus			B08

*This cable wire is not point to point.

Note: Wire numbers prefixed by "T" indicate black wire of twisted pair.

Function	Wire No.	Both Ends
Write Data	4	B02
Erase Gate	5	B04
Write Gate	6	B05
Write I Sel	7	B06
Access 0	8	D02
Access 1	9	D03
Access 2	10	D04
Access 3	11	D05
Diskette Data	12	D07
Head Engage	13	D10
Index	14	D13
Head Select	15	B07
Two-Sided Diskette Sense	16	D08
Two-Sided Drive Sense	17	D09

Cable PNs 4943641 or 1652549 or 1747295

Wire No.	Y/Z Connector	EIA Conn. on Panel
1	D02	22
2*	B02	25
T2*	B13	14
3	D03	3
4	B04	2
5	D05	5
6*	B05	10
T6*	D06	9
7	B06	17
8	B07	11
9	D07	12
10	D08	7
11	B09	8
12	D10	4
13	B10	16
14	D11	18
15	B11	15
16	D12	6
17	B12	23
18	D13	20
19	D09	21
T19	D04	24
20	B03	13

*These wires are used only on internal modems. Remainder are used only for external modems.

Note: Wire numbers prefixed by "T" indicate black wire of twisted pair.

Cable PN 4409516

Wire No.	Y/Z Connector	EIA Conn. on Panel
1	D02	22
2	D03	3
3	B04	2
4	D05	5
5	B06	17
6	B07	11
7	D08	7
8	B09	8
9	D10	4
10	D11	18
11	B11	15
12	D12	6
13	B12	23
14	D13	20




Figure 3-3. Internal Cable PN 4943638/1741686/5645325, Basic Controller Board Connector/Diskette File Control Card




Figure 3-4. Internal Cable PN 4943641/1652549/1747295/4409516/Modem/EIA Connector for Communication Link







Figure 3-5. Internal Modem Cables, Board/Cable Panel



CABLE PN 4406670

3601-2/3

	Local	Cable Panel			Remote †	
		Color*	Connector	Terminal		
Loop 1	A1H1A11	Black	J2	Ring	Twisted Pair	
	A1H1A13	White	J2	Tip		
	A1H1B11	Black	J3	Ring		
	A1H1B13	White	J3	Tip		
Loop 2	A1H1C11	Black	J4	Ring	A2A5D02	A2B2B02
	A1H1C13	White	J4	Tip	A2A5B02	A2B2B03
	A1H1D11	Black	J5	Ring	A2A5D03	A2B5D11
	A1H1D13	White	J5	Tip	A2A5B03	A2B5B09
Loop 3	A1H1E11	Black	J6	Ring	A2A5D04	A2C2B02
	A1H1E13	White	J6	Tip	A2A5B04	A2C2B03
	A1J1A11	Black	J7	Ring	A2A5D05	A2C5D11
	A1J1A13	White	J7	Tip	A2A5B05	A2C5B09
Loop 4	A2A6D02	Black	J8	Ring	A2A5D06	A2F2B02
	A2A6D04	White	J8	Tip	A2A5B06	A2F2B03
	A2A6E02	Black	J9	Ring	A2A5D07	A2F5D11
	A2A6E04	White	J9	Tip	A2A5B07	A2F5B09
Loop 5	A2B6A02	Black	J10	Ring	A2A5D10	A2E2B02
	A2B6A04	White	J10	Tip	A2A5B10	A2E2B03
	A2B6B02	Black	J11	Ring	A2A5D11	A2E5D11
	A2B6B04	White	J11	Tip	A2A5B11	A2E5B09
Loop 6	A2B6C02	Black	J12	Ring	A2A5D12	A2D2B02
	A2B6C04	White	J12	Tip	A2A5B12	A2D2B03
	A2B6D02	Black	J13	Ring	A2A5D13	A2D5D11
	A2B6D04	White	J13	Tip	A2A5B13	A2D5B09

PN 4943640

3601-C/D

	Local	Cable Panel		
		Color*	Connector	Terminal
Loop 1	A1D1E11	Black	J2	Ring
	A1D1E13	White	J2	Tip
	A1E1A11	Black	J3	Ring
	A1E1A13	White	J3	Tip

PN 4406670

3602

	Local	Cable Panel			Remote †	
		Color*	Connector	Terminal		
Loop 1	B1H1A11	Black	J3	Ring	Twisted Pair	
	B1H1A13	White	J3	Tip		
	B1H1B11	Black	J2	Ring		
	B1H1B13	White	J2	Tip		
Loop 2	B1H1C11	Black	J5	Ring	A2A5D02	A2B2B02
	B1H1C13	White	J5	Tip	A2A5B02	A2B2B03
	B1H1D11	Black	J4	Ring	A2A5D03	A2B5D11
	B1H1D13	White	J4	Tip	A2A5B03	A2B5B09
Loop 3	B1H1E11	Black	J7	Ring	A2A5D04	A2C2B02
	B1H1E13	White	J7	Tip	A2A5B04	A2C2B03
	B1J1A11	Black	J6	Ring	A2A5D05	A2C5D11
	B1J1A13	White	J6	Tip	A2A5B05	A2C5B09
Loop 4	A2A6D02	Black	J9	Ring	A2A5D06	A2F2B02
	A2A6D04	White	J9	Tip	A2A5B06	A2F2B03
	A2A6E02	Black	J8	Ring	A2A5D07	A2F5D11
	A2A6E04	White	J8	Tip	A2A5B07	A2F5B09
Loop 5	A2B6A02	Black	J11	Ring	A2A5D10	A2E2B02
	A2B6A04	White	J11	Tip	A2A5B10	A2E2B03
	A2B6B02	Black	J10	Ring	A2A5D11	A2E5D11
	A2B6B04	White	J10	Tip	A2A5B11	A2E5B09
Loop 6	A2B6C02	Black	J13	Ring	A2A5D12	A2D2B02
	A2B6C04	White	J13	Tip	A2A5B12	A2D2B03
	A2B6D02	Black	J12	Ring	A2A5D13	A2D5D11
	A2B6D04	White	J12	Tip	A2A5B13	A2D5B09
Loop 7	A2T6A02	Black	J15	Ring	A2U6D02	A2T2B02
	A2T6A04	White	J15	Tip	A2U6D04	A2T2B03
	A2T6B02	Black	J14	Ring	A2U6E02	A2T5D11
	A2T6B04	White	J14	Tip	A2U6E04	A2T5B09
Loop 8	A2T6C02	Black	J17	Ring	A2V6A02	A2U2B02
	A2T6C04	White	J17	Tip	A2V6A04	A2U2B03
	A2T6D02	Black	J16	Ring	A2V6B02	A2U5D11
	A2T6D04	White	J16	Tip	A2V6B04	A2U5B09

PN 1563175, *PN 1741682

*Black may be black or white/black; and white may be white or white/red
 †REMOTE LOOPS: On later level boards (38LS modems), the transmit pair (jack) go directly to the card socket pins Ring J05, Tip G02; the receive pair (plug), Ring J13, Tip G09.

Figure 3-6. Internal Loop Cables, Board/Cable Panel

Fig. 3-7

SY27-2519-0

(4/78) 3-20








Table A

Wire No.	Card Pos	Function
1	B02	+Reset
2	D08	Gnd
3	D02	-Reset
4	D03	+5V
5	B04	+5V Spec
6		Not used
7		-LED
8		+LED
9		+5V

Table A

Wire No.	Card Pos	Function
1	B03	+5V
2	D02	+Reset
3	B08	Gnd.
4	D04	+5V Spec
5	B02	-Reset
6		Gnd



A 3601 Internal Cable, PN 4943646, 01A1Z/Operator's Panel


B 3602 Internal Cable, PN 1652519, 01AB1Z/Operator's Panel

Figure 3-7. Controller Internal Cable to Operator's Panel

Select the controller you have by the model and the power system used. Refer to the figure number indicated for your controller for the correct Power Distribution Wiring Diagram and Cable Assemblies.

Controller Model and Number of Power Supplies	Power Distribution Wiring Diagram	Power Distribution Cable Assemblies
3601-2A, 2B, 3A, 3B (Single TSR-3 power supply)	Figure 3-9, Part 1	Figure 3-9, Part 2
3601-2A, 2B, 3A, 3B (One or two TSR-2 power supplies)	Figure 3-10, Part 1	Figure 3-10, Part 2
3601-C, D	Figure 3-11, Part 1	Figure 3-11, Part 2
3602-1A, 1B (TSR-3 power supply, more than 2 wires on B1Y4)	Figure 3-12, Parts 1, 2	Figure 3-12, Part 2
3602-1A, 1B (TSR-3 power supply, only 2 wires on B1Y4)	Figure 3-13, Parts 1, 2	Figure 3-13, Part 2

Figure 3-8. Power Distribution Wiring Diagram and Cable Assembly Selection



Notes:
1 Wire colors shown in parentheses are applicable for World Trade.
2 RFI (Radio Frequency Interference) feature only for use with filter ASM 1860276.

- A** All Models
- B** All Models
- C** Model 3
- D** Expanded storage
- E** Models
- F** All Models

A. Wiring Diagram

Figure 3-9 (Part 1 of 2). Power Distribution, 3601-2A, 2B, 3A, 3B (Single TSR-3 Power)

Wire No.	From TSR-TB	To	
		01A-TB1-	01A1-Y4-
1	1 (+5)	1	—
2	2 (+5)	2	—
3	3 (+5)	3	—
4	4 (Gnd)	13	—
5	5 (Gnd)	10	—
6	6 (Gnd)	11	—
7	7 (Gnd)	12	—
8	8 (-5)	4	—
9	9 (-12)	7	—
10	10 (Gnd)	11	—
11	11 (Gnd)	—	Gnd Bus
12	12 (+12)	6	—
13	13 (8.5)	8	—
14	14 (Gnd)	12	—
15	15 (+24)	—	D10
16	16 (Gnd)	—	Gnd Bus
17	01A-TB1-7 (-12) to		D05
18	01A-TB1-13 (Gnd) to		Gnd Bus
19	01A-TB1-6 (+12) to		D07

A Cable PN 4943637

Wire No.	From 01A/TB1-	To
		Board A1 Pwr Conn
1	12 (Gnd)	B2E14
2	12 (Gnd)	B3E14
3	11 (Gnd)	B4E14
4	8 (8.5)	B2A14
5	8 (8.5)	B3A14
6	9 (8.5)	B4A14
7	4 (-5)	B3E01
8	5 (-5)	B4E01
9	5 (-5)	B5E01
10	1 (+5)	B3A01
11	1 (+5)	B4A01
12	2 (+5)	B5A01
13	2 (+5)	U3A01
14	3 (+5)	U4A01
15	3 (+5)	U5A01
16	11 (Gnd)	U2E14
17	10 (Gnd)	U3E14
18	10 (Gnd)	U4E14

B Cable PN 4943639

Wire No.	From 01A/TB1-	To
		Board A2 Pwr Conn
1	10 (Gnd)	U2E14
2	11 (Gnd)	U3E14
3	12 (Gnd)	U4E14
4	8 (8.5)	U2A14
5	8 (8.5)	U3A14
6	8 (8.5)	U4A14
7	4 (-5)	U3E01
8	5 (-5)	U4E01
9	5 (-5)	U5E01
10	1 (+5)	U3A01
11	2 (+5)	U4A01
12	3 (+5)	U5A01
13	1 (+5)	B3A01
14	2 (+5)	B4A01
15	3 (+5)	B5A01
16	10 (Gnd)	B2E14
17	11 (Gnd)	B3E14
18	12 (Gnd)	B4E14

C Cable PN 4943643

Wire No.	From 01A/TB1-	To
		Board B1 Pwr Conn
1	1 (+5)	B3A01
2	2 (+5)	B5A01
3	8 (8.5)	B2A14
4	9 (8.5)	B4A14
5	10 (Gnd)	B2E14
6	10 (Gnd)	B4E14

D Cable PN 4405854

Wire No.	From 01A/TB1-	To
		A2Z3
1	6 (+12)	D07
T1	13 (Gnd)	B08
2	7 (-12)	D05
T2	13 (Gnd)	D09

E Cable PN 4943652

Cable & Load Resistor Conn	
From	To TSR TB
R1A	15 (+24)
R3A	12 (+12)
R5A	9 (-12)
R6A	13 (8.5)
R2B	4 (Gnd)
R7B	5 (Gnd)

F Cable & Resistor Assy
PN 4943645

- A** All Models
- B** All Models
- C** Model 3
- D** Expanded Storage
- E** Model 3
- F** All Models

B. Cable Assemblies

Figure 3-9 (Part 2 of 2). Power Distribution 3601-2A,2B,3A,3B (Single TSR-3 Power Supply)




Figure 3-10 (Part 1 of 2). Power Distribution 3601-2A,2B,3A,3B (One or two TSR-2 Power Supplies)

Wire No.	From TSR2 Conn	To 01ATB2
1	1 (8.5)	7
2	2 (8.5)	8
3	3 (Gnd)	2
4	4 (Gnd)	1
5	5 (+5)	4
6	6 (+5)	4
7	7 (+5)	5
8	8 (+5)	6
9	9 (Gnd)	2
10	10 (Gnd)	2
11	11 (Gnd)	1
12	12 (Gnd)	3
13	13 (Gnd)	3
14	14 (-5)	9
15	15 (-5)	10
16	01A-TB2-3 to 01A-TB1-13	

B Cable PN 4406660

Wire No.	From Resistors	To 01A-TB2-
1	R1 - A	4(+5)*
2	R3 - A	9(-5)
3	R6 - B	7(+8.5)
4	R1 - B	1(Gnd)
5	R2 - A	5(+5)*
6	R5 - B	3(Gnd)

C Cable PN 4406661

* With 3 or more logic cards on the expanded storage board, remove and tape wire #1 at TB2 - 4; with 6 or more logic cards, wire #5 at TB2 - 5 also.

B. Cable Assemblies

Figure 3-10 (Part 2 of 2). Power Distribution 3601-2A,2B,3A,3B (One or two TSR-2 Power Supplies)

Wire No.	From 01A-TB2-	To Board A2 Pwr Conn
1	1 (Gnd)	U2E14
2	1	U3E14
3	2 (Gnd)	U4E14
4	2	B2E14
6	3 (Gnd)	B4E14
7	4 (+5)	U3A01
8	4	U4A01
9	5 (+5)	U5A01
10	5	B3A01
12	6 (+5)	B5A01
13	7 (8.5)	U2A14
14	7	U3A14
15	8 (8.5)	U4A14
16	8	B2A14
18	8	B4A14
19	9 (-5)	U3E01
20	9	U4E01
21	10 (-5)	U5E01
22	10	B3E01
24	10	B5E01
25	01A-TB1-6 to A2U4D07	
26	01A-TB1-6 to A2B4D07	

D Cable PN 4406662

Wire No.	From TSR-2B	To 01A-TB1
1	1 (8.5)	9
2	2 (Gnd)	10
3	3 (Gnd)	10
4	4 (-12)	6
5	5 (+24)	7
6	6 (+5)	1
7	7 (+5)	2
8	8 (+5)	3
9	9 (+5)	3
10	10 (Gnd)	11
11	11 (Gnd)	11
12	12 (Gnd)	12
13	13 (Gnd)	12
14	14 (Gnd)	13
15	15 (-5)	5
37	J5-1 (Gnd)	2
38	J5-2 (+5)	10

A Cable PN 4406074

From 01A-TB1-	Wire No.	To Board A1 Pwr Conn
1 (+5)	29	B3A01
	30	B4A01
2 (+5)	16	U4A01
	17	U5A01
3 (+5)	31	B5A01
	32	U3A01
4 (-5)	21	B5E01
	33	B3E01
5 (-5)	20	B4E01
6 (-12)	39	to A1Y4-D05
7 (+24)	40	to A1Y4-D10
8 (8.5)	24	U2A14
	25	U3A14
	26	U4A14
9 (8.5)	22	B3A14
	23	B4A14
	27	B2A14
10 (Gnd)	18	U3E14
11 (Gnd)	19	U4E14
12 (Gnd)	28	U2E14
13 (Gnd)	34	B2E14
	35	B3E14
	36	B4E14


Wire No.	01A-TB2	Board B1 Pwr Conn
1 (Gnd)	1	B2E14
2 (Gnd)	1	B3E14
3 (Gnd)	1	B4E14
4 (8.5)	7	B2A14
5 (8.5)	7	B3A14
6 (8.5)	7	B4A14
7 (+5)	4	B3A01
8 (+5)	4	B4A01
9 (+5)	4	B5A01

E Cable PN 8269854

Line Name	Connect from	To Loop 2	To Loop 3
	TB1 - (+8.5V)	A2B2B11	A2C2B11
	TB1 - (+5V)	A2B2D03	A2C2D03
	TB1 - (-12V)	A2B2D07	A2C2D07
	TB1 - (Gnd)	A2B2D08	A2C2D08
Wrap	A1Z4D03	A2B2B05	
Clock	A1Z4D04	A2B2D09	
Rcv Data	A1Z4B03	A2B2B10	
Send Data	A1Z4B04	A2B2D04	
Wrap	A1Z4D05		A2C2B05
Clock	A1Z4B05		A2C2D09
Rcv Data	A1Z4B06		A2C2B10
Send Data	A1Z4D06		A2C2D04

F Cable PN 4409771

- A** All Models
- B** Model 3 or Expanded Storage
- C** Model 3
- D** Model 3
- E** Expanded Storage
- F** Remote Loop Interface to External Modem (Model 2A only)



A. Wiring Diagram

Figure 3-11 (Part 1 of 2). Power Distribution, 3601 C, D

Wire No.	From	To	Wire No.	To
	TSR-2	01A-TB1		01A-TB1
1	1 (8.5)	8	1 (+5)	B3A01
2	2 (Gnd)	11	22	B4A01
3	3 (Gnd)	12	2 (+5)	B3A14
4	4 (-12)	6	23	B5A01
5	5 (+24)	7	3 (+5)	B2A14
6	6 (+5)	1	18	B4A01
7	7 (+5)	2	21	M2E14
8	8 (+5)	3	36	M3E01
9	9 (+5)	1	37	M3E14
10	10 (Gnd)	10	38	M5E01
11	11 (Gnd)	11	41	M4E01
12	12 (Gnd)	12	39	M4E14
13	13 (Gnd)	13	40	
14	14 (Gnd)	10	42	To A1Z3B10
15	15 (-5)	5	43	To A1Z3B05
16	J5-1 (Gnd)	2	8 (8.5)	M3A14
17	J5-2 (+5)	13	32	M5A01
			35	M2A14
			9 (8.5)	M3A01
			30	M4A01
			31	M4A14
			33	B2E14
			34	B4E14
			10 (Gnd)	B3E01
			24	B5E01
			28	
			11 (Gnd)	
			25	
			29	
			12 (Gnd)	
			—	
			13 (Gnd)	B3E14
			26	B4E01
			27	


Ⓐ Cable PN 4406682

B. Cable Assemblies

Figure 3-11 (Part 2 of 2). Power Distribution 3601-C,D


Fig. 3-12, Part 1

SY27-2519-0
TNL SN31-0864



A. Wiring Diagram

Figure 3-12 (Part 1 of 2). Power Distribution, 3602-1A, 1B (TSR-3 Power Supply, more than 2 wires on B1Y4)



A. Wiring Diagram (Cont)

Wire No.	01A-TB1	Resistor TB Assembly
1 Gnd	1	7
2 Gnd	2	8
3 +5	7	5
4 +8.5	11	4
5 -12	13	3
6 +12	15	2
7 +24	16	1

● Cable PN 1741702

B. Cable Assemblies

Wire No.	TSR 3E	01A-TB1	G-CB1
1 Gnd	4	1	
2 Gnd	5	2	
3 Gnd	6	3	
4 Gnd	7	4	
5 +5	1	5	
6 +5	2	6	
7 +5	3	7	
8 +8.5	13	11	
9 Gnd	10	1	
10 Gnd	14	3	
11 -12	9	13	
12 +12	12	15	
13 +24	15	16	
14 Gnd	16	2	
15 +24	15	01A1A5B02	
T15 Gnd	16	01A1A5D08	
16 -5	8		Line Load
17 Gnd		9	N/C
18 Gnd		4	N/O
19 +24		16	

● Cable PN 1741691

Wire No	01A-A1	01A-TB1	TSR-1	Misc Connection
1 -4				Wire No's. 9, 24, 25
2 Gnd		4		Wire No. 10
3 -12		13	12	
4 +24	Z3B10	16		
5 +24		16	11	
6 +6	Z3D11		4	
7 Gnd	Z3 Bus		3	
8 Gnd	Z3 Bus		9	
9 -4			1	Wire No. 1
10 Gnd			2	Wire No. 2
11 -24	Z3D13		6	
12 Gnd	Z3 Bus			01H-C1-
13 -5	Z3D10	10		
14 +8.5	Z3D09	12		
15 M.C.Ret	Z3B02			01H-C1+
16 +Brk Flt	Z3D04			01H-K1-2
17 Gnd		2		01H-TB1-4
18 Gnd	Gnd Bus	3		
19 Gnd	Gnd Bus	3		
20 +5	+5 Bus	6		
21 +5	+5 Bus	6		
22 +5	+5 Bus	6		
23 +5	+5 Bus	6		
24 -4	C2B06			Wire No. 1
25 -4	A4B06			Wire No. 1
26 Gnd	Gnd Bus	2		
27 Gnd	Gnd Bus	2		
28 +24 Cntl		16		01H-K1-1

● Cable PN 1741690

Wire No.	From 01A-TB1	To Board B2 Pwr Conn
1 +5	5	B3A01
2 +5	5	B4A01
3 +5	5	B5A01
4 +5	7	J3A01
5 +5	7	J4A01
6 +5	7	J5A01
7 Gnd	1	B2E14
8 Gnd	1	B3E14
9 Gnd	1	B4E14
10 Gnd	2	J2E14
11 Gnd	2	J3E14
12 Gnd	2	J4E14
13 +8.5	11	B2A14
14 +8.5	11	B3A14
15 +8.5	11	B4A14
16 +8.5	12	J2A14
17 +8.5	12	J3A14
18 +8.5	12	J4A14

● Cable PN 4404337


Wire No.	01A-TB1	Board Pwr Conn
1 Gnd	1	A2M2E14
2 Gnd	1	A2M3E14
3 Gnd	1	A2M4E14
4 Gnd	2	B1B2E14
5 Gnd	2	B1B3E14
6 Gnd	2	B1B4E14
7 +5	5	A2M3A01
8 +5	5	A2M4A01
9 +5	5	A2M5A01
10 +5	7	B1B3A01
11 +5	7	B1B4A01
12 +5	7	B1B5A01
13 -5	9	A2M3E01
14 -5	9	A2M4E01
15 -5	9	A2M5E01
16 -5	9	B1B3E01
17 -5	9	B1B4E01
18 -5	9	B1B5E01
19 +8.5	12	A2M2A14
20 +8.5	12	A2M3A14
21 +8.5	12	A2M4A14
22 +8.5	12	B1B2A14
23 +8.5	12	B1B3A14
24 +8.5	12	B1B4A14
25 -12	13	A2Z3D05
26 +12	15	A2Z3D07
27 +24	16	B1Y4D10
28 Gnd	3	A2B2E14
29 Gnd	3	A2B3E14
30 Gnd	3	A2B4E14
31 Gnd	4	B1M2E14
32 Gnd	4	B1M3E14
33 Gnd	4	B1M4E14
34 +5	5	A2B3A01
35 +5	5	A2B4A01
36 +5	5	A2B5A01
37 +5	7	B1M3A01
38 +5	7	B1M4A01
39 +5	7	B1M5A01
40 +8.5	11	A2B2A14
41 +8.5	11	A2B3A14
42 +8.5	11	A2B4A14
43 +8.5	11	B1M2A14
44 +8.5	11	B1M3A14
45 +8.5	11	B1M4A14
46 Gnd	1	A2Z3D09
47 Gnd	1	A2Z3B08
48 Gnd	1	B1Y4D09
49 -12	13	B1Y4D05
50 +12	15	B1Y4D07
51 Gnd	4	B1Y4D08
52 Gnd	4	B1Y4B08

● Cable PN 1741681

Figure 3-12 (Part 2 of 2). Power Distribution, 3602-1A, 1B (TSR-3 Power Supply, more than 2 wires on B1Y4)


Fig. 3-12, Part 2

TNL SN31-0864
SY27-2519-0



LOW ENTRY WIRING CHART

01J TB POS	4119419 W.T.	5252950 DOM
1	COMM	COMM
2	COMM	100 V
3	100V 50/60 Hz	115 V
4	110V 50 Hz	
5	115V 60 Hz	
6	123.5V 50 Hz	208 V
7	220V 50 Hz	
8	230V 60 Hz	




Note:
1. RFI feature only for use with filter assembly 1860276.

- Ⓐ All Models
- Ⓑ Expanded Storage
- Ⓒ All Models
- Ⓓ All Models
- Ⓔ All Models

A. Wiring Diagram

Figure 3-13 (Part 1 of 2). Power Distribution, 3602-1A,1B (TSR-3 Power Supply, only 2 wires on B1Y4)



A. Wiring Diagram (Cont)

Wire No.	TSR 3E	O1A-TB1	G-CB1
1	Gnd	4	
2	Gnd	5	
3	Gnd	6	
4	Gnd	7	
5	+5	1	
6	+5	2	
7	+5	3	
8	+8.5	13	
9	Gnd	10	
10	Gnd	14	
11	+24	16	N/O
12	-12	12	
13	+24	15	
14	Gnd	16	
15	+24	15	01A1A5B02
T15	Gnd	16	01A1A5D08
16	-5	8	
17	Gnd	9	Line Load
18	Gnd	4	N/C

A Cable PN 4406665

Wire No.	From O1A-TB1	To Board B2 Pwr Conn
1	+5	5
2	+5	5
3	+5	5
4	+5	7
5	+5	7
6	+5	7
7	Gnd	1
8	Gnd	1
9	Gnd	1
10	Gnd	2
11	Gnd	2
12	Gnd	2
13	+8.5	11
14	+8.5	11
15	+8.5	11
16	+8.5	12
17	+8.5	12
18	+8.5	12

B Cable PN 4404337

Wire No	O1A-A1	O1A-TB1	TSR-1	Misc Connection
1	-4			
2	Gnd		4	Wire No's. 9, 24, 25
3	-12	Z3B10	13	Wire No. 10
4	+24		16	
5	+24	Z3D11	16	
6	+6	Z3D11		
7	Gnd	Z3 Bus	4	
8	Gnd	Z3 Bus	3	
9	-4		9	Wire No. 1
10	Gnd		2	Wire No. 2
11	-24	Z3D13	6	
12	Gnd	Z3 Bus		
13	-5	Z3D10	10	01H-C1-
14	+8.5	Z3D01	12	
15	M.C.Ret	Z3B02		01H-C1+
16	+Brk Flt	Z3D04		01H-K1-2
17	Gnd		2	01H-TB1-4
18	Gnd	Gnd Bus	3	
19	Gnd	Gnd Bus	3	
20	+5	+5 Bus	6	
21	+5	+5 Bus	6	
22	+5	+5 Bus	6	
23	+5	+5 Bus	6	
24	-4	C2B06		Wire No. 1
25	-4	A4B06		Wire No. 1
26	Gnd	Gnd Bus	2	
27	Gnd	Gnd Bus	2	
28	+24 Ctrl		16	01H-K1-1

C Cable PN 1741690

Wire No.	O1A-TB1	Resistor TB Assembly
1	+8.5	11
2	-5	9
3	Gnd	2

D Cable PN 4406667

Wire No.	O1A-TB1	Board Pwr Conn
1	Gnd	1
2	Gnd	1
3	Gnd	1
4	Gnd	2
5	Gnd	2
6	Gnd	2
7	+5	5
8	+5	5
9	+5	5
10	+5	7
11	+5	7
12	+5	7
13	-5	9
14	-5	9
15	-5	9
16	-5	9
17	-5	9
18	-5	9
19	+8.5	12
20	+8.5	12
21	+8.5	12
22	+8.5	12
23	+8.5	12
24	+8.5	12
25	-12	13
26	-12	13
27	+24	16
28	Gnd	3
29	Gnd	3
30	Gnd	3
31	Gnd	4
32	Gnd	4
33	Gnd	4
34	+5	5
35	+5	5
36	+5	5
37	+5	7
38	+5	7
39	+5	7
40	+8.5	11
41	+8.5	11
42	+8.5	11
43	+8.5	11
44	+8.5	11
45	+8.5	11
46	-12	13
47	-5	10
48	-5	10
49	-5	10
50	-5	10
51	-5	10
52	-5	10




C Cable PN 4406666

B. Cable Assemblies

Figure 3-13 (Part 2 of 2). Power Distribution, 3602-1A, 1B (TSR-3 Power Supply, only 2 wires on B1Y4)

Fig. 3-14

SY27-2519-0



Comm. Line Terminal Position	Wire Color	Controller Connector Position	Function
Red	Red	10	Transmit
Green	White	9	
Yellow	Yellow	25	Receive
Black	Black	14	
See sketch above	Shield	1	

Note: For Japanese connection, see Figure 3-16.

PN1563204, 4404219 or equivalent

Connector Position		Lead† Number
Modem End	Controller End	
2	2	1
3	3	2
4	4	3
5	5	4
6	6	5
7	7	6
8	8	7
11	11	8
12	12	9
15	15	10
16	16	11
17	17	12
18	18	13
19	19	14
20	20	15
21	21	16
22	22	17
23	23	18
24	24	19
*	*	20

† Leads through 19 are numbered and coded in accordance with EIA standards. Lead Number 20 is green.

*Lead Number 20 is tied back on cable body inside hood.


B. External Modem

PN 1620182 or equivalent

Wire No.	Male Pin No.	Color		Female Pin No.
		Body	Tracer	
1	24	Black		24
2	2	Brown		2
3	3	Red		3
4	4	Orange		4
5	5	Yellow		5
6	6	Pink		6
7	7	Blue		7
8	8	Violet		8
9	23	Gray		23
10	15	Black	Red	15
11	22	Black	Orange	22
12	17	Black	Yellow	17
13	20	Black	Gray	20
14		Black	Blue	
15		Black	Violet	

Controller Connector Position	Wire Color	Function
10	Red	Transmit
9	White	
25	Yellow	Receive
14	Black	
1	Shield	

C. Internal Modem, World Trade Except Japan (PN 1563243) or equivalent



EIA 25-Pin Receptacle



PN 4404219, 4404220, 4404221 or equivalent

Wire No.	Body Color	Conn Pos
1	Black	5 - 5
2	Brown	14 - 14
3	Red	6 - 6
4	Orange	18 - 18
5	Blue	23 - 23
6	Green	17 - 17
7	White	20 - 20
8	Black	8 - 8
9	Brown	3 - 3
10	Red	11 - 11
11	Orange	2 - 2
12	Blue	22 - 22
13	Green	4 - 4
14	White	15 - 15
Cond Shlds	Drain Wire	7 - 7
Outer Shld	Drain Wire	1 - -


A. Internal Modem, USA, Canada and Japan (PN 1563205) or equivalent

Figure 3-14. External Cables, Controller/Communication Link


Comm Line Terminal Position	Wire Color	Controller Connectors	Function
Red	Red	Plug	Transmit
Green	White		
Yellow	Yellow	Jack	Receive
Black	Black		
See sketch below	Shield	Plug and Jack	



Note: For Japanese connection, see Figure 3-16.




A. USA, Canada, and Japan (PN 1563206) or equivalent



B. World Trade Except Japan (PN 1563242) or equivalent

Figure 3-15. External Cables, Controller/Communication Line for a Remote Loop



Normal Operation: Plug the phone plug of cable 1563205 or 1563206 into the phone jack of cable 5182523.

Wrap Test: Disconnect the above-mentioned plug and jack, and connect plug assembly 1864271, 1864272, or jack assembly 1864671 into their respective counterparts. See the installation instruction for details of wrap test of NTT D1 Service Requirement.

Figure 3-16. Japanese Connection of External Cables to Communication Line (Loop or Host Link)




Figure 3-17. Adapter Cable PN 1741656





Figure 3-18. Japanese Wrap Test Cable PN 2722052

Fig. 3-18

3.9 COMMUNICATION CONNECTIONS

3.9.1 Selection of Controller/Communication Connections

From the following chart, select the controller you have by model and number of power supplies used; refer to the indicated paragraph number for the correct communication connections for your controller:

Controller Model and Number of Power Supplies Used	Communication Connections Paragraph Number
3601-2A, 2B, 3A, 3B (Single TSR-3 power supply)	3.9.2
3601-2A, 2B, 3A, 3B (One or two TSR-2 power supplies)	3.9.3
3601-C, D	3.9.4
3602-1A, 1B (TSR-3 power supply, more than 2 wires on B1Y4)	3.9.5
3602-1A, 1B (TSR-3 power supply, only 2 wires on B1Y4)	3.9.6

3.9.2 Communication Connections, 3601-2A, 2B, 3A, 3B (Single TSR-3 Power Supply)

NOTES

- 1** If B/M 4941040 or 4941110 is used with B/M 4941942, 4941043, 4941044, or 4941045, then wirewrap PN 811425 from A1C2S13 to A1C2U08.
- 2** If B/M 4941016 or 4941018 is used with B/M 4941112, 4941113, 4941114, or 4941115, then wirewrap PN 811425 from A2K2S13 to A2K2U08.
- 3** If B/M 4941042 or 4941043 is to be installed, then wirewrap PN 811425.

From	To
A1B2B03	A1B5B09
A1B2B02	A1B5D11
A1B4B09	A1B4D04
A1B3B10	A1B3D12
A1B3B08	A1B3B09
A1B3B05	A1B3B07
A1A2B09	A1A2B13
A1A2B04	A1A2D11

Also wire-twisted pair PN 5347623.

From	To
A1B2B02 (YEL)	A1B1B11 (YEL)
A1A2D09 (BK)	A1B1C13 (BK)

4 If B/M 4941044 or 4941045 is to be installed, then wirewrap PN 8111425.

From	To
A1B4B09	A1B4D07
A1B3B10	A1B3B12
A1B5B08	A1B5B10
A1B3B05	A1B3B07
A1A2B09	A1A2B13
A1A2B04	A1A2D11

Also wire-twisted pair PN 5347623.

From	To
A1B2B02 (YEL)	A1B1B11 (YEL)
A1A2D09 (BK)	A1B1C13 (BK)
and	
A1B5B09 (YEL)	A1C1E11 (YEL)
A1B5D11 (BK)	A1A1D11 (BK)

***5** If B/M 4941046 is to be installed, then wirewrap PN 811425.

From	To
A1C5D12	A1A2B13
A1C5B03	A1A2D10
A1C5D09	A1A2B05
A1C5B02	A1A2D05
A1C5D04	A1A2D09
A1C5B04	A1A2D07
A1C5D11	A1A2B04

6 If B/M 4941112 or 4941113 is to be installed, then wirewrap PN 811425.

From	To
A2N4D05	A2N3B09
A2N4B02	A2N3D11
A2N2B09	A2N2D04
A2N5B10	A2N5D12
A2N5B08	A2N5B09
A2N5B05	A2N5B07

Also wire-twisted pair PN 5347623.

From	To
A2N4B02 (YEL)	A2F6C04 (YEL)
A2N4D05 (BK)	A2F6B02 (BK)

7 If B/M 4941114 or 4941115 is to be installed, then wirewrap PN 811425.

From	To
A2N2B09	A2N2D07
A2N5B10	A2N5B12
A2N3B08	A2N3B10
A2N5B05	A2N5B07
A2N3B02	A2P5B10
A2N3B05	A2P5D05

Also wire-twisted pair PN 5347623.

From	To
A2N4B02 (YEL)	A2F6C04 (YEL)
A2N4D05 (BK)	A2F6B02 (BK)
and	
A2N3B09 (YEL)	A2D6E04 (YEL)
A2N3D11 (BK)	A2G6A04 (BK)

8 If B/M 1864633 (Japan only) is requested, then this B/M must be included in addition to USA B/M 4941042, 4941044, 4941112, or 4941114.

9 If B/M 1739375 (PTT wrap – Japan only) is requested, then this B/M must be included in addition to B/M 4941046 or 4941116.

10 If B/M 1739373 (German only) is requested, then this B/M must be included in addition to B/M 4941046 or 4941116.

11 If B/M 4941040, 4941041 or 4403161 is installed, then wirewrap PN 811425.

From	To
A1G5B10	A1F6B02
A1C3D06	A1C3B05
A1C2B07	A1G3D04
A1C3D07	A1G3D07

12 If B/M 4941110 or 4941111 is installed, then wirewrap PN 811425.

From	To
A1G5B10	A1C4D05
A1C4D04	A1F6B02
A1C3B05	A1C3D07
A1C3D06	A1G3D04
A1C2B07	A1G3D07
A1C4B13	A1G4B05
A1C4D11	A1G5D13

13 If B/M 4941110 is installed, then wirewrap PN 811425.

From	To
A1C5D06	A1C5D11
A1C4D12	A1C5D10

14 If B/M 4941016 or 4941017 is installed, then delete by reaming.

Test for no continuity between reamed pin and respective pins

Delete by reaming	below
A2K2B03 (Card Side)	A2K2D08
A2K3B07 (Card Side)	A2M3D06
	A2J3D06
A2K2B12 (Pin Side)	A2K2B10
A2K3D09 (Pin Side)	A2K3D08

Also wirewrap PN 811425.

From	To
A2M3D06	A2J3D06
A2K3B07	A2K3B05
A2K3D06	A2J3B12
A2K2B07	A2J3D06
A2K3D07	A2J3B05
A2K2B12	A2K2D12

15 If B/M 4941116 is installed, then wirewrap PN 811425.

From	To
A2L5B10	A2E6A02

16 If the line discipline is to be in asynchronous mode (i.e., start-stop line control), then wirewrap (PN 811425) between the following location:

From	To
A2K4B13	A2K4D08

17 If B/M 4941110 is used with B/M 4941046, then wirewrap PN 811425.

From	To
A1A3D09	A1A3D08
A1A3D04	A1A3D08

18 If B/M 4403163 is installed, then wirewrap PN 811425.

From	To
A2L4G05	A2L4N08
A2L4J09	A2D4N08
A2L4J04	A2M4N08
A2L4J13	A2M4N08
A2L4G04	A2L4D08
A2L4G03	A2L4D08



3.9.2 Communication Connections (Cont)

B/M No.	Adapter Card Location	Adapter Speed	Speed Select Wirewrap PN 811425 From Pin A1C2 P08	Data Set Ready	Line Adapter B/M No.	EIA	Receive	Transmit	Wrap
4941040 CCA W/Cik Note 11	A1C2	300 600 1200 2400	G13 M04 M05 M03	Note 1	Notes 8 9 10 4941046-EIA Note 5 4941042-2W-USA Note 3 4941043-2W-WTC Note 3 4941044-4W-USA Note 4 4941045-4W-WTC Note 4	A1A2	A1B4	A1B2	A1A2
4941041 CCA W/O Cik Note 11	A1C2				4941046-EIA Note 5	A1A2			
4941110 HPCA W/Cik Note 12 13	A1C2	600 1200 2400	M04 M05 M03	Note 1	4941046-EIA Note 5 17 4941042-2W-USA Note 3 4941043-2W-WTC Note 3 4941044-4W-USA Note 4 4941045-4W-WTC Note 4	A1A2	A1B4	A1B2	A1A2
4941111 HPCA W/O Cik Note 12	A1C2				4941046-EIA Note 5	A1A2			
4941016 ALA CCA W/Cik Note 14	A2K2	300 600 1200 2400	G13 M04 M05 M03	Note 2	4403163-Local attach Note 18 4941116-EIA Note 15 4941112-2W-USA Note 6 4941113-2W-WTC Note 6 4941114-4W-USA Note 7 4941115-4W-WTC Note 7	A2L4	A2N2	A2N4	A2P5
4941017 ALA CCA W/O Cik Note 14	A2K2				4941116-EIA Note 15	A2L4			
4403161 No Host RPQ S25142 Note 11	None				None				

3.9.3 Communication Connections 3601-2A, 2B, 3A, 3B (One or Two TSR-2 Power Supplies)

	FFBM No.	Notes	Card Location 01A-	Line Adapter FFBM No.	Adapter Card Location 01A-	Optional Switch Settings. Following Switches "ON", All Others "OFF"	Notes			
HdSt Link (15)	4946042 No Host Line	1 4	N/A	N/A	N/A					
	4946045 CCA W/Clock	1 4 5	AIC2	4406036 - UCM2WUSA 4406037 - UCM2WWTC 4406038 - UCM4WUSA 4406039 - UCM4WWTC	AIA2	J, N, L M, J, L, A K, P I, K, A	2 2 3 3			
	4946046 CCA W/O Clock	1 4		4406043 - EIA/CCITT		Remove all Jumpers from card. See B				
	4946041 HPCA W/O Clock	6					8			
	4946040 HPCA W/Clock	6 7		4406036 - UCM2WUSA 4406037 - UCM2WWTC 4406038 - UCM4WUSA 4406039 - UCM4WWTC		J, N, L M, J, L, A K, P I, K, A	2 2 3 3			
	ALA Port 1 (80)	4409500 ASYN CCA W/Clock		9 10		AIB2	4409476 - UCM2WUSA 4409492 - UCM2WWTC 4409484 - UCM2WJAP 4409480 - UCM4WUSA 4409496 - UCM4WWTC 4409488 - UCM4WJAP 4409512 - EIA/CCITT	AIA4	J, N, L M, J, L, A M, J, L, A K, P I, K, A I, K, A	See A
4409504 SYNC CCA W/O Clock				4409508 - EIA/CCITT EMI			Remove all Jumpers from card. See B			
4409472 SYNC CCA W/Clock		10	4409512 - EIA/CCITT 4409476 - UCM2WUSA 4409492 - UCM2WWTC 4409484 - UCM2WJAP 4409480 - UCM4WUSA 4409496 - UCM4WWTC 4409488 - UCM4WJAP	J, N, L M, J, L, A M, J, L, A K, P I, K, A I, K, A	See A					
ALA Port 2 (81)		4409501 ASYN CCA W/Clock	9 10	A2N2	4409477 - UCM2WUSA 4409493 - UCM2WWTC 4409485 - UCM2WJAP 4409481 - UCM4WUSA 4409497 - UCM4WWTC 4409489 - UCM4WJAP 4409513 - EIA/CCITT		A2E2		J, N, L M, J, L, A M, J, L, A K, P I, K, A I, K, A	See A
		4409505 SYNC CCA W/O Clock			4409509 - EIA/CCITT EMI				Remove all Jumpers from card. See B	
		4409473 SYNC CCA W/Clock	10		4409513 - EIA/CCITT 4409477 - UCM2WUSA 4409493 - UCM2WWTC 4409485 - UCM2WJAP 4409481 - UCM4WUSA 4409497 - UCM4WWTC 4409489 - UCM4WJAP				J, N, L M, J, L, A M, J, L, A K, P I, K, A I, K, A	See A

	FFBM No.	Notes	Card Location 01A-	Line Adapter FFBM No.	Adapter Card Location 01A-	Optional Switch Settings. Following Switches "ON", All Others "OFF"	Notes			
ALA Port 3 (82)	4409502 ASYN CCA W/Clock	9 10	A2P2	4409478 - UCM2WUSA 4409494 - UCM2WWTC 4409486 - UCM2WJAP 4409482 - UCM4WUSA 4409498 - UCM4WWTC 4409490 - UCM4WJAP 4409514 - EIA/CCITT	A2T2	J, N, L M, J, L, A M, J, L, A K, P I, K, A I, K, A	See A			
	4409506 SYNC CCA W/O Clock			4409510 - EIA/CCITT EMI		Remove all Jumpers from card. See B				
	4409474 SYNC CCA W/Clock	10		4409514 - EIA/CCITT 4409478 - UCM2WUSA 4409494 - UCM2WWTC 4409486 - UCM2WJAP 4409482 - UCM4WUSA 4409498 - UCM4WWTC 4409490 - UCM4WJAP		J, N, L M, J, L, A M, J, L, A K, P I, K, A I, K, A	See A			
	ALA Port 4 (83)	4409503 ASYN CCA W/Clock		9 10		A2Q2	4409479 - UCM2WUSA 4409495 - UCM2WWTC 4409487 - UCM2WJAP 4409483 - UCM4WUSA 4409499 - UCM4WWTC 4409491 - UCM4WJAP 4409515 - EIA/CCITT	A2T4	J, N, L M, J, L, A M, J, L, A K, P I, K, A I, K, A	See A
		4409507 SYNC CCA W/O Clock					4409511 - EIA/CCITT EMI		Remove all Jumpers from card. See B	
		4409475 SYNC CCA W/Clock		10			4409515 - EIA/CCITT 4409479 - UCM2WUSA 4409495 - UCM2WWTC 4409487 - UCM2WJAP 4409483 - UCM4WUSA 4409499 - UCM4WWTC 4409511 - UCM4WJAP		J, N, L M, J, L, A M, J, L, A K, P I, K, A I, K, A	See A



3.9.3 Communication Connections (Cont)

B/M No.	Loop Adapter NO.	Loop Adapter Card Location	Loop Speed	Speed Select. Install Jumper PN 5492084 From Pin S10 To	Remote Only. Install Jumper PN 5492081 From Pin U08 To	Local Loop Cable PN 4943640	Integrated Modem USA and Canada B/M No.	Integrated Modem WTC B/M No.	Undercover Modem Card Location	Remote Loop Cable PN 4406670
		15	11		12	12 18	13 16	13 14 17		
4946036 19	1	A1D2	600 1200 2400 4800	J11 J07 J10 J09	Local Only	A1Y3 Local Only To J2-J3				
4946051	2	A1E2	600 1200 2400 4800	J11 J07 J10 J09	U07	A1Y3 To J4-J5	4946061	4946071	1A-A2B2	A2B3 To J4-J5
4946052	3	A1F2	600 1200 2400 4800	J11 J07 J10 J09	U07	A1Y3 To J6-J7	4946062	4946062	1A-A2C3	A2C3 To J6-J7
4946053	4	A2G2	600 1200 2400 4800	J11 J07 J10 J09	U07	A2Z1 To J8-J9	4946063	4946063	1A-A2B4	A2B5 To J8-J9
4946054	5	A2H2	600 1200 2400 4800	J11 J07 J10 J09	U07	A2Z1 To J10-J11	4946064	4946074	1A-A2C4	A2C5 To J10-J11
4946055	6	A2J2	600 1200 2400 4800	J11 J07 J10 J09	U07	A2Z1 To J12-J13	4946065	4946075	1A-A2D4	A2D5 To J12-J13

Notes:

- 1 If B/M 4946042, 4946045 or 4946046 is to be installed, then wire-wrap PN 811425
From O1A-A1G2S10 To O1A-A1F6B02
- 2 If B/M 4406036 or 4406037 is to be installed, then wire-wrap PN 811425
From O1A-A1A2G09 To O1A-A1A2G02
O1A-A1A2J13 O1A-A1A2J05
Also wire-wrap twisted pair PN 5347623
From O1A-A1B1B11 (YEL) To O1A-A1A2J13
O1A-A1B1C13 (BK) O1A-A-1A2G09
- 3 If B/M 4406038 or 4406039 is to be installed, then wire-wrap twisted pair PN 5347623
From O1A-A1B1B11 (YEL) To O1A-A1A2G02
O1A-A1B1C13 (BK) O1A-A1A2J05
O1A-A1C1E11 (BK) O1A-A1A2J13
O1A-A1A1D11 (YEL) O1A-A1A2G09
- 4 If B/M 4946042, 4946045, or 4946046 is to be installed, then wire-wrap PN 811425
From O1A-A1C2J06 To O1A-A1C2G05
O1A-A1C2B07 O1A-A1D2G12
O1A-A1C2J07 O1A-A1D2G05
- 5 If B/M 4946045 is to be installed, then wire-wrap PN 811425
From O1A-A1C2M05 To O1A-A1C2P08
- 6 If B/M 4946040 or 4946041 is to be installed, then wire-wrap PN 811425
From O1A-A1C2J07 To O1A-A1C2G05
O1A-A1C2B07 O1A-A1D2G05
O1A-A1C2J06 O1A-A1D2G12
O1A-A1C2M13 O1A-A1G2M05
O1A-A1C2P11 O1A-A1G2U13
O1A-A1C2P05 O1A-A1G2S10
O1A-A1C2P04 O1A-A1F6B02
- 7 If B/M 4946040 is to be installed, then wire-wrap PN 811425
From O1A-A1C2M05 To O1A-A1C2P08
O1A-A1C2U11 O1A-A1C2U06
O1A-A1C2U10 O1A-A1C2P12

- 8 If B/M 4946040 and 4406043 are to be installed, then wire-wrap PN 811425
From O1A-A1A2J04 To O1A-A1A2J08
O1A-A1A2J10 O1A-A1A2J08
- 9 If B/M 4409500, 4409501, 4409502, or 4409503 is to be installed, then wire-wrap PN 811425
From card loc pin M13 To card loc pin P08
- 10 If B/M 4409472, 4409473, 4409474, 4409475, 4409500, 4409501, 4409502, or 4409503 is to be installed, then wire-wrap PN 811425
From card loc pin M05 To card loc pin P08
- 11 Local loops will be assigned beginning at position 1. Speeds will be assigned in descending order (position 1 will have the highest speed).
- 12 Remote loops will be assigned beginning at position immediately following the last local loop position.
- 13 Undercover modems applicable to Models 03A or 03B only.
- 14 If B/M 1864633 (Japan only) is requested, then this B/M must be included in addition to USA B/Ms.
- 15 Loop adapters 1, 2, 3 are applicable to Models 02A, 02B, 03A, 03B. Loop adapters 4, 5, 6 and applicable to Models 03A, 03B only.
- 16 Set rocker switches K and P "ON". All other switches should be "OFF". See (A).
- 17 Set rocker switches I, A and K "ON". All other switches should be "OFF". See (A).
- 18 If integrated modem (remote loop) is also being installed, do not install local loop cable.
- 19 Wire wrap PN 811425
From A1E5B12 To A1L6E04
A1F5B12 To A1M6C04

3.9.4 Communication Connections, 3601 C,D

FFBM No.	Card Location OIA	Adapter Speed BPS	Speed Select Wire Wrap #811425 From Pin P08 To	Line Adapter FFBM No.	Line Adapter Card Location OIA	Strapping Options Set the Following Rocker Switches ON. All Others Should Be OFF. See A	Notes
4406041 CCA W/CLK Note 3	A1B2	1200	M05	4406043-EIA/CCITT	A1A2	Remove all jumpers from card. See B	
				4406036-UCM2WUSA		J, N, L	1
				4406037-UCM 2WWTC		M, J, L, A	1
		4406038-UCM 4WUSA	K, P	2			
		4406039-UCM 4WWTC	I, K, A	2			
4406042 CCA W/O CLK Note 3	A1B2			4406043-EIA/CCITT	A1A2	Remove all jumpers from card. See B	

Notes:



- 1 If B/M 4406037 or 4406036 is to be installed, then wire-wrap PN 811425
From 01A-A1A2G09 To 01A-A1A2G02
01A-A1A2J13 01A-A1A2J05
Also wire-wrap twisted pair PN 5347623
From 01A-A1B1B11(YEL) To 01A-A1A2J13
01A-A1B1C13(BLK) 01A-A1A2G09
- 2 If B/M 4406038 or 4406039 is to be installed, then wire-wrap twisted pair PN 5347623
From 01A-A1B1B11(YEL) To 01A-A1A2G02
01A-A1B1C13(BLK) 01A-A1A2J05
And
01A-A1C1E11(BLK) 01A-A1A2J13
01A-A1A1D11(YEL) 01A-A1A2G09
- 3 If B/M 4406041 or 4406042 is to be installed, then wire-wrap PN 811425
From 01A-A1A5D07 To 01A-A1H5D05

Switch Description

	U.S. Card	W.T. Card
2-Wire	J on, K off	M on, I off.
	Must use board/panel cable PN4406671	
4-Wire	K on, J off	I on, M off
	Must use board/panel cable PN4406672	
Echo Clamp	50-ms delay, L, on 150-ms delay, L off	50-ms delay, L on 150-ms delay, L off
Clear to Send	30-ms delay, P on, N off 80-ms delay, N on, P off 230-ms delay, N off, P off	30-ms delay, K on, J off 80-ms delay, J on, K off 230-ms delay, J off, K off
Equalizer *	W.T. Only	Normal delay, CC on High-Frequency delay, AA on Mid-Frequency delay, DD on Low-Frequency delay, BB on

*To be used by TP specialist only. Requires line distortion information. For transmit level, see 1.123.

Loop Adapter Card Location OIA	Loop Speed	Speed Select Install Jumper P/N 5492084 From Pin S10 To	Plug Loop Cable From
A1D2	600	J11	01A-A1Y2 TO 01S-J2 & J3
	1200	J07	
	2400	J10	
	4800	J09	
A1C2	600	J11	01A-A1Y2 TO 01S-J4 & J5
	1200	J07	
	2400	J10	
	4800	J09	



Blank Page

**3.9.5 Communication Connections
3602-1A, 1B (TSR-3 Power Supply,
More Than 2 Wires on B1Y4)**

NOTES

- 1 If B/M 1652526 or 4941142 is used with B/M 1745441, 1745442, 1745443 or 1745444 then wire wrap PN 811425 from B1C2S13 to B1C2U08.
- 2 If B/M 4944360 is used with B/M 4941145, 4941146, 4941147 or 4941148 then wire wrap PN 811425 from A2K2S13 to A2K2U08.
- 3 If B/M 1864633 (Japan only) is requested, then this B/M must be included in addition to B/M 1745441, 1745442, 4941146 or 4941145.
- 4 If B/M 1745442 or 1745444 is to be installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
B1 B2B03	B1 B5B09
B1 B2B02	B1 B5D11
B1 B4B09	B1 B4D04
B1 B3B10	B1 B3D12
B1 B3B08	B1 B3B09
B1 B3B05	B1 B3B07
B1 A2B09	B1 A2B13
B1 A2B04	B1 A2D11

Also wire-twisted pair PN 5347623.

<u>From</u>	<u>To</u>
B1 B2B02	B1 B1B11 (YEL)
B1 A2D09	B1 B1C13 (BK)

- 5 If B/M 1745441 or 1745443 is to be installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
B1 B4B09	B1 B4D07
B1 B3B10	B1 B3B12
B1 B5B08	B1 B5B10
B1 B3B05	B1 B3B07
B1 A2B09	B1 A2B13
B1 A2B04	B1 A2D11

Also wire-twisted pair PN 5347623.

<u>From</u>	<u>To</u>
B1 B2B02	B1 B1B11 (YEL)
B1 A2D09	B1 B1C13 (BK)

and

B1 B5B09	B1 C1E11 (YEL)
B1 B5D11	B1 A1D11 (BK)

- 6 If B/M 1652528 is to be installed, then wire wrap PN 811425

<u>From</u>	<u>To</u>
B1 C5D12	B1 A2B13
B1 C5B03	B1 A2D10
B1 C5D09	B1 A2B05
B1 C5B02	B1 A2D05
B1 C5D04	B1 A2D09
B1 C5B04	B1 A2D07
B1 C5D11	B1 A2B04

- 7 If B/M 4941146 or 4941148 is to be installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
A2 N4D05	A2 N3B09
A2 N4B02	A2 N3D11
A2 N2B09	A2 N2D04
A2 N5B10	A2 N5D12
A2 N5B08	A2 N5B09
A2 N5B05	A2 N5B07

Also wire-twisted pair PN 5347623.

<u>From</u>	<u>To</u>
A2 N4B02	A2 F6C04 (YEL)
A2 N4D05	A2 F6B02 (BK)

- 8 If B/M 4941145 or 4941147 is to be installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
A2 N2B09	A2 N2D07
A2 N5B10	A2 N5B12
A2 N3B08	A2 N3B10
A2 N5B05	A2 N5B07
A2 N3B02	A2 P5B10
A2 N3B05	A2 P5D05

Also wire-twisted pair PN 5347623.

<u>From</u>	<u>To</u>
A2 N4B02	A2 F6C04 (YEL)
A2 N4D05	A2 F6B02 (BK)

and

A2 N3B09	A2 D6E04 (YEL)
A2 N3D11	A2 G6A04 (BK)

- 9 If B/M 1652526, 1652527, or 4944362 is to be installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
B1 G5B10	B1 F6B02
B1 C3D06	B1 C3B05
B1 C2B07	B1 G3D04
B1 C3D07	B1 G3D07

- 10 If B/M 4941142 or 4941143 is to be installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
B1 G5B10	B1 C4D05
B1 C4D04	B1 F6B02
B1 C3B05	B1 C3D07
B1 C3D06	B1 G3D04
B1 C2B07	B1 G3D07
B1 C4B13	B1 G4B05
B1 C4D11	B1 G5D13

- 11 If B/M 4941142 is to be installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
B1 C5D06	B1 C5D11
B1 C4D12	B1 C5D10

- 12 If B/M 4944360 or 4944361 is to be installed, then delete by reaming the following:

<u>Delete</u>	<u>Test for No Continuity</u>
A2K2B03 (cardside)	A2K2D08
A2K2B07 (cardside)	A2M3D06
	A2J3D06
A2K2B12 (pinside)	A2K2B10
A2K3D09 (pinside)	A2K3D08

Also wire wrap PN 811425.

<u>From</u>	<u>To</u>
A2M3D06	A2J3D06
A2K3B07	A2K3B05
A2K3D06	A2J3B12
A2K2B07	A2J3D06
A2K3D07	A2J3B05
A2K2B12	A2K2D12

- 13 If B/M 1739375 (PTT wrap-Japan only) is requested, then this B/M must be included in addition to B/M 1652528 or 4941144.

- 14 If B/M 1739373 (Germany only) is requested, then this B/M must be included in addition to B/M 1652528 or 4941144.

- 15 If B/M 4941144 is installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
A2L5B10	A2E6A02

- 16 If the line discipline is to be in an asynchronous mode (i.e., start-stop line control), then wire wrap PN 811425.

<u>From</u>	<u>To</u>
A4K4B13	A2K4D08

- 17 If B/M 4941142 is used with B/M 1652528, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
B1 A3D09	B1 A3D08
B1 A3D04	B1 A3D08

- 18 If B/M 4403178 is installed, then wire wrap PN 811425.

<u>From</u>	<u>To</u>
A2 L4G05	A2 L4J08
A2 L4J09	A2 L4J08
A2 L4J04	A2 M4J08
A2 L4J13	A2 M4J08
A2 L4G04	A2 L4D08
A2 L4G03	A2 L4D08

3.9.5 Communication Connections (Cont)



B/M No.	Communication Adapter Card Location	Adapter Speed	Speed Select Wirewrap PN 811425 From Pin B1C2 P08	Data Set Ready	Line Adapter B/M No.	Line Adapter Card Location			
B/M No.		BPS	TO		Notes 3 13 14	EIA	Receive	Transmit	Wrap
1652526 CCA W/Cik	B1C2 Note 9	300	G13		EIA 1652528 Note 6	B1A2			
		600 1200 2400	M04 M05 M03						
		1200	M05	Note 1	M-12 1745442 2-Wire, Note 4 M-12 1745444 2-Wire, Note 4 M-12 1745441 2-Wire, Note 5 M-12 1745443 2-Wire, Note 5		B1B4	B1B2	B1A2
1652527 CCA W/O Cik	B1C2 Note 9				EIA 1652528 Note 6 17	B1A2			
4941142 HPCA W/Cik	B1C2 Note 10 Note 11	600	M04		EIA 1652528 Note 6 17	B1A2			
		1200	M05	Note 1	M-12 1745442 2-Wire, Note 4 M-12 1745444 2-Wire, Note 4 M-12 1745441 4-Wire, Note 5 M-12 1745443 4-Wire, Note 5		B1B4	B1B2	B1A2
4941143 HPCA W/O Cik	B1C2 Note 10				EIA 1652528 Note 6	B1A2			
4944360 ALA CCA W/Cik ALA	A2K2 Note 12 16	300	G13		EIA 4941144 Note 15 Local 4403178 Note 15 18	A2L4			
		600 1200 2400	M04 M05 M03						
		1200	M05	Note 2	M-12 4941146 2-Wire, Note 7 M-12 4941148 2-Wire, Note 7 M-12 4941145 4-Wire, Note 8 M-12 4941147 4-Wire, Note 8		A2N2	A2N4	A2P5
4944361 ALA CCA W/O Cik	A2K2 Note 12				EIA 4941144 Note 15	A2L4			
4944362 RPQ S25142	Note 9				None				

3.9.6 Communication Connections 3602-1A, 1B (TSR-3 Power Supply; Only 2 Wires on B1Y4)

FFBM No.	Notes	Card Location O1A-	Line Adapter FFBM No.	Adapter Card Location O1A-	Optional Switch Settings. Following Switches "ON", All Others "OFF"		Notes
4946124 No Host Line	1 4	N/A	N/A	N/A			
4946120 CCA W/Clock	1 4 5	AIC2	4946126 - UCM2WUSA	AIA2	J, N, L	See A	2
			4946127 - UCM2WWTC		M, J, L, A		2
			4946128 - UCM4WUSA		K, P		3
			4946129 - UCM4WWTC		I, K, A		3
4946121 CCA W/O Clock	1 4	AIC2	4946125 - EIA/CCITT	AIA2	Remove all Jumpers from card.		
4946123 HPCA W/O Clock	6		See B		8		
4946122 HPCA W/Clock	6 7	AIC2	4946126 - UCM2WUSA	AIA2	J, N, L	See A	2
			4946127 - UCM2WWTC		M, J, L, A		2
			4946128 - UCM4WUSA		K, P		3
			4946129 - UCM4WWTC		I, K, A		3
6814500 ASYN CCA W/Clock	9 10	AIB2	6814520 - UCM2WUSA	AIA4	J, N, L	See A	
			6814536 - UCM2WWTC		M, J, L, A		
			6814528 - UCM2WJAP		M, J, L, A		
			6814524 - UCM4WUSA		K, P		
			6814540 - UCM4WWTC		I, K, A		
			6814532 - UCM4WJAP		I, K, A		
6814516 - EIA/CCITT	Remove all Jumpers from card.						
6814512 - EIA/CCITT EMI	See B						
6814504 SYNC CCA W/Clock	10	AIB2	6814516 - EIA/CCITT	AIA4	J, N, L	See A	
			6814520 - UCM2WUSA		M, J, L, A		
			6814536 - UCM2WWTC		M, J, L, A		
			6814528 - UCM2WJAP		K, P		
			6814524 - UCM4WUSA		I, K, A		
			6814540 - UCM4WWTC		I, K, A		
6814501 ASYN CCA W/Clock	9 10	A2N2	6814521 - UCM2WUSA	A2E2	J, N, L	See A	
			6814537 - UCM2WWTC		M, J, L, A		
			6814529 - UCM2WJAP		M, J, L, A		
			6814525 - UCM4WUSA		K, P		
			6814541 - UCM4WWTC		I, K, A		
			6814533 - UCM4WJAP		I, K, A		
6814517 - EIA/CCITT	Remove all Jumpers from card.						
6814513 - EIA/CCITT EMI	See B						
6814505 SYNC CCA W/Clock	10	A2N2	6814517 - EIA/CCITT	A2E2	J, N, L	See A	
			6814521 - UCM2WUSA		M, J, L, A		
			6814537 - UCM2WWTC		M, J, L, A		
			6814529 - UCM2WJAP		K, P		
			6814525 - UCM4WUSA		I, K, A		
			6814541 - UCM4WWTC		I, K, A		

FFBM No.	Notes	Card Location O1A-	Line Adapter FFBM No.	Adapter Card Location O1A-	Optional Switch Settings. Following Switches "ON", All Others "OFF"		Notes
6814502 ASYN CCA W/Clock	9 10	A2P2	6814522 - UCM2WUSA	A2T2	J, N, L	See A	
			6814538 - UCM2WWTC		M, J, L, A		
			6814530 - UCM2WJAP		M, J, L, A		
			6814526 - UCM4WUSA		K, P		
			6814542 - UCM4WWTC		I, K, A		
			6814534 - UCM4WJAP		I, K, A		
6814518 - EIA/CCITT	Remove all Jumpers from card.						
6814514 - EIA/CCITT EMI	See B						
6814506 SYNC CCA W/Clock	10	A2P2	6814518 - EIA/CCITT	A2T2	J, N, L	See A	
			6814522 - UCM2WUSA		M, J, L, A		
			6814538 - UCM2WWTC		M, J, L, A		
			6814530 - UCM2WJAP		K, P		
			6814526 - UCM4WUSA		I, K, A		
			6814542 - UCM4WWTC		I, K, A		
6814503 ASYN CCA W/Clock	9 10	A2Q2	6814523 - UCM2WUSA	A2T4	J, N, L	See A	
			6814539 - UCM2WWTC		M, J, L, A		
			6814531 - UCM2WJAP		M, J, L, A		
			6814527 - UCM4WUSA		K, P		
			6814543 - UCM4WWTC		I, K, A		
			6814535 - UCM4WJAP		I, K, A		
6814519 - EIA/CCITT	Remove all Jumpers from card.						
6814515 - EIA/CCITT EMI	See B						
6814507 SYNC CCA W/Clock	10	A2Q2	6814519 - EIA/CCITT	A2T4	J, N, L	See A	
			6814523 - UCM2WUSA		M, J, L, A		
			6814539 - UCM2WWTC		M, J, L, A		
			6814531 - UCM2WJAP		K, P		
			6814527 - UCM4WUSA		I, K, A		
			6814543 - UCM4WWTC		I, K, A		

- Notes:
- If B/M 4946120, 4946121 or 4946124 is to be installed, then wire-wrap PN 811425
From O1A-B1G2S10 To O1A-B1F6B02
 - If B/M 4406126 or 4406127 is to be installed, then wire-wrap PN 811425
From O1A-B1A2G09 To O1A-B1A2G02
O1A-B1A2J13 O1A-B1A2J05
Also wire-wrap twisted pair PN 5347623
From O1A-B1B1B11 (YEL) To O1A-B1A2J13
O1A-B1B1C13 (BK) O1A-B1A2G09
 - If B/M 4406128 or 4406129 is to be installed, then wire-wrap twisted pair PN 5347623
From O1A-B1B1B11 (YEL) To O1A-B1A2J13
O1A-B1B1C13 (BK) O1A-B1A2G09
O1A-B1C1E11 (BN) O1A-B1A2G02
O1A-B1A1D11 (YEL) O1A-B1A2J05
 - If B/M 4946120, 4946121, or 4946124 is to be installed, then wire-wrap PN 811425
From O1A-B1C2J06 To O1A-B1C2G05
O1A-B1C2B07 O1A-B1D2G12
O1A-B1C2J07 O1A-B1D2G05
 - If B/M 4946120 is to be installed, then wire-wrap PN 811425
From O1A-B1C2M05 To O1A-B1C2P08
 - If B/M 4946122 or 4946123 is to be installed, then wire-wrap PN 811425
From O1A-B1C2J07 To O1A-B1C2G05
O1A-B1C2B07 O1A-B1D2G05
O1A-B1C2J06 O1A-B1D2G12
O1A-B1C2M13 O1A-B1G2M05
O1A-B1C2P11 O1A-B1G2U13
O1A-B1C2P05 O1A-B1G2S10
O1A-B1C2P04 O1A-B1F6B02
 - If B/M 4946122 is to be installed, then wire-wrap PN 811425
From O1A-B1C2M05 To O1A-B1C2P08
O1A-B1C2U11 O1A-B1C2U06
O1A-B1C2U10 O1A-B1C2P12
 - If B/M 4946122 and 8 4406125 are to be installed, then wire-wrap PN 811425
From O1A-B1A2J04 To O1A-B1A2J08
O1A-B1A2J10 O1A-B1A2J08
 - If B/M 6814500, 6814501, 6814502, or 6814503 is to be installed, then wire-wrap PN 811425
From card loc pin M13 To card loc pin P08
 - If B/M 6814500, 6814501, 6814502, 6814503, 6814504, 6814505, 6814506, or 6814507 is to be installed, then wire-wrap PN 811425
From card loc pin M05 To card loc pin P08
 - Local loops will be assigned beginning at position 1. Speeds will be assigned in descending order (position 1 will have the highest speed).
 - Remote loops will be assigned beginning at position immediately following the last local loop position.
 - If B/M 1864633 (Japan only) is requested, then this B/M must be included in addition to USA B/Ms.
 - Set rocker switches K and P "ON". All other switches should be "OFF". See A.
 - Set rocker switches I, A and K "ON". All other switches should be "OFF". See A.
 - If integrated modem (remote loop) is also being installed, do not install local loop cable.
 - Wire wrap PN 811425
From B1E5B12 To B1L6E04
B1F5B12 B1M6C04



3.9.6 Communication Connections (Cont)

B/M No.	Loop Adapter No.	Loop Adapter Card Location	Loop Speed	Speed Select. Intall Jumper PN 5492084 From Pin S10 To	Remote Only. Install Jumper PN 5492081 From Pin U08 To	Local Loop Cable PN 1563675 Loops 1-3 PN 1741662 Loops 4-8	Integrated Modem USA and Canada B/M No.	Integrated Modem WTC B/M No.	Undercover Modem Card Location	Remote Loop Cable PN 4406670
			11		12	12 16	14	13 15		
4946110 17	1	B1D2	600 1200 2400 4800	J11 J07 J10 J09	Local Only	B1Y3 Local Only To J2-J3				
4946139	2	B1E2	600 1200 2400 4800	J11 J07 J10 J09	U07	B1Y3 To J4-J5	4946146	4946153	1A-A2B2	A2B3 To J4-J5
4946140	3	B1F2	600 1200 2400 4800	J11 J07 J10 J09	U07	B1Y3 To J6-J7	4946147	4946154	1A-A2C3	A2C3 To J6-J7
4946141	4	A2G2	600 1200 2400 4800	J11 J07 J10 J09	U07	A2Z1 To J8-J9	4946148	4946155	1A-A2B4	A2B5 To J8-J9
4946143	5	A2H2	600 1200 2400 4800	J11 J07 J10 J09	U07	A2Z1 To J10-J11	4946149	4946156	1A-A2C4	A2C5 To J10-J11
4946143	6	A2J2	600 1200 2400 4800	J11 J07 J10 J09	U07	A2Z1 To J12-J13	4946150	4946157	1A-A2D4	A2D5 To J12-J13
4946144	7	A2S2	600 1200 2400 4800	J11 J07 J10 J09	U07	A2Z6 To J14-J13	4946151	4946158	1A-A2U2	A2U3 To J14-J15
4946145	8	A2R2	600 1200 2400 4800	J11 J07 J10 J09	U07	A2Z6 To J16-J17	4946152	4946159	1A-A2U4	A2U3 To J16-J17

3.10 SUPPLY VOLTAGES ON LOGIC BOARDS AND CARDS

Note: Refer to Chapter 1 (right side) to determine the location of a specific card.

All card locations on both logic boards are supplied with +8.5V, +5V, -5V, and ground. These voltages are distributed by the internal voltage and ground planes in the board.

+8.5V	+5V*	-5V*	Ground
B11	D03	B06	D08
G11	J03	G06	J08
M11	P03	M06	P08
S11	U03	S06	U08

Special voltages (+12V, -12V and +24V) are supplied on the logic boards through surface busing and are distributed only to those card locations requiring them. The +5V is also wired to the modem cards. The following chart shows the pins to which these special voltages are distributed.

Card	+12V*	-12V*	+24V*	+5V*
1200-bps modem:				
Receive	B04,G04	D10,J10	--	B13
Transmit	B04,G04	D10,J10	--	B12
Wrap	B04	--	--	--
600-bps modem:				
Receive	B04,G04	D10,J10	--	B13
Transmit	B04,G04	D10,J10	--	B12
EIA	D11	J06	--	--
Diskette Adapter	--	--	B13	--
Diskette Drive Control (01X2W2)	--	--	D10	--
M/D RCVR XMIT	B04,G04 M04,J04	D10,J10 P10,U10	--	B12 M13
38LS EIA	--	D07	--	--
Remote Loop EIA		D07		

*Voltage limits

V dc	Limits
-5	-4.5 and -5.5
-12	-10.8 and -13.2
+5	+4.5 and +5.5
+8.5	+7.6 and +9.4
+12	+10.8 and +13.2
+24	+21.0 and +27.0

3.11 BACK PANEL CONNECTIONS

Note: Refer to Chapter 1 (right side) to determine the location of a specific card.

3.11.1 Loop Control Cards

Speed Selection

At each loop control card location, connect pin S10 to one of the following:

- 4800 bps = J09
- 2400 bps = J10
- 1200 bps = J07
- 600 bps = J11

Remote Loop Operation

If a loop is connected to a modem, connect pin U07 at the loop control card location to pin U08 (ground) at that card location.

3.11.2 Modem Compatibility (Internal Modem M-12)

In order for modems to communicate properly, the Clear to Send delay of the transmit location must be greater than the Echo Clamp at the receiver location. The following options are available to achieve this compatibility.

Clear to Send delay:

(Approximately)

- 25 ms M/D Xmit Card G10 to G12
- 90 ms M/D Xmit Card G10 to J12
- 250 ms M/D Xmit Card G10 to G13

Echo Clamp:

(Approximately)

- 0 ms M/D Xmit Card G07 to G05
- 60 ms M/D Xmit Card G08 to G09
G07 to G05
- 175 ms M/D Xmit Card G08 to G09
G07 to J05

See communications connections for 38LS M/D options.

3.11.3 External Modems

Modem	Internal Clock	Speed (bps)	Comments
3872	Yes	2400	Has a switched network feature
3874	Yes	4800	Has a switched network feature
3976-3	No	1200	World Trade only
3978-14	Yes	4800	World Trade only
4872	Yes	4800	US and Canada only
GH 2002-Q13	No	1200	Swedish modem
ZAT	Yes	2400	Swedish modem

Grounding of EIA Lines Not Used

When using the EIA card to drive external modems, all lines not used (both inputs and outputs) should be connected to ground at the EIA card location. The following chart shows lines that are not used for various external modems and which pin is to be grounded for these not-used lines.

8523023 Card Only

EIA Pin No.	EIA Line Name	Ground the following pins at the EIA card if not used
11	Select Standby *	G05
15	Transmit Signal Element Timing	J09
17	Receive Signal Element Timing	J04
18	Test	J13
20	Data Terminal Ready	G12
22	Ring Indicator *	G04
23	Data Signal Rate Selector	G03

*These lines are used only when the switched network feature is present.

3.11.4 Communications Link Connections

Standard EIA Pin	3601	Line Name	Modem
1	X	Protective Frame Gnd	X
2	X	Transmit Data	
3		Received Data	X
4	X	Request to Send	
5		Clear to Send	X
6		Data Set Ready	X
7	X	Signal Gnd	X
8		Received Carrier Det	X
9		*	X
10		*	X
11	X	Select Standby	
12		Sec Received Carrier Det	
13		Sec Clear to Send	
14	X	*	
15		Transmit Timing	X
16		Sec Received Data	
17		Receive Timing	X
18	X	Test	
19		Sec Request to Send	
20	X	Data Terminal Ready	
21		Signal Quality Det	
22		Ring Indicator	X
23	X	Data Signal Rate Sel	
24		Sec Transmit Timing	
25	X	*	

*These signals are used with integrated modems. All other signals are for external modems.

3.11.5 Storage Connections (Basic Controller Board)

Basic Storage

- L2M07 to M2G13
- L2B13 to M2G08

Expanded Storage

- L2M07 to V2M12
- L2B13 to V2P05

3.12 DISK STORAGE DIAGNOSTICS (3602 Only)

3.12.1 General Description

The disk storage tests are used with the MAPs for troubleshooting disk storage.

The tests verify all disk operations and force error conditions to check the error detection logic.

The tests are provided on the diagnostic diskette. After a test is run, status and error information is displayed on the keyboard/display.

The tests are divided into four major areas. They are:

1. Basic checkout
2. Diagnostic mode
3. Extended
4. Selectable

Basic Checkout (Routines 01,02,03, and 04)

These routines test the communications between the controller and the storage logic, and test for Disk Ready.

Diagnostic Mode (Routines 10,11,12,13,14, and 15)

These routines test and single-step various operations through the disk storage logic (Read, Write, Seek, and Test controls).

Extended (Routines 21,22,23,24,25,26,31,32,33,34,35,36, 41,42,43,44,45,46,47,48, and 49)

These routines test the ability of the entire disk storage logic and the Disk Enclosure (DE) to run in an operational mode.

Selectable (Routines 50,51,53,54,55,56, and 57)

These routines test for a certain status, do format tasks, or other special operations.

3.12.2 Operating Procedure

Results of this diagnostic are valid only if the complete procedure is followed from power on reset.

1. Power off all terminals other than the 3604 at address 1 on loop 1, to prevent interference.
2. Insert the diagnostic diskette, and activate the controller power-on or reset switch.
3. When the control program has been loaded, BC80 may display; respond with the model number of the 3604 that you are using, followed by enter (EM). BC80 should then display on this 3604.

4. Enter data LASLRR where:
 - LA = 10 (Logical Address)
 - S = Test Selection Option
 - 0 = Test disk storage logic (not DE)
 - 1 = Test disk storage and DE
 - 2 = Test disk storage and DE with manual intervention
 - L = Loop Option (Routines 3, 24 and 32 should not be looped. The Free key cannot stop them).
 - 0 = No looping
 - 1 = Loop; stop on error
 - 2 = Loop; do not stop on error
 - RR = Specific Routine to Run (otherwise, no entry is required)
5. Messages will be displayed defining machine status:
 - 1000 = Tests completed successfully.
 - 1080 = Temporarily unable to do input/output. This is normal for short periods of time during the tests. A stop (one minute or more) at this point indicates a controller problem; see MAP 2.
 - 10EE = Machine failure; see Error Codes (1.115).
 - 10F0 = Test running.
 - BCXX = Procedure error; see 3.12.4

Note: The diagnostic run can be ended at any time by pressing the FR (free) key on the 3604 (see Figure 3-2 for keyboard locations).

CAUTION: Do not use reset to end. This could terminate an incomplete write operation. Use the free key.

3.12.3 Test Routines

Routine 01 - Test Basic Operations

Routine 02 - Test Control Data

This routine reads Control Data, and tests for Machine Check and correct status.

Routine 03 - Disk Speed Test (Do not loop)

This routine reads the speed pulses from the speed transducer to verify that the disk speed is correct.

Routine 04 - Test for Disk Ready

Routine 10 - Read Diagnostic Step Mode

This routine steps through a Read Data operation and checks for proper completion.

Routine 11 - Checks the Ability to Detect a CRC Error

Routine 12 - Write in Diagnostic Mode

This routine steps through a Write Data operation and checks for proper completion.

Routine 13 - Seek in Diagnostic Mode

This routine steps through a Seek operation and checks for proper completion.

Routine 14 - Test Time Out Logic

Routine 15 - Interrupt Logic Test

Routine 21 - Recalibrate and Test for Correct Status

Routine 22 - Read Track ID Head 0

Routine 23 - Read Track ID Head 1

Routine 24 - Read Track ID 61 Times (Do not loop)

Routine 25 - Read IDs, Sectors 00-59 Track 0

Routine 26 - Read IDs, Sectors 00-59 Track 1

Routine 31 - Initial Seek Testing

Routine 32 - Initial Seek Testing and Verify Seeks (Do not loop)

Routine 33 - Seeks Behind Home

Routine 34 - Single Cylinder Seek

Routine 35 - Seek in 1, 7, and 11 Track Increments

Routine 36 - Seek in All Seek Increments

Routine 41 - Read IDs on CE Cylinder

Routine 42 - Write/ Read Sector ID on CE Cylinder

Routine 43 - Sector ID Flag Bit Test

Routine 44 - Read/Write Data Transfer Test

Routine 46 - Test Disk Diagnostic Operations

Routine 47 - Status Bit Test

Routine 48 - CE Track Sector ID Write and Compare Test

Routine 49 - Fixed-Head Read ID Test

This routine reads IDs on the fixed-head tracks.

The basic status is for the first fixed-head error encountered.

Count Field Bit	0123	4567	8 → 15
Fixed-Head Number	2345	6789	Not Used

Routine 50 - Fixed-Head Write ID Test

This routine writes IDs on the fixed-head tracks, then reads the IDs just written.

The basic status is for the first fixed-head error encountered.

Count Field Bit	0123	4567	8 → 15
Fixed-Head Number	2345	6789	Not Used

Routine 51 - Write CE Cylinder Routine

Routine 53 - Write if Read Cannot Be Performed

CAUTION: Do not run this routine without visually making sure the head is at the CE Track. This routine attempts to write on the CE track.

Manual intervention stop:

1005 5300 = Visually observe the access to verify it is at the outer stop indicator (3.6.1). Then press Enter (EM) to start execution of the routine.

Error Data Bits

- 0 Not Used
- 1 No Interrupt Head 0
- 2 Write Bit Check Head 0
- 3 Data Unsafe Head 0
- 4 Not Used
- 5 No Interrupt Head 1
- 6 Write Bit Check Head 1
- 7 Data Unsafe Head 1
- 8-15 Not Used


3.12.3 Test Routines (Cont)

Routine 54 - Seek Between Selected Cylinders

This routine seeks between two selected cylinders. The selected cylinders must be entered as four right justified hex digits.

Seek Data Format

Bit 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15



To loop routine, enter the loop option at load.

Manual intervention stops:


- 1007 5400 = Enter selected cylinders.
- 1008 5400 = Cylinders selected are too large or are equal.

Routine 55 - Read Selected Sector

This routine reads a selected sector. The selected cylinder must be entered as four right justified digits.

Read/Write data format - movable heads.

Bit 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15



Bit 8 Even/Odd
Bit 9 In/Out

Manual intervention stops:

- 1009 5500 = Enter selected ID;
- 100A 5500 = Sector or cylinder ID invalid.

Routine 56 - Test for Disk Ready after Power On or Reset.

This routine must be selected and run before any other routines are run after power on or reset for the sense information to be valid. Should be run for all Not Ready conditions.

Routine 57 - Test for Bus Hangs after Power-On Reset

This routine must be selected and run before any other routines are run after power on or reset for the sense information to be valid. Should be run for all Not Ready conditions.

Error hang will be 1081 and will probably hang the bus, not allowing interrupts from the panel.

3.12.4 Procedure Errors

Message	Cause	Action
BC81	RR has been entered without a valid L field (0, 1 and 2 are valid).	Correct input.*
BC82	L=2 has been entered without a routine number.	Correct input.*
BC83	No routine (RR) has been entered. S field is invalid (0, 1 and 2 are valid), and L field is not 2.	Correct input.*
BC84	No routine (RR) has been entered. L field is invalid (0, 1 and 2 are valid), and S field is valid.	Correct input.*
BC85	A request has been made to loop, and R does not equal 0.	Correct input.*
BC86	A logical address, other than 10, has been entered.	Correct input.*
BC87	Selected routine is invalid.	Correct input.*
BC88	A failure was detected while using the keyboard/display.	Test basic loop and keyboard/display.
BC89	An invalid interrupt has occurred.	Power off unused terminals.
BC8A	Diskette read error	Try another diskette Test basic machine
BC90	A request has been made to loop, and S does not equal 0 or 1.	Correct input.*
BC92	Machine check occurred.	Test basic machine.
BC93	Incorrect keyboard input was made at a manual intervention stop.	Correct input.*
BC94	Input message was too long.	Correct input.*
BC96	Program check occurred.	Try another diskette. Test basic machine.
BC97	Machine check occurred.	Test basic machine.

Message	Cause	Action
BC98	Routine requested is not able to loop.	Correct input.*
BC99	Selected routine is invalid.	Correct input.*
BC9A	Program check occurred.	Try another diskette. Test basic machine.
BC9B	Program check occurred.	Try another diskette. Test basic machine.
BC9C	Program check occurred.	Try another diskette. Test basic machine.
BC9D	Program check occurred.	Try another diskette. Test basic machine.
BCA0** thru BCA7	An invalid interrupt has occurred.	Power off unused terminals. Test basic machine

*To correct the input, press the FR (free) key (see Figure 3-2 for keyboard locations). When BC80 is displayed, enter the correct input. If this fails, reload the diagnostic diskette.

**Except BC80, which requires entry of the 3604 model number.

3.12.5 Disk Storage Utility Programs

CAUTION: *Running programs 1, 3, or 4 will destroy disk data.*

These programs are provided on the stand-alone diskette used for the disk storage maintenance. The procedure to use any of these programs is as follows:

1. Power off all terminals other than the 3604 at address 1 on loop 1 to prevent any interference from them.
2. Insert the diagnostic diskette and activate the controller power on or reset switch.
3. When the control program has been loaded, BC80 may display; respond with the model number of the 3604 that you are using, followed by enter (EM). BC80 should then display on this 3604.
4. You may then request the routine desired (00000X and enter, where X is the routine number).
5. 00F0 is the system response to valid input.
6. Respond with EM (enter key) to the routine complete message to terminate.

1 = Start = This routine zeros the system sectors and the relocate sectors used for defective sector recovery (alternates). Routine 3 or 4 must be run following this routine.

3 = Bad ID = This routine attempts to read every ID field on the disk element. It assigns new alternates for all sectors that had alternates assigned.

CAUTION: This routine uses new alternates each time it is run. To reclaim alternates again, routine 1 must be run; then run this routine once.

4 = Write ID = This routine rewrites the IDs on the entire disk, a single sector, or the fixed head area in accordance with the options requested by the CE as described in the detailed description of messages.

5 = Analysis = This routine analyzes the surface of the entire disk, a single sector, or the fixed head area in accordance with the options requested by the CE as described in the detailed description of messages.

Each routine, when loaded, reads the sense information from the hardware jumpers (1.72) that define this 3602. The control program can then determine when the operation indicates an error or expected results. This configuration information remains with the control program through subsequent starts until changed by running a utility with a different configuration.

Utility Program Routine Messages

Message	Meaning	Action
0000	Routine complete and terminated.	Enter another request if desired.
0012	Manual stop to insure that this routine should be run.	F and EM (enter key) to run or free key to terminate.
0014	Routine complete.	C EM (enter key) to terminate.
0031,DDD	Unable to write a displaced ID for this sector, where DDD is the sector ID.	EM (enter key) alone to try again. If this fails, replace the DE.
0034,DDD	Routine complete, where DD is the decimal count of bad sectors (alternates assigned).	C EM (enter key) to terminate.
0041,DDD	Unable to write an ID or displaced ID to this sector, where DDD is the sector ID.	EM (enter key) alone to try again. If this fails, replace the DE.
0044,DDD	Routine complete, where DDD is the decimal count of bad sectors (alternates assigned).	C EM (enter key) to terminate.
0045	Option request.	Specify the options desired as follows: CX EM (enter key) or AOIDID EM (enter key) or A = unconditionally assign an alternate for IDID. FXIDID EM (enter key) where: C = Write IDs on the entire disk F = Write IDs on a single sector, where IDID is the four-digit sector ID X=8 = Write IDs to the fixed head area X=4 = Zero the data fields X=2 = Write IDs to all sectors X=1 = Write IDs and zero the data field on sectors that have unreadable displaced IDs } 6,A,C, and E Combinations of X are valid
0046,DDD	Unable to write data to this sector, where DDD is the sector ID.	EM (enter key) alone to try again. If this fails, respond with C EM (enter key) to try to assign an alternate.
0051,DDD	A displaced ID has been read, where DDD is the sector ID.	C EM (enter key) to continue.
0052,DDD	An unreadable ID has been detected, where DDD is the sector ID.	C EM (enter key) to continue.
0053,DDD	Unable to read data, where DDD is the sector ID.	C EM (enter key) to continue.
0054,DDD	Routine complete, where DDD is the decimal count (four digits each) of the number of displaced ID sectors, number of displaced ID sectors with alternates assigned, number of unreadable ID sectors, number of unreadable data sectors, and actual number of alternates used.	C EM (enter key) to terminate.

Utility Program Routine Message (Cont)


Message	Meaning	Action
0055	Option request.	Specify the options desired as follows: CX EM (enter key) or FXIDID EM (enter key) where: C=Whole disk F=Single sector where IDID is the four-digit sector ID X=8=Fixed head area X=4=Stop on displaced ID Combinations of X=2=Stop on unreadable state X are valid X=1=Stop on unreadable ID
0181	Disk storage error.	Use MAPs.
0182	Disk storage error.	Use MAPs.
0183	Diskette error.	Test basic system with starter diskette.
0184	Disk storage error.	Use MAPs.
0381	Unable to read the label record.	Run routine 1. If failure still occurs, replace the DE.
0382,DDD	Unable to initialize the control program.	Run machine diagnostics.
0383	Unable to update configuration.	Run machine diagnostics.
0384	Configuration incorrect.	Run machine diagnostics.
0385	Unable to assign alternate sector.	Replace DE.
0386	Relocate tracks are full.	Run routine 1. If failure still occurs, replace the DE.
0387	Unable to restore label record.	Run routine 1. If failure still occurs, replace the DE.
038A,DDD	Unable to read ID or displaced ID for this sector, where DDD is the sector ID.	EM (enter key) alone to try to write the ID or, if that fails, write a displaced ID to try to recover this sector.
038B	Unable to find the correct track.	Run machine diagnostics.
038C IDID XXYY XXYY XXYY	If processing of the track identified in IDID resulted in any of the track's sector(s) being reformatted, the facility will verify the readability of the track by reading all of that track's sector IDs. If any sector IDs are found to be bad during the verification, this message is displayed. IDID is the address of the last reformatted sector of this track. Each XXYY addresses a sector whose ID is bad.	Replace DE.
038D IDID	This facility was unable to verify that the read/write head is positioned over the correct track before rewriting a sector ID. Verify by attempting to read a sector ID containing the expected track number. If this is not possible with any of the 60 sectors, then the head position is not verified.	If the machine diagnostics run without error, enter E to force writing. Then if error repeats, replace the DE.

Message	Meaning	Action
0481	Unable to read the label record.	Run routine 1. If failure still occurs, replace the DE.
0482,DDD	Unable to initialize the control program.	Run machine diagnostics.
0483	Unable to update configuration.	Run machine diagnostics.
0484	Configuration incorrect.	Run machine diagnostics.
0485	Unable to assign alternate sector.	Replace DE.
0486	Relocate tracks are full.	Run routine 1. If failure still occurs, replace the DE.
0487	Unable to restore label record.	Run routine 1. If failure still occurs, replace the DE.
048B	Unable to find correct track.	Replace the DE.
048C IDID XXYY XXYY XXYY	This sector, IDID, has been successfully formatted; the IDs of sector(s) XXYY (in IDID format) of this same track could not be read. If processing of the track identified in IDID resulted in any of the track's sector(s) being reformatted, the facility will verify the readability of the track by reading all of that track's sector IDs. If any sector IDs are found to be bad during the verification, this message is displayed. IDID is the address of the last reformatted sector of this track. Each XXYY addresses a sector whose ID is bad.	If FXIDID or AOIDID was used: Use this facility to correct the XXYY sectors. If CX was used: Replace the DE.
048D TDID	This facility was unable to verify that the read/write head is positioned over the correct track before rewriting a sector ID. Verify by attempting to read a sector ID containing the expected track number. If this is not possible with any of the 60 sectors, then the head position is not verified.	If the machine diagnostics ran without error, enter E to force writing. Then if error repeats, replace the DE.
0581	Unable to read the label record.	Run routine 1. If failure still occurs, replace the DE.
0582,DDD	Unable to initialize the control program.	Run machine diagnostics.
0583	Unable to update configuration.	Run machine diagnostics.
0584	Configuration incorrect.	Run machine diagnostics.
BC80	Control program loaded.	Enter request.
BC80	3604 Type request	Enter 3604 model number.


CAUTION: Do not use RESET to end. This could terminate an incomplete write operation. Use the FREE key.

Contents

Figure	Title	Page
4-1	Component Locations, 3601 2A, 2B, 3A, 3B (Single TSR-3 Power Supply)	4-2
4-2	Component Locations, 3601 2A, 2B, 3A, 3B One or Two TSR-2 Power Supplies. . .	4-3
4-3	Component Locations, 3601 Models C and D	4-4
4-4	Component Locations, 3602 1A, 1B	4-5
4-5	Logic Boards, Card and Pin Locations	4-6



3601 Finance Communication Controller, Model 2A, 2B, 3A, 3B, C and D



3602 Finance Communication Controller






Figure 4-1. Component Locations 3601-2A, 2B, 3A, 3B (Single TSR-3 Power Supply)



Cable No.	Part No.	Cable Title
1	4943646	A1 Board to OP Panel
2	6812757	Motor Input
3	1831749	Filter to POWER ON Switch
4	5645325	Signal and DC
5	4943641	Signal Communications Line Input
6	4943640	Loop Adapter, Loop 1
7	4406074	Power DC Input to Gate
8	4406660	Cable Assembly - DC Input to Gate
9	1831752	Power Cord TSR Input
10	1831752	Power Cord TSR Input (2nd)
11	4406075	Power AC Gate Fan
12	4406670	Remote Loop Cable
13	4943640	Local Loop Cable
14	4409516	ALA Cable
15	4406662	Cable Assembly DC Input Board A2

Reference Only: Use cable label PNs.



Figure 4-2. Component Locations 3601-2A, 2B, 3A, 3B (One or two TSR-2 Power Supplies)



Cable No.	Part No.	Cable Title
1	1831752	Power Cord TSR Input
2	1831774, 6812757	Motor Input
3	1831749	Filter to Power on Sw
4	4943638 REF	Signal and DC
5	4943641 REF	Signal Comm Line Input
6	4943646	A1 Board to OP Panel
7	4406682 REF	PWR DC Input to Gate
8	4943640 REF	Loop Adapter

Reference Only: Use Cable Label PNs


Figure 4-3. Component Locations (3601 Models C, D)



Cable No.	Cable Part Number*	From	To
1	4944498	01A-B1Y1	01S Ext. C/A (Feature)
2	1741683, 8269882	01F	01D-J2
3	1741685	01H-K1	01D-J3
4	1741684	01H-Fan	01D-J7
5	1741691, 4406665	01A-TB1	01G-1-CB1
6	1741689	01D-TB1	01E-Sw1
7	1741686	01A-B1Z3	01F
8	1741702, 4406667	01G-3	01A-TB1
9	1652519	01E	01A-B1Z5
10	1842168	01D-J4	01G-1
11	1741690	01A	01H, 01G-2
12	1741681, 4406666	01A Only	
13	1741693 (Flat Cable List 01A Only)		
14	1652549	01A-A2Z2	01S-J2
15	1741682	01A-A2	01U
16	1741679	01D	01J
17	1747294	01D-J5	01A-Fan
18	1747295	01A-B1Y1	01S-J1
19	1563175	01A-B1Y1	01U
20	4944498	01A-A2Y1 or A2Y6	Ext. C/A
21	4944499	01A-A2Y1 or A2Y6	Ext. C/A
22	4944499	01A-B1Y2	Ext. C/A

Note: Refer to Power Distribution Diagram
 * Reference Only; Use Cable Label PNs.

Figure 4-4. Component Locations, 3602-1A, 1B



Legend

● Probe Pin

Notes:

1. For multiple-socket cards (such as cards G2, E4, D3, and C2 in illustration), card location designation is specified by the uppermost row. Example: The location of card G2 (which actually occupies four sockets) is specified by the uppermost row, G2. If this card is located on board A1, its location is identified as A1G2.
2. Pin-column letter designations are signified by card size (rather than vertical position of card on board), beginning with DB in the first pin row used. Subsequent designations are JG, PM, and US, which, when required, specify pin columns in the second, third, and fourth card row, respectively. See examples in the illustration.
3. Ground = Any D08, J08, P08, or U08 pin; identified by a square surrounding each ground pin. (The square is not shown.) +5 = Any D03, J03, P03, or U03 pin.
4. Cards are shown for instruction purposes only. See Figure 4-2 for actual card locations.




Figure 4-5. Logic Boards, Card and Pin Locations

Chapter 5. Parts Catalog

Refer to S126-0013 for 3601 Parts Catalog and to S126-0014 for 3602 Parts Catalog.

BLANK PAGE

Chapter 6. Installation Instructions

Contents

Heading	Page
6.1 Preliminary Instructions	6-1
6.1.1 Basic Installation Procedure.	6-1
6.1.2 Manuals Available	6-1
6.1.3 Special Tools Needed	6-1
6.1.4 Preparing the Location	6-1
6.1.5 Setting the Loop Speed and the Terminal Address	6-2
6.1.6 Use of the Starter Diskette	6-2
6.2 Installation: Controller	6-3
6.2.1 Check Controller and Apply Power (3601).	6-3
6.2.2 Check Controller and Apply Power (3602).	6-3
6.2.3 Install Mandatory Local Loop 1	6-5
6.2.4 Install Additional Local Loops.	6-6
6.2.5 Install Remote Loops.	6-6
6.2.6 Complete the Installation	6-6

Figures

Figure	Page
6-1 3601 Left Cover Removal	6-3
6-2 3601 Front Cover Holding Screws	6-3
6-3 Controller Voltage Plate	6-3
6-4 Disk Enclosure	6-4
6-5 Shipping Clamps	6-4
6-6 3604 Switches	6-5
6-7 3604 Universal Translate Table Key Locations	6-5
6-8 World Trade Communication Cable	6-6

Tables

Table	Page
6-1 Address (Group 1) Switch Settings	6-2
6-2 Loop Speed (Group 2) Switch Settings	6-2
6-3 Starter Diskette Configuration	6-2

6.1 PRELIMINARY INSTRUCTIONS

6.1.1 Basic Installation Procedure

A 3600 system is installed in the following sequence:

1. Install the controller and a local 3604 to be used as the control operator terminal for receiving system messages and for starting terminal tests.
2. Connect each local loop, starting with the mandatory loop 1, and test that the loop operates properly.
3. Once a loop has been tested, connect terminals, one at a time, to the loop and run exercisers to test the terminals.
4. After all terminals on all local loops are operational, install any remote loops.
5. Set the address and speed switches on all terminals according to the customer's configuration.
6. Clean up and turn the system over to the customer; INSTALLATION IS NOW COMPLETE.
7. If a communication link to the computer is available, the customer should test communications with the computer.

Note: In World Trade countries, if a communication link to the computer is available, this step should be done by the customer before step 6.

8. When the 3604 at address 1 on loop 1 is not physically the first terminal on the loop, the startup diagnostic messages may not be displayed correctly. (Normal operation after startup is not affected by this incorrect display.) If you must see these messages, turn power off on the terminals that physically precede the 3604.

Instructions for performing these steps follow.

6.1.2 Manuals Available

- *IBM 3604 Keyboard Display Maintenance Information*, SY27-2361.
- *IBM 3610 Document Printer Maintenance Information*, SY27-2362.
- *IBM 3611 Passbook Printer Maintenance Information*, SY27-2408.
- *IBM 3612 Passbook and Document Printer Maintenance Information*, SY27-2363.
- *IBM 3614 Consumer Transaction Facility Maintenance Library Manual*.
- *IBM 3618 Administrative Line Printer Maintenance Information*, SY27-2364.
- Maintenance Information, Installation, and other manuals for IBM modems to be installed with the 3600 System.
- *IBM 3600 System, Field Engineering Maintenance Information Manual*, SY27-2520.

Also, the following customer's manuals are available for reference:

- *IBM 3600 Finance Communication System – System Summary*, GC27-0001. This manual introduces the 3600 System.
- *IBM 3600 Finance Communication System Configurator*, GA19-0063 (World Trade) or GA27-2762 (U.S.A.). This manual lists the terminals and features that are available for the 3600 System and shows how they can be connected.
- *IBM 3600 Finance Communication System Installation Manual – Physical Planning*, GA27-2766. This manual describes: (1) what the customer must do to prepare the location before installation and (2) the cables that are needed.
- *Operating Guide for the IBM 3600 Finance Communication System*, GA27-2776. This manual gives operating instructions and problem-recovery procedures for customer personnel.
- *IBM 3614 Consumer Transaction Facility Operator's Guide*, GA26-1624. This manual contains procedures for preparing the 3614 for operation and for determining the cause of a failure.

6.1.3 Special Tools Needed

The following special tools are shipped as required:

- Passbook printer test form, PN 1842880 (with 3611 and 3612).
- Test card, PN 2143816 (MSR machines).
- Magnetic stripe reader/encoder passbook, PN 1652251 (MSR machines).

The following branch office tools may be required:

- 453 oscilloscope or equivalent, PN 453047.
- 33FD head alignment tool, PN 2200698.
- DB meter, PN 453545.
- General logic probe, PN 453212.
- Berg connector extractor tool, PN 453705.
- Berg connector screwdriver, PN 460811.
- Berg connector probe tip, PN 453718.
- Card caddy – container, PN 963400.
- Chute adjusting tool, PN 1738543.

6.1.4 Preparing the Location

Before installation, the customer should have:

- Obtained and installed loop cables.

- Completed all location changes as needed (such as expansion of electrical wiring, installation of communications equipment, and preparing an outside wall for the 3614 Model 2).
- Tested all electrical and communications equipment.

Also, when the equipment comes, the customer must unpack it and place it in the proper location. He should show you: (1) which terminals are on each loop, (2) the address of each terminal, and (3) the proper loop speed for each terminal. The customer should also label* loop cables at each end with information that identifies: (1) the loop, (2) the terminal to which that cable end is to be connected, and (3) the terminal to which the other end of the cable is to be connected. He should have also filled out an installation reference page (from the *3600 Operating Guide*, GA27-2776), showing the location of terminals on each loop and their addresses

For the 3614, the customer must also:

- Install and provide any protection for the signal cable.
- Obtain, install, and provide any protection for alarm and control cables. These cables are not supplied by IBM.
- Connect and supply dc power for the alarm and control system. (Alarm and control cables and dc power should be ready before the terminal is sent.)
- Install the floor fastening stud for the Model 1.
- Install the heavy-duty enclosure, bezel, mounting stand, and baseplate for the Model 2.
- Place the 3614 Model 2 in the heavy-duty enclosure.

If, during installation, you find that the customer has not prepared the location properly, inform the customer, your branch office, and the responsible DP branch office.

6.1.5 Setting the Loop Speed and the Terminal Address

Each 3600 terminal has two groups of switches. Group 1 is used to set the terminal address, and group 2 is used to set the terminal to the loop speed. Each group has four switches, labeled 1 to 4. Table 6-1 shows the setting of the address switches for each terminal address, and Table 6-2 shows the setting of the loop speed switches for each loop speed.

Table 6-1. Address (Group 1) Switch Settings

Terminal Address	Switch Settings			
	1	2	3	4
1	On	Off	Off	Off
2	Off	On	Off	Off
3	On	On	Off	Off
4	Off	Off	On	Off
5	On	Off	On	Off
6	Off	On	On	Off
7	On	On	On	Off
8	Off	Off	Off	On
9	On	Off	Off	On
10	Off	On	Off	On
11	On	On	Off	On
12	Off	Off	On	On
13	On	Off	On	On
14	Off	On	On	On
15	On	On	On	On
16	Off	Off	Off	Off

Table 6-2. Loop Speed (Group 2) Switch Settings

Loop Speed in Bits per Second (bps)	Switch Settings			
	1	2	3	4
600	On	Off	Off	Off
1200	Off	On	Off	Off
2400	Off	Off	On	Off
4800	Off	Off	Off	On

6.1.6 Use of the Starter Diskette

An IBM-controlled starter diskette is shipped with each controller. During installation, it is recommended that you use the starter diskette instead of the customer's operational diskette. (But, if you use the customer's operational diskette and set the address switches to the customer's address and then run into a problem, use the starter diskette and follow the procedures in this manual.)

The starter diskette is configured for one terminal of each type on each of two loops, loops 1 and 2. (Loop 1 contains the control operator's 3604 at address 1, and loop 2 is named as having a wrappable modem.) After initial loading of the starter diskette is complete, loops 1 and 2 are both running. Keyboard commands are available to stop loop 2, name another loop to take loop 2's place, and start the other loop.

Note: You must use a prompt mode startup to specify the component that is to be tested (section 1.1.1). The starter diskette optional module ID codes are:

- 0A= ADDRESS SHARING
- 0B= PIN keyboard
- 83= 3610, 3611, 3612
- 85= 3618
- 86= 3604 magnetic stripe encoder
- 87= 3614
- 6A= ALA/Host Link Test

For all loops, the starter diskette is configured as shown in Table 6-3. Thus, if a terminal is being used in the testing, its address switches must be set as shown in Table 6-3. For terminals that are on the loop being tested but are not

Table 6-3. Starter Diskette Configuration

For starter diskettes at EC 745122 and above, see command code 973 in the IBM 3600 FE MIM, SY27-2520. Only addresses 01, 02, and 03 are valid on these diskettes.

Terminal	Address	Slots Used	Components
3604	01	1, 9	Keyboard (magnetic stripe reader) and display.
3618	02	2, 10	132 print positions and dual forms feed.
3604	03	3, 11	Keyboard (magnetic stripe reader), display, and magnetic stripe encoder.
3610	04	4, 12	Cut form - continuous form printer.
3611	05	5, 13	Passbook printer: 28 lines, centerfold starts on line 14 and ends on line 17.
3612	05	5, 13	Cut form-continuous form printer. Passbook printer: 28 lines, centerfold starts on line 14 and ends on line 17.
3614	08	8, 16	Cash issuer.

being used in the testing, configuration needs are met by turning off their power switches instead of changing the normal setting of their address switches. There is no need to change the address switches or the power switches of terminals on loops that are not being tested.

The system tries to start loops 1 and 2. If it can, the READY lights on the terminals on loops 1 and 2 will light. Logon on loop 1 is automatic, following initial loading; message 92222 appears on the control operator display (address 1 on loop 1), indicating the CE is automatically logged on that 3604 and may run exerciser tests by using its keyboard.

To test other loops and their terminals, enter the following to stop all loops except loop 1:

040 0 0X 00 0Y

where: X is set to 2 if there is no wrappable modem on the loop (local loop or World Trade 600-bps remote loop).

X is set to 3 if there is a wrappable modem (1200-bps remote loop) or an external loop modem.

Y is set to the loop number of the loop that is to be tested.

Then enter:

040 0 to start the loop that is to be tested.

You can then test the terminals on the selected loop.

For more information on the starter diskette and for the commands you can enter at the 3604, refer to 3600 System, FE MIM, SY27-2520.

*Labels are shipped with the 3602 and with the remote location 3604.

6.2 INSTALLATION: Controller

These are the step-by-step instructions, in the preferred order, for installing a 3600 system. Controller and system installation instructions are given in detail in this chapter; refer to the appropriate terminal Maintenance Information Manual, Chapter 6, for detailed terminal installation instructions. For your convenience, a box is provided next to each step to allow you to check off completed steps.

The customer must have installed electrical and communications equipment, installed cables, and unpacked and placed terminals. If you observe that any of these steps have not been completed correctly, inform the customer, your branch office, and the responsible DP branch office.

If, during installation, you observe an error indication in a terminal or determine that a terminal is in need of repair or adjustment, refer to the error indication index or to the repair and adjustment procedures in the terminal Maintenance Information manual. For system error indications, refer to Chapter 1 MAPs.

Perform steps in 6.2.1 or 6.2.2 for your controller type.

6.2.1 Check Controller and Apply Power (3601)

- 1. If the communication link to the computer is to be checked, have the customer tell the computer operator to vary this controller location (online) at this time.
- 2. Remove the left cover on the 3601 (Figure 6-1). To remove, push the cover up from the bottom, tilt out from the top, and lift up.
- 3. Remove the diskette cover by opening with a key obtained from the customer, rotate it open and disengage.
- 4. Remove the 3601 front cover by unscrewing the two screws that hold it on (Figure 6-2). Go to step 10.
- 5. Check the controller for damage and loose parts.
- 6. Check the seating of all cards and internal cable connectors.
- 7. Remove the shipping block under the diskette assembly (between the diskette assembly and the lower shock mount). On the two-sided diskette drive, remove the plastic shipping clamps from the frame.
- 8. Check the diskette assembly for damage and loose parts.




Figure 6-1. 3601 Left Cover Removal




Figure 6-2. 3601 Front Cover Holding Screws

- 9. Using your CE volt-ohmmeter (VOM), check that the ac voltage at the customer's outlet, provided for the controller, equals the voltage shown on the controller voltage plate (Figure 6-3).

CAUTION: Before performing the next step, check that the power ON/OFF switch on the controller is in the OFF position.

- 10. Insert the controller power plug in the customer's outlet.

DANGER

AC voltage is now present in the controller.

- 11. Go to step 13 of 6.2.3.

6.2.2 Check Controller and Apply Power (3602)

- 1. If the communication link to the computer is to be checked, have the customer tell the computer operator to vary this controller location (online) at this time.
- 2. Swing open the front and rear covers by pulling slightly up and out.




Figure 6-3. Controller Voltage Plate

- 3. Remove the left and right covers by pulling out at the bottom and unhooking the top.
- 4. Move the three shock mount locking spacers and bolts from the lock position to the upper (storage) position (Figure 6-4).
- 5. Unlock the disk storage spindle, remove the drive motor locking bolt (Figure 6-4), and install the drive belt (smooth side to pulleys).


CAUTION: Observe the arrow by the spindle pulley; do not turn the spindle counterclockwise.

- 6. Unlock the disk storage access assembly (Figure 6-4).
- 7. Check the controller for damage and loose parts.
- 8. Check the seating of all cards and internal cable connectors.
- 9. Remove the shipping block under the diskette assembly (between the diskette assembly and the lower shock mount). Remove the two plastic shipping clamps (Figure 6-5) from the frame.
- 10. Check the diskette assembly for damage and loose parts.
- 11. Using your CE volt-ohmmeter (VOM), check that the ac voltage at the customer's outlet, provided for the controller, equals the voltage shown on the controller voltage plate (Figure 6-3).

CAUTION: Before performing the next step, check that the power ON/OFF switch on the controller is in the OFF position.

- 12. Insert the controller power plug in the customer's outlet.

DANGER
AC voltage is now present in the controller.



* Locking bolts are on the other side.

Figure 6-4. Disk Enclosure (DE)




Figure 6-5. Shipping Clamps

6.2.3 Install Mandatory Local Loop 1

The following steps are used: (1) to install and test a small loop that is made up of the controller and the control operator's 3604 and (2) then to install the test other terminals, one at a time, until the mandatory local loop 1 is complete.

- 13. Check the 3604 to be used as the control operator terminal (address 1 on loop 1 on the starter diskette) for damage.

Note: Remove the protective, transparent tape from the screen, if present.

- 14. Using your CE VOM, check that the ac voltage at the customer's outlet, provided for the 3604, equals the voltage shown on the 3604 voltage plate.

CAUTION: Before performing the next step, check that the power ON/OFF switch on the 3604 is in the OFF position.

- 15. Insert the 3604 power plug in the customer's outlet.

DANGER
AC voltage is now present in the 3604.

- 16. Connect the loop cables to the 3604.
- 17. Set the 3604 address switches to 1 (switch 1 on), and the speed switches to the speed requested by the customer. If the customer is unavailable, set the speed switches to the same speed as the 3602 (Figure 6-6 and paragraph 6.1.5).
- 18. Connect the loop cables for loop 1 to the controller.
- 19. Refer to the chart on the end of the controller logic gate, and jumper the speed requested by the customer (if the customer is unavailable, leave the speed at the factory setting).




Figure 6-6, 3604 Switches

- 20. Complete loop 1 by connecting the remaining connectors together. Insert the plug end into the jack end of the two cables that normally connect to each terminal on the loop.


Note: At this point, loop 1 is made up of the controller and the control operator's 3604. To complete start-up faster using the starter diskette, jumper loop 2 at the controller.

- 21. Turn power on at the controller. Observe that the diskette drive motor and fans are operating.
- 22. Turn power on at the 3604.
- 23. Insert the starter diskette in the controller, and press the controller RESET key.
- 24. Observe that a series of three-letter messages appears in the upper left corner of the 3604 display within a short time. The first of these messages is IDL (initial diagnostic load), and the last message is DTC (diagnostic test complete). Each message is displayed for a short time and is then replaced by the following message. These messages indicate the part of the start-up tests that is operating. If one of these messages remains on the display, a start-up test error has occurred. Refer to MAP 1 to resolve the problem.
- 25. If the automatic start-up tests are good, a message similar in format to the following message is displayed in the upper left corner of the 3604 display:
24 STRTR01 03/13/74 D4 00 0001 00001
The 5-digit code, 00001, requests a 1-digit answer to indicate the type of start that is needed.


Note: For step 25, be aware of component test requirements (see 6.1.6). If there are gaps between the top and bottom of the displayed characters, define the 3604 at this time by entering "6X" where "X" is the model number of the 3604 which is to be used. Also be aware of the link requirements. See 1.1.1.

- 26. Enter the start. If the computer link is available, enter 1 for a cold start. If the computer link is not available, enter 8 for a cold start with no Start Link sent. The display will then go blank.


Note: The location of the keyboard keys is as named by the Universal Translation Table (UTT). Refer to Figure 6-7 for the key locations for the different 3604 keyboards.




A. 30-Key Keyboard




B. 45-Key Keyboard




C. 74-Key Keyboard




D. 77-Key Keyboard



E. 92-Key Keyboard




F. 94-Key Keyboard



G. 99-Key Keyboard

Legend:

- BS = backspace
- RE = reset
- EM = end of message
- NK = return to normal keyboard = 045
- SP = space
- AV = advance/clear*
- FR = free*



* Used only for large disk storage utilities and error code diagnostics.

Figure 6-7. 3604 Universal Translation Table Key Locations

27. Logon at the 3604 is automatic at reset with the starter diskette. A good logon is indicated by 92222 on the display. If (1) you are not using the starter diskette, or (2) if you log off this 3604 and wish to log on this 3604 again, or (3) if you wish to log on any other 3604, proceed as follows:
- Press the RESET (RE) key three times (Figure 6-7).
 - Message 90000 should be displayed.
- Note:** If 90000 is not displayed and the CHECK indicator lights, try to log on again by pressing the RESET (RE) key three times. If the CHECK indicator still lights, make sure that you are not already logged on at a 3604, and then refer to the error indication index in the 3604 Maintenance Information.
- Enter the starter diskette identification (ID) code (12345) at the 3604, using the 3604 JTT keyboard locations.
- Note:** The ID is not displayed.
- Message 91111 should be displayed, indicating a good logon. If 91111 is not displayed, press the RESET (RE) key, and enter the correct ID again.

If you want to log off, press the 0 key three times and the ENTER (EM) key once.

28. If the 3604 has the magnetic strip reader feature or the magnetic stripe encoder feature, test the feature as instructed in the 3604 Maintenance Information manual.
29. Install the remaining terminals on loop 1, one at a time, using the starter diskette loop configuration (refer to 6.1.6). (See terminal Maintenance Information manual for terminal installation instructions).
30. (3602 only) Verify the operation of the disk storage by running the diagnostic as described in section 1.114. Refer to Chapter 1 MAPs if any errors occur.

Notes:

- After testing each remaining terminal, turn its power off.
- If you observe an error indication in a terminal or determine that a terminal is in need of repair or adjustment, refer to the error indication index or to the repair and adjustment procedures in the terminal Maintenance Information manual. For system error indications, refer to Chapter 1 MAPs of this manual.

6.2.4 Install Additional Local Loops

31. Connect the loop cables to the loop connectors on the controller.
32. Refer to the chart on the end of the controller logic gate and jumper the speed requested by the customer (if the customer is unavailable, leave the speed at the factory setting).
33. Connect the loop cables to one terminal on this loop.
34. Complete the loop by connecting the remaining cable connectors together. Insert the plug end into the jack end of the two cables that would attach to each terminal on the loop.
35. Name the loop and terminal per the instructions in 6.1.6.
36. Perform the installation instructions for the terminal. (See the terminal Maintenance Information manual.)

Note: After testing any terminal, turn its power off.

37. Repeat steps 33, 35, and 36 for each terminal on the loop.
38. Repeat steps 35–38 for each local loop.

6.2.5 Install Remote Loops

If two locations are on one loop, it is necessary to apply power to all 3604s or 3614s with a teleprocessing interface, and to connect the loop cables before starting to install the loops within each remote location.

39. Install the cables from the controller to the communications facilities. Normally the transmit level is factory set to 0 db. If the transmit level must be adjusted, refer to the Chapter 1 procedures.
40. Name the loop and terminal per the procedure in 6.1.6. If the remote loop has a 3604, log off the loop 1 3604 by pressing the 0 key three times and the enter (EM) key.

41. Complete the loop at the remote location by connecting the loop cable connectors together, except the connectors that attach to the 3604 or the 3614 that contains the teleprocessing interface.
42. Install the 3604 or 3614 that contains the teleprocessing interface (see the 3604 or the 3614 Maintenance Information manual). Log on a 3604 at this location to name tests for the rest of the terminals at this location. See Figure 6-8 for World Trade cable connectors.




Figure 6-8. World Trade Communication Cable

43. Install the remaining terminals on the remote loop, one at a time.

Note: After testing any terminal, turn its power off, except for terminals with a teleprocessing interface.

6.2.6 Complete the Installation

44. Connect the communication link cables. Normally, the transmit level is factory set to 0 db. If the transmit level must be adjusted, refer to the Chapter 1 procedures. For external modems, refer to section 3.11.3 to ground unused lines. Also, verify whether speed jumpering is required (3.9).
45. Perform a wrap test of the controller (issue a start-link command, command 041, and specify a wrappable modem if the modem may be automatically wrapped. An example is the 1200-bps internal modem). Perform a wrap test of the ALA with command code 929 if present. See 3600 System, FE MIM, SY27-2520.

46. Display the system log to make sure there are no hardware errors.
47. Set up the address switches on all installed terminals per the customer's request. (Refer to 6.1.5).
48. Replace all covers.
49. INSTALLATION IS NOW COMPLETE; turn the system over to the customer.
50. If a communication link to the computer is available, the customer should now test communications with the computer.

Note: In World Trade countries, if a communication link to the computer is available, this step should be done by the customer before step 49.

Appendix A. List of Abbreviations

BCC	block check count	MAP	maintenance analysis procedure
BS	back space	MC	motor current (stepper motor)
		MI	maintenance information
CA	cancel	MV0	memory volume 0
COM	common	MV1	memory volume 1
CRC	cyclic redundancy check	M/D	modem
CUA	control unit address		
		NK	return to normal keyboard translate table
DTC	diagnostic test complete	N/C	normally closed
		N/O	normally open
EIA	Electronic Industries Association	SCR	silicon controlled rectifier
EM	enter	SDLC	synchronous data link control
ESA	extended storage addressing	SP	space
		TP	test point
FRU	field-replaceable unit	TSR	transistor switching regulator (power supply)
FSU	functional storage unit		
		UTT	Universal Translate Table
GEN	generation	VOLID	volume identification (diskette)
GL probe	General Logic Probe	VOM	volt-ohmmeter
		VTL	vendor transistor logic
ID	identification		
IDL	initial diagnostic load		
LED	light emitter diode		

BLANK PAGE

Appendix B. Glossary

Acknowledgment to the American National Standards Institute

IBM is grateful to the American National Standards Institute (ANSI) for permission to reprint definitions from the *American National Standard Vocabulary for Information Processing* (Copyright 1970 by American National Standards Institute, Inc.), which was prepared by Subcommittee X3K5 on Terminology and Glossary of the American National Standards Committee X3. In this glossary, a complete commentary taken from ANSI is identified by an asterisk (*) that appears between the term and the beginning of the commentary; a single definition taken from ANSI is identified by an asterisk after the item number for that definition.

access: The manner in which files on the disk storage and the diskette storage are referred to by the controller.

assign a test component: To enter a command at a 3604 keyboard to designate the terminal component that will be tested by subsequent keyboard commands. This assignment remains in effect until any of the following occurs: (1) the CE assigns a different test component, (2) the CE logs off, or (3) the controller is reset. See *terminal component*.

assign an output printer: To enter a command at a 3604 keyboard that designates the printer (or display) that will be the output printer. (Additional commands are entered to cause the output printer to print/display specific information during the time the CE is logged on.) This assignment remains in effect until any of the following occurs: (1) the CE assigns a different output printer, (2) the CE logs off, or (3) the controller is reset.

axe circuit: A circuit that detects out-of-tolerance conditions in a supply voltage and turns off the power supply by causing a direct short circuit across the power supply output.

component: (1) In general, a part of a larger unit. (2) In connection with the 3600 system, a shortened name for a terminal component. See *terminal component*.

configuration image: A combination of formatted configuration data with selected modules of controller data which, when loaded into controller storage, determines the operations of the controller. A configuration image is produced by the Finance Image Processor. The completed image is stored in the 3600 and is later transmitted to a controller.

data byte: See *parameter data byte*.

*American National Standard definition

debug *To detect, locate, and remove mistakes from a routine or malfunctions from a computer. Synonymous with *troubleshoot*.

displacement: With reference to addressing a field in a segment of storage, the number of bytes that the first byte of the field is away from byte 1 of the segment.

dump: With reference to the 3600 controller, to copy a part of storage onto a diskette.

flag byte: See *parameter flag byte*.

frame: (1) The basic fixed-format entity that is transmitted under SDLC procedures. Each frame is delimited by a unique sequence (FLAG) at its beginning and end. The frame format consists of a station address (8 bits), a control field (8 bits), an information field (variable in length), and block checking information. (2) For transmissions on terminal loops, see *loop transmission frame*.

hang: With reference to startup (reset) of the controller, a failure of the controller not only to complete the startup, but also a failure to establish any communication with the CE.

inquiry: A request from a terminal for information from storage.

log: In a 3600 controller, a temporary file on the diskette in which hardware error statistics are recorded and in which other operational data can be recorded, such as commands and messages from control operators.

logical work station: The combination of a section of storage and a controller application program that the controller treats as a unit; terminals may be associated with the unit, and the unit may communicate with the host system. See also *user work station*.

loop transmission frame: A group of 16 message slots for terminals (plus a frame synchronization slot) transmitted around a loop as an entity.

operating diskette: A diskette containing the configuration image (and other data) relating to the operation of a particular controller. The operating diskette must be in the controller during its operations. A second diskette containing the same configuration image and data is sometimes referred to as a *backup operating diskette*.

parameter: (1) *A variable that is given a constant value for a specific purpose or process. (2) See *parameter flag byte* and *parameter data byte*.

parameter data byte: When setting up or changing the parameters of a terminal component, the data bytes give values to the various parameters. See *parameter flag byte*.

parameter flag byte: When setting up or changing the parameters of a terminal component that can operate with different groups of parameters, the flag byte specifies which group of parameters are being set up or changed by the connected parameter data bytes. See *parameter data byte*.

permanent file (on a controller diskette): An optional file on a diskette that can be used to store data to be retained from one controller startup to another. Permanent data might include such things as a customized image for a 3614 Consumer Transaction Facility, day-to-day totals, or checkpoint/restart data.

prompt: To help a terminal user by displaying messages that request him to enter information necessary to continue an operation.

seat: To plug a logic card into its socket correctly, or to plug two cable connectors together correctly. Contrast with *unseat*.

seek: To position the read/write head of the disk drive at a specified location.

segment: In a 3600 controller, one of 16 portions into which the programmable storage related to an application program can be divided. The length of each segment is specified by the user.

segment header: In a 3600 controller, an 8-byte field at the beginning of each segment. The segment header contains four 2-byte fields, as follows: primary field pointer, secondary field pointer, field-length indicator, and segment-length indicator.

session: With reference to communications between the controller and the host system, the period of time during which a logical connection exists between a controller application program (which is serving terminals) and a host application program; thus, the period of time between the point at which a host application program recognizes a controller application program and agrees to exchange messages with it, and the point at which the host application program breaks its connection with the controller application program.

slot: A portion of a transmission frame that is sent around a loop. See *loop transmission frame*.

starter diskette: A diskette used in a 3600 controller to initiate communication with the host computer and to prepare the controller for reception and recording of the configuration image. Just before the configuration image is to be sent to the controller, the starter diskette is removed and replaced by a formatted diskette on which the image is actually written. After a configuration image has been written on a diskette, it is known as an *operating diskette*. See also *operating diskette*.

synchronous data link control (SDLC): A line-control discipline that allows efficient serial-by-bit synchronous transmissions between buffered units on a data transmission link under central control. The data-transmission link may be customer-owned, leased, or switched facilities in a duplex, half-duplex, or loop configuration.

system monitor: The portion of the configuration image in a controller that handles communications with control operators and records error statistics and other operational data.

temporary file (on a controller diskette): A file on a diskette that can be overwritten when it is no longer needed. Data in a temporary file is not retained from one controller startup to the next. Contrast with *permanent file*.

terminal: A point in a communication network at which data can enter and leave. See also *terminal component*.

terminal component: A separately addressable part of a terminal. The component performs an input or an output function, but usually not both.

track: (1) *The portion of a moving storage medium, such as drum, tape, or disk, that is accessible to a given reading head position. (2) In the controller, the portion of the diskette that is accessible to a given position of the diskette drive read/write head. (3) In a 3600 system, to display the information entered at a 3604 keyboard on the display screen of the same 3604.

transaction: (1) In a 3600 system, generally, an exchange between a terminal and another unit to effect a particular action or result. (2) More specifically, a single communication action involving an inquiry from a terminal that produces a response containing desired information (such as a request from a terminal for a customer's account balance) or a more complex action in which data records must be changed (such as a request to update a customer's balance with a new deposit).

unseat: With reference to logic cards on controller boards 01A1, 01A2, and 01B1, to open both levers (upper and lower) of a logic card holder. This action breaks the electrical connection between the card and the card socket without the necessity of removing the card from the socket.

user work station: (1) A terminal or group of terminals, usually located near each other in a financial establishment, that are considered by one or two operators to be the terminal or group of terminals at which they are to perform their transactions. (2) Logically related terminals that are associated with the same logical work station inside the controller. (3) See also *logical work station*.

work station: See *user work station* and *logical work station*.

BLANK PAGE

Appendix C. Index

- access arm actuator 3-9
- address and speed switches on terminals 3-2
- adjustments:
 - belt tracking 1-15R
 - drive band 1-52R
 - drive belt 1-46R
 - head carriage position 1-36R
 - head load solenoid/bail assembly 1-40R
 - lower limit stop 1-22R
 - motor brake 1-70R
 - phototransistor 1-26R
 - pressure pad actuator 1-17R
 - read/write head 1-20R
 - speed sensing transducer 1-74R
 - stepper motor 1-24R
 - track indicator 1-14R
 - transmit level for 600-bps integrated modem 1-97R
 - transmit level for 1200-bps integrated modem 1-96R
 - upper limit stop 1-22R
- alignment LED/PTX 1-57R
- alternative line attachment 3-2
- assigning a component as the output printer 1-8R
- assigning component to be tested 1-9R

- back panel connections 3-46
- basic controller 3-2
- basic installation procedures 6-1

- cable and jumper assembly component parts 5-14
- cable assembly selection 3-21
- check controller and apply power 6-3
- check receive level for 1200-bps and 600-bps integrated modems 1-100R
- cleaning head and pressure pad 1-20R
- commands given at keyboard (table) 3-6
- communications between controller and control operator or CE 3-4
- communication connections 3-36
- communications link connections 3-48
- complete installation 6-6
- component description 3-9
- component locations 3-8, 4-1
- controller/communication link external cables 3-32
- controller and system installation instruction 6-1
- controller log 2-2
- create disk function 3-28

- data recording 3-9
- DE brake assembly 1-73R
- DE cables 1-77R
- diagnostic diskette 2-2
- disk 3-9
- disk diagnostic error codes 1-80R, 3-48
- disk enclosure 3-9, 6-4
- disk motor 3-9
- disk servo 3-9
- disk spindle 3-9
- disk storage 3-2, 3-8
- disk storage card jumpers 1-76R
- disk storage diagnostic 1-80R, 3-47
- disk storage locations 3-8
- disk storage utility programs 3-49
- diskette 3-10, 3-13, 3-16
- diskette AC drive components 3-13
- diskette cover assembly 3-13
- diskette drive assembly 3-10, 3-13
- diskette drive control card 3-10, 3-13
- diskette drive control card pin assignment 1-29R, 1-60R
- diskette EC levels 3-4
- diskette head carriage assembly 3-13
- diskette head load actuator assembly 3-10
- diskette head load solenoid/bail 3-13
- diskette motor and drive 3-10, 3-13
- diskette stepper motor assembly 3-10, 3-13
- diskette storage 3-2
- displayed messages 3-7
- displayed messages and status 2-2, 3-7, 3-48, 3-49
- displayed status 3-7
- display/print controller log 1-12R
- display/print statistic counters 1-11R

- entering MAPs 2-2
- error-free startup (reset) 3-4
- external modems 3-48
- external modem signal cable 1-95R
- external modem wrap card 1-95R

- finance communications controllers 3-2, 4-1
- first status byte (Table 3-6) 3-7
- fixed heads (optional) 3-9
- functional parts of the controller 2-1
- functional storage 3-2

- general description, diskette drive 3-10, 3-13
- Glossary (Appendix B) B-1

- host communication link 3-2

- information that supports MAPs 2-2
- install additional local loops 6-6
- install mandatory local loop 1 6-5
- install remote loops 6-6
- installation 6-1
- interconnect diagrams 3-17

- Japanese wrap test cable 3-35

- keyboard display terminals 3-4
- keyed input commands 2-1, 3-6

- LED/PTX assembly 3-10, 3-13
- List of Abbreviations (Appendix A) A-1
- List of Pages (Appendix D) D-1
- local and remote loops 3-2
- logic boards, card and pin locations 4-6
- logic cards and boards 1-101R, 1-102R, 1-107R, 1-108R
- logon/logoff procedures for CE 1-7R, 3-5, 3-6
- loop control cards 3-46
- loop error log message 1-12R

- maintenance aids 2-2
- maintenance approach 2-1
- maintenance facilities 2-1
- manual logon/logoff procedures 3-5
- manuals available 6-1
- MAP format 2-2
- modem compatibility 3-46
- motor, disk 3-9

- operating diskette 1-5R, 3-4
- operating sequence 3-12, 3-14
- operator controls 3-4

- parts catalog 5-1
- power distribution wiring diagram 3-21
- power supply voltages 3-45
- preliminary instructions, installation 6-1
- preparing the location 6-1
- prompt mode message sequence 3-5
- PTX alignment 1-57R

- read/write circuit principles, diskette 3-12, 3-15
- removal and replacement
 - collet 1-13R, 1-33R
 - cover assembly 1-13R, 1-33R
 - disk enclosure 1-64R, 1-66R
 - disk motor 1-68R
 - diskette drive assembly 1-12R, 1-32R
 - diskette drive control card 1-30R, 1-61R
 - drive band 1-54R
 - drive motor 1-15R, 1-46R
 - drive pulley 1-16R, 1-46R
 - head carriage assembly 1-38R
 - head load solenoid/bail assembly 1-44R
 - hub assembly 1-16R
 - idler assembly 1-46R
 - latch assembly 1-13R, 1-33R

- leadscrew and head carriage assembly 1-18R
- leadscrew wheel 1-21R
- light emitting diode (LED) 1-28R, 1-58R
- logic board 1-101R
- motor brake assembly 1-72R
- phototransistor 1-26R
- power supply 1-101R
- PTX 1-58R
- pulley/clamp 1-50R
- stepper drive idler assembly 1-56R
- stepper motor 1-24R
- wiper 1-50R

- service check
 - anti-static brush 1-74R
 - drive band 1-52R
 - drive belt 1-46R
 - head/carriage position 1-36R
 - head load solenoid/bail assembly 1-40R
 - light emitting diode (LED) 1-28R, 1-57R
 - motor brake 1-70R
 - phototransistor 1-26R
 - PTX amplifier 1-57R
 - speed-sensing transducer 1-74R
- servo 3-9
- setting loop speed and terminal address 3-2, 6-2
- special tools 2-2, 6-1
- starter diskette 1-5, 2-2, 3-4, 3-6
- startup errors 3-5
- startup (reset) 1-5R
- startup (reset) diagnostic messages 2-1
- startup (reset) errors 3-5
- startup (reset) sequence 3-4
- statistic counters 2-2, 3-7
- supply voltages on logic boards and cards 3-46

- test points
 - diskette drive control card 1-30R, 1-61R
 - index 1-63R
 - supply voltage 1-95R
- test component 1-9R, 3-6

- universal translate table keyboard layout 3-5, 6-5
- use of starter diskette 6-2
- use of MAPs 2-2

- 3600 Finance Communications System 3-2

BLANK PAGE

Appendix D. List of Pages

Page	EC	REA	Form Number
Title Page			SY27-2519-0
Preface	745948		↑
MAP 01	↑		↑
1-1	↑		↑
1-2	↑		↑
1-3	↑		↑
MAP 2-1	↑		↑
2-2	↑		↑
2-3	↑		↑
2-4	↑		↑
2-5	↓		↓
2-6	745948		SY27-2519-0
2-7	745949		TNL SN31-0864
2-8	745949		TNL SN31-0864
2-9	745948		SY27-2519-0
2-10	↑		↑
2-11	↑		↑
MAP 3-1	↑		↑
3-2	↑		↑
3-3	↑		↑
3-4	↑		↑
MAP 4-1	↑		↑
4-2	↓		↓
4-3	745948		SY27-2519-0
MAP 5-1	745949		TNL SN31-0864
5-2	745949		TNL SN31-0864
5-3	745948		SY27-2519-0
MAP 6-1	↑		↑
6-2	↑		↑
6-3	↑		↑
6-4	↑		↑
MAP 7-1	↑		↑
7-2	↑		↑
7-3	↑		↑
MAP 8-1	↑		↑
8-2	↑		↑
8-3	↑		↑
8-4	↑		↑
MAP 9-1	↑		↑
9-2	↑		↑
9-3	↑		↑
MAP 10-1	↑		↑
10-2	↑		↑
10-3	↑		↑
10-4	↓		↓
MAP 11-1	745948		SY27-2519-0

Page	EC	REA	Form Number
MAP 12-1	745948		SY27-2519-0
12-2	745949		TNL SN31-0864
12-3	745948		SY27-2519-0
12-4	↑		↑
MAP 13-1	↑		↑
MAP 14-1	↑		↑
14-2	↑		↑
14-3	↑		↑
MAP 15-1	↑		↑
MAP 16-1	↑		↑
16-2	↑		↑
16-3	↑		↑
16-4	↑		↑
MAP 17-1	↑		↑
17-2	↑		↑
17-3	↑		↑
17-4	↑		↑
1-1R	↑		↑
1-2R	↑		↑
1-3R	↑		↑
1-4R	745948		SY27-2519-0
1-5R	745949		TNL SN31-0864
1-6R	745948		SY27-2519-0
1-7R	↑		↑
1-8R	↑		↑
1-9R	↑		↑
1-10R	↑		↑
1-11R	↑		↑
1-12R	↑		↑
1-13R	↑		↑
1-14R	↑		↑
1-15R	↑		↑
1-16R	↑		↑
1-17R	↑		↑
1-18R	↑		↑
1-19R	↑		↑
1-20R	↑		↑
1-21R	↑		↑
1-22R	↑		↑
1-23R	↑		↑
1-24R	↑		↑
1-25R	↑		↑
1-26R	↑		↑
1-27R	↑		↑
1-28R	↑		↑
1-29R	↓		↓
1-30R	745948		SY27-2519-0

Page	EC	REA	Form Number
1-31R	745948		SY27-2519-0
1-32R	↑		↑
1-33R	↑		↑
1-34R	↑		↑
1-35R	↑		↑
1-36R	↑		↑
1-37R	↑		↑
1-38R	↑		↑
1-39R	↑		↑
1-40R	↑		↑
1-41R	↑		↑
1-42R	↑		↑
1-43R	↑		↑
1-44R	↑		↑
1-45R	↑		↑
1-46R	↑		↑
1-47R	↑		↑
1-48R	↑		↑
1-49R	↑		↑
1-50R	↑		↑
1-51R	↑		↑
1-52R	↑		↑
1-53R	↑		↑
1-54R	↑		↑
1-55R	↑		↑
1-56R	↑		↑
1-57R	↑		↑
1-58R	↑		↑
1-59R	↓		↓
1-60R	745948		SY27-2519-0
1-61R	745949		TNL SN31-0864
1-62R	745948		SY27-2519-0
1-63R	↑		↑
1-64R	↑		↑
1-65R	745948		SY27-2519-0
1-66R	745949		TNL SN31-0864
1-67R	745948		SY27-2519-0
1-68R	↑		↑
1-69R	↑		↑
1-70R	↑		↑
1-71R	↑		↑
1-72R	↑		↑
1-73R	↑		↑
1-74R	↑		↑
1-75R	↑		↑
1-76R	745948		SY27-2519-0
1-77R	745949		TNL SN31-0864
1-78R	745948		SY27-2519-0
1-79R	745948		SY27-2519-0

Page	EC	REA	Form Number
1-80R	745948		SY27-2519-0
1-81R	745949		TNL SN31-0864
1-82R	745948		SY27-2519-0
1-83R	↑		↑
1-84R	↑		↑
1-85R	↑		↑
1-86R	↑		↑
1-87R	↑		↑
1-88R	↑		↑
1-89R	↑		↑
1-90R	↑		↑
1-91R	↑		↑
1-92R	↓		↓
1-93R	↓		↓
1-94R	745948		SY27-2519-0
1-95R	745949		TNL SN31-0864
1-96R	745948		SY27-2519-0
1-97R	↑		↑
1-98R	↑		↑
1-99R	↓		↓
1-100R	745948		SY27-2519-0
1-101R	745949		TNL SN31-0864
1-102R	↑		↑
1-103R	↑		↑
1-104R	↑		↑
1-105R	↓		↓
1-106R	↓		↓
1-107R	745949		TNL SN31-0864
1-108R	745948		SY27-2519-0
1-109R	745949		TNL SN31-0864
1-110R	745948		SY27-2519-0
1-111R	↑		↑
1-112R	↑		↑
2-1	↓		↓
2-2	745948		SY27-2519-0
2-3	745949		TNL SN31-0864
2-4	745948		SY27-2519-0
3-1	745949		TNL SN31-0864
3-2	745948		SY27-2519-0
3-3	↑		↑
3-4	↑		↑
3-5	↑		↑
3-6	↑		↑
3-7	↑		↑
3-8	↑		↑
3-9	↑		↑
3-10	↓		↓
3-11	↓		↓
3-12	745948		SY27-2519-0

Appendix D. List of Pages (Cont)

Page	EC	REA	Form Number
3-13	745948		SY27-2519-0
3-14	↕		↕
3-15	↕		↕
3-16	745948		SY27-2519-0
3-17	745949		TNL SN31-0864
3-18	745949		TNL SN31-0864
3-19	745949		TNL SN31-0864
3-20	745948		SY27-2519-0
3-21	↕		↕
3-22	↕		↕
3-23	745948		SY27-2519-0
3-24	745949		TNL SN31-0864
3-25	745949		TNL SN31-0864
3-26	745949		TNL SN31-0864
3-27	745949		TNL SN31-0864
3-28	745948		SY27-2519-0
3-29	745949		TNL SN31-0864
3-30	745949		TNL SN31-0864
3-31	745949		TNL SN31-0864
3-32	745948		SY27-2519-0
3-33	↕		↕
3-34	↕		↕
3-35	↕		↕
3-36	↕		↕
3-37	745948		SY27-2519-0
3-38	745949		TNL SN31-0864
3-39	745949		TNL SN31-0864
3-40	745949		TNL SN31-0864
3-41	745948		SY27-2519-0
3-42	745948		SY27-2519-0
3-43	745948		SY27-2519-0
3-44	745949		TNL SN31-0864
3-45	↕		↕
3-46	↕		↕
3-47	↕		↕
3-48	745949		TNL SN31-0864
3-49	745948		SY27-2519-0
3-50	↕		↕
4-1	↕		↕
4-2	745948		SY27-2519-0
4-3	745949		TNL SN31-0864
4-4	745949		TNL SN31-0864
4-5	745949		TNL SN31-0864
4-6	745948		SY27-2519-0
5-1	↕		↕
5-2	↕		↕
6-1	↕		↕
6-2	↕		↕
6-3	745948		SY27-2519-0

Page	EC	REA	Form Number
6-4	745948		SY27-2519-0
6-5	↕		↕
6-6	↕		↕
A-1	↕		↕
A-2	↕		↕
B-1	↕		↕
B-2	↕		↕
C-1	↕		↕
C-2	745948		SY27-2519-0
D-1	745949		TNL SN31-0864
D-2	745949		TNL SN31-0864
Reader's Comment			SY27-2519-0
Business Reply			SY27-2519-0
Back Cover			SY27-2519-0

G H

3602 Power

PAGE 2 OF 4

010
Go to Step 012, Entry Point D.

011
Turn off power.
• Replug all voltage connectors on board 01A1, including 01A1Z3.
• Unplug all voltage connectors on board 01B2.
• Turn on power.

Are all voltages within limits?
Y N

012
(Entry Point D)
• Replug all voltage connectors on board 01A1, including 01A1Z3 and/or 01B2.
• Unplug the voltage connector on power supply TSR 1 (3-8).
• Turn on power.

Are all voltages within limits?
Y N

013
CAUTION
Turn off power.
• Unplug all voltage connectors on boards 01B1, 01B2, 01A1, 01A2.
• Unplug the special voltage cables at 01B1Y4, 01A1Z3, and 01A2Z3. (Slip-on connectors A2D07, V2D07 on later machines).
• Unplug the cable from 01B1Z3 at the diskette drive control card, including the ground wire.
• Disconnect the ground strap at 01A1TB1 (3-8).
• Measure the resistance between the dc return, various voltage leads, and frame ground. Refer to Figure 3-8.

Are there any short circuits?
Y N

014
CAUTION
Turn off power.
• Replace power supply TSR 3.
• Replug all connectors and ground straps.
• Turn on power.

Are all voltages within limits?
Y N

015
• Call for aid.

016
• Verify fix.

J K L

F J K L

017
• Repair or replace cable, or cause of short.
• Verify fix.

018
• Replace power supply TSR 1.
• Verify fix.

019
CAUTION

Turn off power.
• Replug all board 01B2 voltage connectors.
• Unseat all cards on board 01B2.
• Turn on power.

Are all voltages now within limits?
Y N

020
• Replace board 01B2.
• Verify fix.

021
CAUTION

Turn off power when reseating a card.
• Reseat a few cards at a time on board 01B2 to find problem card.
• Replace problem card and reseat others.
• Verify fix.

022
CAUTION

Turn off power.
• Replug all board 01A1 voltage connectors.
• Unseat all cards on board 01A1.
• Turn on power.

Are all voltages now within limits?
Y N

023
• Replace board 01A1.
• Verify fix.

024
CAUTION

Turn off power when reseating a card.
• Reseat a few cards at a time on board 01A1 to find problem card.
• Replace problem card and reseat others.
• Verify fix.

Chapter 1. Maintenance Analysis Procedures (MAPs)

PAGE 1 OF 1

3600 CONTROLLER

MAINTENANCE ANALYSIS PROCEDURES (MAPs)

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

Contents

MAP	Title
1	Error Indication Index
2	Check for Error Indications
3	Local Loop Problem
4	1200-bps Remote Loop Problem, Internal Modem
5	Remote Loop Problem, External Modem
6	Host Communication Link Problem
7	Alternative Line Attachment
8	Diskette Drive Assembly Not Ready
9	Diskette Drive Assembly Seek Error
10	Diskette Drive Assembly Data Check
11	Disk Storage - System Hang
12	Disk Storage - Operational Failure
13	Basic Controller Problem
14	Minimum Configuration Method of Fault Isolation
15	Power
16	3601 Power
17	3602 Power

Error Indication Index

PAGE 1 OF 3

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

Error Indication	Go to MAP
Controller Log Messages; 11 001 ** 900XX XXXX ** 11 005 Loop X Error Code Y Z 11 006 11 007 XX--XX 11 008	12 3,4,5 6 12 7
Displayed Messages: 82000, 82001, 82031-82037, 82070, 82071 82074, 82075 82080, 82090, 82093, 82094 82092 90002, 90012, 90014 82010, 82020 82030 90027, 90028	2 2 9 3 10 10 2 12
Diskette Statistic Counters 1 7 2, 3, 4, 5, 6, 8 9	8 9 10 No action needed
Miscellaneous: Nothing displayed at startup time Diskette not turning Diskette seek error Diskette data check or write error All terminals on one local loop failing, READY lights off or flashing All terminals on one remote 1200 bps loop failing, READY light off or flashing All terminals on one remote external modem loop failing, READY lights off or flashing Loop statistic counters Host communication link problem Link statistic counters No reported symptom, or symptom reported does not definitely lead to one MAP Startup error occurs only on 1 or 2 start Power	2 8 9 10 3 4 5 3,4,5 6 6 2 2 14

Error Indication Index

PAGE 2 OF 3

Error Indication	Go to MAP
Startup diagnostic message sequence stops	
At:	
MVX XXX	2
LSW, LDI	2
INS	2
IDL, IRT, HSH	8
LDC, PCK, ESA, INV, ROS, LEC	13
DTC	2

MAPs and possible FRUs

Suggestion:

For intermittent problems, refer to the possible FRU list for the indicated MAP.

NOTE: As you become familiar with the system you may choose to enter the MAPs at any point based upon your observation, the customer's description of the trouble, and your experience. If, however, you do not correct a problem on your first pass through the MAPs, you should use MAP 2. This will make sure that you observe error indications which you may not have observed, or which you believed to be not connected with the problem.

Error Indication Index

PAGE 3 OF 3

MAP	FRUs
2	This MAP is for use when problem is not defined. Therefore, it is not reasonable to list possible FRUs
3	Loop CTRL card
4	Loop CTRL card M/D Rcvr/Xmit card
5	Loop CTRL card EIA/PTT card
6	CA card (with or without clocking) M/D Xmit card (Host 15) M/D Rcvr card (Host 15) M/D Wrap card (Host 15) EIA card (Host 15) 38LS EIA card (Host 15) 38LS M/D card (Host 15)
7	CA card (with or without clocking) M/D Xmit card (ALA XX) M/D Rcvr card (ALA XX) M/D wrap card (ALA XX) EIA card (ALA XX) 38LS M/D card (ALA XX) 38LS EIA card (ALA XX)
8 9 or 10	Diskette drive control card Diskette adapter card Phototransistor Light emitter diode Diskette drive mechanical and electromechanical parts
10	All cards on basic controller board
11-12	DE unit parts
13	CTLR 1 card CTLR 2 card CTLR 3 card FSU 1 Vol. 0 card ESA 1 card ESA 2 card
14	All cards
15-19	Power: Circuit breaker Fuse Power switch Power supplies

Check for Error

Indications

PAGE 1 OF 11

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
1	A	1	001
13	F	5	027

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
11	114	10	A
11	109	10	A
9	073	10	A
8	057	10	A
8	048	10	A
9	063	11	A
10	097	12	A
10	096	12	A
10	090	12	A
3	009	14	A
5	026	14	A
9	060	14	A
8	058	14	A
8	055	14	A
8	051	14	A
2	004	15	A
10	104	3	A
7	042	3	A
10	103	4	A
10	102	5	A
11	113	6	A
11	112	7	A
10	094	7	A
11	115	8	A
11	111	8	A
9	075	8	A
6	030	8	A
11	110	9	A
9	074	9	A

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

(Entry Point A)

- Check for loose cards and cables. Be sure to check all small cards and cable connectors.
- Insure that fan/s are running. (Power distribution diagrams)
- For a failure that occurs when the controller RESET switch is activated but does not occur when the controller power switch is activated, refer to Power (Step 001 continues)

Check for Error Indications

PAGE 2 OF 11

(Step 001 continued)
distribution diagrams.

Is the controller power indicator on?

Y N

002

Is the controller power cord plugged in and power switch turned on?

Y N

003

Plug cord in and/or turn on power.
• Verify fix.

004

Go To Map 15, Entry Point A.

005

• Open the outside front cover.

Is there a diskette rotation problem that you can readily observe?

Y N

006

• Attempt to log on (1.2) at a 3604. If unsuccessful, try others.

Is logon successful?

Y N

007

Go to Page 4, Step 017, Entry Point D.

008

(Entry Point B)

• If a functioning printer is available, key the command that assigns it to be the output printer.

006 XXXX Y Assign printer XXXX, side Y, as output printer. See procedures (1.4) for more detail.

• Now, key the command to print statistic counters for all components. If no printer is available, key the command to display statistic counters of one component at a time. On your first pass through this MAP, display only those associated with the customer complaint.

012 Y (Print statistic counters for all components, where Y=total number of loops attached to controller.)

010 LSSD (Print statistic counters for component specified by LSSD.) See procedures (1.5) for more detail.

Does the system print or display the statistic counters?

Y N

1
1 3 3
A B C

B C
2 2

Check for Error Indications

PAGE 3 OF 11

009

Go To Map 14, Entry Point A.

010

- Key a command to display or print some or all of the controller log (1.6).

Does the system respond by displaying error message 90002?

Y N

011

- Check the statistic counters and the controller log. Also note the condition of the READY light on all powered terminals.*A* On your first pass through this MAP, check only those easily available.
- Also use the customers complaint in answering the following questions.

(Entry Point C)

A

Refer to IBM 3600 System, FE Maintenance Information Manual, SY27-2520 for the meaning of the statistic counters and the log messages. The READY lights of all powered terminals should be on solid. A loop problem is indicated if any of these lights are off or flashing.

- If the data directs you to a Map in this manual go to that MAP.
- If the data indicates that a terminal is failing, go to the Maintenance Information manual for that terminal.
- Otherwise return to Entry Point C of this MAP.

Does the data checked above indicate a host communication link problem?

Y N

012

Does the data indicate an alternative line failure?

Y N

013

Does the data indicate a diskette problem?

Y N

014

Does the data indicate a loop problem?

Y N

1	1	1	1	1	
1	1	1	0	0	4
D	E	F	G	H	J

J
3

Check for Error Indications

PAGE 4 OF 11

015

Does the data indicate a disk storage problem?

Y N

016

- If your machine has disk storage, key in the commands to run the disk storage tests (command codes 091,2,3).

Do these tests fail?

Y N

017

(Entry Point D)

Has backup operating diskette been tried?

Y N

018

- Remove original diskette.
- Load backup operating diskette.
- Press controller RESET switch to startup.

Is startup good (1.1.3)?

Y N

019

Go to Step 021, Entry Point E.

020

The original diskette was the problem, or the problem no longer exists.

- Request customer to verify fix.
- Verify fix.

021

(Entry Point E)

Turn off power.

- Remove the diskette that is in the controller.
- Load the Starter Diskette.*B*
- Manually move Read/Write Head upward (away from track 0) by at least four tracks.*C*
- Turn power on (reset).

Is startup good (1.1.3)?

Y N

022

CAUTION

Turn off power.

- Unseat the redrive card, if present.
- Lock the DE access arm, if present (3.4.1).
- Turn on power.

Is startup good (1.1.3)?

Y N

B

For starter diskette information, refer to 3.3.3. If the starter diskette does not operate correctly, try the backup starter diskette, if available.

C

Moving head away from track 0 enables you to see head step from track to track as it seeks track 0 during startup.

1 1
0 0 9 9 5
K L M N P

P
4

Check for Error Indications

PAGE 5 OF 11

023

CAUTION

Turn off power.

- Reseat the redrive card, if present.
- Unlock the DE access arm, if present (3.4.1).

Did the diagnostic message sequence get started (IDL displayed)?

Y N

024

Did the ready light of the 3604 at address 1 on loop 1 flash on and off during the startup attempt?

Y N

025

Did the diskette drive seek (head assembly move to track 0 of the diskette)?

Y N

026

Go To Map 14, Entry Point A.

027

(Entry Point F)

The problem appears to be a failure to communicate with the 3604 at address 1 on loop 1. The method of isolating the problem depends on your configuration. The following isolation methods are recommended. They are not necessarily connected with each other, nor are they in any order.

- Check that the 3604 address and speed switches are set correctly.*D*
- Turn off power at other terminals on loop 1. Another terminal may be causing loop to fail.
- Change the cabling, if necessary, so that the 3604 at address 1 on loop 1 is physically the first terminal on the loop. Another terminal may be causing the loop to fail.
- Observe READY indicators at other terminals to determine if failure is in controller or 3604. If any of these indicators flash ON and OFF, problem is in 3604.
- Check the continuity from the controller board to the terminal address card in the 3604.*E*
- Check the speed jumper for the loop 1 control card for correct setting and continuity.*F*
- Change the loop 1 control card in the controller.

CAUTION

Turn off power whenever you change a card.

- If the above checks do not result in problem identification, the problem is most likely a 3604 problem. Refer to the 3604 Maintenance Information manual.

D

The address switches are Switch Group 1. For address 1, switch 1 should be ON. Switches 2, 3, and 4 should be OFF.

The speed switches are Switch Group 2. One switch should be turned on, as follows.

Switch	Speed (bps)
1	600
2	1200
3	2400
4	4800

E

Refer to Figure 3-6 for internal loop 1 cabling from board to the controller cable panel. Refer to the 3604 Maintenance Information manual for wiring internal to the 3604.

F

For all loop cards, the speed is selected by jumpering as follows:

Speed (bps)	Jumper	
	From Pin	To Pin
600	S10	J11
1200	S10	J07
2400	S10	J10
4800	S10	J09

6 6
Q R

Q R
5 5

Check for Error Indications

X

PAGE 6 OF 11

028

The problem appears to be in 3604.
 • Turn off power to all loop 1 devices to prevent address interference. At least IDL should display when the 3604 READY light flashes.
 • Change loop 1 control card, if that does not correct the problem, go to the 3604 MAPs.

029

(Entry Point G)
 Does the head carriage assembly go toward track 0 and the pressure pad or head push against the diskette?

Y N

030

Go To Map 8, Entry Point A.

031

Did the diagnostic message sequence terminate at an identified storage card (MVX message)? Sometimes, the message may identify more than one card as a possibility. MVX 0, take the No Leg, MVX MAX, take the yes leg.

Y N

032

Did diagnostic message sequence terminate at any of the following: LDC, ROS, PCK, ESA, LEC, MV2 0, MV3 0, or INV?

Y N

033

Did diagnostic message sequence terminate at IDL or IRT or repeat a part of the diagnostic message sequence?

Y N

034

Did diagnostic message sequence terminate at LSW?

Y N

035

Did diagnostic message sequence terminate at LDI?

Y N

036

Did diagnostic message sequence terminate in HSH?

Y N

037

(Entry Point H)

Did operation terminate with INS, 82000, 82001, 82030-82037, 82070, 82071, 82074, or 82075 displayed?

Y N

038

Did the startup message sequence terminate with 82092 displayed?

Y N

039

Were any other 82XXX or 9XXXX error messages displayed?

Y N

040

You have reached this point possibly for one of the reasons given below (and possibly under the condition that the startup message sequence terminated in DTC). Check these possibilities now. If problem is not corrected, return to beginning of this map and/or call for aid.

- Check speed jumpers for all loop cards. See chart on end of gate.
- The startup message appeared on a 3604 that you did not observe. Unseat the loop cards in the controller for all loops other than loop 1, if you wish to remove the requirement of looking at 3604s on other loops.
- If this failure occurs only on a '1' or a '2' start (3.3.2), change the HOST CA card.
- Loop 1 is failing. Check speed jumper for loop 1 for continuity, and change the loop 1 control card.

Check continuity of internal cabling for loop 1 (Figure 3-6). Also, check continuity of external cabling for loop 1, or try substitute cabling.

- A diskette signal failed. Change diskette card.
- You may not have followed MAP correctly.
- The problem no longer exists.

8 8 8 8 8
S T U V W X

7 7
8 7 A A
Y Z A B

Check for Error Indications

Z A A
6 A B
6 A B

PAGE 7 OF 11

041

Refer to the IBM 3600 System, FE Maintenance Informational Manual, SY27-2520 for meaning of the message. Then reenter controller MAPs or go to the MAPs for correct terminal.

042

Go To Map 3, Entry Point A.

043

These messages are usually caused by a configuration image error or by a storage card not being seated correctly **J**. To identify configuration image errors, use the starter diskette (Ref. 3.3.3).

CAUTION

Turn off power.

- If this failure occurs only on a '1' or '2' start (3.3.2), change the HOST CA card.
- If this failure occurs only on the customers diskette, use the starter diskette to start any optional loops (command code 040) to determine if there is a loop problem. If yes, refer to the appropriate loop MAP.
- Reseat all memory cards (Some of these cards are optional.)

Turn on power.

J

- When the startup diagnostic routine finds an error in functional storage, the displayed diagnostic message sequence terminates with MVX N, where N identifies an 8K block of memory, if the error is not at the first address on that block.
- When the diagnostic routine finds an error at the first address of an 8K block, it assumes that card location is not included in this specific storage configuration, and temporarily displays MVX with the card identifier. MVX 0 indicates that there are no cards in this volume.
- Press RESET to startup and view the temporary messages again.
- If there is a card in the location given by a temporary MVX message, then the possible corrective actions are: change the card, check the supply voltages at the card sockets (see 3.10) and inspect socket pins.

Displayed Message	OR	Displayed Message	8K Block
MVX H/P		MVX 1	FSU 1
MVX G/Q		MVX 2	FSU 2
MVX F/R		MVX 3	FSU 3
MVX E/S		MVX 4	FSU 4
MVX D/T		MVX 5	FSU 4
MVX C/U		MVX 6	FSU 5
MVX B/V		MVX 7	FSU 7
MVX A/W		MVX 8	FSU 8
MVX MAX		MVX MAX	**

**All volume tested ok.

Is operation good (1.1.3)? **J**

Y N

044

CAUTION

Turn off power.

- One at a time, change all of the FSU memory cards and adapter cards (loop, diskette, etc.).
- Remember to return the original card each time a card does not correct problem.

Does any card change result in good operation?

Y N

8 8 8
A A A
C D E

W Y A A A
6 6 C D E
7 7 7

Check for Error Indications

S T U V
6 6 6 6

PAGE 8 OF 11

045

Problem appears to be in user's program.
• If this problem appears only when the customers operating diskette is used, advise the customer.
• Otherwise, call for aid.

046

• Verify fix.

047

• Verify fix.

048

Go To Map 10, Entry Point A.

049

CAUTION

Turn off power.

- Change FSU 1 Vol. 0 card.
- Turn on power (reset).

Is startup good (1.1.3)?

Y N

050

CAUTION

Turn off power.

- Return original FSU 1 card Vol. 0
- Change FSU 3 Vol. 0 card.
- Turn on power (reset).

Is startup good (1.1.3)?

Y N

051

CAUTION

Turn off power.

- Return original FSU 3 Vol. 0 card.

Go To Map 14, Entry Point A.

052

• Verify fix.

053

• Verify fix.

054

CAUTION

Turn off power.

- One at a time change the following cards:

ESA 1
FSU 1 Vol. 1
ESA 2
CTLR 1
CTLR 2
CTLR 3
FSU 1 Vol. 0

Turn on power after each card change.

- Remember to return original card each time a card change does not correct the problem.

Does any card change result in a good startup(1.1.3)?

Y N

055

Go To Map 14, Entry Point A.

056

• Verify fix.

057

Diskette Data Check,
Go To Map 10, Entry Point A.

058

Go To Map 14, Entry Point A.

059

CAUTION

Turn off power.

- Change the identified storage card/cards.

Displayed Message	OR	Displayed Message	8K Block
MVX H/P		MVX 1	FSU 1
MVX G/Q		MVX 2	FSU 2
MVX F/R		MVX 3	FSU 3
MVX E/S		MVX 4	FSU 4
MVX D/T		MVX 5	FSU 4
MVX C/U		MVX 6	FSU 5
MVX B/V		MVX 7	FSU 7
MVX A/W		MVX 8	FSU 8
MVX MAX		MVX MAX	**

**All volume tested ok.

NOTE: If there is no card in the identified location, or if all tested good, go to MAP 14 Entry Point A. (Step 059 continues)

M N
4 4

Check for Error Indications

PAGE 9 OF 11

(Step 059 continued)

• Turn on power (reset).
Is startup good (1.1.3)?
Y N

060

CAUTION

Turn off power.
• Return original storage card/cards.
Go To Map 14, Entry Point A.

061

• Verify fix.

062

• Turn off power.
• Unseat loop control cards 7 and 8, if present.
• Reseat the redrive card.
• Turn on power (reset).
Is startup good (1.1.3)?
Y N

063

Go To Map 11, Entry Point A.

064

• Turn off power.
• One at a time, reseat loop control cards 7 and 8 to determine which is causing the failure.
• Replace the failing card and reseat the other.
• Unlock the DE access arm, if required (3.4.1).
• Verify fix.

065

(Entry Point I)

• Key the commands to run diskette exerciser tests:

Diskette read test: Command code 031.

Diskette seek test: Command code 034.

CAUTION: Once a diskette is written on by this command, it may no longer be used for startup. Do not write on the starter diskette.

Diskette write test: Command code 936.

Note: Test both sides of the diskette, if 2 sided.

Do these tests run without error?

Y N

066

Is the failure only on the second side of the diskette?
Y N

1
O A A
F G H

A A
G H

067

Is diskette drive Not Ready?
Y N

068

Does diskette drive have a seek error?
Y N

069

Does diskette drive have a data check?
Y N

070

Is this the first time at this step?
Y N

071

• Call for aid

072

Go to Page 4, Step 021, Entry Point E.

073

Go To Map 10, Entry Point A.

074

Go To Map 9, Entry Point A.

075

Go To Map 8, Entry Point A.

076

(Entry Point J)

• Turn off power.
• Replace the diskette drive control card (1.33).
• Turn on power and retest the diskette.

Is the problem corrected?
Y N

077

• Turn off power.
• Return the original diskette drive control card.
• Replace the diskette adapter card.
• Turn on power and retest the diskette.

Is the problem corrected?
Y N

078

• Turn off power.
• Return the original diskette adapter card.
• Check wires 15, 16 and 17 of the cable in Figure 3-3 for continuity and no shorts.

Are the wires good?
Y N

1 1 1 1
O O O O
A A A A
J K L M

A A A A A
F J K L M
9 9 9 9 9

Check for Error Indications

PAGE 10 OF 11

079

- Repair or replace as required.
- Verify fix.

080

- Do the LED/PTX alignment (1.85) and LED service check (1.86).

Is the problem corrected?

Y N

081

- Replace the PTX (1.90 and 1.91).

Is the problem corrected?

Y N

082

- Change the head assembly (1.65, 1.66).

Is the problem corrected?

Y N

083

- Call for aid.

084

- Verify fix.

085

- Verify fix.

086

- Verify fix.

087

- Verify fix.

088

- Verify fix.

089

- Load and run the disk storage diagnostic tests, if this is a large file machine. (1.114) (take YES leg if no disk storage).

Do tests run without error?

Y N

090

Go To Map 12, Entry Point A.

091

Does this machine have alternative line attachment?

Y N

092

- Reload the operating diskette.
- Go to Page 6, Step 037, Entry Point H.

G H K L A
3 3 4 4 N

093

- Load the starter diskette with optional module 6A and run the ALA wrap tests, command code 929.

Do these tests run without error?

Y N

094

Go To Map 7, Entry Point A.

095

- Reload the operating diskette.
- Go to Page 6, Step 037, Entry Point H.

096

Go To Map 12, Entry Point A.

097

Go To Map 12, Entry Point A.

098

Is the problem with a Local Loop?

Y N

099

Is the problem with a Remote Loop, 1200 bps Internal Modem?

Y N

100

Is the problem with a Remote Loop, External Modem?

Y N

101

Go to Page 2, Step 008, Entry Point B.

102

Go To Map 5, Entry Point A.

103

Go To Map 4, Entry Point A.

104

Go To Map 3, Entry Point A.

105

Is diskette Not Ready?

Y N

106

Does diskette have Seek Error?

Y N

1 1 1
1 1 1
A A A
P Q R

A
N

D E F A A A Check for Error Indications
3 3 3 P Q R

0 0 0
1 1 1
2 2 2
3 3 3
4 4 4
5 5 5
6 6 6
7 7 7
8 8 8
9 9 9
10 10 10
11 11 11
12 12 12
13 13 13
14 14 14

PAGE 11 OF 11

107
Does diskette have Data Check?
Y N

108
Go to Page 2, Step 008,
Entry Point B.

109
Go To Map 10, Entry Point A.

110
Go To Map 9, Entry Point A.

111
Go To Map 8, Entry Point A.

112
Go To Map 7, Entry Point A.

113
Go To Map 6, Entry Point A.

114
Go To Map 10, Entry Point A.

A
2

115
Go To Map 8, Entry Point A.

Local Loop Problem

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

NOTE: In your first pass through this MAP, 'bypass' a suspect terminal by turning off its power switch. In your second pass, 'bypass' a suspect terminal by disconnecting its cables and plugging the cable connectors together.

(Entry Point B)

- Verify that the jumper *A* for the loop control card and the speed switches *B* of each terminal on the problem loop are all set for the same speed. The customer will provide you with the information required to locate all the terminals on a loop.
- If only loop 7 or 8 is failing, replace the redrive card first.
- Use the starter diskette to ensure that the loop should be running (Command code 040).

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

A

For each loop control card, the speed is selected by jumpering as follows:

Speed (bps)	Jumper *	
	From Pin	To Pin
600	S10	J11
1200	S10	J07
2400	S10	J10
4800	S10	J09

B

At each terminal the speed is selected by switches (Switch Group 2) that are labeled 1,2,3, and 4. To select a speed, set the appropriate switch to the ON position as follows:

Speed (bps)	Switch
600	1
1200	2
2400	3
4800	4

Are any READY lights flashing on the problem loop?

Y N

002

No READY lights are flashing.

- Bypass the first terminal on loop.

Is problem corrected,

Y N

003

CAUTION

Turn off power.

- Change loop control card.
- Turn on power (Reset).

Is problem corrected?

Y N

2 2 2 2
A B C D

B C D

Local Loop Problem

PAGE 2 OF 4

004

CAUTION

Turn off power.

- Return original loop control card.
- Check the cable from the controller to the first terminal on the loop. (If available, try a substitute cable).

Is cable good?

Y N

005

External cables are customer responsibility. Inform customer of problem.

- Verify fix.

006

- Check the internal cable between logic board and the cable panel for continuity and no shorts. See figure 3-6
- If working on loop 4 or higher check the cables from the basic controller board Z1 and Z2 to the adapter board Y4 and Y5, for continuity and no shorts. Cables are wired point to point with B08, B13, D02, and D08 common.

Are cables good?

Y N

007

- Repair or replace the bad cable.
- Verify fix.

008

Is this your first pass through the MAP?

Y N

009

Go to Page 3, Step 034, Entry Point D.

010

Go to Page 1, Step 001, Entry Point B.

011

- Verify fix.

012

Problem is with a bypassed terminal.

- Go to the Maintenance Information manual for that terminal.

Also,

Go to Page 3, Step 034, Entry Point D.

A

013

Are all READY lights flashing on this loop?

Y N

014

Some, but not all, READY lights are flashing.

- Bypass the last terminal on which the READY light is flashing.

Do the READY lights of the remaining terminals on the loop turn on solid?

Y N

015

- Bypass the first terminal on which the READY light is off.

Do the READY lights of the remaining terminals on the loop turn on solid?

Y N

016

- Check the cable between the last terminal on which the READY light is flashing and the first terminal on which the ready light is off. (If available, try a substitute cable.)

Is cable good?

Y N

017

External cables are customers responsibility. Inform customer of the problem.

- Verify fix.

018

Is this your first pass through this MAP?

Y N

019

Go to Page 3, Step 034, Entry Point D.

020

Go to Page 1, Step 001, Entry Point B.

021

Problem is with bypassed terminal.

- Go to Maintenance Information manual for that terminal.

Also,

Go to Page 3, Step 034, Entry Point D.

022

Problem is with bypassed terminal.

- Go to Maintenance Information manual for that terminal.

Also,

Go to Page 3, Step 034, Entry Point D.

3
E

E
2

Local Loop Problem

G H

PAGE 3 OF 4

023

•Bypass the last terminal on the loop.
Do the READY lights of remaining terminals on the loop turn on solid?

Y N

024

CAUTION

Turn off power.
•Change the loop control card.
•Turn on power (reset).

Is problem corrected?

Y N

025

Is this loop #4 or higher?

Y N

026

Go to Step 029, Entry Point C.

027

Check the cables from the basic controller board Z1 and Z2 to the adapter board Y4 and Y5, for continuity and no shorts. Cables are wired point to point with B08, B13, D02, and D08 common.

Are cables good?

Y N

028

• Repair or replace bad cable.
• Verify fix.

029

(Entry Point C)

CAUTION

Turn off power.
•Return the original loop control card.
•Check the cable from the last terminal on the loop to the controller. (If available, try a substitute cable.)

Is this cable good?

Y N

030

External loop cables are customers responsibility. Inform customer of problem.
• Verify fix.

031

•Check the internal cable between logic board and the cable panel for continuity and no shorts. See figure 3-6

Is cable good?

Y N

032

•Repair or replace internal cable.
• Verify fix.

033

Is this your first pass through the MAP?

Y N

034

(Entry Point D)

You have just made your second pass through the MAP, without finding the problem. Breaks in loop cabling can cause problems that appear not logical. Test for a loop cabling break, as follows:

CAUTION

Turn off power.
•Remove loop control card.
•Turn off power at all terminals on the loop.
•At the board, measure for continuity (no more than 40 ohms per 2000 feet) from ring to ring and tip to tip around the entire loop. See Figure 3-6. There should also be infinite resistance between ring, tip, and shield.

Does the loop cabling have the required continuity and no shorts?

Y N

035

Determine whether the problem is in an external cable or inside one of the terminals. If the problem is inside one of the terminals, go to the maintenance information manual for that terminal.
External cables are the customers responsibility.

036

Possible operating diskette generation problem. Try starter diskette. See 3.3.3 for starter diskette information.
•Call for aid.

037

Go to Page 1, Step 001, Entry Point B.

038

• Verify fix.

4
F G H

F
3

Local Loop Problem

PAGE 4 OF 4

039

Problem is with the bypassed terminal. Go to the Maintenance Information manual for that terminal.

Also,

Go to **Page 3, Step 034, Entry Point D.**

1200 bps Remote Loop Problem

Internal Modem

PAGE 1 OF 3

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
2	009	15	A
2	019	15	A
3	027	15	A

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

A

For transmit level check, refer to 1.123.

(Entry Point A)

- For the loop in error, verify that it is jumpered for 1200 bps, remote operation, and that its modem cards are 1200 bps cards. See the chart on the end of the gate. *A* If you wish to verify that you are receiving a signal, refer to 1.125.
- Log on (1.2) if you are not already logged on.
- Key in start loop message, 040 0.
- Display/print controller log (1.6) if you have not already done so, and analyze the loop error message (1.7).
- If only loop 7 or 8 is failing, replace the redrive card first.
- If the loop is reported failing but there is no error log message, change the loop control card and the M/D Rcvr/Xmit card, one at a time, to try to correct the problem. Also, use the starter diskette to ensure that the loop should be running (command code 040).

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

Is code Y=0?

Y N

002

Is code Y=2 or 4?

Y N

3 2 2
A B C

C
1200 bps Remote Loop Problem
Internal Modem
 PAGE 2 OF 3

003
 Code Y=1 (modem check).

CAUTION

- Turn off power.
- One at a time, in order indicated, change the following:
 M/D Rcvr/Xmit card.
 Loop control card.
 - After each card change: turn on controller power, log on (1.2) and display the controller log (key in 001) to determine if the problem is corrected.

NOTE: Return original card each time a card change does not correct problem.

Does any card change correct problem?

Y N

004
Is this loop 2 or 3.

Y N

005
 Go to Step 008, Entry Point B.

006
 Check the cable from the basic controller board Z4 to the adapter board Y2 for continuity and no shorts. The cable is wired point to point with B07, B13, D02, and D08 common.

Is cable good?

Y N

007

- Repair or replace cable.
- Verify fix.

008
(Entry Point B)

- Measure the voltages with reference to ground (D08) on the M/D Rcvr/Xmit card and the loop card. See 3.10

Are all supply voltages within limits,

Y N

009
 Go To Map 15, Entry Point A.

010

- Call for aid.

011

- Verify fix.

B
012
 Code Y=2 or 4.

CAUTION

- Turn off power.
- Change loop control card.
 - Turn on power, log on (1.2), and display the controller log (key in 001) to determine if problem is corrected.

Is problem corrected?

Y N

013
CAUTION

- Turn off power.
- Return the original loop control card.
 - Change the M/D Rcvr/Xmit card. *A*
 - Turn on power, log on (1.2), and display the controller log (key in 001) to determine if problem is corrected.

Is problem corrected?

Y N

014
Is this loop #4 or higher?

Y N

015
 Go to Step 018, Entry Point C.

016
 Check the cables from the basic controller board Z1 and Z2 to the adapter board Y4 and Y5, for continuity and no shorts. Cables are wired point to point with B07, B13, D02, and D08 common.

Are the cables good?

Y N

017

- Repair or replace cable.
- Verify fix.

018
(Entry Point C)

CAUTION

- Turn off power.
- Return original M/D Rcvr/Xmit card.
- Turn on power.
- On the loop control card and modem card, measure the voltages with reference to ground. See 3.10

Are these voltages within limits,

Y N

019
 Go To Map 15, Entry Point A.

3 3 3
 D E F

A D E F 1200 bps Remote Loop Problem

1 2 2 2

Internal Modem

PAGE 3 OF 3

020
• Call for aid.

021
• Verify fix.

022
• Verify fix.

023
Loop error message has reported good wrap tests at controller end of the loop.

Have wrap tests at remote branch(es) on this loop been good,

Y N

024
Trouble is at remote branch that failed wrap test.
• Verify that a CE is at that branch or is being dispatched there.
• Verify fix.

025
• Now use the starter diskette to start this loop with a wrapable modem (command code 040). If this indicates a modem failure, enter this MAP again and inform the customer that his diskette gen should specify this loop as having a wrapable modem.

The good wrap test indicates that the problem is most likely in the communication channel. However, a small possibility exists for a failure in the following IBM equipment. Also, see Maintenance Aid 8 (Ref. 2.6).

- M/D Rcvr/Xmit card.
- Supply voltages to this card.
- Cable between logic board and the cable panel. See Figure 3-6.
- Cable between the controller and the communication line termination.
- Teleprocessing equipment at remote branch.

Note: If this is a callback, or if the required cards are available, proceed along this path. Otherwise notify customer that the trouble is external to our equipment.

CAUTION

- Turn off power.
- Change the M/D Rcvr/Xmit card. *A*
- Turn on power, log on (1.2), and display the controller log (key in 001) to determine if problem is corrected.

NOTE: Return original card if it does not correct problem. Does M/D Rcvr/Xmit card change correct the problem?

Y N

G H

G H

026
• Measure the voltages with reference to ground (D08) on the M/D Rcvr/Xmit card. See 3.10.

Are all voltages within limits?

Y N

027
Go To Map 15, Entry Point A.

028
• Check the internal cable between logic board and the connectors on the cable panel, for continuity and no shorts. See figure 3-6.

Is the cable good?

Y N

029
• Repair or replace cable.
• Verify fix.

030
• Check for continuity and lack of shorts in the external cable between cable panel connectors and the communication channel termination. (See Figure 3-15.)

Is this cable good?

Y N

031
• Repair or replace cable.
• Verify fix.

032
Indications are that the problem is not the controller. Inform the customer that the problem appears to be in the communication channel.
• Verify fix.

033
• Verify fix.

Remote Loop Problem

External Modem

PAGE 1 OF 3

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
2	005	15	A
2	010	15	A
3	017	15	A

001


CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

- For the loop in error, verify that the board is jumpered correctly. See the chart at the end of the logic gate. Also verify that the EIA PTT card is jumpered properly (1.121).
- Log on (1.2) if you are not already.
- For loops 2 and 3, verify the cable from Basic Controller board Z4 to the interface cards (small board or Adapter board).
- Display print controller log (1.6) if you have not already done so, and analyze the loop error message (1.7).
- If the loop is failing but there is no error message in the controller log after approximately 2 minutes, you should start up the controller again (power on or reset). Use the starter diskette to ensure that the loop should be running (Command code 040).
- If only loop 7 or 8 is failing, replace the redrive card.

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

Is code Y=0?



2 2 2
A B C

B C

Remote Loop Problem
External Modem

PAGE 2 OF 3

003

Code Y=1 (modem interface check).

CAUTION

Turn off power when changing a card.

- One at a time, in the order indicated, change the following cards:

EIA PTT (1.121)

Loop adapter

- After each card change:
- Turn on power, log on (1.2), and display the controller log (key in 001) to determine if problem is corrected.

NOTE: Return original card each time a card change does not correct problem.

Does any card change correct problem?

Y N

004

- Measure the voltages with reference to ground (D08) on the EIA PTT card and the loop control card. See 3.10

Are all supply voltages within limits?

Y N

005

Go To Map 15, Entry Point A.

006

- Call for aid.

007

- Verify fix.

008

Code Y=2 or 4.

CAUTION

Turn off power.

- Change loop control card.
- Turn on power, log on (1.2), and display the controller log (key in 001) to determine if problem is corrected.

Is problem corrected?

Y N

009

CAUTION

Turn off power.

- Return original loop control card.
- For loop 4 and above, verify the cables from Basic Controller board Z1 and Z2 to the Adapter board.

Turn on power.

- On the loop control card measure the voltages with reference to ground. See 3.10

Are these voltages within limits?

Y N

D E F

A D E F

010

Go To Map 15, Entry Point A.

011

- Call for aid.

012

- Verify fix.

013

- Loop error message has reported good wrap tests at controller end of the loop.

Have wrap tests at remote branch(es) on this loop been good?

Y N

014

- Trouble is at remote branch that failed wrap test.
- Verify that a CE is at that branch or is being dispatched there.
- Verify fix.

015

- Now use the starter diskette to start this loop with a wrapable modem (command code 040). If this indicates a modem failure, enter this MAP again and inform the customer that his diskette gen should specify this loop as having a wrapable modem.

The good wrap test indicates that the problem is most likely in the communication channel. However, a small possibility exists for a failure in the following IBM equipment.

Note: If this is a call back, or if the required card is available, proceed along this path. Otherwise, notify the customer that trouble is external to our equipment.

- EIA PTT card.
- Supply voltages to this card.
- Cable between controller and the modem.
- Teleprocessing equipment at remote branch.

CAUTION

Turn power off when you change a card.

- Change EIA PTT card (1.121).
- Turn on power, log on (1.2), and display the controller log (key in 001) to determine if problem is corrected.

NOTE: Return original card if it does not correct problem.

Does the card change correct the problem?

Y N

3 3
G H

G H
2 2**Remote Loop Problem****External Modem**

PAGE 3 OF 3

016

- Measure the voltages with reference to ground (D08) on the EIA PTT card. See 3.10

Are all voltages within limits?

Y N

017**Go To Map 15, Entry Point A.****018**

- Check the cable between logic board and the connector for continuity and no shorts (1.122).

Is cable good?

Y N

019

- Repair or replace cable.
- Verify fix.

020

- Indications are that the problem is not in the controller.
- Inform the customer that the problem appears to be in the communication channel.
- Verify fix.

021

- Verify fix.

Host Communication Link

Problem

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
2	008	15	A
4	038	15	A
4	029	15	A

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

If Host Link configuration never worked, verify feature jumpering. See 3.9.

- Verify that correct parameters are being used. See command code 041.

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations. Observe controller log (1.6) for link wrap test messages.

Note: Log messages:

11 006 0
0=Good wrap test.

11 006 1xxxYxxxxxxxxxxx.
1=wrap failure.
Y=9=CA wrap failure.
Y=D=modem wrap failure.

11 006 2.
2=link stopped (users request).

Are all link wrap tests good?

Y N

002.
Does the controller log report a CA wrap test failure?

Y N

4 4 2
A B C

Host Communication Link

Problem

PAGE 2 OF 4

C

003

(Entry Point B)

Check the plug chart to see if there is a host link internal modem.

Is the modem internal to the controller?

Y N

004

- Determine if the external modem is automatically wrap tested by the controller.

Note: The controller automatically wrap tests the CA card and integrated modems, and may or may not automatically wrap test an external modem. This is determined by the configuration image and the external modems capability. The customers DP group can tell you whether the controller is configured to wrap test an external modem automatically. If the external modem is an IBM modem, check the IBM modem manual for details on wrap testing that modem.

Also you can determine if the controller is trying to wrap test the external modem. To do this: (1) key in 041 0 (start link command), and (2) use the GL probe to probe pin S05 on the Host CA card. A down-level pulse indicates that the controller is trying to wrap test the external modem.

Is the external modem automatically wrap tested by the controller?

Y N

005

(Entry Point C)

CAUTION

Turn off power.

- Change EIA (Host 15) card, or 38LS EIA (Host 15) card.

Turn on power.

Is problem corrected?

Y N

3 3 3
D E F G

G

006

Turn off power.

- Return original EIA (Host 15) card, or 38LS EIA (Host 15) card.
- Problem appears to be in the communication channel or the external modem. If this is a callback, or if you already have a replacement CA card, proceed along this path. Otherwise, inform customer that trouble is external to IBM equipment.

CAUTION

Turn off power.

- Change CA (Host 15) card.

Turn on power.

Is problem corrected?

Y N

007

CAUTION

Turn off power.

- Return original CA (Host 15) card, or 38LS EIA (Host 15) card.
- Turn on power and check the voltages on CA and EIA cards with reference to ground (D08). See 3.10

Are these voltages within limits?

Y N

008

Go To Map 15, Entry Point A.

009

- Check for continuity and no shorts.
- Cable between the basic controller board and cable panel connector J1 (Figure 3-5).
- External cable between controller and the external modem (Figure 3-14).

Are cables good?

Y N

010

- Repair or replace, as required.
- Verify fix.

011

Is external modem an IBM modem?

Y N

012

- Notify customer that problem appears to be in the external modem or the communication channel, or call for aid if this is a callback.

3 3
H J

E F H J
2 2 2 2

Host Communication Link

Problem

PAGE 3 OF 4

013

- Use IBM modem manual to check the external modem.

Is the external modem good?

Y N

014

- Repair the IBM modem.
- Verify fix.

015

- Notify customer that trouble appears to be in the communication channel, or call for aid if this is a callback.
- Verify fix.

016

- Verify fix.

017

- Verify fix.

018

- Observe controller log (1.6) for modem wrap test messages.

Note: Log messages:

11 006 0

0=Good wrap test.

11 006 1xxxYxxxxxxxxxxx.

1=wrap failure.

Y=9=CA wrap failure.

Y=D=modem wrap failure.

11 006 2.

2=link stopped (users request).

Does controller log report a modem wrap failure?

Y N

019

Go to Page 2, Step 005, Entry Point C.

020

Is external modem an IBM MODEM?

Y N

021

Go to Page 2, Step 005, Entry Point C.

K

D K
2

022

CAUTION

Turn off power.

- Change EIA (Host 15) card, or 38LS EIA (Host 15) card.

Turn on power.

Is problem corrected?

Y N

023

Turn off power.

- Return original EIA (Host 15) or 38LS EIA (Host 15) card.
- Use IBM modem manual to repair the modem.
- Verify fix.

024

- Verify fix.

025

Does the controller log report a modem wrap failure?

Y N

026

The good wrap test indicates that the problem is most probably in the communication channel. If this is a callback, or if the required cards are available, proceed along this path. Otherwise, inform customer that trouble is external to our equipment. Also see maintenance aid 8(2.6).

Go to Step 027, Entry Point D.

027

(Entry Point D)

CAUTION

Turn off power whenever you change a card.

- Make sure that the transmit level potentiometer is adjusted correctly (1.123).
- One at a time, in the order indicated, change the following cards:
 - M/D Rcvr (Host 15).
 - M/D Xmit (Host 15).
 - M/D wrap (Host 15) (jumper, PN 816645, must be installed on wrap card.).
- On later machines, the modem is one card, 38LS M/D (Host 15).
- CA (Host 15) card.

NOTE: Remember to return the original card if a card change does not correct problem.

Does any card change correct the problem?

Y N

4 4
L M

B L M
1 3 3

Host Communication Link

Problem

PAGE 4 OF 4

028

Check the voltages with reference to ground (D08) on cards just changed. See 3.10

Are these voltages correct?

Y N

029

Go To Map 15, Entry Point A.

030

- Check for continuity and no shorts:
- Cable between the basic controller board and cable panel connector J1 (Figure 3-5).
- External cable between controller and communication channel termination or external modem (Figure 3-14).

Are cables good?

Y N

031

- Repair or replace as required.
- Verify fix.

032

Were the wrap tests all good?

Y N

033

- The problem appears to be the board assembly.
- Replace the board, or call for aid.

034

Problem appears to be in the communication channel, advise customer.

035

- Verify fix.

036

CAUTION

Turn off power.

- Change CA (Host 15) card.
- Turn on power (reset).

Is problem corrected?

Y N

037

CAUTION

Turn off power.

- Return original CA (Host 15) card.
- Turn on power and check the voltages on CA card with reference to ground (D08). See 3.10

Are these voltages within limits?

Y N

N P Q

A N P Q
1 1 1 1

038

Go To Map 15, Entry Point A.

039

Is this your first time through this MAP?

Y N

040

- Problem appears to be the basic controller board assembly.
- Replace board or call for aid.

041

Go to Page 1, Step 001, Entry Point A.

042

- Verify fix.

043

If you wish to verify that you are receiving a signal refer to 1.125.

Is the host transmitting?

Y N

044

- Host problem.
- Verify fix.

045

Are wrap tests good at host end?

Y N

046

- Host problem.
- Verify fix.

047

Are other controllers connected to the same communication line as yours?

Y N

048

Go to Page 2, Step 003, Entry Point B.

049

Are other controllers having host communication link problems?

Y N

050

Go to Page 2, Step 003, Entry Point B.

051

Problem appears to be in communication channel. Advise customer.

Alternative Line Problem

PAGE 1 OF 3

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER

No entries in this table

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
1	004	15	A
2	011	15	A
2	020	15	A
3	025	15	A

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

- For the alternative line in error, verify that the correct cards are plugged and that the feature jumpering is correct. Refer to Chapter 3 for jumper requirements and chapter 1 plug charts for card locations.
- Load the starter diskette with optional module 6A. (3.3.3).
- Run command code 929 to wrap test the adapter.

Was the adapter wrap test good?

Y N

002

Turn off power.

- Replace the CA (ALA XX) card.

Turn on power.

Is the problem corrected?

Y N

003

- Measure the voltages on the CA (ALA XX) card. See 3.10.

Are these voltages within limits?

Y N

004

Go To Map 15, Entry Point A.

005

Problem appears to be the adapter board.

- Replace board or call for aid.

006

- Verify fix.

Alternative Line Problem

PAGE 2 OF 3

A
1

007
Is the modem internal to the controller?
Y N

008
Turn off power.
• Change the EIA or 38LS EIA (ALA XX) card.
Turn on power.
Is the problem corrected?
Y N

009
Turn off power.
• Return the original EIA or 38LS EIA (ALA XX) card.
• The problem appears to be in the communication channel or the external modem. If this is a call-back or if you have a replacement CA card proceed along this path. Otherwise, advise customer that problem is external to the controller.
Turn off power.
• Change the CA (ALA XX) card.
Turn on power.
Is the problem corrected?
Y N

010
Turn off power.
• Return the original CA (ALA XX) card.
• Turn on power and measure the voltages on the EIA and CA cards.
See 3.10
Are these voltages within limits?
Y N

011
Go To Map 15, Entry Point A.

012
Turn off power.
• Check the following for continuity and no shorts.
• Cable between the adapter board and the cable panel connector.
• Cable between controller and external modem.
Are cables good?
Y N

013
• Repair or replace as required.
• Verify fix.

B C D E

B C D E

014
Notify customer that problem appears to be in the external modem or communication channel, or call for aid if this is a call back.

015
• Verify fix.

016
• Verify fix.

017
• Run command code 929 to wrap test the modem.
Was the modem wrap test good?
Y N

018
CAUTION

Turn off power whenever you change a card.
• Make sure that the transmit level potentiometer is adjusted correctly 1.123, 1.124.
• One at a time, in the following order, change the following cards.
• M/D Rcvr (ALA XX) card.
• M/D Xmit (ALA XX) card.
• M/D Wrap (ALA XX) card (Jumper, PN816645 must be installed on the wrap card.)
• On later machines, the above is one card 38LS M/D(ALA XX) card.
• CA (ALA XX) card.

Note: Remember to return the original card if a card change does not correct the problem.
Does any card change correct the problem?
Y N

019
Check the voltages on the cards just changed.
See 3.10
Are these voltages within limits?
Y N

020
Go To Map 15, Entry Point A.

021
The problem appears to be the adapter board.
• Replace the board or call for aid.

022
• Verify fix.

3
F

F
2**Alternative Line Problem**

G

PAGE 3 OF 3

023

The good wrap test indicates that the problem is most probably in the communication channel. If this is a callback, or if the required cards are available, proceed along this path. Otherwise, inform customer that trouble is external to our equipment.

029

- Verify fix.

CAUTION

Turn off power whenever you change a card.

- Make sure that the transmit level potentiometer is adjusted correctly. 1.123, 1.124.
- One at a time, in the order indicated, change the following cards:
 - M/D Rcvr (ALA XX) card.
 - M/D Xmit (ALA XX) card.
 - M/D Wrap (ALA XX) card (Jumper, PN816645, must be installed on wrap card.)
- On later machines the above is one card 38LS M/D (ALA XX) card.
- CA (ALA XX) card.

Note: Remember to return the original card if a card change does not correct problem.

Does any card change correct the problem?

Y N

024

Check the voltages on the cards just changed 3.10.

Are these voltages within limits?

Y N

025

Go To Map 15, Entry Point A.

026

Turn off power.

- Check the following for continuity and no shorts.
- Cable between adapter and the cable panel connector.
- Cable between controller and communication channel.

Are cables good?

Y N

027

- Repair or replace as required.
- Verify fix.

028

Notify customer that problem appears to be the communication channel or call for aid if this is a call-back.

G

Diskette Drive Assembly

Not Ready

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
11	A	1	001
12	B	1	005
2	A	1	001
9	D	4	041

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
1	004	15	A
3	027	15	A
3	034	15	A
3	039	9	A

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

- Check that the diskette is not visibly damaged or bound in the diskette drive assembly.
- Check that the diskette is in the correct operating position and the drive belt is in place.

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

Is the drive hub turning?

Y N

002

Is the drive motor turning?

Y N

003

• Measure ac line voltage at motor connector.
Is measured voltage within ±10% of line voltage specified on label in controller?

Y N

004

Go To Map 15, Entry Point A.

005

(Entry Point B)

- Unplug motor connector.
- Remove drive belt.
- Replug motor connector.

Note: The motor may require up to 5 minutes to start if the thermal protector has been tripped.

Does the motor start?

Y N

2 2 2 2
A B C D

B C D

Diskette Drive Assembly

Not Ready

PAGE 2 OF 4

006

- Remove binds, if any or,
- remove and replace drive motor (1.25 and 1.26, or 1.70 and 1.71).
- Verify fix.

007

- Unplug motor connector.
- Is there a bind in the hub assembly?**
Y N

008

- Is there a bind in the idler assembly?**
Y N

009

- Install a new belt and adjust (1.27 or 1.69).
- If trouble still exists, install a new drive motor (1.25 and 1.26, or 1.70 and 1.71).
- Verify fix.

010

- Remove bind or replace the idler assembly (1.28 or 1.74).
- Verify fix.

011

- Open the cover of the diskette drive assembly.
- Is there still a bind in the hub assembly?**
Y N

012

- Replace cover (1.22 or 1.62) or collet (1.23 or 1.63) as required.
- Verify fix.

013

- Remove bind or remove and replace hub and shaft assembly (1.29).
- Verify fix.

014

- (Entry Point C)**
- Unplug motor connector.
- Are any pulleys loose?**
Y N

015

- Remove drive belt.
- Is there a bind in the hub assembly?**
Y N

E F G

A E F G

016

- Is there a bind in the idler assembly?**
Y N

017

- Install a new belt.
- Verify fix.

018

- Remove bind or replace the idler assembly (1.28 or 1.74).
- Verify fix.

019

- Open the cover of the diskette drive assembly.
- Is there still a bind in the hub assembly?**
Y N

020

- Replace cover (1.22 or 1.62) or collet (1.23 or 1.63) as required.
- Verify fix.

021

- Remove bind or replace the diskette hub and shaft assembly (1.29).
- Verify fix.

022

- Tighten loose pulleys.
- Verify fix.

023

- Use the GL probe to test for pulsing index line at the '+Index' test point on the diskette drive control card (1.51 or 1.94).

Is the line pulsing(Up and Down lights both on)?
Y N

024

- Perform the phototransistor service check (1.44 or 1.87).

Is the phototransistor output good?
Y N

025

- Measure for +1.3 ±0.3V between the 'LED CURRENT' test point (two test points for a 2 sided drive) and the 'ground' test point on the diskette drive control card (1.51 or 1.94).

Is the voltage within limits?
Y N

3 3 3 3
H J K L

J K L
2 2 2

Diskette Drive Assembly

Not Ready

PAGE 3 OF 4

026

- Measure the following voltages at the test points on the diskette drive control card (1.51 or 1.94).

Test Point	Limits
+5V dc	+4.5 and 5.5
+24V dc	+21 and +27
-5V dc	-4.5 and -5.5

Are the voltages within limits?

Y N

027

Go To Map 15, Entry Point A.

028

- Replace the LED (1.48, or 1.88 and 1.89).
- Verify fix.

029

- Check the two-wire cable from the diskette drive control card to the phototransistor for continuity and no shorts.

Is this cable good?

Y N

030

- Repair or replace the cable.
- Verify fix.

031

- Replace and adjust the phototransistor (1.46, or 1.90 and 1.91).
- Verify fix.

032

CAUTION

Turn off power.

- Change diskette drive control card (1.50 or 1.93).

Turn on power.

Is the problem corrected?

Y N

M N

H M N
2

033

CAUTION

Turn off power.

- Return the original diskette drive control card.

Turn on power.

- Measure the following voltages at the test points on the diskette drive control card (1.51 or 1.94):

Test Point	Limits
+5V dc	+4.5 and +5.5
+24V dc	+21 and +27
-5V dc	-4.5 and -5.5

Are the voltages within limits?

Y N

034

Go To Map 15, Entry Point A.

035

- Call for aid.

036

- Verify fix.

037

- If an oscilloscope is available check the diskette speed, look for index pulses every 166.6 ms at the '+Index' test point on the diskette drive control card (1.51 or 1.94). Pulse width should be 1.7 to 8.0 ms. (1.95).

Is there a diskette rotation problem that you can readily observe?

Y N

038

CAUTION

Turn off power.

- Change diskette drive control card (1.50 or 1.93).

Turn on power.

Is problem corrected?

Y N

039

CAUTION

Turn off power.

- Return original diskette drive control card.

Go To Map 9, Entry Point A.

040

- Verify fix.

4
P

P
3**Diskette Drive Assembly****Not Ready**

PAGE 4 OF 4

041**(Entry Point D)**

- Check cover latch pivots and collet assembly for defects that are readily observed.

Do these parts appear to be functioning properly?

Y N

042

Replace as required:

- Cover latch(1.21 or 1.61).
- Pivots (1.22 or 1.62).
- Collet (1.23 or 1.63).

- Verify fix.

043**Does this controller have a one head diskette drive?**

Y N

044

- Check the head load operation.

Is operation correct?

Y N

045

- Repair, adjust, or replace.
- End of call.

046

Go to Page 2, Step 014, Entry Point C.

047**Is the pressure pad arm in front of the actuator bail?**

Y N

048

- Place the pressure pad arm in front of the actuator bail.

Go to Step 049, Entry Point E.

049**(Entry Point E)****Is bail adjustment correct?**

Y N

050

Adjust pressure pad actuator (1.33) or replace it (1.32).

End of call.

051

Go to Page 2, Step 014, Entry Point C.

Diskette Drive Assembly

Seek Error

PAGE 1 OF 3

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001
7	B	2	005
9	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
3	031	10	A
1	003	15	A

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

- Load starter diskette, if not previously loaded.

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

Note: For starter diskette information, refer to 3.3.3. If starter diskette does not operate properly try backup starter diskette.

NOTE: Intermittent seek problems may be caused by diskette control card.

CAUTION

Turn off power.

- Manually move diskette head upwards (away from track 0 by at least four tracks).
- Turn on power (reset).

Does the head carriage assembly go to track 0?

Y N

002

- Measure +24V on diskette drive control card (1.50 or 1.93) at '+24V dc' test point (1.51 or 1.94).

Is voltage within +21.6V and +26.4V?

Y N

003

Go To Map 15, Entry Point A.

004

- Press controller RESET switch to cause accessing.
- Using GL probe, probe for pulsing lines on diskette drive control card while accessing. Probe test points and access 0, 1, 2, and 3 (1.51 or 1.94).

Are all lines pulsing (UP and DOWN lights on)?

Y N

3 2 2
A B C

B C **Seek Error**

PAGE 2 OF 3

005
(Entry Point B)

CAUTION

- Turn off power.
- Change diskette adapter card.
 - Turn on power (reset).

Is startup good (1.1.3)?

Y N

006

CAUTION

- Turn off power.
- Return original diskette adapter card.
 - Check diskette drive control cable (Figure 3-3) continuity and lack of shorts.

Is cable good?

Y N

007

- Repair or replace cable.
- Verify fix.

008

- Call for aid.

009

- Verify fix.

010

CAUTION

- Turn off power.
- Change the diskette drive control card (1.50 or 1.93).
 - Turn on power (reset).

Is startup good (1.1.3)?

Y N

011

CAUTION

- Turn off power.
- Return original diskette drive control card.
- Does this controller have a one head diskette drive?

Y N

012

- The following may be causing the error.
- Bad diskette adapter card. Power off and replace.
 - Head/carriage position adjustment. (1.64)
 - Bind in head/carriage. (1.65 and 1.66).
 - Stepper motor bad. (1.75 and 1.76).

Is the problem corrected?

Y N

E F G

013

- Call for aid.

014

- Verify fix.

015

Is the leadscrew wheel loose on shaft (1.36)?

Y N

016

- With power off, manually rotate leadscrew wheel to check for binds in the access mechanism.

Are there any binds in the access mechanism?

Y N

017

- Replace the stepper motor and adjust (1.42 and 1.43).
- Verify fix.

018

- Check the gap between the leadscrew wheel and the stepper motor wheel (1.36).

Is this gap as indicated in step 6 of 1.36?

Y N

019

- Perform the read/write head adjustment (1.36).
- Verify fix.

020

- Check the upper and lower limit carriage stop adjustments (1.40 and 1.41).

Are the carriage stop adjustments correct?

Y N

021

- As necessary, do one or more of the following.
- Adjust lower limit stop (1.40).
- Adjust upper limit stop (1.41).
- Replace upper or lower stop (1.34 and 1.35).
- Verify fix.

022

- Loosen stepper motor screws (1.42).
- Check the leadscrew preload spring.

Note: The leadscrew should have an up and down movement of about 0.030 inch (0.76mm) against the preload spring.

Does the preload spring have correct action?

Y N

3
D E F G

3 3 3
H J K

A D H J K
 1 2 2 2 2 **Seek Error**

PAGE 3 OF 3

023

- Replace the preload spring (1.34 and 1.35).
- Verify fix.

024

- Check for binds in the head carriage, leadscrew, and bearings.

Are there any binds in these components?

Y N

025

Is there a bind in the stepper motor itself?

Y N

026

- Reinstall the same stepper motor and adjust (1.42 and 1.43).
- Verify fix.

027

- Install and adjust a new stepper motor (1.42 and 1.43).
- Verify fix.

028

- As necessary replace or adjust:
- Head carriage (1.34 and 1.35).
- Bearings (1.34 and 1.35).
- Leadscrew and head (1.38 and 1.36).
- Verify fix.

029

- As required, replace leadscrew wheel (1.38) or adjust leadscrew wheel per steps 10 through 16 of 1.36.
- Verify fix.

030

- Verify fix.

031

Go To Map 10, Entry Point A.

Diskette Drive Assembly

Data Check

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001
8	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
2	015	13	A
3	029	14	A
2	011	15	A
1	002	8	A
4	041	8	D

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

- Load starter diskette if not already loaded.

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

Note: For starter diskette information, refer to 3.3.3. If starter diskette does not operate correctly, try backup starter diskette.

CAUTION

Turn off power.

- Manually move diskette head away from track 0 (upwards) by at least four tracks.
- Turn on power (reset).

Does the head carriage assembly go to track 0?

Note: For a one head diskette drive assure the pressure pad arm contacts the diskette (1.33). For a two head diskette drive check head load operation (1.67).

Y N

002
Go To Map 8, Entry Point A.

003

- If an oscilloscope is available, check the diskette speed, check for index pulses every 166.6 ms at the '+Index' test point on the diskette drive control card (1.51 or 1.94). Pulse width should be 1.7ms to 8.0ms. (1.95).

Is there a diskette rotation problem that you can readily observe?

Y N

4 2
A B

B
|

Diskette Drive Assembly

Data Check

PAGE 2 OF 4

004

CAUTION

Turn off power.

- Change the diskette adapter card.
- Turn on power (reset).

Is startup good (1.1.3)?

Y N

005

CAUTION

Turn off power.

- Return the original diskette adapter card.
- Change the diskette drive control card (1.50 or 1.93).
- Turn on power (reset).

Is startup good (1.1.3)?

Y N

006

CAUTION

Turn off power.

- Return the original diskette drive control card.

Does this controller have a one head diskette drive?

Y N

007

The following may be causing the error.

- Head/carriage position adjustment. (1.64)
- Head assembly bad. (1.65 and 1.66)
- Stepper motor bad. (1.75 and 1.76)
- Diskette drive control cable bad. Check for continuity and lack of shorts. See Figure 3-3.
- Incorrect voltage on the diskette drive control card. (1.94)

Is problem corrected?

Y N

008

Go to Page 3, Step 028, Entry Point B.

009

- Verify fix.

4 4
C D E

E
|

010

Turn on power.

- Measure the following voltages on the diskette drive control card at test points (1.51).

Vdc Limits

+5	+4.5 and +5.5
-5	-4.5 and -5.5
+24	+21.6 and +26.4

Are these voltages within limits?

Y N

011

Go To Map 15, Entry Point A.

012

- Press the controller RESET switch.
- Visually check for movement of pressure pad arm or head load actuator during startup.

Note: For a one head diskette drive, assure the pressure pad arm contacts the diskette (1.33).

Does this arm move?

Y N

013

- Connect the GL probe to the 'Head Load' test point on diskette drive control card (1.51).
- Press the controller RESET switch.

Is there at least one pulse prior to DTC?

Y N

014

CAUTION

Turn off power.

- Check the diskette drive control cable (Figure 3-3) for continuity and lack of shorts.

Turn on power.

Does the pressure pad arm now move during startup?

Y N

015

Go To Map 13, Entry Point A.

016

- Verify fix.

3 3
F G

F G
2 2

Diskette Drive Assembly

Data Check

PAGE 3 OF 4

017

- Check the head load actuator cable for opens and shorts (two wires from electromagnet to diskette drive control card connector (1.49).

Is this cable good?

Y N

018

- Repair or replace cable, as required.
- Verify fix.

019

- Replace pressure pad (head load) actuator and adjust (1.32 and 1.33).
- Verify fix.

020

- Check the diskette drive control cable (Figure 3-3) for continuity and lack of shorts.

Is the cable good?

Y N

021

- Repair or replace.
- Verify fix.

022

- Press controller RESET switch.

Is startup good (1.1.3)?

Y N

023

- Remove head cable connector from socket.

CAUTION

Do not try to measure coil continuity. Meter current could damage coil.

Are any of the head cable connector pins (1.34) grounded (none of these pins should be grounded)?

Y N

024

- Perform the Read/Write Head adjustment and the phototransistor adjustment (1.36 and 1.45).

Turn on power (reset).

Is startup good (1.1.3)?

Y N

4 4 4
H J K L

L

025

CAUTION

Turn off power.

- Clean the Read/Write head (1.37).
- Turn on power (reset).

Is startup good (1.1.3)?

Y N

026

- Replace the head and carriage assembly (1.34 and 1.35).

Turn on power (reset).

Is startup good (1.1.3)?

Y N

027

- Replace the stopper motor (1.42).
- Turn on power (reset).

Is start up good (1.1.3)?

Y N

028

(Entry Point B)

The problem may be that the diskette contents are being destroyed by erasing or writing at the wrong time. To eliminate this possibility, proceed as follows:

CAUTION

Turn off power.

- Change the diskette adapter card.
- Change the diskette drive control card (1.50 or 1.93).
- Obtain and load another known-to-be-good diskette.
- Turn on power (reset).

Is startup good (1.1.3)?

Y N

029

Go To Map 14, Entry Point A.

030

- If you have enough backup diskettes available, isolate the card that was destroying the diskette. Otherwise allow both new cards to remain plugged in the machine.
- Verify fix.

031

- Verify fix.

032

- Verify fix.

4
M

C D H J K M
2 2 3 3 3 3 **Diskette Drive Assembly**

A
1

Data Check

PAGE 4 OF 4

033
• Verify fix.

034
• Verify fix.

035
• Check the head cables and connector.
Are the cables and connector good?
Y N

036
• Repair or replace, as required.
• Verify fix.

037
• Replace the head and carriage assembly (1.34 and 1.35).
• Verify fix.

038
• Verify fix.

039
• Verify fix.

040
• Verify fix.

041
Go To Map 8, Entry Point D.

Disk Storage-System Hang

PAGE 1 OF 1

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001

001

(Entry Point A)

- Turn power off.
- Unseat all logic cards on 01A1 board.
- Lock the DE access arm (3.4.1).
- Turn on power (reset).

Is startup good?

Y N

002

- Replace the redrive card.

Is startup good?

Y N

003

- Return the original redrive card.
- Check the cables from 01A1Z4 to 01A2V4 and 01A1Z5 to 01A2V5 for continuity and lack of shorts (cables wired point to point, with B07, B13, D02 and D08 common).

Are cables good?

Y N

004

- Repair or replace the cable.
- Reseat any unseated cards and cables.
- Unlock the DE access arm (3.4.1).
- Verify fix.

005

- Inspect 01A1 board for bent pins, shorted pins.

Did you find a problem?

Y N

006

- Replace board 01A1 (1.127).
- Verify fix.

007

- Remove the short.
- Reseat any unseated cards and cables.
- Unlock the DE access arm (3.4.1).
- Verify fix.

A B

008

- Reseat any unseated cards and cables.
- Unlock the DE access arm (3.4.1).
- Verify fix.

009

- Turn off power.
- Reseat one card at a time to locate the failing card (crossovers on cards J2 and K2 may be a cause of failure).
- Replace failing card and reseat the others.
- Unlock the DE access arm (3.4.1).
- Verify fix.

A B

Disk Storage-Operational Failure

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
2	013	15	A
3	030	15	A

001

(Entry Point A)

- Turn off power.
- Disconnect disk storage power plug (DJ3) at the power box.
- Turn on power.

CAUTION

Parts may be hot.

CAUTION

Ensure drive motor has stopped.

CAUTION

Observe the rotation arrow on the DE (3.4.1). Failure to do so may result in DE damage.

- Rotate the brake pulley to test for binds in the drive assembly (1.107).

Note: If your machine has HPCA host communication, a good HPCA card must be installed in order for the disk storage to function.

Does the drive assembly turn freely?

Y N

002

- Remove the drive belt guard.
- Remove the drive belt by pivoting the drive motor upward.

Does the disk spindle turn free?

Y N

003

- Replace the disk enclosure (DE) (1.100, 1.101).
- Verify fix.

004

Does the disk storage relay (H-K1) pick with power on?

Y N

005

- Repair relay wiring (1.113).
- Verify fix.

2 2
A B

A B
1 1

Disk Storage-Operational Failure

E

PAGE 2 OF 4

006

- Evenly loosen the three brake assembly mounting screws to disengage the pad and coil pins (1.106).

Does the drive motor turn freely?

Y N

007

- Replace the drive motor (1.102 and 1.103).
- Verify fix.

008

- Tighten the 3 brake assembly mounting screws. Be sure brake pad slots and coil pins align.

Does the brake assembly energize with power on (cable still unplugged)?

Y N

009

- Repair wiring (1.113).
- Verify fix.

010

- Adjust or replace brake as required (1.105, 1.106, 1.107).
- Verify fix.

011

- Turn off power.
- Remove the drive belt guard.
- Inspect the drive belt for wear.
- Ensure motor mount maintains tension on belt.
- Connect disk storage power plug at the power box.

Did you find the problem?

Y N

012

- Turn on power.

Does the storage drive motor run?

Y N

013

Go To Map 15, Entry Point A.

014

- Turn off power.
- Ensure the two antistatic brush arms have tension and are in place (1.101, 1.107).
- Replace the drive belt guard.
- Turn on power.
- Load the disk storage diagnostics (1.114).

Is there a 10EE error stop?

Y N

015

Did the customer have an 11 007 message?

Y N

016

Did the statistic counters indicate a disk storage problem?

Y N

017

There is no disk storage problem at this time.

- Return the system to the customer or reenter the beginning of the MAP's.

018

(Entry Point B)

- Advise the customer that some information on the disk has been destroyed.
- Utility program routines are provided for his use for data correction.

Does the customer wish to attempt salvage of the remaining data?

Y N

019

The following steps are going to write all data sectors on the disk to zero's. Run utility program routines 1 and 4 as follows:

1. Load the diagnostic/utility diskette in the diskette drive.
2. Power off all devices on loop 1 other than the 3604 at address 1 on loop 1 to prevent any interference.
3. Press reset on the controller.
4. When the control program has been loaded, BC80 may display, respond with the model number of the 3604 that you are using, followed by EM (enter key). BC80 should then display on this 3604. When BC80 is displayed, respond with 00001 EM (enter key).
5. When 0012 is displayed, respond with F and EM (enter key).
6. When 0014 is displayed, respond with C and EM (enter key).
7. When 0000 is displayed (routine complete) respond with 000004 EM (enter key).
8. When 0045 is displayed, respond with C6 EM (enter key). This should write all sector ID's and write zero's in all data fields.
9. When this routine is complete (nearly 1 hour) 0044, DDD should display, where DDD is the decimal count of the sectors with alternates assigned (recoverable surface defects). Respond with C and EM enter key) to terminate. Any other error messages indicate that there is a permanent (Step 019 continues)

4 3
C D E

3 3
F G

D F G
2 2 2

Disk Storage-Operational Failure

H J K

PAGE 3 OF 4

(Step 019 continued)
unrecoverable disk defect and the DE must be replaced. Refer to chapter 3 for the meaning of the error messages and 1.100/1.101 for DE removal and replacement.

020

Return the system to the customer. If the customer requires assistance, call for aid.

021

Go to Page 2, Step 018, Entry Point B.

022

Refer to diagnostic error list for corrective action (1.115).
Is the problem resolved?

Y N

023

CAUTION

Turn off power when changing cards.

- If you have not already done so, change the following cards on 01A1 board one at a time, in the order indicated:

G2 D2 J2 C4 K2 F2

- After each card change, turn on power and run the diagnostics.

Note: Return the original card each time it does not correct the problem.

Is the problem resolved?

Y N

024

- Turn off power.
- Replace redrive card.
- Turn on power.
- Run the disk storage diagnostics.

Is the problem resolved?

Y N

025

- Turn off power.
- Return original redrive card.

CAUTION

Turn off power when changing cards.

- If you have not already done so, change the following cards one at a time in the order indicated:

01A1 board- L2, B2, B4, C2, H2, M2

On the DE- B3, A5, A2

- After each card change, turn on power and run the diagnostic.

(Step 025 continues)

H J K

(Step 025 continued)

Note: Return the original card each time it does not correct the problem.

Is the problem resolved?

Y N

026

- Test the cables from 01A1 to the DE for continuity and no shorts (1.112).
- Test the cables from 01A2V4 to 01A1Z4 and 01A2V5 to 01A1Z5, for continuity and no shorts. The cables are wired point to point, with B07, B13, D02, and D08 common.

Are the cables good?

Y N

027

- Repair or replace the defective cable.
- Verify fix.

028

- Inspect card jumpers (1.111).
- Inspect board jumpers (1.111).

Did you resolve the problem?

Y N

029

- Check the power to 01A1 board and to the DE (Figure 3-8).

Is the power good?

Y N

030

Go To Map 15, Entry Point A.

031

- Suspect board 01A1 (1.127) or the DE (1.100).
- Call for aid.

032

- Verify fix.

033

- Verify fix.

034

- Verify fix.

035

- Verify fix.

036

- Verify fix.

C
2

Disk Storage-Operational Failure

PAGE 4 OF 4

037

- Repair or replace as required.
- Verify fix.

Basic Controller Problem

PAGE 1 OF 1

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
13	A	1	001
2	A	1	001

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

CAUTION

Turn off power when you change a card. Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

- One at a time, in the order indicated, change the following cards:
 CTLR 2.
 CTLR 3.
 CTLR 1.
 FSU 1 Vol 0.
 ESA 1.
 RESET.
 Loop Ctrl (1).
 Diskette Adapter.
 FSU 1 Vol 1, if present.
 ESA 2, if present.

- After each card change, turn on power (RESET).
- Check location and continuity of crossovers.

NOTE: Return original card each time a card change does not correct problem.

Does any card change result in a good startup? (1.1.3) (If there is no FSU 1 Vol. 1 card, a display of LSW is as far as startup can go.

Y N

002

- Check the special +5V to the reset card (Fig. 3-8).
- Check that G02 and J02 on the reset card change voltage levels when the reset switch is operated. If no, check the reset switch and its wiring (Fig. 3-8).

Did you find the problem?

Y N

A B C

A B C

003

- Call for aid.
- It is possible that one of the replacement cards was defective. Also, suspect the basic controller board and voltages to it (3.8).

004

- Turn off power.
- Repair the reset switch or wiring.
- Reseat any unseated cards and cables.
- Unlock the DE access arm (3.4.1) if it was locked.
- Verify fix.

005

- Turn off power.
- Reseat any unseated cards and cables.
- Unlock the DE access arm (3.4.1) if it was locked.
- Verify fix.

**Minimum Configuration Method
Of Fault Isolation**

PAGE 1 OF 3

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2	A	1	001
9	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
2	014	13	A
3	017	13	A
1	002	15	A
3	016	2	F
3	025	8	A

001

CAUTION: These MAP's deal with more than one machine type/feature. Included are questions about items this machine may not have.

(Entry Point A)

If starter diskette is not loaded, load diskette.

Note: For starter diskette information, refer to 3.3.3.

Logic cards are called by name, refer to the card list and board layout in Chapter 1, Maintenance Procedures or the board charts located in later machines for locations.

- Check the supply voltages for the BASIC CONTROLLER board (3.10).

Are all of these voltages within limits?

Y N

002

Go To Map 15, Entry Point A.

003

- Open the outside cover and observe the diskette assembly.

Is there any obvious mechanical problem with the diskette drive?

Y N

004

At the 3604 designated by customer to be address 1 on loop 1, are the address switches set correctly (See Chapter 3, Table 3-1)?

Y N

005

Set address switches of the designated 3604 to address 1.

Go to Page 2, Step 006, Entry Point B.

3 2
A B

B

**Minimum Configuration Method
Of Fault Isolation**

PAGE 2 OF 3

006

(Entry Point B)

See if the speed switches (switch group 2) of all terminals on loop 1 agree with the speed jumper for the loop 1 adapter card in the controller?

- Either check the speed switches of all terminals on loop 1, or check only the speed switches on the 3604 at address 1 and temporarily turn off power on other terminals on loop 1.
- Loop jumpering instructions are on a label on the controller logic gate.
- Speed switches are set as follows:

Switch	Speed (bps)
1 on	600
2 on	1200
3 on	2400
4 on	4800

Do they agree?

Y N

007

- Consult customers configuration chart to determine correct speed on loop 1.
 - Correct loop or terminal speed as required.
 - Load operating diskette.
- Verify fix.

Note: Verification will include turning on power at all terminals that you may have turned off.

008

- Turn on power or press RESET to cause a startup.

Is startup good (1.1.3)?

Y N

009

CAUTION

Turn off power.

- Unseat cables Z1 and Z2 coming out of the basic controller board. If none present, take the No leg.
- Lock the DE access arm, if present (3.4.1).
- Turn on power (reset).

Is startup good?

Y N

3 3
C D E

E

010

CAUTION

Turn off power.

- Unseat all the cards from the basic controller board except the following:
 CTLR 2.
 CTLR 3.
 CTLR 1.
 FSU 1 Vol 0.
 ESA 1.
 RESET.
 Loop Ctrl (1).
 Diskette Adapter.
 FSU 1 Vol 1, if present.
 ESA 2, if present.
- Turn on power (reset).

Did diagnostic message sequence reach DTC? (This is as far as the sequence can go without error with the minimum storage.)

Y N

011

Did diagnostic message sequence start (IDL displayed)?

Y N

012

CAUTION

Turn off power.

- Move the head assembly at least four tracks from track 0.
- Turn on power (reset).

Did the head assembly go to track 0?

Y N

013

- Unseat the diskette adapter card.
- Turn on power (Reset).

Did IDL display?

Y N

014

Go To Map 13, Entry Point A.

015

- Change the bad diskette adapter card.
- Reseat the unseated cards and cables.
- Load the operating diskette.
- Unlock the DE access arm, if present (3.4.1).
- Verify Fix.

3 3 3
F G H

D 2
F 2
G 2
H 2

**Minimum Configuration Method
Of Fault Isolation**

PAGE 3 OF 3

016

- Reseat any unseated cards and cables.
- Unlock the DE access arm (3.4.1).

Go To Map 2, Entry Point F.

017

Go To Map 13, Entry Point A.

018

CAUTION

Turn off power each time you reseat or change a card.

- Reseat the cards, one at a time until you identify the card that causes the diagnostic message sequence to fail to reach DTC.
- Change the bad card and reseat any unseated cards and cables.
- Load the operating diskette.
- Unlock the DE access arm, if present (3.4.1).
- Verify fix.

019

CAUTION

Turn off power.

- Replug cables Z1, Z2 on the basic controller board.
- Unseat all logic cards on the adapter board.
- Turn on power (reset).

Is startup good?

Y N

020

CAUTION

Turn off power.

- Unseat cables Y4, Y5 on the adapter board.
- Turn on power (reset).

Is startup good?

Y N

021

- Replace the cable that causes the failure.
- Unlock the DE access arm, if present (3.4.1).
- Verify fix.

022

- Replace the adapter board.
- Unlock the DE access arm (3.4.1).
- Verify fix.

A 1
C 2
J

023

CAUTION

Turn off power.

- Reseat the cards, one at a time to identify the one causing the failure.
- Replace that card and reseat any unseated cards and cables.
- If reseating the redrive card causes the failure, the problem may be loop control card 7 or 8 or any card on the disk storage adapter board.
- Unlock the DE access arm, if present (3.4.1).
- Verify fix.

024

- Load the operating diskette.
- Verify fix.

Note: Verification will include turning on power at all terminals that you may have turned off.

025

Go To Map 8, Entry Point A.

J

Power

PAGE 1 OF 1

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER

No entries in this table

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
1	003	16	A
1	002	17	A

001

(Entry Point A)

Is this a 3601?

Y N

002

• You have a 3602.

Go To Map 17, Entry Point A.

003

Go To Map 16, Entry Point A.

3601 Power

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
15	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
1	006	8	B

001

(Entry Point A)

- With power off, verify that ribbon cables are properly seated on board 01A1, and for a Model 3 machine, 01A2.
- Verify that the controller power cord is plugged into an outlet and that the controller power switch is on.
- Verify that the dc indicator lamp circuit is good (3-8).
- Remove the diskette from the diskette drive assembly.

Is the diskette drive motor turning?

Y N

002

- Measure the ac voltage across the black and white leads at the drive motor connector.

Is the measured voltage within ±10% of the voltage specified on label in controller?

Y N

003

- Check the power cord, fuse, and power switch. (Refer to Power Distribution Diagram, Figure 3-8).

Are these parts good?

Y N

004

- Repair or replace the failing part.
- If the fuse opens, also repair the cause of the fuse opening. Look for shorts/grounds or defective power supply using Power Distribution Diagram, Figure 3-8.
- Verify fix.

005

Customer power input to controller must be incorrect.

- Verify fix.

006

Go To Map 8, Entry Point B.

A
1

3601 Power

PAGE 2 OF 4

007

- Verify input power to the supply. If not present, refer to the power distribution diagram for repair.

NOTE: If the power supply is failing to remain on, connect voltmeter to the terminal of any dc voltage and look upon this voltage as the 'failing' voltage.

Vdc	Limits
+5	+4.5 and +5.5
+8.5	+7.7 and +9.3
+12	+10.8 and +13.2
+24	+21.6 and +26.4
-5	-4.5 and -5.5
-12	-10.8 and -13.2

- Do not disconnect leads from the power supply. Insert any suitable probe (paper clip, scribe, probe tip) into the connector to connect this meter lead.
- If your machine has 2 power supplies, the vertical one primarily goes to board A2, the horizontal one to A1. see the power distribution diagram.
- Connect voltmeter to the terminal of the failing voltage at the power supply. If the voltage is correct at the power supply refer to Power Distribution Diagram, (Figure 3-8) and the cabling diagrams to correct the problem. If voltage is not correct at power supply, continue on this path.

CAUTION

Turn off power.

- At the diskette drive control card, unplug the cable that goes to 01A1.

Turn on power.

- Check the power supply output voltages.

Are all voltages now within limits?

Y N

008

CAUTION

Turn off power.

- Replug the cable to the diskette drive control card.
- Unplug the voltage connectors on board 01A1, including the connector for special voltages at 01A1Y4. (Z3 on model C or D).

Turn on power.

- Check the power supply output voltages.

Vdc	Limits
+5	+4.5 and +5.5
+8.5	+7.7 and +9.3
+12	+10.8 and +13.2
+24	+21.6 and +26.4
-5	-4.5 and -5.5
-12	-10.8 and -13.2

(Step 008 continues)

3
8

(Step 008 continued)

Are all voltages now within limits?

Y N

009

CAUTION

Turn off power.

- Replug the voltage connectors on board 01A1.
- Unplug the voltage connectors on board 01A2, including 01A2Z3 (Model 3 only). (Slip connectors on A2D07, V2D07 on later machines.).

Turn on power.

Are all voltages now within limits?

Y N

010

Do you have expanded storage (B1 Board)?

Y N

011

Go to Step 013, Entry Point B.

012

Turn off power.

- Unplug the voltage connectors on board 01B1.

Are all voltages now within limits?

Y N

013

(Entry Point B)

CAUTION

Turn off power.

- Unplug the voltage connectors on board 01A1.
- Remove the frame ground strap on the hinge side of the gate, and the ground wire on the diskette cable.
- Measure the resistance of all power supply terminals to frame ground. (Resistance should be infinite.)

Are resistance readings good?

Y N

014

- Repair or replace power distribution cabling. Refer to Figure 3-8, Power Distribution Diagram.
- Verify fix.

015

- Replace the power supply (1.126).
- Verify fix.

3 3 3
C D E

D E
2 2

3601 Power

PAGE 3 OF 4

016

CAUTION

Turn off power.

- Replug board 01B1 voltage connectors.
- Unseat all cards on board 01B1.

Turn on power.

Are all voltages still within limits?

Y N

017

- Replace board 01B1.
- Verify fix.

018

CAUTION

Turn off power when reseating or changing a card.

- Reseat a few cards at a time on board 01B1 to find the one that causes failure.
- Change the card that causes failure, reseat the others, and replug the connectors on board 01A2.
- Verify fix.

019

CAUTION

Turn off power.

- Replug board 01A2 voltage connectors, including 01A2Y3. (Slip connectors on A2D07, V2D07 on later machines.)
- Unseat all cards on board 01A2.

Turn on power.

Are all voltages still within limits?

Y N

020

- Replace board 01A2.
- Verify fix.

021

CAUTION

Turn off power when reseating or changing a card.

- Reseat a few cards at a time on board 01A2 to find the one that causes failure.
- Change the card that causes failure, reseat the others.
- Verify fix.

B C
2 2

022

CAUTION

Turn off power.

- Replug voltage connectors on board 01A1.
- If this machine has a TSR 3 power supply, verify that the resistor A1U2D08 to A1T2B06 is on the correct pins.
- Unseat all cards on board 01A1.

Turn on power.

- Check the following power supply output voltages.

Vdc	Limits
+5	+4.5 and +5.5
+8.5	+7.7 and +9.3
+12	+10.8 and +13.2
+24	+21.6 and +26.4
-5	-4.5 and -5.5
-12	-10.8 and -13.2

Are all voltages now within limits?

Y N

023

- Replace 01A1 board assembly.
- Verify fix.

024

CAUTION

Turn off power each time you reseat or change a card.

- Reseat one card at a time on board 01A1 to find the one that causes failure.
- Change the card that causes failure, reseat the others.
- Verify fix.

025

CAUTION

Turn off power.

- Change the diskette drive control card (1.50 or 1.93).
- Replug the cable to diskette drive control card.

Turn on power.

Are all voltages still within limits?

Y N

4 4
F G

F G
3 3

3601 Power

PAGE 4 OF 4

026

CAUTION

Turn off power.

- Return original diskette drive control card.
- Check the wiring in the diskette drive assembly.

Note: Wiring is from the diskette drive control card connector (1.49,1.92) to:

- Stepper motor
- Head assembly
- Phototransistor
- Light emitter diode
- Pressure pad actuator magnet

Does this wiring check good?

Y N

027

- Repair or replace the diskette drive assembly wiring.
- Verify fix.

028

- Call for aid.

029

- Verify fix.

3602 Power

PAGE 1 OF 4

ENTRY POINTS

FROM	ENTER THIS MAP		
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
15	A	1	001

001
(Entry Point A)

- Verify that the controller power cord is plugged into an outlet and that the controller power switch is on.
- Verify that ribbon cables are properly seated on TSR 1 and boards 01A1, 01A2, and 01B1.

CAUTION

- When working on a power problem, lock the DE access arm (3.4.1). Be sure to unlock it at the end of the call.
- Observe the fan and the diskette drive motor (ignore the storage drive motor at this time).

Are both turning?

Y N

002

- See Power Distribution Diagram, Figure 3-8, to make repair.
- Verify fix.

003

Is the power indicator on?

Y N

004

- Measure the dc voltages on 01B1. See Figure 3-8.

Are all voltages within limits?

Y N

005

(Entry Point B)

- Verify input power to the supply. If not present, refer to the power distribution diagram for repair.
- If the power supply is failing to remain on, connect voltmeter to any dc voltage terminal and use this voltage for the 'failing' voltage. If G-CB1 trips, reset it for each power test.
- Use a suitable probe to connect voltmeter to power supply (figure 3-8). Do not remove wires from power supply terminals.
- Connect a voltmeter to the terminal of the failing voltage at the power supply (TSR 3). If the voltage is correct at the supply, see the Power Distribution Diagram, 3-8, to make repair.

CAUTION

Turn off power.
(Step 005 continues)

(Step 005 continued)

- Unplug cable at 01B1Z3.
- Turn on power.

Are all voltages within limits?

Y N

006

CAUTION

- Turn off power.
- Replug cable at 01B1Z3.
- Unplug voltage connectors on board 01B1 including 01B1Y4.
- Turn on power.

Are all voltages within limits?

Y N

007

CAUTION

- Turn off power.
- Replug all voltage connectors on board 01B1.
- Unplug voltage connectors on board 01A2, including 01A2Z3. (Slip-on connectors on A2D07, V2D07 on later machines).
- Turn on power.

Are all voltages within limits?

Y N

008

CAUTION

- Turn off power.
- Replug all voltage connectors on board 01A2, including 01A2Z3. (Slip-on connectors on A2D07, V2D07 on later machines).
- Unplug all voltage connectors on board 01A1, including 01A1Z3.
- Turn on power.

Are all voltages within limits?

Y N

009

Do you have expanded memory (B2 Board)?

Y N

3 3
A B

3 3 3 2 2 2
C D E F G H

C D E

3602 Power

PAGE 3 OF 4

025

CAUTION

- Turn off power.
- Replug all board 01A2 voltage connectors, including 01A2Z3. (Slip-on connectors A2D07, V2D07 on later machines).
 - Unseat all cards on board 01A2.
 - Turn on power.

Are all voltages within limits?

Y N

026

- Replace board 01A2.
- Verify fix.

027

CAUTION

- Turn off power when reseating a card.
- Reseat a few cards at a time on board 01A2 to find problem card.
 - Replace problem card and reseat others.
 - Verify fix.

028

CAUTION

- Turn off power.
- Replug all voltage connectors on board 01B1, including 01B1Y4.
 - Unseat all cards on board 01B1.
 - Turn on power.

Are all voltages within limits?

Y N

029

- Replace 01B1 board.
- Verify fix.

030

CAUTION

- Turn off power when reseating a card.
- Reseat a few cards at a time on board 01B1 to find problem card.
 - Replace problem card and reseat others.
 - Verify fix.

031

CAUTION

- Turn off power.
- Change diskette drive control card (1.53).
 - Replug cable 01B1Z3.
 - Turn on power.

Are all voltages within limits?

Y N

M N

A B M N

032

CAUTION

- Turn off power.
- Return original diskette drive control card.
 - Check the diskette drive wiring.

Note: Wiring is from the diskette drive control card connector (1.92) to:

- Stepper motor
- Head assembly
- Phototransistor
- Light emitter diode (LED)
- Pressure pad actuator magnet
- Board 01B1 connector Z3.

Does wiring check good?

Y N

033

- Repair or replace wiring.
- Verify fix.

034

- Call for aid.

035

- Verify fix.

036

- There is no power problem.
- Repair the power indicator circuit. See Figure 3-8.
 - Verify fix.

037

Is the disk storage drive motor turning?

Y N

038

(Entry Point C)

Does the motor relay H-K1 pick with power on?

Y N

039

- Refer to 1.113 to correct the problem.
- Verify fix.

040

- Check the ac path to the drive motor (3-8).

Is the problem corrected?

Y N

041

- Replace the drive motor (1.102 and 1.103).
- Verify fix.

4 4
P Q

P Q
3 3**3602 Power**

PAGE 4 OF 4

042

- Repair or replace as required.
- Verify fix.

043

- Measure the voltages on board 01A1 and the DE, supplied by TSR 1 on Figure 3-8.

Are all voltages within limits?

Y N

044**CAUTION**

Turn power off when reseating a card.

- Unseat a few cards on board 01A1 at a time to determine if a card is loading the supply. At each power off, reseat all cards before unseating more.
- Unseat cards in the DE to determine if one is loading the supply.

Is a card causing the problem?

Y N

045

- Measure the voltage at pins 11 and 12 of power supply TSR 1 (3-8).

Is voltage good?

Y N

046

Go to Page 1, Step 005, Entry Point B.

047

- Replace TSR 1, or if the problem voltage is from 01A1TB1,

Go to Page 1, Step 001, Entry Point A.

048

- Replace problem card and reseat the others.
- Verify fix.

049

- Measure the dc voltages at each board, supplied by TSR 3 on Figure 3-8.

Are all voltages within limits?

Y N

050

Go to Page 1, Step 005, Entry Point B.

051

There is no power problem at this time.

3601/3602 Finance Communication
Controllers
Maintenance Information

Order No. SY27-2519-0

Your views about this publication may help improve its usefulness; this form will be sent to the author's department for appropriate action. Using this form to request system assistance or additional publications will delay response, however. For more direct handling of such request, please contact your IBM representative or the IBM Branch Office serving your locality.

Possible topics for comment are:

Clarity Accuracy Completeness Organization Index Figures Examples Legibility

**READER'S
COMMENT
FORM**

3601/3602 Finance Communication
Controllers
Maintenance Information

Order No. SY27-2519-0

Your views about this publication may help improve its usefulness; this form will be sent to the author's department for appropriate action. Using this form to request system assistance or additional publications will delay response, however. For more direct handling of such request, please contact your IBM representative or the IBM Branch Office serving your locality.

Possible topics for comment are:

Clarity Accuracy Completeness Organization Index Figures Examples Legibility

**READER'S
COMMENT
FORM**

Cut or Fold Along Line

Cut or Fold Along Line

What is your occupation? _____

Number of latest Technical Newsletter (if any) concerning this publication: _____

Please indicate if you wish a reply. Yes No

If yes: Name _____

Address _____

Thank you for your cooperation. No postage stamp necessary if mailed in the U.S.A. (Elsewhere, an IBM office or representative will be happy to forward your comments.)

What is your occupation? _____

Number of latest Technical Newsletter (if any) concerning this publication: _____

Please indicate if you wish a reply. Yes No

If yes: Name _____

Address _____

Thank you for your cooperation. No postage stamp necessary if mailed in the U.S.A. (Elsewhere, an IBM office or representative will be happy to forward your comments.)

Your comments, please . . .

Your comments, together with your answer to the questions on the back of this form will help us produce better publications for your use. Your comments will be carefully reviewed by the persons responsible for writing and publishing this material. All comments and suggestions become the property of IBM.

Your comments, please . . .

Your comments, together with your answer to the questions on the back of this form will help us produce better publications for your use. Your comments will be carefully reviewed by the persons responsible for writing and publishing this material. All comments and suggestions become the property of IBM.

Fold

Fold

Fold

Fold

First Class
Permit 40
Armonk
New York

First Class
Permit 40
Armonk
New York

Business Reply Mail
No postage stamp necessary if mailed in the U.S.A.



Business Reply Mail
No postage stamp necessary if mailed in the U.S.A.

Postage will be paid by:

Postage will be paid by:

International Business Machines Corporation
Department 63T
Neighborhood Road
Kingston, New York 12401

International Business Machines Corporation
Department 63T
Neighborhood Road
Kingston, New York 12401



Cut or Fold Along Line

Cut or Fold Along Line

3601/3602 Finance Communication Controllers (M1) Printed in U.S.A. SY27-2519-0

3601/3602 Finance Communication Controllers (M1) Printed in U.S.A. SY27-2519-0

Fold

Fold

Fold


Fold



International Business Machines Corporation
Data Processing Division
1133 Westchester Avenue, White Plains, N.Y. 10604
IBM World Trade Americas/Far East Corporation
Town of Mount Pleasant, Route 9, North Tarrytown, N.Y., U.S.A. 10591
IBM World Trade Europe/Middle East/Africa Corporation
360 Hamilton Avenue, White Plains, N.Y., U.S.A. 10601



International Business Machines Corporation
Data Processing Division
1133 Westchester Avenue, White Plains, N.Y. 10604
IBM World Trade Americas/Far East Corporation
Town of Mount Pleasant, Route 9, North Tarrytown, N.Y., U.S.A. 10591
IBM World Trade Europe/Middle East/Africa Corporation
360 Hamilton Avenue, White Plains, N.Y., U.S.A. 10601



International Business Machines Corporation
Data Processing Division
1133 Westchester Avenue, White Plains, N.Y. 10604
IBM World Trade Americas/Far East Corporation
Town of Mount Pleasant, Route 9, North Tarrytown, N.Y., U.S.A. 10591
IBM World Trade Europe/Middle East/Africa Corporation
360 Hamilton Avenue, White Plains, N.Y., U.S.A. 10601