

01234567890123456789  
01234567890123456789  
01234567890123456789

\*\* RSX-11M V3.2 \*\*  
\*\* RSX-11M V3.2 \*\*  
\*\* RSX-11M V3.2 \*\*

DK3:[140,6]736RPQLM.;6  
COPY 1 OF 3  
DELETION NOT SPECIFIED

9-MAY-83 13:44:12  
9-MAY-83 13:44:12  
9-MAY-83 13:44:12

01234567890123456789  
01234567890123456789  
01234567890123456789

77777777	333333	666666	RRRRRRRR	PPPPPPPP	QQQQQQ	LL	MM	MM					
77777777	333333	666666	RRRRRRRR	PPPPPPPP	QQQQQQ	LL	MM	MM					
77	33	33	66	RR	RR	PP	PP	QQ	QQ	LL	MMM	MMM	
77	33	33	66	RR	RR	PP	PP	QQ	QQ	LL	MMM	MMM	
77		33	66	RR	RR	PP	PP	QQ	QQ	LL	MM	MM	MM
77		33	66	RR	RR	PP	PP	QQ	QQ	LL	MM	MM	MM
77		33	66666666	RRRRRRRR	PPPPPPPP	QQ	QQ	LL	LL	MM	MM		
77		33	66666666	RRRRRRRR	PPPPPPPP	QQ	QQ	LL	LL	MM	MM		
77		33	66	66	RR	RR	PP	QQ	QQ	QQ	LL	MM	MM
77		33	66	66	RR	RR	PP	QQ	QQ	QQ	LL	MM	MM
77	33	33	66	66	RR	RR	PP	QQ	QQ	LL	MM	MM	....
77	33	33	66	66	RR	RR	PP	QQ	QQ	LL	MM	MM	....
77	333333	666666	RR	RR	PP	PP	QQ	QQ	LL	LLLLLLLLLL	MM	MM	....
77	333333	666666	RR	RR	PP	PP	QQ	QQ	LL	LLLLLLLLLL	MM	MM	....

```
;;; 666666
;;; 666666
;;; 66
;;; 66
;;; 66
;;; 66
;;; 66666666
;;; 66666666
;;; 66 66
;;; 66 66
;; 66 66
;; 66 66
;; 666666
;; 666666
```

01234567890123456789  
01234567890123456789  
01234567890123456789

\*\* RSX-11M V3.2 \*\*  
\*\* RSX-11M V3.2 \*\*  
\*\* RSX-11M V3.2 \*\*

DK3:[140,6]736RPQLM.;6  
COPY 1 OF 3  
DELETION NOT SPECIFIED

9-MAY-83 13:44:12  
9-MAY-83 13:44:12  
9-MAY-83 13:44:12

01234567890123456789  
01234567890123456789  
01234567890123456789

\*\*\*\*\*  
\*\*\*\*\*

736Q -- RPQ -- Left Margin Set

Problem:

Customer wishes to set the left margin to other than 0.0 inches w/o Dual Sheet feeder or 3.0 inches w/ Dual Sheet feeder. (Margins are measured from left of platen at the NEC restore point.)

Solution:

Define DIP switch 10 -- Left Margin Procedure at power-up

Procedure:

DIP switch 10 will be on at power-up. It indicates to the firmware that the Left Margin Procedure is to be allowed.

After the printer becomes ready (no fault conditions) and the READY LED lights, the operator will place the printer in HOLD PRINT.

The operator will press INDEX 12 times to space the paper to a point where the effect of left margin setting can be observed. The print head will remain centered. (This is "thanks" to NEC who "helped" the OEM by suppressing head motion not followed by a printing character until the sheet fed form is advanced to the top roller.)

The operator will dial the Form Length switches to the desired margin in tenth inches. (This step must NOT be performed before power-up if proper forms length is to be established at power-up.) (NOTE: the standard margin is 30/10 inches.)

The operator will press the TEST switch on the front panel. The printer will read the "Left Margin" (Form Length) switches, set the left margin, and move the print head to the indicated position.

(If the operator is not satisfied with the resulting position, the switches can be set to another value and TEST pressed again.)

When a satisfactory left margin is established the operator will restore the Form Length switches to the proper form length setting.

The operator will perform any other switch operations required to prepare the printer for the user's application followed by HOLD/ENABLE to allow actual printing to begin.

Once a new margin is set it will remain in effect until altered or until power is removed from the device. The margin can be altered ONLY during the FIRST HOLD PRINT after power-up. Normal tests may not be executed during that HOLD PRINT. Once the printer exits the first HOLD PRINT, the function (Left Margin Procedure) is disabled, and the TEST button assumes its standard function during HOLD PRINT.

5/9/83(d)

rlc

\*\*\*\*\*  
\*\*\*\*\*