




Version 1.2.1.2



Interface Control Guide

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTION
INTERFACE CONTROL GUIDE**

Note: Before using this information and the product it supports, read the information in Notices on page 24.

This edition applies to version 1, release 2, modification 1.2 of IBM Tivoli Netcool Service Quality Manager Roaming AT Service Solution and to all subsequent releases and modifications until otherwise indicated in new editions.

© Copyright International Business Machines Corporation, 2002, 2008. All rights reserved.

US Government Users Restricted Rights - Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Table of Contents

1	About this Documentation	5
1.1	Audience	5
1.2	Required Skills and Knowledge	5
1.3	Document Conventions	6
1.4	Document Structure	7
1.5	User Publications	8
2	Interface Specifications.....	11
2.1	Overview.....	11
2.2	Supported Version	11
2.3	Interface Definition	11
2.3.1	File Naming Convention	11
	File Examples.....	11
2.4	Data Specification	12
2.4.1	Roaming AT CSV File Format	12
	Example Data	17
2.4.2	CSV File Granularity	17
2.4.3	SQM Delivery/Collection Mechanism.....	18
	Transfer Mechanism.....	18
	Data Directory	18
	File Interval	18
	Transfer Latency	18
	Files per Interval	18
3	Enumerations and Definitions	19
3.1	Roaming Type.....	19
3.2	Roaming Direction.....	19
3.3	Roaming Test Type	19
3.4	Roaming Destination Type	20
3.5	Metric Type	20
3.6	Test Outcome	21
	Appendix A Glossary.....	23
	Appendix B Notices	24
	Trademarks.....	26

1 About this Documentation

The *IBM® Tivoli® Netcool® Service Quality Manager Roaming AT Service Solutions Interface Control Guide* details the Roaming AT Service Solution input interface i.e. CSV input files in terms of:

- File naming conventions
- Data file format, structure, and semantics
- Supported delivery/Collection mechanism
- Data file input and output directory
- File granularity
- File frequency
- Maximum latency tolerated

1.1 Audience

This guide is intended for parties wishing to provide mediated data to the IBM Tivoli Netcool Service Quality Manager Roaming AT Service Solutions.

1.2 Required Skills and Knowledge

This guide assumes you are familiar with the following:

- General IT Principles
- IP Networking
- Unix® Operating Systems
- GSM Roaming Services

1.3 Document Conventions

The following command prompts can be seen throughout this document where the user has to enter commands at the command line:

- # (hash): This prompt will be displayed if the user is logged in as user root.
- \$ (dollar): This prompt will be displayed if the user is logged in as either the saserver or oracle user.

Please note the above prompts are not part of commands. All commands must be entered after these prompts.

This document uses the typographical conventions shown in the following table:

Table 1: General Document Conventions

<i>Format</i>	<i>Examples</i>	<i>Description</i>
ALL UPPERCASE	GPS NULL MYWEBSERVER	Acronyms, device names, logical operators, registry keys, and some data structures.
<u>Underscore</u>	See Document Conventions	For links within a document or to the Internet. Note that TOC and index links are not underscored. Color of text is determined by browser settings.
Bold	Note: The busy hour determiner is...	Heading text for Notes, Tips, and Warnings.
SMALL CAPS	The STORED SQL dialog box... ...click VIEW... In the main GUI window, select the FILE menu, point to NEW, and then select TRAFFIC TEMPLATE.	Any text that appears on the GUI.
<i>Italic</i>	<i>A busy hour is...</i> <i>A web server must be installed...</i> See the <i>User Guide</i>	New terms, emphasis, and book titles.
Monospace	<code>./wminstall</code> <code>\$ cd /cdrom/cdrom0</code> <code>/xml/dict</code> <code>addmsc.sh</code> <code>core.spec</code> Type OK to continue.	Code text, command line text, paths, scripts, and file names. Text written in the body of a paragraph that the user is expected to enter.

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTIONS
INTERFACE CONTROL GUIDE**

Monospace Bold	<code>[root] # pkginfo grep -i perl</code> system Perl5 On-Line Manual Pages system Perl 5.005_03 (POD Documentation) system Perl 5.005_03	For contrast in a code example to show lines the user is expected to enter.
<i><Monospace italics></i>	<code># cd <oracle_setup></code>	Used in code examples: command-line variables that you replace with a real name or value. These are always marked with arrow brackets.
[square bracket]	<code>log-archiver.sh [-i][-w][-t]</code>	Used in code examples: indicates options.

1.4 Document Structure

This guide is organized into the following chapters:

Table 2: Document Structure

Chapter	Description
Interface Specifications	Provides interface specification and file naming conventions.
Enumerations and Definitions	Describes the call types.
Glossary	Glossary.

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTION
INTERFACE CONTROL GUIDE**

1.5 User Publications

The following user publications are provided with the Roaming AT Service Quality Manager Service Solution:

Table 3 Roaming AT Service Solution Documentation

Document	Description
<i>Tivoli Netcool Service Quality Manager Service Solutions Installation Guide</i>	Details the generic steps required to install any Service Quality Manager Service Solution including Roaming AT.
<i>Tivoli Netcool Service Quality Manager Roaming Probe Service Solution Interface Control Guide</i>	Details the Roaming Probe Service Solution input interface.
<i>Tivoli Netcool Service Quality Manager Roaming AT Solution Interface Control Guide</i>	Details the Roaming AT Service Solution input interface.
<i>Tivoli Netcool Service Quality Manager Roaming Service Solution Release Notes</i>	Provides information on the Roaming Service Solution release contents, platform requirements, installation and upgrade procedures, and known issues.
<i>Tivoli Netcool Service Quality Manager Roaming Service Solution Version 1.2.1 to 1.2.1.2 Upgrade Guide</i>	Provides information on how to upgrade the Roaming Service Solution to Version 1.2.1.2 from Version 1.2.1

The following user publications are provided with the Service Quality Manager software in Adobe® Portable Document Format (PDF) and HTML formats.

Table 4: Service Quality Manager User Documentation

Document	Description
<i>Release Notes</i>	Provides information on the Service Quality Manager 4.1.1 release contents, platform requirements, installation and upgrade procedures, and known issues.
<i>Configuration Guide</i>	Describes SLA Provisioning (Parties, SLAs, and SLA Templates applications) and SQM Provisioning (Services Resources, KQI Models and Service Models applications) in Service Quality Manager.
<i>Monitoring Guide</i>	Describes Monitoring (SLA Monitor, KQI Analyzer, Alarm Monitor, Audit Manager and SLA Web Monitor applications) in Service Quality Manager.

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTIONS
INTERFACE CONTROL GUIDE**

<i>CEM Monitoring Guide</i>	Describes how to use and monitor the Customer Experience Management [CEM] feature in Service Quality Manager.
<i>CEM Provisioning Guide</i>	Reference Guide containing information for provisioning the Customer Experience Management system.
<i>Solaris Server Installation Guide</i>	Describes how to install the Service Quality Manager Server system on Solaris 10g
<i>Client Installation Guide</i>	Describes how to install the Service Quality Manager Client.
<i>AIX Server Installation Guide</i>	Describes how to install the Tivoli Netcool Service Quality Manager Server system on AIX 5.3L.
<i>Solaris System Administration Guide</i>	Provides an overview of the Service Quality Manager administrative tasks including instructions on how to complete the following tasks: <ul style="list-style-type: none"> - Starting and stopping Service Quality Manager. - Running batch processes such as archiving trace files and log files. - Backing up and restoring the system.
<i>AIX System Administration Guide</i>	Provides an overview of the AIX Service Quality Manager administrative tasks including instructions on how to complete the following tasks: <ul style="list-style-type: none"> - Starting and stopping Service Quality Manager. - Running batch processes such as archiving trace files and log files. - Backing up and restoring the system.
<i>Upgrade Guide</i>	Details how to upgrade from one Service Quality Manager from v3.1.3 to v 4.1.1
<i>BusinessObjects Installation & Configuration Guide</i>	Provides information on the steps required to install and configure the BusinessObjects (v 6.5 or XI) Server and Client for use with Service Quality Manager.
<i>Service Quality Manager Service Solution Installation Guide</i>	Details the generic steps required to install any Service Quality Manager Service Solution including CEM GPRS.
<i>CEM GPRS Service Solution Interface Control Guide</i>	Details the CEM GPRS Service Solution input interface.
<i>CEM GPRS Service Solution Overview Guide</i>	Provides an overview of the CEM GPRS Service Solution product architecture.
<i>Service Quality Manager Core Online Help</i>	Provides information and procedures for using Service Quality Manager client applications

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTION
INTERFACE CONTROL GUIDE**

<i>Customer Experience Management Online Help</i>	Describes how to use and monitor the Customer Experience Management feature in the Service Quality Manager
<i>SLA Webview Online Help</i>	Describes how to use and monitor the SLA Webview feature in the Service Quality Manager

2 Interface Specifications

2.1 Overview

This document provides all the required information for parties intending to provide data from Roaming service systems to IBM Tivoli Netcool Service Quality Manager Roaming AT Service Solution.

The Service Solution expects to be supplied with data related to Roaming AT probes in files which are detailed below.

2.2 Supported Version

This document refers to IBM Roaming AT Service Solution 1.2.1.2.

2.3 Interface Definition

2.3.1 File Naming Convention

The file naming convention is as follows:

```
A<YYYYMMDD>.<hhmm>-<YYYYMMDD>.<hhmm>[_<UniqueID>].csv
```

Where:

<YYYYMMDD>.<hhmm> elements correspond to the file interval start time and end time respectively.

- YYYY is the year in four-digit notation.
- MM is the month in two-digit notation (01 - 12).
- DD is the day in two-digit notation (01 - 31).
- HH is the two-digit hour of the day (local time), based on the 24-hour clock (00 - 23).
- MM is the two-digit minute of the hour 00-59 (local time).

UniqueID is an optional element that can be used to, for instance, uniquely identify the Roaming System. This element is recommended in situations where the deployed solution has multiple mediation points.

File Examples

The following are example files which show the naming convention:

- Filename: A20080314.0000-20080314.0015.csv
- Filename: A20080314.0015-20080314.0030.csv

2.4 Data Specification

2.4.1 Roaming AT CSV File Format

The data files must provide the fields in top down order as shown in the tables below. The files are expected to contain standard CSV header lines containing the field names shown below.

Table 5: Roaming AT Server File Format

<i>Field Name</i>	<i>Field Description</i>	<i>Constraints</i>	<i>Example</i>
ORIG_SUBSC_ID	The ID of the subscriber or modem that is the originating party in the test scenario. For example, in a voice call scenario this should be the ID of the subscriber or modem who initiated the call. ID presented in this field may be MSISDN or IMSI.	Digits range = 0...9 Total length ≤ 15 digits.	
ORIG_PROBE_ID	The ID of the probe where the originating subscriber or modem is located or connected.	String ≤ 64 characters	
ORIG_PROBE_LOCATION	The geographical location of the originating probe.	String ≤ 64 characters	Dublin
DEST_ID	The ID of the entity which is the destination party in the test scenario. For example: - In a Voice Call scenario this should be the ID of the destination subscriber/modem - In a Location Update scenario this should be the destination network ID where the subscriber/modem is trying to update the location. - In a GPRS http DL throughput scenario this should be the APN ID/name.	String ≤ 64 characters	
ROAMING_DEST_TYPE	The type of the destination entity.	Enumeration	See section 3
DEST_PROBE_ID	The ID of the probe where the destination subscriber or modem is located or connected.		
DEST_PROBE_LOCATION	The geographical location of the destination probe.	String ≤ 64 characters	San Francisco

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTIONS
INTERFACE CONTROL GUIDE**

ROAMING_TEST_TYPE	<p>The type of test provided to verify a specific roaming service.</p> <p>One row in the CSV file is expected for one specific test execution. This row provides information about test execution attempts and also provides results (successes, metrics values, etc., depending on the test type).</p>	Enumeration	See section 3
H_PLMN	<p>The identification of Home PLMN which is the party (the operator) whom TNSQM roaming model will provide the metrics to. The PLMN is Operator Centric, i.e. Home PLMN is considered to be Home for the Operator perspective, i.e. the PLMN(s) that the Operator owns and controls are considered to be the HPLMN(s)</p> <p>HPLMN shall be identified by address of it's node (e.g HLRs or VLR/MSC) involved in the transactions call flow Depends on the measurement/transaction type - SCCP, ISUP - different addressing schemas exists. For the SCCP addressing is based on MGT (Mobile Global Title) and for ISUP addressing is based on SPC (Signalling Pint Codes). Network nodes identification shall have a distinction indicating the addressing schema (SCCP or ISUP). Expected format of HPLMN column: S8101 - for SCCP addressing</p> <p>WHERE: S - SCCP prefix 81 - Japan Country Code 01 - sample of NTTDoCoMo Network Code</p>	String ≤ 64 characters	JPNTTDoCoMo

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTION
INTERFACE CONTROL GUIDE**

	<p>OR</p> <p>I40073 - sample of Signalling Point Code for Bharti Dlehi in India (ISUP addressing)</p>		
V_PLMN	<p>The identification of Visitor PLMN which normally is the foreign party during roaming transactions call flow. The PLMN is Operator Centric i.e. The VPLMN(s) are the PLMN(s) that do not belong or or under the control of the Home Operator (the Operator to whom the TN SQM roaming model is providing the metrics to).</p> <p>VPLMN shall be identified by any address of it's node (e.g HLRs or VLR/MSC) involved in the transactions call flow It depends on the measurement/transaction type - SCCP, ISUP - different addressing schemas exists. For the SCCP addressing is based on MGT (Mobile Global Title) and for ISUP addressing is based on SPC (Signalling Point Codes). Network nodes identification shall have a distinction indicating the addressing schema (SCCP or ISUP). Expected format of V_PLMN column:</p> <p>S8101 - for SCCP addressing WHERE: S-SCCP 81 - Japan Country Code 01 - sample NTTDoCoMo Network Code</p> <p>OR</p> <p>I40073 - sample Signalling Point Code for Bharti Delhi India (ISUP addressing)</p>	String ≤ 64 characters	IEO2

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTIONS
INTERFACE CONTROL GUIDE**

ROAMING_TYPE	May be international OR national. International roaming means that the PLMN involved in signaling traffic exchange are in two different countries. In national roaming both PLMNs are in the same country	Enumeration	See section 3
ROAMING_DIRECTION	Depends on location of the Roamer. Inbound Roaming is when foreign network subscriber is roamed in H_PLMN Outbound Roaming is when H_PLMN subscriber is roamed in a foreign V_PLMN	Enumeration	See section 3
FAILURE_REASON	The test/procedure failure reason. If available from Active Test platform, this shall present the reason for the tested procedure/service failure.	String \leq 64 characters	Network Problem
ROAMING_TEST_OUTCOME	The outcome of the test.	Enumeration	See section 3
METRIC_TYPE	Indicates the type of measurement in the 'METRIC_VALUE' column.	Enumeration	See section 3
METRIC_VALUE	This is the column where all 'metric' values shall be provided. By "metric values" it is meant: - Voice Quality score - Transmitted data volume [kbits] - Throughput [kbit/s] What will be presented depends on ROAMING_TEST_TYPE. For ROAMING_TEST_TYPES : Voice_Q, GPRS_http_DL_throughput, GPRS_ftp_DL_throughput metric values are expected as the test results. Values for those ROAMING_TEST_TYPES are expected with different units.	FLOAT \geq 0	35

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTION
INTERFACE CONTROL GUIDE**

TIME	The time/duration of a specific procedure tested by test (specific test scenario)	FLOAT ≥ 0 ms	212
------	---	----------------------	-----

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTIONS
INTERFACE CONTROL GUIDE**

Example Data

The following are examples of data showing headers and fields:

```
ORIG_SUBSC_ID,ORIG_PROBE_ID,ORIG_PROBE_LOCATION,DEST_ID,ROAMING_DEST_TYPE,DEST_PROBE_I
D,DEST_PROBE_LOCATION,ROAMING_TEST_TYPE,H_PLMN,V_PLMN,ROAMING_TYPE,ROAMING_DIRECTION,F
AILURE_REASON,ROAMING_TEST_OUTCOME,METRIC_TYPE,METRIC_VALUE,TIME
44111222333,IE_01,Dublin,UKSampleNetwork1,2,,,1,IESampleNetwork1,UKSampleNetwork1,1,1,
,-2,-1,,1455
44111222333,IE_01,Dublin,UKSampleNetwork1,2,,,1,IESampleNetwork1,UKSampleNetwork1,1,1,
,-2,-1,,1230
44111222333,IE_01,Dublin,UKSampleNetwork1,2,,,1,IESampleNetwork1,UKSampleNetwork1,1,1,
,-2,-1,,1240
44111222333,IE_01,Dublin,UKSampleNetwork1,2,,,1,IESampleNetwork1,UKSampleNetwork1,1,1,
Network Error,-4,-1,,
353222333444,UK_02,London,IESampleNetwork1,2,,,1,IESampleNetwork1,UKSampleNetwork1,1,2
,-2,-1,,2100
```

2.4.2 CSV File Granularity

The granularity of the file is expected to be such that only 1 CSV row will be specified for each test execution, with the following columns:

- ROAMING_TYPE
- ROAMING_DIRECTION
- V_PLMN
- H_PLMN
- ROAMING_TEST_TYPE
- ORIG_SUBSC_ID
- METRIC_TYPE

The columns below are expected to contain the following data in each row based on the above grouping:

- TIME
- METRIC_VALUE
- ROAMING_TEST_OUTCOME
- FAILURE_REASON (if available from data source)

2.4.3 SQM Delivery/Collection Mechanism

Transfer Mechanism

The data files will be transferred by Data Push to the data directory on the IBM Tivoli Netcool Service Quality Manager Host platform.

Data Directory

The data directory is configurable by the IBM Tivoli Netcool Service Quality Manager customer. The default value is `/appl/sa/var/adapter/roaming_at_loader`. The IBM Tivoli Netcool Service Quality Manager Customer will need to ensure that mediation can deliver files to the configured location.

File Interval

The file interval is 15 minutes and must be on 15 minute boundaries, for example: 1615 to 1630.

Transfer Latency

The transfer latency is configurable by the IBM Tivoli Netcool Service Quality Manager customer. The default value is 60 minutes. The value of this parameter represents the maximum delay allowed in data presentation at the data directory.

Files per Interval

The service solution expects 1 file per Roaming AT system per interval.

3 Enumerations and Definitions

3.1 Roaming Type

The data file must use the following table to identify the ROAMING_TYPE type.

Table 6: Roaming AT ROAMING_TYPE Type

<i>Id</i>	<i>ROAMING_TYPE Type</i>
1	International
2	National

3.2 Roaming Direction

The data file must use the following table to identify the ROAMING_DIRECTION type.

Table 7: Roaming AT ROAMING_DIRECTION Type

<i>Id</i>	<i>ROAMING_DIRECTION Type</i>
1	Inbound
2	Outbound

3.3 Roaming Test Type

The data file must use the following table to identify ROAMING_TEST_TYPE type.

Table 8: Roaming AT ROAMING_TEST_TYPE Type

<i>Id</i>	<i>ROAMING_TEST_TYPE Type</i>
1	LU
2	Voice_Call
3	Voice_Q
4	CLIP

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTION
INTERFACE CONTROL GUIDE**

5	CLIR
6	CF_Act
7	SMS_e2e
8	MMS_e2e
9	GPRS_Attach
10	GPRS_PDP_act
11	GPRS_http_DL_throughput
12	GPRS_ftp_DL_throughput

3.4 Roaming Destination Type

The data file must use the following table to identify ROAMING_DEST_TYPE type.

Table 9: Roaming AT ROAMING_DEST_TYPE Type

<i>Id</i>	<i>ROAMING_DEST_TYPE Type</i>
1	Subscriber
2	Network
3	APN

3.5 Metric Type

The data file must use the following table to identify METRIC_TYPE type.

Table 10: Roaming AT METRIC_TYPE.Type, MAP Causes

<i>Id</i>	<i>METRIC_TYPE Type</i>
-1	NOT SET
1	data_volume
2	throughput
3	voice_q

3.6 Test Outcome

The data file must use the following table to identify TEST_OUTCOME type.

Table 11: Roaming AT TEST_OUTCOME.Type, MAP Causes

<i>Id</i>	<i>TEST_OUTCOME Type</i>
-1	NOT SET (if not available/not expected for the specific ROAMING_TEST_TYPE)
-2	Success
-3	Inconclusive
-4	Failure

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTION
INTERFACE CONTROL GUIDE**

Appendix A Glossary

Table 12: Glossary of Terms

<i>Acronym</i>	<i>Description</i>
AT	Active Test
FTP	File Transfer Protocol
HTTP	HyperText Transfer Protocol
HTTPS	HyperText Transfer Protocol Secure
KB	Kilobytes
KPI	Key Performance Indicator
KQI	Key Quality Indicator
QoS	Quality of Service
SFTP	Secure File Transfer Protocol
SLA	Service Level Agreement
SLO	Service Level Objective (i.e. thresholds)
SRP	Server Routing Protocol
TNSQM	Tivoli Netcool Service Quality Manager

Appendix B Notices

IBM may not offer the products, services, or features discussed in this document in all countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk NY 10504-1785
U.S.A.

For license inquiries regarding double-byte (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

IBM World Trade Asia Corporation
Licensing
2-31 Roppongi 3-chome
Minato-ku
Tokyo 106-0032
Japan.

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law: INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTIONS
INTERFACE CONTROL GUIDE**

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

IBM Corporation
5300 Cork Airport Business Park
Kinsale Road
Cork
Ireland.

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement or any equivalent agreement between us.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

All statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTION
INTERFACE CONTROL GUIDE**

Trademarks

IBM, IBM logo, Tivoli, and Netcool are trademarks of International Business Machines Corporation in the United States, other countries or both.

Adobe, the Adobe logo, PostScript, and the PostScript logo are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States, and/or other countries.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Other company, product or service names may be trademarks or service marks of others

**TIVOLI NETCOOL SERVICE QUALITY MANAGER ROAMING AT SERVICE SOLUTIONS
INTERFACE CONTROL GUIDE**

IBM®

Printed in the Republic of Ireland.